



PARTS CATALOG

FOR

RICOH FAX 77/80/85 (for Europe)

[Model C]

RICOH COMPANY, LTD.

1	March 9, 1990	First edition

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

Section 1. Part Location and List

1. Exterior	1—1
2. ADF/Scanner	1—2
3. Printer/Electrical Components	1—3
Section 2. Parts Index	2—1

Note: Version

G	Germany U1	Universal 1
UK	U.K. U2	Universal 2
I	Italy UV	Universal and
		Universal 2

Model

77	FAX 77
80	FAX 80
85	FAX 85

1. EXTERIOR


March 5th, 1990

A

B

C

D



1. EXTERIOR

March 9th 1990

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
1- 1	H053 4801	Original Tray-A4			A - 1
1- 2	H053 4800	Copy Tray -A4			A - 2
1- 3	H053 4829	Copy Retainer Wire			A - 2
1- 4	H051 3165	Quick Dial Cover		77	B - 1
1- 4	H053 3165	Quick Dial Cover		80/85	B - 1
1- 5	H051 4388	Quick Dial Sheet		77	B - 1
1- 5	H053 4388	Quick Dial Sheet	G	80/85	B - 1
1- 5	H053 3166	Quick Dial Sheet	UK/U1	80/85	B - 1
1- 5	H053 4390	Quick Dial Sheet	I	80/85	B - 1
1- 5	H053 4393	Quick Dial Sheet	U2	80/85	B - 1
1- 6	H051 3145	Op-Port Cover Ass'y- FAX77	G	77	B - 2
1- 6	H051 3150	Op-Port Cover Ass'y-FAX77	UK	77	B - 2
1- 6	H051 3151	Op-Port Cover Ass'y-FAX77	I	77	B - 2
1- 6	H051 3152	Op-Port Cover Ass'y-FAX77	UV	77	B - 2
1- 6	H053 3145	Op-Port Cover Ass'y-FAX80	G	80	B - 2
1- 6	H053 3150	Op-Port Cover Ass'y-FAX80	UK	80	B - 2
1- 6	H053 3151	Op-Port Cover Ass'y-FAX80	I	80	B - 2
1- 6	H053 3152	Op-Port Cover Ass'y-FAX80	UV	80/85	B - 2
1- 6	H055 3112	Op-Port Cover Ass'Y-FAX85	G	85	B - 2
1- 6	H055 3113	Op-Port Cover Ass'Y-FAX85	UK	85	B - 2
1- 6	H055 3114	Op-Port Cover Ass'Y-FAX85	I	85	B - 2
1- 7	H051 6000	PCB Ass'y-Op-Port		77	B - 2
1- 7	H053 6000	PCB Ass'y-Op-Port		80/85	B - 2
1- 8	H053 3142	Adjustment Screw Cap			B - 2
1- 9	H051 3102	Upper Cover Ass'y-FAX77		77	D - 3
1- 9	H053 3148	Upper Cover Ass'y-FAX80		80	D - 3
1- 9	H055 3119	Upper Cover Ass'Y-FAX85		85	D - 3
1- 10	H053 3158	Sub Document Table			D - 4
1- 11	H053 3143	Rear Cover Ass'Y			C - 3
1-12	H053 3146	NCU Cover			C - 2
1-13	H053 4124	Decal -Caution : Small SAF	G	80	D - 3
1-13	H053 4125	Decal -Caution : Small SAF	UK/U1	80	D - 3
1-13	H053 4126	Decal -Caution : Small SAF	I	80	D - 3
1-13	H053 4128	Decal -Caution : Small SAF	U2	80	D - 3
1-13	H055 4106	Decal -Caution : SAF	G	85	D - 3
1-13	H055 4107	Decal -Caution : SAF	UK/U1	85	D - 3
1-13	H055 4108	Decal -Caution : SAF	I	85	D - 3

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
1- 13	H055 4110	Decal -Caution : SAF	U2	85	D - 3
1- 14	H053 3113	Interface Plate Cover			C - 3
1- 15	H053 4112	Decal -Set Document	G		D - 3
1- 15	H053 4113	Decal -Set Document	UK/U1		D - 3
1- 15	H053 4114	Decal -Set Document	I		D - 3
1- 15	H053 4116	Decal -Set Document	U2		D - 3
1- 16	H053 3101	Right Cover			C - 4
1- 17	H053 3117	Inner Cover -Scanner : A4			C - 3
1- 18	H053 3078	Spring -Hopper			D - 4
1- 19	H041 3156	Clamper -Spring : Hopper			D - 4
1- 20	H053 3102	Left Cover			A - 3
1-21	H054 3111	NCU Fixing Plate			B - 3
1- 22	H053 3126	Rubber Foot -20.6 X 7.6			B - 4
1- 23	H053 3121	Metal Base Ass'y			B - 4
1- 24	H053 3138	Base Guide - Rear-Right			C - 4
1- 25	H053 3137	Base Guide - Front-Right			B - 4
1- 26	H053 3136	Base Guide-Rear-Left			C - 4
1- 27	H053 3135	Base Guide-Front-Left			B - 4
1- 28	H053 2123	Stepped Screw-M4 : Printer			A - 3
1- 29	H053 1160	Spring Wire - Locking			A - 3
1-30	H053 1144	Spacer -Locking			A - 3
1-31	H053 1145	Locking Ass'Y			A - 3
1- 32	H053 1150	Stepped Screw- Locking			A - 3
1-33	H012 3628	Space Roller -Locking			A - 4
1-34	H053 4137	Decal -Replace Paper	G		A - 4
1-34	H053 4138	Decal -Replace Paper	UK/U1		A - 4
1-34	H053 4139	Decal -Replace Paper	I		A - 4
1-34	H053 4141	Decal -Replace Paper	U2		A - 4
1- 35	H053 3100	Front Cover			A - 4
1- 36	H053 5314	Harness - Front/Upper			B - 3
1-37	H053 4192	Decal -Power Switch	G		D - 2
1-38	H053 4913	Decal -Gear : G	G		D - 3
1-38	H053 4914	Decal -Gear : I	I		D - 3
1-38	H053 4915	Decal -Gear : U1	U1		D - 3
1-38	H053 4916	Decal -Gear : U2	U2		D - 3
1-39	H053 2174	Cord Clamp -TEL	G/I/UV		D - 3
1-40	0804 6097	Allen Screw -M3X6			D - 1

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
1- 41	H053 3227	Spring-Hopper : Rear			D - 4
1- 42	H022 5003	Telephone Line -UK	UK		D - 2
1- A	H051 5101	Op-Port Unit - FAX77 (1- 4 ~ 1- 7)	G	77	B - 1
1- A	H051 5102	Op-Port Unit - FAX77 (1- 4 - 1- 7)	UK	77	B - 1
1- A	H051 5103	Op-Port Unit - FAX77 (1- 4 - 1- 7)	I	77	B - 1
1- A	H051 5104	Op-Port Unit - FAX77 (1-4 - 1-7)	UV	77	B - 1
1- A	H053 5101	Op-Port Unit FAX80 (1- 4 - 1- 7)	G	80	B - 1
1- A	H053 5102	Op-Port Unit FAX80 (1-4 - 1 -7)	UK	80	B - 1
1- A	H053 5103	Op-Port Unit FAX80 (1- 4 - 1- 7)	I	80	B - 1
1- A	H053 5104	Op-Port Unit FAX80 (1- 4 - 1- 7)	UV	80/85	B - 1
1- A	H055 5101	Op-Port Unit - FAX85 (1- 4 - 1- 7)	G	85	B - 1
1- A	H055 5102	Op-Port Unit - FAX85 (1- 4 - 1- 7)	UK	85	B - 1
1- A	H055 5103	Op-Port Unit - FAX85 (1- 4 - 1- 7)	I	85	B - 1
1- **	H033 4806	Allen Key - 2.5			
1- **	H053 4316	N E C R			
1- **	H053 4302	Quick Dial Labels			
1- **	H051 4304	Operator's Manual - FAX77	G	77	
1- **	H051 4305	Operator's Manual - FAX77	UK	77	
1- **	H051 4306	Operator's Manual - FAX77	I	77	
1- **	H051 4307	Operator's Manual - FAX77	U1	77	
1- **	H051 4308	Operator's Manual - FAX77	U2	77	
1- **	H053 4310	Operator's Manual - FAX80/85	G	80/85	
1- **	H053 4317	Operator's Manual - FAX80/85	UK	80/85	
1- **	H053 4319	Operator's Manual - FAX80/85	I	80/85	
1- **	H053 4321	Operator's Manual - FAX80/85	U1	80/85	
1- **	H053 4323	Operator's Manual - FAX80/85	U2	80/85	
1- **	H051 4314	Quick Reference Guide - FAX77	G	77	
1- **	H051 4315	Quick Reference Guide - FAX77	UK	77	
1- **	H051 4316	Quick Reference Guide - FAX77	I	77	
1- **	H051 4317	Quick Reference Guide - FAX77	U1	77	
1- **	H051 4318	Quick Reference Guide - FAX77	U2	77	
1- **	H053 4315	Quick Reference Guide - FAX80	G	80	
1- **	H053 4318	Quick Reference Guide - FAX80	UK	80	
1- **	H053 4320	Quick Reference Guide - FAX80	I	80	
1- **	H053 4322	Quick Reference Guide - FAX80	U1	80	
1- **	H053 4324	Quick Reference Guide - FAX80	U2	80	

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
1- **	H055 4343	Quick Reference Guide - FAX85	G	85	
1- **	H055 4346	Quick Reference Guide - FAX85	UK	85	
1- **	H055 4345	Quick Reference Guide - FAX85	I	85	
1- **	H055 4344	Quick Reference Guide - FAX85	U1	85	
1- **	H055 4347	Quick Reference Guide -FAX85	U2	85	
1- **	H051 4328	Operation Panel Sheet	U1	77	
1- **	H051 4329	Operation Panel Sheet	U2	77	
1- **	H053 4484	Operation Panel Sheet	U1	80	
1- **	H053 4485	Operation Panel Sheet	U2	80	
1- **	H055 4331	Operation Panel Sheet	U1	85	
1- **	H055 4337	Operation Panel Sheet	U2	85	
1-100	0951 3006B	Philips Screw with Flat Washer -M3x6			
1-101	0951 3008B	Philips Screw with Flat Washer -M3x8			
1-102	0951 4006B	Philips Screw with Flat Washer -M4x6			
1-103	0720 0060E	Retaining Ring -M6			
1-104	1105 0115	Tie Wrap - SKB-85			
1-105	1105 0109	Cord Keep			

2. ADF / SCANNER

March 5th, 1990

A

B

C


D

1

2

3

4



2. ADF/SCANNER

March 9th, 1990

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
2- 1	H053 5018	Document Sensor			B - 1
2- 2	H041 1549	Trast Screw			A - 1
2- 3	H053 1516	Slider -Release : Separation			A - 1
2- 4	H053 1560	Slider -Release : ADF			B - 1
2- 5	H053 1523	Spring-Separation Roller			B - 1
2- 6	H053 1515	Slider - Friction			B - 1
2- 7	H053 1514	Bracket - Separation			A - 2
2- 8	H053 1529	Adjustment Screw-PB			B - 1
2- 9	H041 1537	Shaft - Pressure Plate : Separation			B - 1
2-10	H041 1539	Spring -Pressure Plate : Right			B - 1
2-11	H053 1524	Spacer - M6x14			A - 2
2-12	H053 1537	Pressure Plate - Separation			B - 2
2-13	H053 1513	Base - Separation Unit			B - 1
2-14	H053 1538	Shaft -Bracket : Separation Roller			A - 2
2-15	H053 1576	Separation Roller			A - 2
2-16	H053 1547	Shaft - Separation Roller			A - 1
2-17	H053 1581	Disk - Friction : Separation Roller			A - 2
2-18	H053 1558	Washer - M6x1.5			A - 2
2-19	H053 1582	Spring - Friction : Separation Roller			A - 2
2-20	H053 1548	Stopper - Friction : #180			A - 2
2-21	H041 1502	ADF Feed Roller			A - 3
2-22	H041 1505	Pick Up Roller			A - 3
2-23	H053 1506	Idle Gear - Pick Up			A - 3
2-24	H053 1502	Bracket Ass'y -Pick Up Roller			A - 3
2-25	H053 1507	Shaft - Feed Roller			B - 3
2-26	H041 1527	Boss - Pick Up			B - 3
2-27	H041 1528	Spring - Friction : Pick Up			A - 3
2-28	H041 1525	Sleeve - Pick Up			A - 3
2-29	H053 1575	Bushing - M6.2			A - 3
2-30	H041 1563	Cushion - Pick Up			A - 3
2-31	H053 1500	Guide Plate - ADF : Lower			A - 3
2-32	H053 1508	Base Ass'y - ADF:A4			B - 2
2-33	H012 1183	White Mylar - A4			B - 3
2-34	H053 1517	Inner Cover -Operation Panel : Front			A - 3
2-35	H053 1521	Inner Cover -Operation Panel : Rear			B - 2
2-36	H053 2136	Antistatic Brush-Printer : A4			B - 2
2-37	H053 1566	Shaft -Release : ADF			B - 2

INDEX	PART NO	DESCRIPTION	VERSION	MODEL	LOCATION
2-38	H053 1567	Arm-Release : ADF			B - 2
2-39	H053 1568	Locking - ADF : Front			A - 2
2-40	H053 1554	Spring -Locking : Front			A - 2
2-41	H053 1600	Bushing - M6 : CUFE			A - 4
2-42	H053 1555	Spring-Locking : Rear			B - 2
2-43	H053 1569	Locking - ADF : Rear			B - 2
2-44	H053 1574	Spring -Release : Slider			B - 1
2-45	H053 1527	Shaft - Pressure Roller			B - 3
2-46	H053 1525	Plate Spring -Pressure Roller			B - 3
2-47	H012 1144	Pressure Roller			B - 3
2-48	H053 1100	Base-Scanner : A4			C - 3
2-49	H053 1101	1st Mirror			B - 3
2-50	H053 1107	Holder - 1st Mirror : Front			B - 3
2-51	H053 1106	Holder - 1st Mirror : Rear			B - 3
2-52	H053 1103	2nd Mirror			C - 1
2-53	H053 1104	Dust Cover - 2nd Mirror			C - 1
2-54	H053 1109	Holder - 2nd Mirror : Front			C - 1
2-55	H053 1108	Holder - 2nd Mirror : Rear			C - 1
2-56	H053 1105	3rd Mirror			B - 1
2-57	H053 1133	Exposure Glass			C - 1
2-58	H053 1172	Holder -Exposure Glass : Front			C - 1
2-59	H053 1173	Holder -Exposure Glass : Rear			C - 1
2-60	H053 1132	Guide Plate-Scanner : Lower			C - 1
2-61	H053 5205	Xenon Lamp - A4			B - 2
2-62	H053 5208	Xenon Lamp Stabilizer - A4			C - 2
2-63	H053 1153	Insulating Sheet - Xe Lamp Stabilizer			C - 2
2-64	H053 1113	Plate-Harness Holder : Xenon Lamp			B - 2
2-65	H053 1161	Guide - Xenon Lamp			A - 4
2-66	H053 1112	Shading Plate - A4			C - 2
2-67	H014 1101	Lens - F4.5/22.2			D - 2
2-68	H053 1111	Lens Block-A4			D - 2
2-69	H053 6022	PCB Ass'y - SBU			D - 2
2-70	H053 5315	Harness - SBU/FCU			D - 2
2-71	H053 3115	Inner Cover - ADF Clutch			D - 2
2-72	H053 5012	Electromagnetic Clutch			D - 2
2-73	H053 1141	Timing Belt - 189			D - 2
2-74	H053 1163	Timing Belt -171			D - 2

INDEX	PART NO	DESCRIPTION	VERSION	MODEL	LOCATION
2-75	H053 1139	Pulley - R2 Roller			C - 2
2-76	H053 1138	Pulley - R1 Roller			C - 2
2-77	H053 5306	Ground Wire - 120 mm			C - 2
2-78	H053 1140	Idle Gear - Scanner			C - 2
2-79	H053 1137	Reduction Pulley-Scanner			C - 2
2-80	H053 1170	Belt Tensioner Bracket			C - 2
2-81	H053 1126	Belt Tensioner Roller			C - 2
2-82	H053 1120	Side Plate Ass'y -Rear			C - 2
2-83	H053 5028	Tx Motor			C - 2
2-84	H053 1130	R1 Roller			B - 4
2-85	H053 1131	R2 Roller			B - 4
2-86	H053 1115	Side Plate Ass'y -Front			A - 4
2-87	H053 1119	Arm-Side Plate : Front			A - 4
2-88	H053 1156	Bracket Ass'y -Hinge : ADF			A - 4
2-89	H053 1110	Mirror Cover			C - 4
2-90	H053 2146	Guide Plate -Feed-out : A4			C - 4
2-91	H053 2148	Lavel -Black : SB-4 Sensor			C - 4
2-92	H053 2191	Feed-out Roller Ass'y-A4 : Upper			C - 3
2-93	H053 2144	Holder -Feed-out Roller : Front			B - 4
2-94	H053 2145	Holder -Feed-out Roller : Rear			C - 3
2-95	H053 2129	Plate Spring -Thermal Head			C - 3
2-96	H053 2177	Harness Cover -Thermal Head			C - 3
2-97	H053 5203	Thermal Head- A4 : Kyocera			C - 3
2-98	H053 2163	Fixing Plate -Thermal Head : Front			D - 4
2-99	H053 2164	Bracket -Thermal Head : Front			C - 3
2-100	H053 2118	Fixing Plate -Thermal Head : Center			C - 3
2-101	H053 2166	Bracket -Thermal Head : Center			C - 3
2-102	H053 2165	Bracket -Thermal Head : Rear			D - 3
2-103	H053 2117	Fixing Plate -Thermal Head : Rear			D - 3
2-104	H053 2110	Guide Roller – Printer			D - 3
2-105	H053 2142	Thermal Head Cover : A4			D - 3
2-106	H053 5316	Harness - T .Head/PSU			D - 4
2-107	H053 1143	Release Lever – Scanner			D - 4
2-108	H053 2115	Turn Roller – A4			D - 4
2-109	H053 1148	Spring -Lock : Scanner			D - 4
2-110	H012 3623	Stepped Screw – Scanner – Left			B - 4
2-111	H053 2197	Bracket -Turn Roller : Front			D - 4

INDEX	PART NO	DESCRIPTION	VERSION	MODEL	LOCATION
2-112	H053 2198	Bracket -Turn Roller : Rear			D - 4
2-113	H012 2119	Bushing - M4			C - 4
2-114	H053 1534	Slider Sheet			B - 1
2-115	H053 1545	Trast Screw- Spring			B - 1
2-116	H053 1168	Sheet -Guide Plate : Front			B - 2
2-117	H053 1167	Sheet -Guide Plate : Rear			B - 2
2-118	H053 2189	O Ring - P3			D - 3
2-119	H053 1165	Sheet -Lock Lever			D - 4
2-120	H053 1571	Sheet -Side Plate : Rear			D - 4
2-121	H053 1572	Sheet -Side Plate : Rear 2			D - 4
2-122	H053 5308	Ground Wire -Bottom-Side : Rear			C - 2
2-123	H053 5313	Ground Wire -Separation Base			A - 1
2-124	5466 3198	Washer - SBU			D - 3
2-125	H053 1570	Mylar -Document Stopper			B - 3
2-126	H053 1174	Washer M6 -Scanner Unit			A - 4
2-200	0951 3006B	Philips Screw with Flat Washer - M3x6			
2-201	0951 3008B	Philips Screw with Flat Washer - M3x8			
2-202	0951 4006B	Philips Screw with Flat Washer - M4x6			
2-203	0954 3010B	Philips Screw - M3X10			
2-204	0951 3005B	Philips Screw with Flat Washer - M3X5			
2-205	0313 0060B	Philips Pan Head Screw – M3X6			
2-206	0573 0040E	Hexagon Headless Set Screw - M3X4			
2-207	0954 3006B	Double Sens Screw – M3X6			
2-208	0720 0040E	Retaining Ring - M4			
2-209	0720 0020E	Retaining Ring - M2			
2-210	0720 0030E	Retaining Ring - M3			
2-211	0720 0050E	Retaining Ring - M5			
2-212	0807 3005	Washer -Reverse Gear			
2-213	1105 0115	Tie Wrap - SKB-85			

3. PRINTER / ELECTRICAL COMPONENTS

March 5th, 1990

A

B

C


D

1

2

3

4



3 PRINTER/ELECTRICAL COMPONENTS

March 9th 1990

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
3- 1	H053 2109	Feed-out Roller - A4 : Lower	G UK/UI I U2		B - 2
3- 2	H012 2119	Bushing - M4			B - 1
3- 3	H053 2113	Pulley - Feed-out			A - 2
3- 4	H053 2114	Belt - M2.5 : Feed-out			A - 2
3- 5	H053 2108	Platen Roller - A4			B - 2
3- 6	H012 2113	Pulley - Platen Roller - A4			A - 2
3- 7	5474 2152	Bushing -Platen Roller			B - 2
3- 8	H053 2112	Pulley - Platen			B - 1
3- 9	H053 4143	Decal - Cutter			B - 2
3- 9	H053 4144	Decal - Cutter			B - 2
3- 9	H053 4145	Decal - Cutter			B - 2
3- 9	H053 4147	Decal -Cutter			B - 2
3- 10	H053 4149	Decal -Cutter Guide			B - 2
3- 11	H053 2161	Cutter Ass'y -A4			B - 2
3- 12	H053 2141	Plate Spring - Feed-out Roller			B - 1
3- 13	H053 5308	Ground Wire -Bottom-Side -Rear			C - 3
3- 14	H053 2131	Ground Plate-Feed-out Roller			B - 1
3- 15	H041 2122	Timing Belt - 180 : 4			C - 1
3- 16	H053 2126	Reduction Pulley -Printer			C - 1
3- 17	H053 2111	Timing Belt - 56T			C - 1
3- 18	H001 4221	Harness Clamper -Document Table			C - 2
3- 19	H053 2132	Harness Guide -Rear			C - 2
3-20	H053 2171	Bracket -RX Motor			C - 2
3-21	H053 2130	Ground Plate-Motor Bracket			C - 2
3- 22	H053 2178	Inner Cover -Cutter			C - 3
3- 23	H053 3130	Shield Plate - PSU			D - 2
3-24	H053 2199	Sheet -Paper Holder : A4			B - 4
3-25	H053 5014	Rx Motor			C - 3
3- 26	H053 2106	Sensor Cover – Feed out			B - 3
3- 27	H053 5013	Sensor Ass'y-SB4			B - 3
3-28	H053 3131	Insulating Sheet - PSU			D - 2
3- 29	H053 5016	Sensor Ass'y-SB5			B - 3
3- 30	H053 2155	Sheet -Roll Paper : Front			C - 3
3-31	H053 2128	Sheet -Roll Paper : Rear			C - 3
3- 32	H053 5310	Ground Wire -Bottom-Side -Front			B - 3
3- 33	H053 3118	Bracket -Cover : Front			B - 3
3- 34	H053 2107	FCU Cover - A4			B - 3

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
3-35	H053 5023	Monitor Speaker Ass'y	G/I/UV UK		B - 4
3-36	H053 3220	Bracket -Door Switch			B - 4
3-36	H053 3119	Bracket -Door Switch			B - 4
3-37	H053 5027	Sensor Ass'y-SB10			B - 4
3-38	H053 2102	Base Ass'y -Printer : A4	G/UV UK/I		C - 4
3- 39	H053 5305	Harness - NCU/FCU			C - 2
3-40	H053 5302	Harness - PSU/FCU			D - 2
3-41	H053 2182	Fixing Plate - SRAM			C - 4
3-42	H053 6023	PCB ASS'y - NCU	G UK	77	C - 2
3-42	H053 6026	PCB Ass'y - NCU			C - 2
3-43	H053 5003	PSU Ass'y - Europe : 220V			D - 2
3-44	H051 6007	PCB Ass'y - FCU : FAX77 : G			D - 4
3-44	H051 6008	PCB Ass'y - FCU : FAX77 : UK	I	77	D - 4
3-44	H051 6009	PCB Ass'y - FCU : F~77 : I	U1	77	D - 4
3-44	H051 6010	PCB Ass'y - FCU : FAX77 : U1	U2	77	D - 4
3-44	H05 16014	PCB Ass'y - FCU : FAX77 : U2	G	80	D - 4
3-44	H053 6007	PCB Ass'y - FCU : FAX80 : G	UK	80	D - 4
3-44	H053 6008	PCB Ass'y - FCU : FAX80 : UK	I	80	D - 4
3-44	H053 6009	PCB Ass'y - FCU : FAX80 : I	U1	80	D - 4
3-44	H053 6010	PCB Ass'y - FCU : FAX80 : U1	U2	80	D - 4
3-44	H053 6014	PCB Ass'y - FCU : FAX80 : U2	G	85	D - 4
3-44	H055 6007	PCB Ass'y - FCU : FAX85 : G	UK	85	D - 4
3-44	H055 6008	PCB Ass'y - FCU : FAX85 : UK	I	85	D - 4
3-44	H055 6009	PCB Ass'y - FCU : FAX85 : I	U1	85	D - 4
3-44	H055 6010	PCB Ass'y - FCU : FAX85 : U1	U2	85	D - 4
3-44	H055 6014	PCB Ass'y - FCU : FAX85 : U2	G/I/UV UK		D - 3
3-45	H041 6014	R96FI Modem-411			C - 4
3-46	H053 6012	PCB Ass'y - SRAM			D - 2
3-47	2801 0031	Power Cord			D - 2
3-47	H022 5002	Power Cord-UK			D - 2

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION
3-100	0951 3006B	Philips Screw with Flat Washer - M3X6			
3-101	0951 3008B	Philips Screw with Flat Washer - M3X8			
3-102	0951 4006B	Philips Screw with Flat Washer - M4X6			
3-103	0951 3005B	Philips Screw with Flat Washer - M3X5			
3-104	0954 3006B	Double Sens Screw - M3X6			
3-105	0954 3008B	Philips Screw -M3X8			
3-106	0951 3010B	Philips Screw with Flat Washer -M3X10			
3-107	0312 0080B	Philips Screw with Flat Washer - M2X8			
3-108	0574 0040E	Hexagon Headless Set Screw - M4X4			
3-109	0720 0060E	Retaining Ring -M6			
3-110	0720 0030E	Retaining Ring -M3			
3-111	0720 0040E	Retaining Ring -M4			

INDEX	PART NO.	DESCRIPTION	VERSION	MODEL	LOCATION

PARTS INDEX

Note: Version

G	Germany	U1	Universal 1
UK	U.K.	U2	Universal 2
I	Italy	UV	Universal 1 and Universal 2

Model

77	FAX 77
80	FAX 80
85	FAX 85

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO
0804 6097	Allen Screw - M3x6	G/I/UV		1-40
2801 0031	Power Cord			3-47
5466 3198	Washer - SBU			2-124
5474 2152	Bushing - Platen Roller			3- 7
H001 4221	Harness Clamper -Document Table			3-18
H012 1144	Pressure Roller			2-47
H012 1183	White Mylar - A4			2-33
H012 2113	Pulley - Platen Roller - A4			3- 6
H012 2119	Bushing - M4			2-113
H012 2119	Bushing - M4			3- 2
H012 3623	Stepped Screw-Scanner - Left			2-110
H012 3628	Space Roller -Locking			1-33
H014 1101	Lens - F4.5/22.2			2-67
H022 5002	Power Cord-UK			3-47
H022 5003	Telephone Line-UK			1-42
H033 4806	Allen Key -2.5			1- **
H041 1502	ADF Feed Roller			2-21
H041 1505	Pick Up Roller			2-22
H041 1525	Sleeve - Pick Up			2-28
H041 1527	Boss - Pick Up			2-26
H04 1528	Spring - Friction : Pick Up			2-27
H041 1537	Shaft - Pressure Plate : Separation			2- 9
H041 1539	Spring -Pressure Plate : Right			2-10
H041 1549	Trast Screw			2- 2
H041 1563	Cushion - Pick Up			2-30
H041 2122	Timing Belt - 180 : 4			3-15
H041 3156	Clamper -Spring : Hopper			1- 19
H041 6014	R96FI Modem-411			3-45
H051 3102	Upper Cover Ass'y-FAX77	G	77	1- 9
H051 3145	Op-Port Cover Ass'y-FAX77		77	1- 6
H051 3150	Op-Port Cover Ass'y-FAX77		77	1- 6
H051 3151	Op-Port Cover Ass'y-FAX77		77	1- 6
H051 3152	Op-Port Cover Ass'y-FAX77		77	1- 6
H051 3165	Quick Dial Cover		77	1- 4
H051 4304	Operator's Manual - FAX77		77	1- **
H051 4305	Operator's Manual - FAX77		77	1- **
H051 4306	Operator's Manual - FAX77		77	1- **

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO
H051 4307	Operator's Manual - FAX77	U1	77	1 - * *
H051 4308	Operator's Manual - FAX77	U2	77	1- **
H051 4314	Quick Reference Guide - FAX77	G	77	1- **
H051 4315	Quick Reference Guide - FAX77	UK	77	1- **
H051 4316	Quick Reference Guide - FAX77	I	77	1- **
H051 4317	Quick Reference Guide - FAX77	U1	77	1- **
H051 4318	Quick Reference Guide - FAX77	U2	77	1- **
H051 4328	Operation Panel Sheet	U1	77	1- **
H051 4329	Operation Panel Sheet	U2	77	1- **
H051 4388	Quick Dial Sheet		77	1- 5
H051 5101	Op-Port Unit - FAX77 (1- 4 - 1- 7)	G	77	1- A
H051 5102	Op-Port Unit - FAX77 (1- 4 - 1- 7)	UK	77	1- A
H051 5103	Op-Port Unit - FAX77 (1- 4 - 1- 7)	I	77	1- A
H051 5104	Op-Port Unit - FAX77 (1- 4 - 1- 7)	UV	77	1- A
H051 6000	PCB Ass'y - Op-Port		77	1- 7
H051 6007	PCB Ass'y - FCU : FAX77 : G	G	77	3-44
H051 6008	PCB Ass'y - FCU : FAX77 : UK	UK	77	3-44
H051 6009	PCB ASS'y - FCU : FAX77 : I	I	77	3-44
H051 6010	PCB ASS'y - FCU : FAX77 : U1	U1	77	3-44
H051 6014	PCB Ass'y - FCU : FAX77 : U2	U2	77	3-44
H053 1100	Base -Scanner : A4			2-48
H053 1101	1st Mirror			2-49
H053 1103	2nd Mirror			2-52
H053 1104	Dust Cover - 2nd Mirror			2-53
H053 1105	3rd Mirror			2-56
H053 1106	Holder - 1st Mirror : Rear			2-51
H053 1107	Holder - 1st Mirror : Front			2-50
H053 1108	Holder - 2nd Mirror : Rear			2-55
H053 1109	Holder - 2nd Mirror : Front			2-54
H053 1110	Mirror Cover			2-89
H053 1111	Lens Block-A4			2-68
H053 1112	Shading Plate-A4			2-66
H053 1113	Plate-Harness Holder : Xenon Lamp			2-64
H053 1115	Side Plate Ass'y -Front			2-86
H053 1119	Arm-Side Plate : Front			2-87
H053 1120	Side Plate Ass'y -Rear			2-82
H053 1126	Belt Tensioner Roller			2-81

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO
H053 1130	R1 Roller			2-84
H053 1131	R2 Roller			2-85
H053 1132	Guide Plate -Scanner : Lower			2-60
H053 1133	Exposure Glass			2-57
H053 1137	Reduction Pulley-Scanner			2-79
H053 1138	Pulley - R1 Roller			2-76
H053 1139	Pulley - R2 Roller			2-75
H053 1140	Idle Gear - Scanner			2-78
H053 1141	Timing Belt - 189			2-73
H053 1143	Release Lever - Scanner			2-107
H053 1144	Spacer - Locking			1-30
H053 1145	Locking Ass'y			1-31
H053 1148	Spring -Lock : Scanner			2-109
H053 1150	Stepped Screw - Locking			1-32
H053 1153	Insulating Sheet - Xe Lamp Stabilizer			2-63
H053 1156	Bracket Ass'y -Hinge : ADF			2-88
H053 1160	Spring Wire -Locking			1-29
H053 1161	Guide - Xenon Lamp			2-65
H053 1163	Timing Belt - 171			2-74
H053 1165	Sheet - Lock Lever			2-119
H053 1167	Sheet - Guide Plate : Rear			2-117
H053 1168	Sheet - Guide Plate : Front			2-116
H053 1170	Belt Tensioner Bracket			2-80
H053 1172	Holder -Exposure Glass : Front			2-58
H053 1173	Holder -Exposure Glass : Rear			2-59
H053 1174	Washer M6 -Scanner Unit			2-126
H053 1500	Guide Plate - ADF : Lower			2-31
H053 1502	Bracket Ass'y - Pick Up Roller			2-24
H053 1506	Idle Gear - Pick Up			2-23
H053 1507	Shaft - Feed Roller			2-25
H053 1508	Base Ass'y-ADF : A4			2-32
H053 1513	Base - Separation Unit			2-13
H053 1514	Bracket - Separation			2- 7
H053 1515	Slider - Friction			2- 6
H053 1516	Slider - Release : Separation			2- 3
H053 1517	Inner Cover -Operation Panel : Front			2-34
H053 1521	Inner Cover -Operation Panel : Rear			2-35

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO.
H053 1523	Spring - Separation Roller			2 - 5
H053 1524	Spacer - M6x14			2-11
H053 1525	Plate Spring- Pressure Roller			2-46
H053 1527	Shaft - Pressure Roller			2-45
H053 1529	Adjustment Screw-PB			2- 8
H053 1534	Slider Sheet			2-114
H053 1537	Pressure Plate - Separation			2-12
H053 1538	Shaft -Bracket : Separation Roller			2-14
H053 1545	Trast Screw – Spring			2-115
H053 1547	Shaft - Separation Roller			2-16
H053 1548	Stopper – Friction : #180			2-20
H053 1554	Spring -Locking : Front			2-40
H053 1555	Spring-Locking : Rear			2-42
H053 1558	Washer - M6x1.5			2-18
H053 1560	Slider -Release : ADF			2- 4
H053 1566	Shaft - Release : ADF			2-37
H053 1567	Arm-Release : ADF			2-38
H053 1568	Locking - ADF : Front			2-39
H053 1569	Locking - ADF : Rear			2-43
H053 1570	Mylar -Document Stopper			2-125
H053 1571	Sheet -Side Plate : Rear			2-120
H053 1572	Sheet -Side Plate : Rear 2			2-121
H053 1574	Spring -Release : Slider			2-44
H053 1575	Bushing - M6.2			2-29
H053 1576	Separation Roller			2-15
H053 1581	Disk - Friction : Separation Roller			2-17
H053 1582	Spring - Friction : Separation Roller			2-19
H053 1600	Bushing - M6 : CUFE			2-41
H053 2102	Base Ass'y -Printer : A4			3-38
H053 2106	Sensor Cover – Feed out			3-26
H053 2107	FCU Cover - A4			3-34
H053 2108	Platen Roller - A4			3- 5
H053 2109	Feed-out Roller - A4 : Lower			3- 1
H053 2110	Guide Roller -Printer			2-104
H053 2111	Timing Belt - 56T			3-17
H053 2112	Pulley - Platen			3- 8
H053 2113	Pulley - Feed-out			3- 3

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO.
H053 2114	Belt - M2.5 : Feed-out	G/I/UV		3 - 4
H053 2115	Turn Roller - A4			2-108
H053 2117	Fixing Plate -Thermal Head : Rear			2-103
H053 2118	Fixing Plate -Thermal Head : Center			2-100
H053 2123	Stepped Screw -M4 : Printer			1-28
H053 2126	Reduction Pulley-Printer			3-16
H053 2128	Sheet - Roll Paper : Rear			3-31
H053 2129	Plate Spring -Thermal Head			2- 95
H053 2130	Ground Plate -Motor Bracket			3-21
H053 2131	Ground Plate -Feed-out Roller			3-14
H053 2132	Harness Guide -Rear			3- 19
H053 2136	Antistatic Brush-Printer : A4			2-36
H053 2141	Plate Spring -Feed-out Roller			3-12
H053 2142	Thermal Head Cover : A4			2-105
H053 2144	Holder -Feed-out Roller : Front			2-93
H053 2145	Holder -Feed-out Roller : Rear			2-94
H053 2146	Guide Plate-Feed-out : A4			2-90
H053 2148	Lavel -Black : SB-4 Sensor			2-91
H053 2155	Sheet - Roll Paper : Front			3-30
H053 2161	Cutter Ass'y-A4			3-11
H053 2163	Fixing Plate -Thermal Head : Front			2-98
H053 2164	Bracket -Thermal Head : Front			2- 99
H053 2165	Bracket -Thermal Head : Rear			2-102
H053 2166	Bracket -Thermal Head : Center			2-101
H053 2171	Bracket - RX Motor			3-20
H053 2174	Cord Clamp -TEL			1-39
H053 2177	Harness Cover -Thermal Head			2-96
H053 2178	Inner Cover -Cutter			3-22
H053 2182	Fixing Plate - SRAM			3-41
H053 2189	O Ring - P3			2-118
H053 2191	Feed-out Roller Ass'y-A4 : Upper			2-92
H053 2197	Bracket -Turn Roller : Front			2-111
H053 2198	Bracket -Turn Roller : Rear			2-112
H053 2199	Sheet - Paper Holder : A4			3-24
H053 3078	Spring -Hopper			1- 18
H053 3100	Front Cover			1-35
H053 3101	Right Cover			1- 16

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO.
H053 3102	Left Cover	UK		1-20
H053 3113	Interface Plate Cover			1-14
H053 3115	Inner Cover - ADF Clutch			2-71
H053 3117	Inner Cover -Scanner : A4			1-17
H053 3118	Bracket -Cover : Front			3-33
H053 3119	Bracket -Door Switch			3-36
H053 3121	Metal Base Ass'y			1-23
H053 3126	Rubber Foot -20.6 X 7.6			1-22
H053 3130	Shield Plate - PSU			3-23
H053 3131	Insulating Sheet -PSU			3-28
H053 3135	Base Guide -Front-Left			1-27
H053 3136	Base Guide -Rear-Left			1-26
H053 3137	Base Guide -Front-Right			1-25
H053 3138	Base Guide -Rear-Right			1-24
H053 3142	Adjustment Screw Cap	G	80	1- 8
H053 3143	Rear Cover Ass'y			1-11
H053 3145	Op-Port Cover Ass'y-FAX80			1- 6
H053 3146	NCU Cover			1-12
H05 33148	Upper Cover Ass'y-FAX80			80
H053 3150	Op-Port Cover Ass'y-FAX80			1- 9
H053 3151	Op-Port Cover Ass'y-FAX80			80
H053 3152	Op-Port Cover Ass'y-FAX80			1- 6
H053 3158	Sub Document Table			80/85
H053 3165	Quick Dial Cover			1-10
H053 3166	Quick Dial Sheet			80/85
H053 3220	Bracket -Door Switch			1- 4
H053 3227	Spring-Hopper : Rear			1- 5
H053 4112	Decal - Set Document			3-36
H053 4113	Decal - Set Document	UK/U1 G/I/UV	80/85	1-41
H053 4114	Decal - Set Document			1-15
H053 4116	Decal -Set Document			1-15
H053 4124	Decal - Caution : Small SAF			1-15
H053 4125	Decal - Caution : Small SAF			1-13
H053 4126	Decal -Caution : Small SAF			1-13
H053 4128	Decal - Caution : Small SAF			1-13
H053 4137	Decal - Replace Paper			1-13
H053 4138	Decal -Replace Paper			1-34
				1-34
				1-34
				1-34
				1-34
				1-34
				1-34

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO.
H053 4139	Decal -Replace Paper	I		1-34-
H053 4141	Decal -Replace Paper	U2		1-34
H053 4143	Decal - Cutter	G		3- 9
H053 4144	Decal - Cutter	UK/U1		3- 9
H053 4145	Decal - Cutter	I		3- 9
H053 4147	Decal - Cutter	U2		3- 9
H053 4149	Decal -Cutter Guide			3-10
H053 4192	Decal - Power Switch	G		1-37
H053 4302	Quick Dial Labels			1- **
H053 4310	Operator's Manual - FAX80/85	G	80/85	1- **
H053 4315	Quick Reference Guide - FAX80	G	80	1- **
H053 4316	NECR			1- **
H053 4317	Operator's Manual - FAX80/85	UK	80/85	1- **
H053 4318	Quick Reference Guide -FAX80	UK	80	1- **
H053 4319	Operator's Manual - FAX80/85	I	80/85	1- **
H053 4320	Quick Reference Guide -FAX80	I	80	1- **
H053 4321	Operator's Manual -FAX80/85	U1	80/85	1- **
H053 4322	Quick Reference Guide -FAX80	U1	80	1- **
H053 4323	Operator's Manual -FAX80/85	U2	80/85	1- **
H053 4324	Quick Reference Guide - FAX80	U2	80	1- **
H053 4388	Quick Dial Sheet	G	80/85	1- 5
H053 4390	Quick Dial Sheet	I	80/85	1- 5
H053 4393	Quick Dial Sheet	U2	80/85	1- 5
H053 4484	Operation Panel Sheet	U1	80	1- **
H053 4485	Operation Panel Sheet	U2	80	1- **
H053 4800	Copy Tray -A4			1- 2
H053 4801	Original Tray-A4			1- 1
H053 4829	Copy Retainer Wire			1- 3
H053 4913	Decal - Gear : G	G		1-38
H053 4914	Decal - Gear : I	I		1-38
H053 4915	Decal -Gear : U1	U1		1-38
H053 4916	Decal -Gear : U2	U2		1-38
H053 5003	PSU Ass'y -Europe : 220V			3-43
H053 5012	Electromagnetic Clutch			2-72
H053 5013	Sensor Ass'y-SB4			3-27
H053 5014	Rx Motor			3-25
H053 5016	Sensor Ass'y-SB5			3-29

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO.
H053 5018	Document Sensor			2 - 1
H053 5023	Monitor Speaker Ass'y			3-35
H053 5027	Sensor Ass'y-SB10			3-37
H053 5028	Tx Motor			2-83
H053 5101	Op-Port Unit FAX80 (1- 4- 1- 7)	G	80	1- A
H053 5102	Op-Port Unit FAX80 (1- 4- 1- 7)	UK	80	1- A
H053 5103	Op-Port Unit FAX80 (1- 4 - 1- 7)	I	80	1- A
H053 5104	Op-Port Unit - FAX80 (1- 4 - 1- 7)	UV	80/85	1- A
H053 5203	Thermal Head- A4 : Kyocera			2-97
H053 5205	Xenon Lamp -A4			2-61
H053 5208	Xenon Lamp Stabilizer -A4			2-62
H053 5302	Harness - PSU/FCU			3-40
H053 5305	Harness - NCU/FCU			3-39
H053 5306	Ground Wire - 120mm			2-77
H053 5308	Ground Wire -Bottom-Side : Rear			2-122
H053 5308	Ground Wire -Bottom-Side -Rear			3-13
H053 5310	Ground Wire -Bottom-Side -Front			3-32
H053 0313	Ground Wire - Separation Base			2-123
H053 5314	Harness - Front/Upper			1-36
H053 5315	Harness - SBU/FCU			2-70
H053 5316	Harness - T. Head/PSU			2-106
H053 6000	PCB Ass'y-Op-Port		80/85	1- 7
H053 6007	PCB ASS'y -FCU : FAX80 : G	G	80	3-44
H053 6008	PCB ASS'y -FCU : FAX80 : UK	UK	80	3-44
H053 6009	PCB ASS'y -FCU : FAX80 : I	I	80	3-44
H053 6010	PCB ASS'y -FCU : FAX80 : U1	U1	80	3-44
H053 6012	PCB ASS'y - SRAM			3-46
H053 6014	PCB ASS'y -FCU : FAX80 : U2	U2	80	3-44
H053 6022	PCB ASS'y - SBU			2-69
H053 6023	PCB ASS'y - NCU	G/UV		3-42
H053 6026	PCB ASS'y -NCU	UK/I		3-42
H054 3111	NCU Fixing Plate			1-21
H055 3112	Op-Port Cover Ass'y-FAX85	G	85	1- 6
H055 3113	Op-Port Cover Ass'y-FAX85	UK	85	1- 6
H055 3114	Op-Port Cover Ass'y-FAX85	I	85	1- 6
H055 3119	Upper Cover Ass'u-FAX85		85	1- 9
H0554106	Decal -Caution : SAF	G	85	1-13

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO
H055 4107	Decal - Caution : SAF	UK/U1	85	1- 13
H055 4108	Decal - Caution : SAF	I	85	1-13
H055 4110	Decal -Caution : SAF	U2	85	1-13
H055 4331	Operation Panel Sheet	U1	85	1- **
H055 4337	Operation Panel Sheet	U2	85	1- **
H055 4343	Quick Reference Guide - FAX85	G	85	1- **
H055 4344	Quick Reference Guide - FAX85	U1	85	1- **
H055 4345	Quick Reference Guide -FAX85	I	85	1- **
H055 4346	Quick Reference Guide - FAX85	UK	85	1- **
H055 4347	Quick Reference Guide - FAX85	U2	85	1- **
H055 5101	Op-Port Unit - FAX85 (1- 4 - 1- 7)	G	85	1- A
H055 5102	Op-Port Unit - FAX85 (1- 4 - 1- 7)	UK	85	1- A
H055 5103	Op-Port Unit - FAX85 (1- 4- 1- 7)	I	85	1- A
H055 6007	PCB ASS'y -FCU : FAX85 : G	G	85	3-44
H055 6008	PCB Ass'y -FCU : FAX85 : UK	UK	85	3-44
H055 6009	PCB Ass'y -FCU : FAX8,5 : I	I	85	3-44
H055 6010	PCB ASS'y -FCU : FAX85 : U1	U1	85	3-44
H055 6014	PCB ASS'y -FCU : FAX85 : U2	U2	85	3-44

PART NO.	DESCRIPTION	VERSION	MODEL	PAGE AND INDEX NO
0312 0080B	Philips Screw with Flat Washer -M2x8			3-107
0313 0060B	Philips Pan Head Screw -M3x6			2-205
0573 0040E	Hexagon Headless Set Screw -M3x4			2-206
0574 0040E	Hexagon Headless Set Screw -M4x4			3-108
0720 0020E	Retaining Ring -M2			2-209
0720 0030E	Retaining Ring -M3			2-210
0720 0030E	Retaining Ring -M3			3-110
0720 0040E	Retaining Ring -M4			2-208
0720 0040E	Retaining Ring -M4			3-111
0720 0050E	Retaining Ring -M5			2-211
0720 0060E	Retaining Ring -M6			1-103
0720 0060E	Retaining Ring -M6			3-109
0807 3005	Washer -Reverse Gear			2-212
0951 3005B	Philips Screw with Fiat Washer -M3x5			2-204
0951 3005B	Philips Screw with Flat Washer -M3x5			3-103
0951 3006B	Philips Screw with Flat Washer -M3x6			1-100
0951 3006B	Philips Screw with Flat Washer -M3x6			2-200
0951 3006B	Philips Screw with Flat Washer -M3x6			3-100
0951 3008B	Philips Screw with Flat Washer -M3x8			1-101
0951 3008B	Philips Screw with Flat Washer -M3x8			2-201
0951 3008B	Philips Screw with Flat Washer -M3x8			3-101
0951 3010B	Philips Screw with Flat Washer -M3x10			3-106
0951 4006B	Philips Screw with Flat Washer -M4x6			1-102
0951 4006B	Philips Screw with Flat Washer -M4x6			2-202
0951 4006B	Philips Screw with Flat Washer -M4x6			3-102
0954 3006B	Double Sens Screw -M3X6			2-207
0954 3006B	Double Sens Screw -M3x6			3-104
0954 3008B	Philips Screw -M3x8			3-105
0954 3010B	Philips Screw -M3x10			2-203
1105 0109	Cord Keep			1-105
1105 0115	Tie Wrap - SKB-85			1-104
1105 0115	Tie Wrap - SKB-85			2-213