

Bypass Feeder Type 510 (H207)

Bypass Feeder Type 510 (H207)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.BYPASS FEEDER 1 (H207).....	2
2.BYPASS FEEDER 2 (H207).....	4
PARTS INDEX.....	7

July ,5 ' 2002

1.BYPASS FEEDER 1 (H207)




1.BYPASS FEEDER 1 (H207)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H310 3732	Extension Tray	1
2	H310 3733	Extension Tray	1
3	B415 6104	Side Fence - Front	1
4	H310 3748	Side Fence Decal	1
5	B415 6105	Side Fence - Rear	1
6	H310 3744	Base	1
7	5215 2713	Bottom Plate Pad	1
8	H310 3751	Spring	2
9	G012 3050	Side Fence Gear	1
10	H310 3750	Bottom Plate Bracket	1
11	AA08 2021	Bushing - 8x12x10mm	1
12	H310 3758	Feed Roller	1
13	H310 3759	Feed Roller Bracket	1
14	H515 3543	E-ring - Jre4	1
15	H310 3762	Gear - 21Z	1
16	H515 3544	E-ring - Jr-e6	3
17	H523 5050	Magnetic Clutch - 2.5	1
18	H310 3763	Spring	1
19	H310 3734	Grounding Plate	1
20	H310 3731	Lower Base	1
21	H310 3741	Spring	1
22	H310 3737	Friction Pad Ass'y	1
23	H310 3755	Bottom Plate Lever Shaft	1
24	H310 3754	Bottom Plate Lever	1
25	5447 2681	Snap Ring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006H	Tapping Screw - 3x6	
102	0805 3480	Bushing - 6mm	
103	1105 0344	Clamp	

2.BYPASS FEEDER 2 (H207)



2.BYPASS FEEDER 2 (H207)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H310 3767	Upper Base	1
2	H310 3777	Paper Size Dial Cover	1
3	H310 3776	Paper Size Dial Pin	1
4	H310 3793	Paper Size Sensor Decal	1
5	H310 3774	Paper Size Sensor Board	1
6	H515 5054	Paper Size Sensor	1
7	H310 3788	Operation Decal	1
8	H310 5277	Main Harness	1
9	H310 3781	Connector Cover	1
10	H310 3782	Spring	2
11	H310 3783	Connector Guide Bracket	1
12	H310 3780	Connector Bracket	1
13	H310 5278	Grounding Wire Connector	1
14	H310 3790	Upper Cover	1
15	H310 3768	Front Upper Base Bracket	2
16	H310 3770	Paper End Sensor Bracket	1
17	H523 5051	Paper End Sensor	1
18	H310 3769	Rear Upper Base Bracket	1
19	H310 3811	Drive Bracket	1
20	H310 3816	Gear - 19Z/17Z	1
21	H515 3543	E-ring - Jre4	1
22	H310 3817	Gear - 25Z	1
23	H519 3058	Gear - 19Z	1
24	H310 5276	Relay Harness	1
25	G029 1255	Magnet Catch Stay	2
26	H306 4650	Cushion - By-pass Feed Cover	2
27	AA02 1030	Magnet Catch	1
28	H310 3819	Connector Bracket	1
29	H310 4170	Knob	1
30	H310 3771	Paper End Sensor Sheet	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006H	Tapping Screw - 3x6	
102	0450 3008H	Tapping Screw - M3x8	
103	0451 3006B	Tapping Screw - M3x6	
104	0452 3008H	Binding Self-tapping Screw - 3x8	
105	1102 8535	Connector - QR/P17-14P-A	
106	1102 8534	Connector - QR/P17-14S-B	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B415 6104	Side Fence - Front	3 - 3
B415 6105	Side Fence - Rear	3 - 5
G012 3050	Side Fence Gear	3 - 9
G029 1255	Magnet Catch Stay	5 - 25
H306 4650	Cushion - By-pass Feed Cover	5 - 26
H310 3731	Lower Base	3 - 20
H310 3732	Extension Tray	3 - 1
H310 3733	Extension Tray	3 - 2
H310 3734	Grounding Plate	3 - 19
H310 3737	Friction Pad Ass'y	3 - 22
H310 3741	Spring	3 - 21
H310 3744	Base	3 - 6
H310 3748	Side Fence Decal	3 - 4
H310 3750	Bottom Plate Bracket	3 - 10
H310 3751	Spring	3 - 8
H310 3754	Bottom Plate Lever	3 - 24
H310 3755	Bottom Plate Lever Shaft	3 - 23
H310 3758	Feed Roller	3 - 12
H310 3759	Feed Roller Bracket	3 - 13
H310 3762	Gear - 21Z	3 - 15
H310 3763	Spring	3 - 18
H310 3767	Upper Base	5 - 1
H310 3768	Front Upper Base Bracket	5 - 15
H310 3769	Rear Upper Base Bracket	5 - 18
H310 3770	Paper End Sensor Bracket	5 - 16
H310 3771	Paper End Sensor Sheet	5 - 30
H310 3774	Paper Size Sensor Board	5 - 5
H310 3776	Paper Size Dial Pin	5 - 3
H310 3777	Paper Size Dial Cover	5 - 2
H310 3780	Connector Bracket	5 - 12
H310 3781	Connector Cover	5 - 9
H310 3782	Spring	5 - 10
H310 3783	Connector Guide Bracket	5 - 11
H310 3788	Operation Decal	5 - 7
H310 3790	Upper Cover	5 - 14

Part No.	Description	Page and Index No.
H310 3793	Paper Size Sensor Decal	5 - 4
H310 3811	Drive Bracket	5 - 19
H310 3816	Gear - 19Z/17Z	5 - 20
H310 3817	Gear - 25Z	5 - 22
H310 3819	Connector Bracket	5 - 28
H310 4170	Knob	5 - 29
H310 5276	Relay Harness	5 - 24
H310 5277	Main Harness	5 - 8
H310 5278	Grounding Wire Connector	5 - 13
H515 3543	E-ring - Jre4	5 - 21
H515 3543	E-ring - Jre4	3 - 14
H515 3544	E-ring - Jr-e6	3 - 16
H515 5054	Paper Size Sensor	5 - 6
H519 3058	Gear - 19Z	5 - 23
H523 5050	Magnetic Clutch - 2.5	3 - 17
H523 5051	Paper End Sensor	5 - 17

Part No.	Description	Page and Index No.
AA02 1030	Magnet Catch	5 - 27
AA08 2021	Bushing - 8x12x10mm	3 - 11

Part No.	Description	Page and Index No.
0450 3008H	Tapping Screw - M3x8	5 -102
0451 3006B	Tapping Screw - M3x6	5 -103
0451 3006H	Tapping Screw - 3x6	3 -101
0451 3006H	Tapping Screw - 3x6	5 -101
0452 3008H	Binding Self-tapping Screw - 3x8	5 -104
0805 3480	Bushing - 6mm	3 -102
1102 8534	Connector - QR/P17-14S-B	5 -106
1102 8535	Connector - QR/P17-14P-A	5 -105
1105 0344	Clamp	3 -103
5215 2713	Bottom Plate Pad	3 - 7
5447 2681	Snap Ring	3 - 25