

PFU SCHMIDT 1

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

1.EXTERIOR (H110-67/77)	2
2.PAPER REGISTRATION (H110-67/77)	4
3.PAPER TRAY (H110-67/77)	6
PARTS INDEX	9

1.EXTERIOR (H110-67/77)




1.EXTERIOR (H110-67/77)

INDEX	PARTS NO.	DESCRIPTION	Note
1	H545 3690	Lift Spring	2
2	H545 3687	Lift Link	2
3	H545 3688	Cassette Roller	2
4	H515 3543	E-Ring - JR-E4	4
5	H545 3686	Lift Shaft	1
6	H545 3683	Driven Roller	1
7	H545 3684	Lift Roller Shaft	1
8	H545 3685	Lift Arm	1
9	H545 3654	Left Cover	1
10	H545 3639	Link Cushion	2
11	H545 3655	Front Cover	1
12	H545 3696	Rubber Foot	4
13	H545 3653	Right Cover	1
14	H545 5070	2nd Harness	1
15	H515 3542	Rivet	2
16	H515 5018	Cover Switch - Fusing Exit	2
17	H545 3679	Screw:cushion	1
18	H545 3732	Magnetic Cover	1
19	H545 3733	Magnetic Bracket	1
20	H545 3692	Pressure Roller Spring	2
21	H545 3652	Rear Upper Cover	1
22	H545 3143	Transfer Driven Roller	1
23	H545 3148	Roller Shaft	1
24	H545 3731	Friction Pad Film	2
25	H545 3666	Friction Pad	1
26	H545 3691	Cushion	1
27	G800 3147	Spring 2.8	1
28	H545 3663	Transfer Mylar	1
29	H545 3695	Fixing Plate	1
30	H545 3665	Friction Pad Cover	1

INDEX	PARTS NO.	DESCRIPTION	Note
101	0805 3480	Bushing - 6mm	
102	1105 0407	Clamp	

2.PAPER REGISTRATION (H110-67/77)




2.PAPER REGISTRATION (H110-67/77)

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3543	E-Ring - JR-E4	16
2	H545 3642	Lever Shaft	2
3	H545 3641	Lever Bracket	2
4	H545 3668	Grounding Plate	1
5	H545 3640	Paper Lift Lever	2
6	H545 3648	Left Link Ass'y	2
7	H545 3644	Link Roller	2
8	H545 3645	Link 2	2
9	H545 5073	Paper Face Sensor	1
10	H545 3670	Rear Upper Stay	1
11	H545 3656	Front Stay	1
12	H545 3618	Guide Plate - Paper Feed Roller	1
13	H545 3669	Grounding Plate	1
14	H545 5075	Magnetick Clutch - 0.49n	1
15	H545 3630	Joint Bracket	1
16	H545 3628	Clutch Stopper	1
17	H545 3604	Gear - 18Z	1
18	H545 3605	Gear - 20/39Z	1
19	H545 3609	Gear -	1
20	H006 3530	Idle Gear - 15t	1
21	H545 3620	Paper Feed Shaft	1
22	H545 3629	Pressuer Spring	1
23	H545 3633	Joint Shaft	1
24	H545 3601	Paper Feed Roller	1
25	H545 3602	Transfer Roller	1
26	H545 3646	Right Link Ass'y	1
27	H545 3544	E-Ring - JR-E6	1

INDEX	PARTS NO.	DESCRIPTION	Note
101	1105 0407	Clamp	
102	0805 3480	Bushing - 6mm	

3.PAPER TRAY (H110-67/77)



3.PAPER TRAY (H110-67/77)

INDEX	PARTS NO.	DESCRIPTION	Note
1	H545 3708	Cover	1
2	H545 3703	Bottom Plate	1
3	H545 3713	Bottom Plate Pad	1
4	H545 3714	Mylar -	2
5	H545 3712	Side Fence Sheet	2
6	H545 3705	Left Side Fence	1
7	H545 3716	Sheet:side Fence:2	2
8	H545 3715	Bottom Plate Spring	2
9	H545 3704	Right Side Fence	1
10	H545 3701	Cassette Frame	1
11	H545 3709	Paper Level Window	1
12	H545 3107	Paper Size Selector	1
13	H545 3702	Slider - 2nd	1
14	H545 3707	End Fence Spring	1
15	H545 3706	End Fence	1
16	H545 8151	Installation Procedure	1
17	H545 3122	Decal - F4 (EUROPE/ASIA)	1

INDEX	PARTS NO.	DESCRIPTION	Note

PARTS INDEX

PART N O.	DESCRIPTION	INDEX
G800 3147	Spring 2.8	3- 27
H006 3530	Idle Gear - 15t	5- 20
H515 3542	Rivet	3- 15
H515 3543	E-Ring - JR-E4	5- 1
H515 3543	E-Ring - JR-E4	3- 4
H515 5018	Cover Switch - Fusing Exit	3- 16
H545 3107	Paper Size Selector	7- 12
H545 3122	Decal - F4 (EUROPE/ASIA)	7- 17
H545 3143	Transfer Driven Roller	3- 22
H545 3148	Roller Shaft	3- 23
H545 3544	E-Ring - JR-E6	5- 27
H545 3601	Paper Feed Roller	5- 24
H545 3602	Transfer Roller	5- 25
H545 3604	Gear - 18Z	5- 17
H545 3605	Gear - 20/39Z	5- 18
H545 3609	Gear -	5- 19
H545 3618	Guide Plate - Paper Feed Roller	5- 12
H545 3620	Paper Feed Shaft	5- 21
H545 3628	Clutch Stopper	5- 16
H545 3629	Pressuer Spring	5- 22
H545 3630	Joint Bracket	5- 15
H545 3633	Joint Shaft	5- 23
H545 3639	Link Cushion	3- 10
H545 3640	Paper Lift Lever	5- 5
H545 3641	Lever Bracket	5- 3
H545 3642	Lever Shaft	5- 2
H545 3644	Link Roller	5- 7
H545 3645	Link 2	5- 8
H545 3646	Right Link Ass'y	5- 26
H545 3648	Left Link Ass'y	5- 6
H545 3652	Rear Upper Cover	3- 21
H545 3653	Right Cover	3- 13
H545 3654	Left Cover	3- 9

PART N O.	DESCRIPTION	INDEX
H545 3655	Front Cover	3- 11
H545 3656	Front Stay	5- 11
H545 3663	Transfer Mylar	3- 28
H545 3665	Friction Pad Cover	3- 30
H545 3666	Friction Pad	3- 25
H545 3668	Grounding Plate	5- 4
H545 3669	Grounding Plate	5- 13
H545 3670	Rear Upper Stay	5- 10
H545 3679	Screw:cushion	3- 17
H545 3683	Driven Roller	3- 6
H545 3684	Lift Roller Shaft	3- 7
H545 3685	Lift Arm	3- 8
H545 3686	Lift Shaft	3- 5
H545 3687	Lift Link	3- 2
H545 3688	Cassette Roller	3- 3
H545 3690	Lift Spring	3- 1
H545 3691	Cushion	3- 26
H545 3692	Pressure Roller Spring	3- 20
H545 3695	Fixing Plate	3- 29
H545 3696	Rubber Foot	3- 12
H545 3701	Cassette Frame	7- 10
H545 3702	Slider - 2nd	7- 13
H545 3703	Bottom Plate	7- 2
H545 3704	Right Side Fence	7- 9
H545 3705	Left Side Fence	7- 6
H545 3706	End Fence	7- 15
H545 3707	End Fence Spring	7- 14
H545 3708	Cover	7- 1
H545 3709	Paper Level Window	7- 11
H545 3712	Side Fence Sheet	7- 5
H545 3713	Bottom Plate Pad	7- 3
H545 3714	Mylar -	7- 4
H545 3715	Bottom Plate Spring	7- 8

PART N O.	DESCRIPTION	INDEX
H545 3716	Sheet:side Fence:2	7- 7
H545 3731	Friction Pad Film	3- 24
H545 3732	Magnetic Cover	3- 18
H545 3733	Magnetic Bracket	3- 19
H545 5070	2nd Harness	3- 14
H545 5073	Paper Face Sensor	5- 9
H545 5075	Magnetick Clutch - 0.49n	5- 14
H545 8151	Installation Procedure	7- 16

PART N O.	DESCRIPTION	INDEX
0805 3480	Bushing - 6mm	3-101
0805 3480	Bushing - 6mm	5-102
1105 0407	Clamp	3-102
1105 0407	Clamp	5-101