

PFU (H110)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.EXTERIOR (H110) 2
2.PAPER FEED SECTION (H110)..... 4
3.FRAME SECTION (H1110) 6
4.PAPER TRAY (H110)..... 8
PARTS INDEX 11

1.EXTERIOR (H110)




1.EXTERIOR (H110)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H519 4645	Paper Level Cover	1
2	H519 6035	Rib Board	1
3	H519 4903	Front Joint Plate	1
4	H519 4545	Tray Holder	2
5	G020 2620	Push Switch - Paper Size	1
6	H519 5527	Paper Size Sensor Harness	1
7	H519 4635	Right Cover	1
8	H519 4615	Rear Cover	1
9	H519 4616	Joint Bracket Cover	1
10	H519 3810	Paper Feed Cover	1
11	H519 4905	Rear joint Plate	1
12	H519 4547	Spring Plate	1
13	H519 4548	Upper Front Stand	1
14	H519 4902	Stand 20mm	1
15	A048 2838	Nylon Rivet	1
16	H519 4628	Guide Plate Band	1
17	H519 4626	Vertical Left Cover	1
18	H306 3504	Guide Plate Shield	2
19	G697 1263	Magnetic Catch Plate	2
20	H306 3513	Left Cover Ass'y	1
21	G697 1261	Magnetic Catch Bracket	4
22	AG07 0012	Magnet	2
23	H519 4627	Vertical Guide Plate	1
24	H519 4623	Spring Plate	2
25	H519 4629	Vertical Driven Roller	2
26	H306 3503	Guide Plate Shield - Feeler	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0453 3006B	Tapping Screw - M3x6	
103	0451 3006B	Tapping Screw - M3x6	
104	0450 4008B	Tapping Screw - 4x8	
105	0802 5254	Tapping Screw-m3x6	

2.PAPER FEED SECTION (H110)




2.PAPER FEED SECTION (H110)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H519 4730	Paper Sensor Bracket	1
2	AW02 0089	Photointerruptor	1
3	H519 4717	Paper Feed Stay	1
4	AB01 0103	Relay Gear	1
5	AB01 0104	Gear - 24Z	2
6	H519 4718	Rear Feed Shaft	1
7	G697 2561	Bushing	2
8	G697 2558	Bracket - Feed Clutch Shaft	1
9	H519 4731	Paper End Sensor Bracket	1
10	H519 4733	Paper End Sensor	1
11	H519 5525	Sensor Harness	1
12	AW02 0075	Photointerruptor	1
13	AA14 0627	Drive Shaft - Feed Roller	1
14	H519 4720	Front Pick-up Arm	1
15	H519 4714	Timing Pulley - 22Z	1
16	H519 4715	Timing Belt	1
17	H519 4713	Collar	1
18	H519 4722	Rear Pick-up Arm	1
19	H006 2383	Snap Ring	4
20	H306 3530	Balancer	2
21	AF03 1033	Paper Feed Roller	2
22	H306 3525	Paper Feed Shaft	1
23	H519 4721	Upper Guide Plate	1
24	AX20 0129	Relay Clutch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0060E	Retaining Ring - M6	
103	0805 3386	Bushing - 8mm	
104	1105 0229	Clamp	
105	1105 0113	Edge - P108	
106	1105 0199	Clamp	

3.FRAME SECTION (H1110)




3.FRAME SECTION (H1110)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H519 5526	Main Harness	1
2	H519 4556	Safety Switch Bracket	1
3	H519 4741	Transport Relay Roller	1
4	AA08 2070	Bushing - 8x16x7	2
5	H519 4540	Slide Rail	1
6	AW02 0075	Photointerruptor	1
7	H519 4746	Gear - 16Z	1
8	5215 2621	Snap Ring - M6	1
9	H519 4747	Idel Gear - 16Z	2
10	H519 4549	Paper Tray Holder	1
11	H519 4799	Connector Bracket	1
12	H306 6095	PFU Board	1
13	H519 5570	Upper Relay Harness	1
14	H519 4756	Motor Bracket	1
15	H519 4755	DC Motor - DC24V 0.5W	1
16	H519 4768	Idel Gear - 60Z/15Z	1
17	H519 4765	Stepped Motor Bracket	1
18	H515 5065	P. F. Motor - pFU - Dc24v;0.49a	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3014B	Tapping Screw - M3-14	
102	1204 2356	Micro Switch - Am51612a531	
103	0451 3006B	Tapping Screw - M3x6	
104	0720 0060E	Retaining Ring - M6	
105	0720 0040E	Retaining Ring - M4	
106	1105 0230	Clamp	
107	1105 0348	Clamp	
108	1106 0430	Bushing - 13mm	
109	0450 4010B	Tapping Screw - 4x10	
110	1106 0193	Bushing - 7.9mm	
111	1105 0199	Clamp	

4.PAPER TRAY (H110)



4.PAPER TRAY (H110)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H306 3506	Front Paper Size Sensor (NA)	1
1	H306 3508	Front Paper Size Sensor (ASIA)	1
1	H306 3507	Front Paper Size Sensor (EU)	1
2	H519 3033	Paper Size Sensor - Rear	1
3	H519 4795	Paper Tray Cover	1
4	H519 3038	Decal - Paper Level	1
5	H519 4797	Spring Plate	1
6	H519 4780	Paper Set Direction Sheet	1
7	H519 4791	End Fence Seal (EU/ASIA)	6
8	H519 4793	Lever Cushion	1
9	H519 4792	Bottom Plate Cushion (ASIA)	1
10	H519 4788	Grounding Plate	1
11	H519 4781	Separation Hook - Front	1
12	H519 4777	Rear Side Fence	1
13	A134 2978	Spring Plate	1
14	H519 4779	Stopper Lever	1
15	H519 4782	Separation Hook - Rear	1
16	H519 4778	Front Side Fence	1
17	H519 4790	End Fence	1
18	G697 2666	End Fence Holder	1
19	AA06 3390	Rear Fence Spring	1
20	AB01 3868	Gear - 16Z	1
21	H519 4785	Paper Lift Shaft	1
22	H519 4787	Paper Level Actuator	1
23	G697 2669	Lift Bracket - Bottom Plate	1
24	H306 3501	Decal - Size Indication	1
25	H519 4784	Bottom Plate	1
26	A048 2838	Nylon Rivet	2
27	AF01 3015	Friction Pad	2
28	H519 4776	Paper Tray	1
29	H306 3580	Side Fence Shield	1
30	H306 3505	Separation Plate LT (EU/ASIA)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0720 0060E	Retaining Ring - M6	
103	0450 3008B	Tapping Screw - M3x8	
104	0451 3006B	Tapping Screw - M3x6	
105	0452 3008Z	Bind Tapping Screw - M3x8	
106	0450 4008B	Tapping Screw - 4x8	

PARTS INDEX

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No
Paper Feed Section	AF03 1033	Paper Feed Roller	Paper Feed Roller	2	5- 21

Part No.	Description	Page and Index No.
AA06 3390	Rear Fence Spring	9- 19
AA08 2070	Bushing - 8x16x7	7- 4
AA14 0627	Drive Shaft - Feed Roller	5- 13
AB01 0103	Relay Gear	5- 4
AB01 0104	Gear - 24Z	5- 5
AB01 3868	Gear - 16Z	9- 20
AF01 3015	Friction Pad	9- 27
AF03 1033	Paper Feed Roller	5- 21
AG07 0012	Magnet	3- 22
AW02 0075	Photointerruptor	7- 6
AW02 0075	Photointerruptor	5- 12
AW02 0089	Photointerruptor	5- 2
AX20 0129	Relay Clutch	5- 24

Part No.	Description	Page and Index No
A048 2838	Nylon Rivet	3- 15
A048 2838	Nylon Rivet	9- 26
A134 2978	Spring Plate	9- 13

Part No.	Description	Page and Index No.
G020 2620	Push Switch - Paper Size	3- 5
G697 1261	Magnetic Catch Bracket	3- 21
G697 1263	Magnetic Catch Plate	3- 19
G697 2558	Bracket - Feed Clutch Shaft	5- 8
G697 2561	Bushing	5- 7
G697 2666	End Fence Holder	9- 18
G697 2669	Lift Bracket - Bottom Plate	9- 23
H006 2383	Snap Ring	5- 19
H306 3501	Decal - Size Indication	9- 24
H306 3503	Guide Plate Shield - Feeler	3- 26
H306 3504	Guide Plate Shield	3- 18
H306 3505	Separation Plate LT (EU/ASIA)	9- 30
H306 3506	Front Paper Size Sensor (NA)	9- 1
H306 3507	Front Paper Size Sensor (EU)	9- 1
H306 3508	Front Paper Size Sensor (ASIA)	9- 1
H306 3513	Left Cover Ass'y	3- 20
H306 3525	Paper Feed Shaft	5- 22
H306 3530	Balancer	5- 20
H306 3580	Side Fence Shield	9- 29
H306 6095	PFU Board	7- 12
H515 5065	P. F. Motor - PFU - Dc24v;0.49a	7- 18
H519 3033	Paper Size Sensor - Rear	9- 2
H519 3038	Decal - Paper Level	9- 4
H519 3810	Paper Feed Cover	3- 10
H519 4540	Slide Rail	7- 5
H519 4545	Tray Holder	3- 4
H519 4547	Spring Plate	3- 12
H519 4548	Upper Front Stand	3- 13
H519 4549	Paper Tray Holder	7- 10
H519 4556	Safety Switch Bracket	7- 2
H519 4615	Rear Cover	3- 8
H519 4616	Joint Bracket Cover	3- 9
H519 4623	Spring Plate	3- 24
H519 4626	Vertical Left Cover	3- 17
H519 4627	Vertical Guide Plate	3- 23

Part No.	Description	Page and Index No.
H519 4628	Guide Plate Band	3- 16
H519 4629	Vertical Driven Roller	3- 25
H519 4635	Right Cover	3- 7
H519 4645	Paper Level Cover	3- 1
H519 4713	Collar	5- 17
H519 4714	Timing Pulley - 22Z	5- 15
H519 4715	Timing Belt	5- 16
H519 4717	Paper Feed Stay	5- 3
H519 4718	Rear Feed Shaft	5- 6
H519 4720	Front Pick-up Arm	5- 14
H519 4721	Upper Guide Plate	5- 23
H519 4722	Rear Pick-up Arm	5- 18
H519 4730	Paper Sensor Bracket	5- 1
H519 4731	Paper End Sensor Bracket	5- 9
H519 4733	Paper End Sensor	5- 10
H519 4741	Transport Relay Roller	7- 3
H519 4746	Gear - 16Z	7- 7
H519 4747	Idel Gear - 16Z	7- 9
H519 4755	DC Motor - DC24V 0.5W	7- 15
H519 4756	Motor Bracket	7- 14
H519 4765	Stepped Motor Bracket	7- 17
H519 4768	Idel Gear - 60Z/15Z	7- 16
H519 4776	Paper Tray	9- 28
H519 4777	Rear Side Fence	9- 12
H519 4778	Front Side Fence	9- 16
H519 4779	Stopper Lever	9- 14
H519 4780	Paper Set Direction Sheet	9- 6
H519 4781	Separation Hook - Front	9- 11
H519 4782	Separation Hook - Rear	9- 15
H519 4784	Bottom Plate	9- 25
H519 4785	Paper Lift Shaft	9- 21
H519 4787	Paper Level Actuator	9- 22
H519 4788	Grounding Plate	9- 10
H519 4790	End Fence	9- 17
H519 4791	End Fence Seal (EU/ASIA)	9- 7

Part No.	Description	Page and Index No.
H519 4792	Bottom Plate Cushion (ASIA)	9- 9
H519 4793	Lever Cushion	9- 8
H519 4795	Paper Tray Cover	9- 3
H519 4797	Spring Plate	9- 5
H519 4799	Connector Bracket	7- 11
H519 4902	Stand 20mm	3- 14
H519 4903	Front Joint Plate	3- 3
H519 4905	Rear joint Plate	3- 11
H519 5525	Sensor Harness	5- 11
H519 5526	Main Harness	7- 1
H519 5527	Paper Size Sensor Harness	3- 6
H519 5570	Upper Relay Harness	7- 13
H519 6035	Rib Board	3- 2

Part No.	Description	Page and Index No
5215 2621	Snap Ring - M6	7- 8

Part No.	Description	Page and Index No.
0450 3008B	Tapping Screw - M3x8	9-103
0450 3008B	Tapping Screw - M3x8	3-101
0450 4008B	Tapping Screw - 4x8	3-104
0450 4008B	Tapping Screw - 4x8	9-106
0450 4010B	Tapping Screw - 4x10	7-109
0451 3006B	Tapping Screw - M3x6	3-103
0451 3006B	Tapping Screw - M3x6	5-101
0451 3006B	Tapping Screw - M3x6	9-104
0451 3006B	Tapping Screw - M3x6	7-103
0451 3014B	Tapping Screw - M3-14	7-101
0451 4008B	Philips Tapping Screw - M4x8	9-101
0452 3008Z	Bind Tapping Screw - M3x8	9-105
0453 3006B	Tapping Screw - M3x6	3-102
0720 0040E	Retaining Ring - M4	7-105
0720 0060E	Retaining Ring - M6	7-104
0720 0060E	Retaining Ring - M6	9-102
0720 0060E	Retaining Ring - M6	5-102
0802 5254	Tapping Screw-m3x6	3-105
0805 3386	Bushing - 8mm	5-103
1105 0113	Edge - P108	5-105
1105 0199	Clamp	5-106
1105 0199	Clamp	7-111
1105 0229	Clamp	5-104
1105 0230	Clamp	7-106
1105 0348	Clamp	7-107
1106 0193	Bushing - 7.9mm	7-110
1106 0430	Bushing - 13mm	7-108
1204 2356	Micro Switch - Am51612a531	7-102

Part No.	Description	Page and Index No