


Paper Feed Unit PB1160

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

- 1. Paper Feed Section-1 2 P
- 2. Paper Feed Section-2..... 4 P
- 3. Parts Index..... 6 P


1. Paper Feed Section-1



1.Paper Feed Section-1

[illegible][illegible]

2. Paper Feed Section-2



2.Paper Feed Section-2

Index No.	Part No.	Description	Q'ty Per Assembly
A01	D3G71082	CASSETTE ASS'Y	1
1	M2812520	RETARD ROLLER	1
2	M2812536	HOLDER:RETARD B	1
3	D3C21080	GUIDE:RETARD B	1
4	M2812524	SPRING:RETARD B	1
5	M2812523	GEAR:Z48S:LIFT	1
6	D3C21072	GEAR:Z15S:JOINT	1
7	D3C21079	COVER:LIFT GEAR	1
8	M2812537	GEAR:CASSETTE	1
9	M2822861	CURSOR_RIGHT	1
10	M2812539	CURSOR:LEFT	1
11	D3C21074	PLATE:BOTTOM	1
12	M2812544	PAD_BOTTOM	1
13	D3G71077	COVER_CASSETT	1
14	D3G71076	BASE_CASSETTE	1
15	D3C21071	GUIDE:CASSETTE	1
16	D3C21073	PULLEY:MID:IDLE	3
17	D3C21062	SHAFT:MID:MP	1
18	D3C21063	STOPPER:SPRING:FEED	2
19	D3C21069	SPRING:MID:IDLE:M	2
20	D3C21066	LEVER:HOOK	2
21	D3C21064	HOOK:RIGHT	1
22	D3C21065	HOOK:LEFT	1
23	D3C21067	SPRING:HOOK	2
24	D3C21052	SPRING:BLADE:THRUST	1
25	D3C21075	SHEET:CASSETTE	1
26	D3C21068	GUARD:HANDLE	1
27	D3C21070	FLAPPER:HANDLE	1
28	M2812807	DIAL CASSETTE	1
29	D3C21081	LABEL:DIAL:PF	1
30	M2812532	CURSOR:END:ASS'Y	1

[illegible]

Parts Index

Parts Index

Part No.	Description	Section and Index No.
D3C21052	SPRING:BLADE:THRUST	2-24
D3C21062	SHAFT:MID:MP	2-17
D3C21063	STOPPER:SPRING:FEED	2-18
D3C21064	HOOK:RIGHT	2-21
D3C21065	HOOK:LEFT	2-22
D3C21066	LEVER:HOOK	2-20
D3C21067	SPRING:HOOK	2-23
D3C21068	GUARD:HANDLE	2-26
D3C21069	SPRING:MID:IDLE:M	2-19
D3C21070	FLAPPER:HANDLE	2-27
D3C21071	GUIDE:CASSETTE	2-15
D3C21072	GEAR:Z15S:JOINT	2-6
D3C21073	PULLEY:MID:IDLE	2-16
D3C21074	PLATE:BOTTOM	2-11
D3C21075	SHEET:CASSETTE	2-25
D3C21079	COVER:LIFT GEAR	2-7
D3C21080	GUIDE:RETARD B	2-3
D3C21081	LABEL:DIAL:PF	2-29
D3C21089	COVER:TOP	1-12
D3C21090	ACTUATOR:FEED	1-10
D3C21091	ROLLER:MIDDLE:ASS'Y	1-13
D3C21092	ACTUATOR:PE	1-11
D3C21094	PCB:PF:MAIN:ASS'Y	1-5
D3C21095	SPRING:PICKUP	1-14
D3C21121	GEAR:Z58L	1-6
D3C21122	GEAR:Z36R Z20	1-7
D3C21123	DC MOTOR:ASS'Y:SP	1-9
D3C27501	SPRING ACTUATOR FEED	1-23
D3C27502	SHAFT FEED R	1-24
D3G71076	BASE_CASSETTE	2-14
D3G71077	COVER_CASSETT	2-13
D3G71082	CASSETTE ASS'Y	2-A01
D3G71100	COVER REAR	1-2
D3G71102	FRAME TOP	1-18
D3G71251	HOUSING DRIVE	1-22

Part No.	Description	Section and Index No.
D3G71252	LID HOUSING DRIVE	1-21
M0CJ1670	PARTS_MOTOR-B	1-8
M2811053	FOOT	1-1
M2811091	CLUTCH 50 Z35R SP	1-17
M2811131	JOINT_FEED	1-19
M2811132	SHAFT_FEED_CL	1-20
M2812520	RETARD ROLLER	2-1
M2812523	GEAR:Z48S:LIFT	2-5
M2812524	SPRING:RETARD B	2-4
M2812532	CURSOR:END:ASS'Y	2-30
M2812536	HOLDER:RETARD B	2-2
M2812537	GEAR:CASSETTE	2-8
M2812539	CURSOR:LEFT	2-10
M2812544	PAD_BOTTOM	2-12
M2812807	DIAL CASSETTE	2-28
M2812820	GEAR:FEED:Z26	1-15
M2812821	PULLEY:FEED:ASS'Y	1-3
M2812822	GEAR:FEED:Z30	1-16
M2812824	PULLEY:PICK-UP:ASS'Y	1-4
M2812841	SENSOR:OPT SP	1-26
M2812860	SW.PUSH	1-25
M2822861	CURSOR_RIGHT	2-9