

Duplex Unit AD2000 (B806)

Duplex Unit AD2000 (B806)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Duplex Unit 1 (B806)	2
2.Duplex Unit 2 (B806)	4
3.Duplex Unit 3 (B806)	6
4.Duplex Unit 4 (B806)	8
5.Duplex Unit 5 (B806)	10
6.Duplex Unit 6 (B806)	12
PARTS INDEX.....	15

March ,06 ' 2006

1.Duplex Unit 1 (B806)




1.Duplex Unit 1 (B806)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA14 3575	Flat Screw:Knob Screw:M4x10	1
2	AA14 3675	Screw - M4x11	1
3	B806 6101	Coupling Bracket	1
4	B806 2560	Gear - 17Z	1
5	A184 4057	Bushing	1
6	B806 2562	Tension Spring	1
7	B806 2557	Reverse:Input Bracket	1
8	B806 2561	Gear - 22Z	1
9	AA08 2101	Bushing - 6x10x6	1
10	B806 2556	Timing Belt - 40S2M202	1
11	B806 2555	Pulley - 22T	1
12	B806 2554	Ground Plate - Transport Roller	1
13	G020 5626	Push Switch	1
14	B806 2553	Gate Bracket - Rear	1
15	B806 5392	Harness - Gate	1
16	B806 2570	DC Solenoid 24V	1
17	B806 2551	Transport Roller - Drive Reverse	1
18	B806 2552	Transport Roller - Drive	1
19	B806 2550	Reverse Frame	1
20	B806 1309	Screw - M3X8	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	1
102	0313 0040N	Screw:M3x4	1
103	0720 0030E	Retaining Ring - M3	1
104	0720 0040E	Retaining Ring - M4	1
105	1105 0511	Harness Clamp - LWS-0306ZC	1

2.Duplex Unit 2 (B806)




2.Duplex Unit 2 (B806)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B806 4600	Duplex Tray Unit	1
2	AA08 2101	Bushing - 6x10x6	1
3	B806 4642	Decal - Operate Left Upper	1
4	B806 4621	Guide Plate - Left Upper	1
5	B806 4617	Ground Plate - Left Upper	1
6	G552 7217	Pulley - 18Z	1
7	B806 1305	Timing Belt - 40S2M216	1
8	B806 1268	Transport Roller	1
9	B806 4612	Transport Roller	1
10	B806 4626	Guide Plate - Right Upper	1
11	B806 4632	Transport Feeler Spring	1
12	B806 4635	Tray:Guide Feeler - Right Upper	1
13	B806 4627	Ground Plate - Right Upper	1
14	B039 3064	Bushing - 6x8x9.5	1
15	B806 4643	Decal - Operate Right Upper	1
16	AA08 2075	Bushing - M6	1
17	B806 4614	Screw - M3X8	1
18	B806 4606	Ground Plate - Drive Roller	1
19	B044 2756	Spring - Paper Feed Roller	1
20	B806 4609	Joint:Drive	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	1
102	0622 0120	Pin - 2x12	1

3.Duplex Unit 3 (B806)




3.Duplex Unit 3 (B806)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B806 1261	Driven Roller - Dia12	1
2	B806 4604	Detent	1
3	B806 4616	Guide Plate - Left Lower	1
4	B806 4614	Screw - M3x8	1
5	B806 4633	Guide Plate Joint	1
6	B806 4613	Guide Plate - Right Lower	1
7	B806 4605	Input Transport Roller	1
8	AA08 2101	Bushing - 6x10x6	1
9	B806 4603	Ground Plate	1
10	G552 7217	Pulley - 18Z	1
11	B806 1305	Timing Belt - 40S2M216	1
12	B044 2756	Spring - Paper Feed Roller	1
13	B806 4609	Joint:Drive	1
14	B806 4608	Feeler Spring	1
15	B806 4607	Reverse Feeler	1
16	B806 4637	Guide - Front	1
17	B806 4638	Guide - Rear	1
18	B806 1308	Spacer	1
19	B806 4648	Decal - Operation Instructions	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	1
102	0622 0120	Pin - 2x12	1

4. Duplex Unit 4 (B806)




4.Duplex Unit 4 (B806)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2101	Bushing - 6x10x6	1
2	B806 1161	Joint Bracket	1
3	B806 1301	Timing Pulley - 18T	1
4	B806 1305	Timing Belt - 40S2M216	1
5	B806 1159	Transport Joint Shaft	1
6	B806 5314	Harness - Interface Cable	1
7	B806 5100	PCB Main	1
8	B806 1186	PCB Bracket	1
9	B806 1304	Timing Belt - 40S2M160	1
10	B806 5316	Harness - Motor	1
11	B806 5530	Stepper Motor DC3.2V	1
12	B806 1166	Transport Motor Bracket	1
13	B806 1168	Timing Pulley - 44T	1
14	B806 1167	Shaft - Idler Transport	1
15	B806 1302	Timing Pulley - 18T	1
16	B806 1181	Ground Plate - Safety	1
17	B806 1196	Ground Plate - Duplex Tray	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	1
102	1105 0192	Locking Support	1
103	0360 3006N	Screw - M3X6	1
104	0454 3006Q	Tapping Screw - M3x6	1
105	1105 0522	Edge Saddle - Les0510	1
106	1105 0511	Harness Clamp - LWS-0306ZC	1
107	1105 0487	Harness Clamp	1
108	1105 0516	Clamp	1

5.Duplex Unit 5 (B806)




5.Duplex Unit 5 (B806)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B806 1304	Timing Belt - 40S2M160	1
2	B806 1302	Timing Pulley - 18T	1
3	B806 1193	Guard Drive Bracket	1
4	B806 5530	Stepper Motor DC3.2V	1
5	B806 1171	Joint Bracket	1
6	B806 1168	Timing Pulley - 44T	1
7	B806 1180	Gear - 32Z	1
8	B806 1185	Gear - 31Z	1
9	AA08 2101	Bushing - 6x10x6	1
10	B806 1177	Feed Paper Bracket	1
11	B806 1184	Idler Shaft	1
12	B806 1176	Shaft - Idler	1
13	B806 1301	Timing Pulley - 18T	1
14	B806 5510	Magnetic Clutch 0.5n.m - 32z	1
15	AW02 0141	Photointerruptor	1
16	B806 1137	BRACKET:STAY:REAR LOWER	
17	B806 5312	Harness - Reverse Sensor	1
18	C410 7540	Paper Tray Holder	1
19	B806 5310	Harness - Set Sensor	1
20	AW50 0023	Push Switch	1
21	B806 1303	Timing Belt - 40S2M130	1
22	B806 1169	Joint Shaft	1
23	B806 5316	Harness - Motor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	1
102	0360 3006N	Screw - M3X6	1
103	0720 0040E	Retaining Ring - M4	1
104	1105 0511	Harness Clamp - LWS-0306ZC	1

6.Duplex Unit 6 (B806)



6.Duplex Unit 6 (B806)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AG07 0514	Magnet Catch	1
2	B806 1261	Driven Roller - Dia12	1
3	B806 1117	Detent - Left	1
4	B806 1116	Guide Plate - Left	1
5	B806 1309	Screw - M3X8	1
6	AA08 2101	Bushing - 6x10x6	1
7	B806 1107	Entrance Transport Roller	1
8	B806 1192	Tray Stopper	1
9	AW02 0141	Photointerruptor	1
10	B806 5311	Harness - Sensor	1
11	B806 1108	Entrance Feeler	1
12	B806 1109	Entrance Feeler Spring	1
13	G020 5626	Push Switch	1
14	B806 1301	Timing Pulley - 18T	1
15	B806 1271	Rail Bracket	1
16	B806 1258	Roller - Guide Plate Pressure	1
17	B806 1256	Case - Guide Plate Pressure	1
18	B806 1257	Spring - Guide Plate Pressure	1
19	B806 1112	Ground Plate - Entrance	1
20	B806 1127	Ground Plate - Exit	1
21	B806 1128	Ground Plate - Rail Right	1
22	B806 1124	Exit Transport Roller	1
23	B806 1122	Exit Feeler	1
24	B806 1123	Exit Feeler Spring	1
25	B806 1307	Timing Pulley - 18T	1
26	B806 1308	Spacer	1
27	B806 1125	Guide - Right Lower	1
28	B806 1126	Guide Roller	1
29	B806 1131	Guide Plate:Vertical Transport:Right	1
30	AH01 0009	Rubber Pad - H5	1
31	B390 1759	Shaft:Scale	1
32	B806 4631	Cover - Rear	1
33	B806 5313	Harness - Sensor	1
34	B806 1262	Detent	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	1
102	0450 3010N	Tapping Screw - M3x10	1
103	0454 3006Q	Tapping Screw - M3x6	1
104	0720 0040E	Retaining Ring - M4	1
105	0741 3706	Ball Bearing - 6x10x3	1

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B806 1107	Entrance Transport Roller	13 - 7
B806 1108	Entrance Feeler	13 - 11
B806 1109	Entrance Feeler Spring	13 - 12
B806 1112	Ground Plate - Entrance	13 - 19
B806 1116	Guide Plate - Left	13 - 4
B806 1117	Detent - Left	13 - 3
B806 1122	Exit Feeler	13 - 23
B806 1123	Exit Feeler Spring	13 - 24
B806 1124	Exit Transport Roller	13 - 22
B806 1125	Guide - Right Lower	13 - 27
B806 1126	Guide Roller	13 - 28
B806 1127	Ground Plate - Exit	13 - 20
B806 1128	Ground Plate - Rail Right	13 - 21
B806 1131	Guide Plate:Vertical Transport:Right	13 - 29
B806 1137	BRACKET:STAY:REAR LOWER	11 - 16
B806 1159	Transport Joint Shaft	9 - 5
B806 1161	Joint Bracket	9 - 2
B806 1166	Transport Motor Bracket	9 - 12
B806 1167	Shaft - Idler Transport	9 - 14
B806 1168	Timing Pulley - 44T	9 - 13
B806 1168	Timing Pulley - 44T	11 - 6
B806 1169	Joint Shaft	11 - 22
B806 1171	Joint Bracket	11 - 5
B806 1176	Shaft - Idler	11 - 12
B806 1177	Feed Paper Bracket	11 - 10
B806 1180	Gear - 32Z	11 - 7
B806 1181	Ground Plate - Safety	9 - 16
B806 1184	Idler Shaft	11 - 11
B806 1185	Gear - 31Z	11 - 8
B806 1186	PCB Bracket	9 - 8
B806 1192	Tray Stopper	13 - 8
B806 1193	Guard Drive Bracket	11 - 3
B806 1196	Ground Plate - Duplex Tray	9 - 17
B806 1256	Case - Guide Plate Pressure	13 - 17
B806 1257	Spring - Guide Plate Pressure	13 - 18

Part No.	Description	Page and Index No.
B806 1258	Roller - Guide Plate Pressure	13 - 16
B806 1261	Driven Roller - Dia12	7 - 1
B806 1261	Driven Roller - Dia12	13 - 2
B806 1262	Detent	13 - 34
B806 1268	Transport Roller	5 - 8
B806 1271	Rail Bracket	13 - 15
B806 1301	Timing Pulley - 18T	9 - 3
B806 1301	Timing Pulley - 18T	13 - 14
B806 1301	Timing Pulley - 18T	11 - 13
B806 1302	Timing Pulley - 18T	11 - 2
B806 1302	Timing Pulley - 18T	9 - 15
B806 1303	Timing Belt - 40S2M130	11 - 21
B806 1304	Timing Belt - 40S2M160	11 - 1
B806 1304	Timing Belt - 40S2M160	9 - 9
B806 1305	Timing Belt - 40S2M216	9 - 4
B806 1305	Timing Belt - 40S2M216	5 - 7
B806 1305	Timing Belt - 40S2M216	7 - 11
B806 1307	Timing Pulley - 18T	13 - 25
B806 1308	Spacer	13 - 26
B806 1308	Spacer	7 - 18
B806 1309	Screw - M3X8	13 - 5
B806 1309	Screw - M3X8	3 - 20
B806 2550	Reverse Frame	3 - 19
B806 2551	Transport Roller - Drive Reverse	3 - 17
B806 2552	Transport Roller - Drive	3 - 18
B806 2553	Gate Bracket - Rear	3 - 14
B806 2554	Ground Plate - Transport Roller	3 - 12
B806 2555	Pulley - 22T	3 - 11
B806 2556	Timing Belt - 40S2M202	3 - 10
B806 2557	Reverse:Input Bracket	3 - 7
B806 2560	Gear - 17Z	3 - 4
B806 2561	Gear - 22Z	3 - 8
B806 2562	Tension Spring	3 - 6
B806 2570	DC Solenoid 24V	3 - 16
B806 4600	Duplex Tray Unit	5 - 1

Part No.	Description	Page and Index No.
B806 4603	Ground Plate	7 - 9
B806 4604	Detent	7 - 2
B806 4605	Input Transport Roller	7 - 7
B806 4606	Ground Plate - Drive Roller	5 - 18
B806 4607	Reverse Feeler	7 - 15
B806 4608	Feeler Spring	7 - 14
B806 4609	Joint:Drive	5 - 20
B806 4609	Joint:Drive	7 - 13
B806 4612	Transport Roller	5 - 9
B806 4613	Guide Plate - Right Lower	7 - 6
B806 4614	Screw - M3X8	5 - 17
B806 4614	Screw - M3x8	7 - 4
B806 4616	Guide Plate - Left Lower	7 - 3
B806 4617	Ground Plate - Left Upper	5 - 5
B806 4621	Guide Plate - Left Upper	5 - 4
B806 4626	Guide Plate - Right Upper	5 - 10
B806 4627	Ground Plate - Right Upper	5 - 13
B806 4631	Cover - Rear	13 - 32
B806 4632	Transport Feeler Spring	5 - 11
B806 4633	Guide Plate Joint	7 - 5
B806 4635	Tray:Guide Feeler - Right Upper	5 - 12
B806 4637	Guide - Front	7 - 16
B806 4638	Guide - Rear	7 - 17
B806 4642	Decal - Operate Left Upper	5 - 3
B806 4643	Decal - Operate Right Upper	5 - 15
B806 4648	Decal - Operation Instructions	7 - 19
B806 5100	PCB Main	9 - 7
B806 5310	Harness - Set Sensor	11 - 19
B806 5311	Harness - Sensor	13 - 10
B806 5312	Harness - Reverse Sensor	11 - 17
B806 5313	Harness - Sensor	13 - 33
B806 5314	Harness - Interface Cable	9 - 6
B806 5316	Harness - Motor	11 - 23
B806 5316	Harness - Motor	9 - 10
B806 5392	Harness - Gate	3 - 15

Part No.	Description	Page and Index No.
B806 5510	Magnetic Clutch 0.5n.m - 32z	11 - 14
B806 5530	Stepper Motor DC3.2V	11 - 4
B806 5530	Stepper Motor DC3.2V	9 - 11
B806 6101	Coupling Bracket	3 - 3

Part No.	Description	Page and Index No.
A184 4057	Bushing	3 - 5
B039 3064	Bushing - 6x8x9.5	5 - 14
B044 2756	Spring - Paper Feed Roller	5 - 19
B044 2756	Spring - Paper Feed Roller	7 - 12
B390 1759	Shaft:Scale	13 - 31
C410 7540	Paper Tray Holder	11 - 18
G020 5626	Push Switch	3 - 13
G020 5626	Push Switch	13 - 13
G552 7217	Pulley - 18Z	5 - 6
G552 7217	Pulley - 18Z	7 - 10

Part No.	Description	Page and Index No.
AA08 2075	Bushing - M6	5 - 16
AA08 2101	Bushing - 6x10x6	11 - 9
AA08 2101	Bushing - 6x10x6	13 - 6
AA08 2101	Bushing - 6x10x6	3 - 9
AA08 2101	Bushing - 6x10x6	5 - 2
AA08 2101	Bushing - 6x10x6	7 - 8
AA08 2101	Bushing - 6x10x6	9 - 1
AA14 3575	Flat Screw:Knob Screw:M4x10	3 - 1
AA14 3675	Screw - M4x11	3 - 2
AG07 0514	Magnet Catch	13 - 1
AH01 0009	Rubber Pad - H5	13 - 30
AW02 0141	Photointerruptor	11 - 15
AW02 0141	Photointerruptor	13 - 9
AW50 0023	Push Switch	11 - 20

Part No.	Description	Page and Index No.
0313 0040N	Screw:M3x4	3 - 102
0360 3006N	Screw - M3X6	9 - 103
0360 3006N	Screw - M3X6	11 - 102
0450 3008N	Tapping Screw - M3x8	3 - 101
0450 3010N	Tapping Screw - M3x10	13 - 102
0451 3008N	Tapping Screw - M3x8	13 - 101
0454 3006Q	Tapping Screw - M3x6	13 - 103
0454 3006Q	Tapping Screw - M3x6	11 - 101
0454 3006Q	Tapping Screw - M3x6	9 - 104
0622 0120	Pin - 2x12	5 - 102
0622 0120	Pin - 2x12	7 - 102
0720 0030E	Retaining Ring - M3	3 - 103
0720 0040E	Retaining Ring - M4	13 - 104
0720 0040E	Retaining Ring - M4	3 - 104
0720 0040E	Retaining Ring - M4	11 - 103
0720 0040E	Retaining Ring - M4	5 - 101
0720 0040E	Retaining Ring - M4	9 - 101
0720 0040E	Retaining Ring - M4	7 - 101

Part No.	Description	Page and Index No.
0741 3706	Ball Bearing - 6x10x3	13 - 105
1105 0192	Locking Support	9 - 102
1105 0487	Harness Clamp	9 - 107
1105 0511	Harness Clamp - LWS-0306ZC	9 - 106
1105 0511	Harness Clamp - LWS-0306ZC	11 - 104
1105 0511	Harness Clamp - LWS-0306ZC	3 - 105
1105 0516	Clamp	9 - 108
1105 0522	Edge Saddle - Les0510	9 - 105