

ADF Handle Type A (B862)

ADF Handle Type A (B862)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.ADF Handle Type A (B862)	2
Parts Index	6

June ,13 ' 2008

1.ADF Handle Type A (B862)



1.ADF Handle Type A (B862)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B862 1186	Bracket:Fix:Grip	1
2	B862 1181	Bracket:Stud:Contact Point:Grip:Ass'y	1
3	B862 1100	Handle:Ass'y	1
4	B862 6012	Decal:Contact Point	1
5	B862 6013	Decal:Handle:Operate	1
6	B862 8551	User's Manual:Handle:B862-17	1
7	B862 1211	Bracket:Handle:Rise	1
8	B862 1300	Holder:Ass'y	1
9	B862 1241	Stopper:Hinge:Left	1
10	B862 1242	Stopper:Hinge:Right	1
11	5053 0447	Bushing - 6MM	1
12	AA13 2208	Spacer - M6	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 3008N	Screw:M3x8	
102	0452 3012N	Binding Self-Tapping Screw:M3x12	
103	0452 3020N	Tapping Screw - 3x20	
104	0450 3012N	Tapping Screw:3x12	
105	0451 4008N	Tapping Screw:4x8	
106	0741 3906	Bushing - M6	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B862 1100	Handle:Ass'y	3 - 3
B862 1181	Bracket:Stud:Contact Point:Grip:Ass'y	3 - 2
B862 1186	Bracket:Fix:Grip	3 - 1
B862 1211	Bracket:Handle:Rise	3 - 7
B862 1241	Stopper:Hinge:Left	3 - 9
B862 1242	Stopper:Hinge:Right	3 - 10
B862 1300	Holder:Ass'y	3 - 8
B862 6012	Decal:Contact Point	3 - 4
B862 6013	Decal:Handle:Operate	3 - 5
B862 8551	User's Manual:Handle:B862-17	3 - 6

Part No.	Description	Page and Index No.
AA13 2208	Spacer - M6	3 - 12

Part No.	Description	Page and Index No.
0360 3008N	Screw:M3x8	3 - 101
0450 3012N	Tapping Screw:3x12	3 - 104
0451 4008N	Tapping Screw:4x8	3 - 105
0452 3012N	Binding Self-Tapping Screw:M3x12	3 - 102
0452 3020N	Tapping Screw - 3x20	3 - 103
0741 3906	Bushing - M6	3 - 106

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6MM	3 - 11