

**Fuser Unit Air Separator
Type C901 (M390)
Machine Code: M390

Field Service Manual**

17 September, 2010

TABLE OF CONTENTS

1. Replacement and Adjustment

Components.....	3
Air Separator Cover.....	3
CCB (Compressor Control Board)	3
Compressor Fans.....	4
Air Compressor Unit.....	5




1. Replacement and Adjustment

Components

1

Air Separator Cover




m390r507

1. Air separator cover [A] ( x 2)

CCB (Compressor Control Board)

1. Air separator cover ( p.3)




m390r105

2. CCB [A] ( x 2,  x 2)


Compressor Fans

1. Air separator cover (p.3)



m390r501

2. Compressor fan unit [A] ( x 4,  x 3,  x 2)



m390r101


3. Compressor fans [A] ( x 2,  x 1,  x 1 each)

↓ Note

- When reinstalling the compressor fans, install them with their decals facing upward.

Air Compressor Unit

1. Remove the air separator unit.
 - For details, see the installation procedure for "Fuser Unit Air Separator Type C901 (M390)" in the Field Service Manual of the Model Pro-C901S/ Pro C901.
2. Compressor fan unit (p.4 "Compressor Fans")



3. Remove the air tubes [A] from the compressor unit.
4. Two ground cables [A] (1 x 1 each)
5. Compressor unit [B] (1 x 4 each)

MEMO

MEMO

MEMO