# 1 Bin Tray BN1000 Machine Code: M370

**Field Service Manual** 

# **TABLE OF CONTENTS**

### 1. Replacement and Adjustment


Electrical Components	(
Paper Sensor	
·	
1-Bin Tray Exit Sensor	(
LED Board	4
INDEX	

# 1. Replacement and Adjustment

## **Electrical Components**


#### Paper Sensor

1. 1-Bin tray unit



m370r501

2. Paper sensor bracket [A] ( \*\* x 1)



m370r50


## 1-Bin Tray Exit Sensor

- 1. 1-Bin tray unit
- 2. Paper sensor bracket ( p.3 "Paper Sensor")



m370r503

3. 1-Bin Tray Exit Sensor bracket [A] ( 🗗 x 3)




m370r504


4. 1-Bin Tray Exit Sensor [A] (🔎 x 1, hooks)

### **LED Board**

1. 1-Bin tray unit



2. 1-bin tray bottom cover [A] ( $\nearrow$  x 3)



3. LED board [A] (🚅 x 1)

ī