

1 Bin Tray BN3000 (B790)

## **1 Bin Tray BN3000 (B790)**


### **PARTS CATALOG**

This catalog gives the numbers and names of parts on this machine.

|                          |          |
|--------------------------|----------|
| 1.1 BIN TRAY (B790)..... | 2        |
| <b>PARTS INDEX.....</b>  | <b>5</b> |

**April ,20 ' 2006**

1.1 BIN TRAY (B790)



## 1.1 BIN TRAY (B790)

| Index No. | Part No.  | Description                      | Q'ty Per Assembly |
|-----------|-----------|----------------------------------|-------------------|
| 1         | B790 6111 | Tray Support Bracket             | 1                 |
| 2         | B790 6113 | Cover - Tray Support Bracket     | 1                 |
| 3         | B803 6113 | Tray Support Stay                | 1                 |
| 4         | B803 6014 | End Fence - Exit Tray            | 1                 |
| 5         | B803 6011 | Tray - Exit Main                 | 1                 |
| 6         | B803 6013 | Tray - Exit LED                  | 1                 |
| 7         | B803 6012 | Tray - Exit Sub Swivel           | 1                 |
| 8         | C408 6691 | Shield                           | 1                 |
| 9         | B803 1117 | Rear Feeler                      | 1                 |
| 10        | B803 1116 | Front Feeler                     | 1                 |
| 11        | B803 1112 | Ground Plate - Exit              | 1                 |
| 12        | B790 1111 | Upper Frame                      | 1                 |
| 13        | AA12 0131 | Discharge Brush - Exit           | 1                 |
| 14        | AA04 3853 | Timing Belt - 40S3M162           | 1                 |
| 15        | A898 1231 | Pulley - 15Z                     | 1                 |
| 16        | AB01 7812 | Timing Pulley - 28Z/15T          | 1                 |
| 17        | B790 1411 | Drive Cover                      | 1                 |
| 18        | AF04 0056 | Exit Roller                      | 1                 |
| 19        | B803 1122 | Entrance Roller                  | 4                 |
| 20        | B790 1121 | Lower Frame                      | 1                 |
| 21        | AW01 0137 | Paper Feed Sensor                | 1                 |
| 22        | B790 1211 | Exit Roller                      | 1                 |
| 23        | AA08 0287 | Bushing - Dia4                   | 2                 |
| 24        | AA06 3192 | Compression Spring - Exit Roller | 2                 |
| 25        | B790 5500 | PCB Main Control                 | 1                 |
| 26        | B790 5705 | Harness - Interface Cable        | 1                 |
| 27        | AW01 0118 | Paper Feed Sensor                | 1                 |
| 28        | B790 1125 | Original Sensor Bracket          | 1                 |
| 29        | AA12 0132 | Discharge Brush                  | 1                 |
| 30        | B790 5700 | Harness - LED                    | 1                 |
| 31        | B790 1123 | LED Ground Plate                 | 1                 |
| 32        | B790 1124 | Ground Plate                     | 1                 |

| Index No. | Part No.   | Description           | Q'ty Per Assembly |
|-----------|------------|-----------------------|-------------------|
| 101       | 0360 3008N | Screw:M3x8            |                   |
| 102       | 0450 3008N | Tapping Screw - M3x8  |                   |
| 103       | 0451 3006N | Tapping Screw - 3x6   |                   |
| 104       | 0805 3480  | Bushing - 6mm         |                   |
| 105       | 0805 0089  | Retaining Ring - M4   |                   |
| 106       | 1105 0522  | Edge Saddle - Les0510 |                   |
| 107       | 0720 0040E | Retaining Ring - M4   |                   |

# Parts Index

## Parts Index

| Part No.  | Description                  | Page and Index No. |
|-----------|------------------------------|--------------------|
| B790 1111 | Upper Frame                  | 3 - 12             |
| B790 1121 | Lower Frame                  | 3 - 20             |
| B790 1123 | LED Ground Plate             | 3 - 31             |
| B790 1124 | Ground Plate                 | 3 - 32             |
| B790 1125 | Original Sensor Bracket      | 3 - 28             |
| B790 1211 | Exit Roller                  | 3 - 22             |
| B790 1411 | Drive Cover                  | 3 - 17             |
| B790 5500 | PCB Main Control             | 3 - 25             |
| B790 5700 | Harness - LED                | 3 - 30             |
| B790 5705 | Harness - Interface Cable    | 3 - 26             |
| B790 6111 | Tray Support Bracket         | 3 - 1              |
| B790 6113 | Cover - Tray Support Bracket | 3 - 2              |

| Part No.  | Description            | Page and Index No. |
|-----------|------------------------|--------------------|
| A898 1231 | Pulley - 15Z           | 3 - 15             |
| B803 1112 | Ground Plate - Exit    | 3 - 11             |
| B803 1116 | Front Feeler           | 3 - 10             |
| B803 1117 | Rear Feeler            | 3 - 9              |
| B803 1122 | Entrance Roller        | 3 - 19             |
| B803 6011 | Tray - Exit Main       | 3 - 5              |
| B803 6012 | Tray - Exit Sub Swivel | 3 - 7              |
| B803 6013 | Tray - Exit LED        | 3 - 6              |
| B803 6014 | End Fence - Exit Tray  | 3 - 4              |
| B803 6113 | Tray Support Stay      | 3 - 3              |
| C408 6691 | Shield                 | 3 - 8              |

| Part No.  | Description                      | Page and Index No. |
|-----------|----------------------------------|--------------------|
| AA04 3853 | Timing Belt - 40S3M162           | 3 - 14             |
| AA06 3192 | Compression Spring - Exit Roller | 3 - 24             |
| AA08 0287 | Bushing - Dia4                   | 3 - 23             |
| AA12 0131 | Discharge Brush - Exit           | 3 - 13             |
| AA12 0132 | Discharge Brush                  | 3 - 29             |
| AB01 7812 | Timing Pulley - 28Z/15T          | 3 - 16             |
| AF04 0056 | Exit Roller                      | 3 - 18             |
| AW01 0118 | Paper Feed Sensor                | 3 - 27             |
| AW01 0137 | Paper Feed Sensor                | 3 - 21             |

| Part No.   | Description           | Page and Index No. |
|------------|-----------------------|--------------------|
| 0360 3008N | Screw:M3x8            | 3 - 101            |
| 0450 3008N | Tapping Screw - M3x8  | 3 - 102            |
| 0451 3006N | Tapping Screw - 3x6   | 3 - 103            |
| 0720 0040E | Retaining Ring - M4   | 3 - 107            |
| 0805 0089  | Retaining Ring - M4   | 3 - 105            |
| 0805 3480  | Bushing - 6mm         | 3 - 104            |
| 1105 0522  | Edge Saddle - Les0510 | 3 - 106            |