

1 Bin Tray BN3040 (D389)


1 Bin Tray BN3040 (D389)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.1 Bin Tray (D389)	2
Parts Index	6

1.1Bin Tray (D389)



1.1 Bin Tray (D389)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D389 6111	Tray Support Bracket	1
2	D389 6112	Cover - Tray Support Bracket	1
3	D389 6113	Tray Support Shaft	1
4	B803 6014	End Fence - Exit Tray	1
5	B803 6011	Tray - Exit Main	1
6	B803 6013	Tray - Exit LED	1
7	B803 6012	Tray - Exit Sub Swivel	1
8	B803 1117	Rear Feeler	1
9	B803 1116	Front Feeler	1
10	B803 1111	Frame:Upper	1
11	B803 1112	Ground Plate - Exit	1
12	AA12 0131	Discharge Brush - Exit	1
13	C408 6691	Shield	2
14	D389 5300	DC Solenoid - Gate	1
15	AA06 0949	Tension Spring	1
16	B803 1133	Lever:DC Solenoid	1
17	B803 1130	Bracket:DC Solenoid	1
18	AA12 0132	Discharge Brush	1
19	B803 5500	PCB:Main Control	1
20	B803 5700	Harness:LED	1
21	B803 5705	Harness:Interface	1
22	AF04 0057	Exit Roller:Drive	1
23	B803 1122	Entrance Roller	4
24	B803 1121	Frame:Lower	1
25	AW01 0129	Photo Refiection Sensor	1
26	B803 1123	Cover:Original Sensor:Frame:Lower	1
27	B803 1211	Exit Roller:Driven	1
28	AA08 0287	Bushing - Dia4	2
29	AA06 3692	Compression Spring:2.7n	2
30	B803 1411	Cover:Drive	1
31	B803 1412	Cover:Drive:Mo:Baikal	1
32	AB01 7813	Timing Pulley:Z22/15T	2
33	AA13 2413	Flange:Timing Pulley:15T:S3m	2
34	AA04 3853	Timing Belt - 40S3M162	1
35	AB03 0814	Timing Pulley:15T	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0450 3016N	Tapping Screw:3x16	
103	0450 3010N	Tapping Screw - M3x10	
104	0353 0160N	Screw:M3x16	
105	0720 0040E	Retaining Ring - M4	
106	0805 0089	Retaining Ring - M4	
107	0805 3480	Bushing - 6mm	
108	0353 0030N	Screw:M3X3	
109	1105 0522	Edge Saddle - LES0510	
110	0450 3008N	Tapping Screw - M3x8	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D389 5300	DC Solenoid - Gate	3 - 14
D389 6111	Tray Support Bracket	3 - 1
D389 6112	Cover - Tray Support Bracket	3 - 2
D389 6113	Tray Support Shaft	3 - 3

Part No.	Description	Page and Index No.
B803 1111	Frame:Upper	3 - 10
B803 1112	Ground Plate - Exit	3 - 11
B803 1116	Front Feeler	3 - 9
B803 1117	Rear Feeler	3 - 8
B803 1121	Frame:Lower	3 - 24
B803 1122	Entrance Roller	3 - 23
B803 1123	Cover:Original Sensor:Frame:Lower	3 - 26
B803 1130	Bracket:DC Solenoid	3 - 17
B803 1133	Lever:DC Solenoid	3 - 16
B803 1211	Exit Roller:Driven	3 - 27
B803 1411	Cover:Drive	3 - 30
B803 1412	Cover:Drive:Mo:Baikal	3 - 31
B803 5500	PCB:Main Control	3 - 19
B803 5700	Harness:LED	3 - 20
B803 5705	Harness:Interface	3 - 21
B803 6011	Tray - Exit Main	3 - 5
B803 6012	Tray - Exit Sub Swivel	3 - 7
B803 6013	Tray - Exit LED	3 - 6
B803 6014	End Fence - Exit Tray	3 - 4
C408 6691	Shield	3 - 13

Part No.	Description	Page and Index No.
AA04 3853	Timing Belt - 40S3M162	3 - 34
AA06 0949	Tension Spring	3 - 15
AA06 3692	Compression Spring:2.7n	3 - 29
AA08 0287	Bushing - Dia4	3 - 28
AA12 0131	Discharge Brush - Exit	3 - 12
AA12 0132	Discharge Brush	3 - 18
AA13 2413	Flange:Timing Pulley:15T:S3m	3 - 33
AB01 7813	Timing Pulley:Z22/15T	3 - 32
AB03 0814	Timing Pulley:15T	3 - 35
AF04 0057	Exit Roller:Drive	3 - 22
AW01 0129	Photo Refiection Sensor	3 - 25

Part No.	Description	Page and Index No.
0353 0030N	Screw:M3X3	3 - 108
0353 0160N	Screw:M3x16	3 - 104
0450 3008N	Tapping Screw - M3x8	3 - 101
0450 3008N	Tapping Screw - M3x8	3 - 110
0450 3010N	Tapping Screw - M3x10	3 - 103
0450 3016N	Tapping Screw:3x16	3 - 102
0720 0040E	Retaining Ring - M4	3 - 105
0805 0089	Retaining Ring - M4	3 - 106
0805 3480	Bushing - 6mm	3 - 107
1105 0522	Edge Saddle - LES0510	3 - 109