

1 Bin Tray BN3090
Machine Code: D582
Field Service Manual

July, 2011
Subject to change

Safety and Symbols

Replacement Procedure Safety

CAUTION

- Turn off the main power switch and unplug the machine before beginning any of the replacement procedures in this manual.

Symbols Used in this Manual

This manual uses the following symbols.

 : See or Refer to

 : Screws

 : Connector

 : Clip ring

 : E-ring

TABLE OF CONTENTS


Safety and Symbols.....	1
Replacement Procedure Safety.....	1
Symbols Used in this Manual.....	1
1. Replacement and Adjustment	
Electrical Components.....	3
Paper Sensor.....	3
Transport Sensor.....	5
1-Bin Control Board.....	6
INDEX	7

1. Replacement and Adjustment

Electrical Components


1

Paper Sensor




d582r100

1. Open the right door [A] of the machine.
2. Remove the front right cover [B] ( x 1).




d582r101

3. Remove the support bar cover [A] ( x 1).




d582r102

4. Remove the 1-bin-tray [A] ( x 1,  x 1).





d582r103

5. Remove the fusing fan with bracket [A] ( x 2).



d582r104

6. 1-bin sorter unit [A] ( x 1,  x 2).




d582r105

7. Paper sensor [A] ( x 1, hook).

Transport Sensor

1. Remove the 1-bin tray ( p.3 "Paper Sensor")
2. Remove the 1-bin sorter unit ( p.3 "Paper Sensor")




d582r106

3. Transport Sensor [A] ( x 1, hook).

1-Bin Control Board

1. Remove the 1-bin tray ( p.3 "Paper Sensor")
2. Remove the 1-bin sorter unit ( p.3 "Paper Sensor")



d582r107

3. 1-bin control board [A] ( x 1,  x 1).

INDEX

1-Bin Control Board.....	6
--------------------------	---

E

Electrical Components.....	3
----------------------------	---

P

Paper Sensor.....	3
-------------------	---

R

Replacement Procedure Safety.....	1
-----------------------------------	---

S

Safety and Symbols.....	1
Symbols Used in this Manual.....	1

T

Transport Sensor.....	5
-----------------------	---

MEMO