

Copy Tray Type 1075
(B476)

Copy Tray Type 1075 (B476)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.COPY TRAY TYPE 1075 (B476)	2
PARTS INDEX	5

June ,10 ' 2002

1.COPY TRAY TYPE 1075 (B476)



1.COPY TRAY TYPE 1075 (B476)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF04 3106	Copy Tray - Exit	1
2	AF04 3107	Guide - Copy Tray	1
3	A379 1225	Upper Sensor Actuator	1
4	A353 3172	Actuator Bracket	1
5	A229 4489	Sensor Bracket	1
6	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
7	B065 1299	Cap - 22mm	4
8	B065 1344	G4 Cap	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4008B	Philips Tapping Screw - M4x8	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
A229 4489	Sensor Bracket	3 - 5
A353 3172	Actuator Bracket	3 - 4
A379 1225	Upper Sensor Actuator	3 - 3
B065 1299	Cap - 22mm	3 - 7
B065 1344	G4 Cap	3 - 8

Part No.	Description	Page and Index No.
AF04 3106	Copy Tray - Exit	3 - 1
AF04 3107	Guide - Copy Tray	3 - 2
AW02 0056	Photointerruptor - EE-SX4235A-P1	3 - 6

