

Mail Box CS4000
(D616)

Mail Box CS4000 (D616)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior (D616).....	2
2.Paper Exit 1 (D616).....	4
3.Paper Exit 2 (D616).....	6
4.Paper Exit 3 (D616).....	8
Parts Index	12

April 12, 2012

1.Exterior (D616)




1.Exterior (D616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D616 1611	Cover:Rear	1
2	D616 2281	Cover:Surface of Paper Sensor:Gray	1
2	G566 2281	Cover - Paper Sensor (Tray 8)	1
3	D616 1711	Cover:Upper	1
4	5447 2681	Snap Ring	1
5	B471 2331	Stopper	1
6	AG07 0514	Magnet Catch	2
7	D616 2321	Cover:Open and Close:Lower	1
8	B471 2324	Front Guide	1
9	B471 2323	Rear Guide	1
10	D616 1511	Cover:Front	1
11	D616 7851	Decal:Misfeed Removal	1
12	D616 7810	Decal:Bin Display	1
13	B471 6214	Front Side Plate	1
14	B471 6212	Left Guide Plate	1
15	B471 6216	Guide Plate:Coupling:Right	1
16	B471 6222	Exchange Pawl	1
17	A548 1317	Lever Cushion	1
18	B471 6215	Tension Spring	1
19	B471 6213	Inner Side Plate	1
20	D616 6111	Tray	9
21	D616 2322	Cover:Open and Close:Upper	1
22	A458 2251	Cushion - Bin Solenoid Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0450 3008N	Tapping Screw - M3x8	
103	0451 3006N	Tapping Screw - 3x6	
104	0805 0089	Retaining Ring - M4	
105	1607 2472	Ferrite Core:GTFC-16-8-16	

2.Paper Exit 1 (D616)




2.Paper Exit 1 (D616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G518 2262	Actuator - Paper Sensor	5
2	AW02 0156	Photointerruptor:EE-SX4235A-P2	11
3	G518 1236	Cushion - 0.5mm	1
4	B471 1131	Upper Stay	1
5	B471 1135	Sheet - Cover	1
6	B762 2611	Discharge Brush:L=346:12.5mm	6
7	G518 1237	Sheet - Shielding Plate	1
8	B762 3337	Compression Spring:Driven	20
9	B352 2205	Bushing - Driven Roller	10
10	AF02 2097	Driven Roller	5
11	G518 2291	Cushion - Guide Plate	10
12	G518 2212	Guide Plate	5
13	D616 5460	Harness:3Bin:Surface of Paper Sensor: Connecting	4
14	AW01 0124	Photo Reflection Sensor:GP2A200LCS0F	5
15	G835 0801	Tension Spring:Transport:Feeler:0.07N	5
16	G518 2272	Transport Actuator	5
17	G312 2114	Driven Roller - 23mm	5
18	AA08 0232	Bushing - M4	10
19	D616 5440	Harness:1Bin:Surface of Paper Sensor: Connecting	1
20	B762 1125	Cushion:Cover:Rear	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	0454 3006Q	Tapping Screw - M3x6	
104	1105 0326	Locking Support	
105	1105 0328	Harness Clamp - ES-0505	

3.Paper Exit 2 (D616)




3.Paper Exit 2 (D616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G518 2262	Actuator - Paper Sensor	4
2	G518 2291	Cushion - Guide Plate	8
3	G518 2212	Guide Plate	4
4	AW02 0156	Photointerruptor:EE-SX4235A-P2	8
5	AW01 0124	Photo Reflection Sensor:GP2A200LCS0F	4
6	D616 5450	Harness:2Bin:Surface of Paper Sensor: Connecting	4
7	B762 2611	Discharge Brush:L=346:12.5mm	4
8	G312 2114	Driven Roller - 23mm	4
9	AA08 0232	Bushing - M4	8
10	B762 3337	Compression Spring:Driven	8
11	C685 2710	DC Solenoid:Exit	7
12	D616 5425	Harness:Solenoid	1
13	D616 5405	Harness:Sensor:Upper	1
14	B471 5511	Bracket - Main Control Board	1
15	D616 5415	Harness:Sensor:Lower	1
16	D616 5550	Harness:Interface	1
17	D616 5211	PCB:Main Control	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	0313 0030N	Pan Head Screw:M3x3	
104	1105 0326	Locking Support	
105	1105 0328	Harness Clamp - ES-0505	
106	0454 3006Q	Tapping Screw - M3x6	
107	1905 0045	UVEPROM:512K:X8:100NS	

4.Paper Exit 3 (D616)



4.Paper Exit 3 (D616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 4152	Stepper Motor:Transport:Ass'y	1
2	B471 2511	Stepper Motor Bracket	1
3	AB03 0639	Timing Pulley - T26 S2M	5
4	5053 0447	Bushing - 6mm	35
5	B471 2115	Timing Pulley - 28TS2M	8
6	AA06 0802	Tension Spring	8
7	AF02 0477	Transport Roller	8
8	A548 1317	Lever Cushion	8
9	G566 2411	Polarization Powl:Exit	8
10	5447 2681	Snap Ring	14
11	B471 1155	Middle Stay	1
12	AF02 0478	Exit Roller	9
13	B471 1145	Lower Guide Stay	1
14	B471 1141	Lower Stay	1
15	B471 1165	Front Bracket	1
16	B471 1162	Rear Guide Bracket	1
17	B471 1161	Rear Bracket	1
18	B471 1111	Front Side Plate	1
19	B471 1120	Rear Side Plate	1
20	B471 2811	Powl Lever	1
21	B471 2531	Timing Belt	1
22	AA04 3531	Timing Belt - B40S2M144	1
23	A548 2139	Pulley	4
24	B471 2256	Tension Spring - 4.2N	1
25	B312 1615	Tension Roller	4
26	AA14 3790	Screw:Contact Point	1
27	B471 2160	Tightener Bracket	1
28	AB03 0699	Timing Pulley - T57 T28 S2M	1
29	B762 2515	Heat Sink:Drive	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0454 3006Q	Tapping Screw - M3x6	
103	0805 0089	Retaining Ring - M4	
104	0951 4006P	Screw:Polished Round:M4x6	
105	1105 0487	Harness Clamp	
106	1105 0328	Harness Clamp - ES-0505	
107	0451 3008N	Tapping Screw - M3x8	
108	0313 0050N	Philips Pan Head Screw - M3x5	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D616 1511	Cover:Front	3 - 10
D616 1611	Cover:Rear	3 - 1
D616 1711	Cover:Upper	3 - 3
D616 2281	Cover:Surface of Paper Sensor:Gray	3 - 2
D616 2321	Cover:Open and Close:Lower	3 - 7
D616 2322	Cover:Open and Close:Upper	3 - 21
D616 5211	PCB:Main Control	7 - 17
D616 5405	Harness:Sensor:Upper	7 - 13
D616 5415	Harness:Sensor:Lower	7 - 15
D616 5425	Harness:Solenoid	7 - 12
D616 5440	Harness:1Bin:Surface of Paper Sensor:Connecting	5 - 19
D616 5450	Harness:2Bin:Surface of Paper Sensor:Connecting	7 - 6
D616 5460	Harness:3Bin:Surface of Paper Sensor:Connecting	5 - 13
D616 5550	Harness:Interface	7 - 16
D616 6111	Tray	3 - 20
D616 7810	Decal:Bin Display	3 - 12
D616 7851	Decal:Misfeed Removal	3 - 11

Part No.	Description	Page and Index No.
A458 2251	Cushion - Bin Solenoid Lever	3 - 22
A548 1317	Lever Cushion	3 - 17
A548 1317	Lever Cushion	9 - 8
A548 2139	Pulley	9 - 23
B312 1615	Tension Roller	9 - 25
B352 2205	Bushing - Driven Roller	5 - 9
B386 4152	Stepper Motor:Transport:Ass'y	9 - 1
B471 1111	Front Side Plate	9 - 18
B471 1120	Rear Side Plate	9 - 19
B471 1131	Upper Stay	5 - 4
B471 1135	Sheet - Cover	5 - 5
B471 1141	Lower Stay	9 - 14
B471 1145	Lower Guide Stay	9 - 13
B471 1155	Middle Stay	9 - 11
B471 1161	Rear Bracket	9 - 17
B471 1162	Rear Guide Bracket	9 - 16
B471 1165	Front Bracket	9 - 15
B471 2115	Timing Pulley - 28TS2M	9 - 5
B471 2160	Tightener Bracket	9 - 27
B471 2256	Tension Spring - 4.2N	9 - 24
B471 2323	Rear Guide	3 - 9
B471 2324	Front Guide	3 - 8
B471 2331	Stopper	3 - 5
B471 2511	Stepper Motor Bracket	9 - 2
B471 2531	Timing Belt	9 - 21
B471 2811	Pawl Lever	9 - 20
B471 5511	Bracket - Main Control Board	7 - 14
B471 6212	Left Guide Plate	3 - 14
B471 6213	Inner Side Plate	3 - 19
B471 6214	Front Side Plate	3 - 13
B471 6215	Tension Spring	3 - 18
B471 6216	Guide Plate:Coupling:Right	3 - 15
B471 6222	Exchange Pawl	3 - 16
B762 1125	Cushion:Cover:Rear	5 - 20
B762 2515	Heat Sink:Drive	9 - 29

Part No.	Description	Page and Index No.
B762 2611	Discharge Brush:L=346:12.5mm	7 - 7
B762 2611	Discharge Brush:L=346:12.5mm	5 - 6
B762 3337	Compression Spring:Driven	7 - 10
B762 3337	Compression Spring:Driven	5 - 8
C685 2710	DC Solenoid:Exit	7 - 11
G312 2114	Driven Roller - 23mm	7 - 8
G312 2114	Driven Roller - 23mm	5 - 17
G518 1236	Cushion - 0.5mm	5 - 3
G518 1237	Sheet - Shielding Plate	5 - 7
G518 2212	Guide Plate	7 - 3
G518 2212	Guide Plate	5 - 12
G518 2262	Actuator - Paper Sensor	7 - 1
G518 2262	Actuator - Paper Sensor	5 - 1
G518 2272	Transport Actuator	5 - 16
G518 2291	Cushion - Guide Plate	7 - 2
G518 2291	Cushion - Guide Plate	5 - 11
G566 2281	Cover - Paper Sensor (Tray 8)	3 - 2
G566 2411	Polarization Powl:Exit	9 - 9
G835 0801	Tension Spring:Transport:Feeler:0.07N	5 - 15

Part No.	Description	Page and Index No.
AA04 3531	Timing Belt - B40S2M144	9 - 22
AA06 0802	Tension Spring	9 - 6
AA08 0232	Bushing - M4	7 - 9
AA08 0232	Bushing - M4	5 - 18
AA14 3790	Screw:Contact Point	9 - 26
AB03 0639	Timing Pulley - T26 S2M	9 - 3
AB03 0699	Timing Pulley - T57 T28 S2M	9 - 28
AF02 0477	Transport Roller	9 - 7
AF02 0478	Exit Roller	9 - 12
AF02 2097	Driven Roller	5 - 10
AG07 0514	Magnet Catch	3 - 6
AW01 0124	Photo Reflection Sensor:GP2A200LCS0F	7 - 5
AW01 0124	Photo Reflection Sensor:GP2A200LCS0F	5 - 14
AW02 0156	Photointerruptor:EE-SX4235A-P2	7 - 4
AW02 0156	Photointerruptor:EE-SX4235A-P2	5 - 2

Part No.	Description	Page and Index No.
0313 0030N	Pan Head Screw:M3x3	7 - 103
0313 0050N	Philips Pan Head Screw - M3x5	9 - 108
0450 3008N	Tapping Screw - M3x8	5 - 102
0450 3008N	Tapping Screw - M3x8	3 - 102
0450 3008N	Tapping Screw - M3x8	7 - 102
0451 3006N	Tapping Screw - 3x6	7 - 101
0451 3006N	Tapping Screw - 3x6	9 - 101
0451 3006N	Tapping Screw - 3x6	5 - 101
0451 3006N	Tapping Screw - 3x6	3 - 103
0451 3008N	Tapping Screw - M3x8	9 - 107
0451 3008N	Tapping Screw - M3x8	3 - 101
0454 3006Q	Tapping Screw - M3x6	5 - 103
0454 3006Q	Tapping Screw - M3x6	7 - 106
0454 3006Q	Tapping Screw - M3x6	9 - 102
0805 0089	Retaining Ring - M4	9 - 103
0805 0089	Retaining Ring - M4	3 - 104
0951 4006P	Screw:Polished Round:M4x6	9 - 104
1105 0326	Locking Support	5 - 104
1105 0326	Locking Support	7 - 104
1105 0328	Harness Clamp - ES-0505	5 - 105
1105 0328	Harness Clamp - ES-0505	7 - 105
1105 0328	Harness Clamp - ES-0505	9 - 106
1105 0487	Harness Clamp	9 - 105
1607 2472	Ferrite Core:GTFC-16-8-16	3 - 105
1905 0045	UVEPROM:512K:X8:100NS	7 - 107

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	9 - 4
5447 2681	Snap Ring	3 - 4
5447 2681	Snap Ring	9 - 10