

Cover Interposer Tray Type 1075 (B470)

This parts catalog is includes MB No. 1 to 4

Cover Interposer Ttay Type 1075 (B470)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.EXTERIOR (B470).....	2
2.ORIGINAL FEED 1 (B470)	4
3.ORIGINAL FEED 2 (B470)	6
4.ORIGINAL FEED 3 (B470)	8
5.TRANSPORT SECTION (B470).....	10
6.ELECTRICAL AND DRIVE (B470)	12
7.DECAL AND DOCUMENTS (B470)	14
PARTS INDEX	17

August ,10 ' 2004

1.EXTERIOR (B470)




1.EXTERIOR (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B470 4572	Lower Cover Bracket	4
2	B470 4571	Lower Cover	2
3	B470 4552	Door Hinge	2
4	B470 4557	Door Stopper	1
5	B470 4551	Front Door	1
6	B470 4531	Upper Front Cover	1
7	B470 4591	Spacer Cover	1
8	B470 4523	Decal - Paper Feed Table	1
9	B470 4522	Paper Feed Table - Back	1
10	AW01 0087	Photo Sensor - Ass'y	3
11	B470 5270	Long Relay Harness - Paper Size	1
12	B470 4521	Paper Feed Table	1
13	B470 4541	Upper Rear Cover	1
14	B470 4561	Middle Rear Cover	1
15	B470 4581	Base Cover	1
16	AA14 3062	Shoulder Screw - M4	3
17	B470 4596	Right Front Spacer Cover	1
18	B470 4597	Right Rear Spacer Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0451 3008N	Tapping Screw - M3x8	
103	0450 4008N	Tapping Screw - 4x8	
104	0451 3006N	Tapping Screw - M3x6	

2.ORIGINAL FEED 1 (B470)




2.ORIGINAL FEED 1 (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5446 2824	Screw - Duplex Guide Plate	2
2	B387 4661	Front Rack - Side Fence	1
3	B470 2375	Rear Rack	1
4	AW01 0057	Pegistration Sensor	1
5	B470 2372	Base - Paper Feed Table	1
6	B470 2377	Sensor Bracket	1
7	AW02 0086	Photointerruptor	3
8	B470 5260	Relay Harness - Paper Size	1
9	B387 4646	Side Fence Pad	4
10	B470 2373	Front Side Fence	1
11	A859 4665	Gear - 16Z	1
12	B470 2365	Rear Side Fence	1
13	B470 7101	Decal - Side Fence	1
14	B470 2378	Original Table Holder	1
15	AG07 0014	Magnet Catch	2
16	B470 7104	Decal - Misfeed Removal	1
17	B470 4511	Cover - Paper Feed	1
18	B470 4515	Pressure Plate	1
19	AF02 2106	Driven Roller	1
20	AA08 0242	Bushing - 4mm	2
21	B470 4514	Compression Spring	2
22	B470 4513	Roller Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	1105 0511	Harness Clamp - LWS-0306ZC	
103	0451 3006N	Tapping Screw - M3x6	
104	0450 4008N	Tapping Screw - 4x8	

3.ORIGINAL FEED 2 (B470)




3.ORIGINAL FEED 2 (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A806 2153	Timing Pulley - T27 S2M	1
2	A806 4118	Timing Belt - B40S2M148	1
3	AA13 2171	Spacer - 6x20x1	1
4	A806 1321	Pickup Roller	1
5	A858 6022	Decal Blue	1
6	5053 0447	Bushing - 6mm	2
7	5447 2681	Snap Ring	2
8	B470 2261	Pick-up Roller Bracket	1
9	A806 2151	Timing Pulley - T19/Z23 S2M/M0.6	1
10	A806 2271	Gear - Z18	1
11	B470 2211	Drive Shaft	1
12	AW02 0086	Photointerruptor	2
13	B470 5281	Harness - Paper Near End	1
	B470 5280	X/O MB2	
14	AW02 0006	Photointerruptor - EE-SX460-P2	1
15	B470 2214	Entrance Guide Plate	1
16	5304 1639	Bushing - 8mm	1
17	A628 1225	Bushing - 8mm	4
18	A806 1293	Feed Belt Drive Roller	1
19	B470 2212	Drive Gear - Pick-up	1
20	A806 1292	Feed Belt Bracket	1
21	A806 4261	Spring Belt Guide Roller	2
22	A806 1295	Feed Belt	1
23	A806 1294	Feed Belt Driven Roller	1
24	A806 1298	Transport Belt Roller Shaft	1
25	B470 2213	Entrance Guide Plate	1
26	AA13 2013	Spacer	2
27	AA06 3315	Spring - Belt Drive Shaft	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0632 0120G	Parallel Pin - 2x12	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	

4.ORIGINAL FEED 3 (B470)




4.ORIGINAL FEED 3 (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B470 1511	Left Stay	1
2	B470 2321	Base Shaft	1
3	A806 1342	Base Lever	1
4	5053 0447	Bushing - 6mm	1
5	B470 1621	Stay - Reverse Roller	1
6	AW02 0086	Photointerruptor	1
7	B470 2112	Upper Guide Plate	1
8	B470 2113	Separation Pad Holder	1
9	B301 1155	Separation Support Pad	1
10	B470 2111	Guide Plate - Paper Feed	1
11	B470 5230	Relay Harness	1
12	B470 5240	Relay Harness	1
13	AW01 0057	Pegistration Sensor	2
14	5447 2681	Snap Ring	1
15	A859 2241	Reverse Roller	1
16	A294 6700	Torque Limiter - 53mnxm	1
	A247 2900	O/O MB4	
17	B470 3141	Reverse Roller Shaft	1
18	B470 1710	Stay - Reverse Roller	1
19	B470 2511	Drive Roller	1
20	B470 1811	Base Frame	1
21	B470 3151	Gear - 36Z	1
22	B301 2221	Gear - 31Z	1
23	A806 2281	Gear - Z47	1
24	5304 1639	Bushing - 8mm	1
25	B470 5200	Interface Harness	1
26	B470 5170	Connector Bracket	1
27	B470 5165	Gasket - Connector Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - M3x6	
102	0632 0140G	Parallel Pin	
103	0720 0040E	Retaining Ring - M4	
104	0720 0060E	Retaining Ring - M6	
105	0741 3808	Ball Bearing - 8x16x5mm	
106	0632 0120G	Parallel Pin - 2x12	
107	0741 3706	Ball Bearing - 6x10x3	
108	0741 3506	Ball Bearing - 6x12x4 mm	
109	0802 5276	Tapping Screw With Washer - M3x6	
110	1105 0516	Clamp	

5.TRANSPORT SECTION (B470)




5.TRANSPORT SECTION (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B470 7105	Decal - Misfeed Removal	1
2	5053 0447	Bushing - 6mm	6
3	B470 1111	Front Side Plate	1
4	AG07 0014	Magnet Catch	4
5	AF02 2147	Driven Roller	1
6	AA06 3529	Pressure Spring - 14.5mm	6
7	GB03 0032	Timing Pulley - T28-S2M	1
8	B470 7102	Decal - Q1	1
9	B470 4311	Guide Plate	1
10	AW02 0095	Photointerruptor	1
11	B470 5250	Relay Harness	1
12	B470 4112	Guide Plate - Vertical Transport	1
13	AW02 0086	Photointerruptor	1
14	B408 1413	Coupling Stay	3
15	B352 2620	Lower Transport Roller	2
16	AF02 0501	Transport Roller	1
17	B470 7103	Decal - Q2	1
18	B470 4225	Guide Plate Myler	2
19	B470 4223	Side Guide Plate MB3 DELETED	1
20	B470 1121	Rear Side Plate	1
21	B352 1607	Timing Pulley - T20-S3M	2
22	A697 1128	Joint Lever	1
23	A697 1125	Stepped Screw - Lever	2
24	A376 1295	Spacer - M6x10x5	3
25	AA08 0242	Bushing - 4mm	4
26	AF02 2106	Driven Roller	2
27	B470 4232	Shaft - Side Guide Plate MB3 ADDED	1
28	B470 4231	Side Guide Plate MB3 ADDED	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - M3x6	
102	0805 0089	Retaining Ring - M4	
103	1105 0511	Harness Clamp - LWS-0306ZC	

6.ELECTRICAL AND DRIVE (B470)




6.ELECTRICAL AND DRIVE (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B470 3131	Drive Shaft	1
2	A806 2285	Gear - Z20/Z47	1
3	A806 2287	Gear - Z20/Z47	1
4	A806 2283	Gear - Z20/Z47	2
5	B470 2351	Timing Pulley - T30/Z20	1
6	A806 4117	Timing Belt - B40S2M158	1
7	A806 2362	Base Bracket	1
8	A806 2911	Stepper Motor Ass'y - DC 13W	1
9	B470 3161	Timing Belt - B40S2M224	1
10	B470 3171	Timing Belt - B40S2M176	1
11	B470 3133	Timing Pulley - T48S2M	2
12	B470 3181	Drive Bracket	1
13	B470 5510	Stepper Motor - Paper Feed	2
14	B301 2222	Gear - 20Z	1
15	B470 3134	Gear - 23Z	1
16	B470 3211	Idler Pulley - T20/Z30	1
17	B470 3250	Timing Belt - B40S3M456	1
18	A300 3151	Support Bracket	2
19	B470 5301	Base Bracket	4
20	5442 4121	Spring - Oil Blade	1
21	A697 1125	Stepped Screw - Lever	1
22	B312 1605	Tightener	1
23	B470 3322	Timing Belt - B40S2M146	1
24	B312 1524	Motor Bracket	1
25	B470 5500	Stepper Motor	1
26	B470 5121	Main Control Board	1
	B470 5120	X/O MB1	
27	B470 5222	Main Sensor Harness	1
	B470 5220	X/O MB2	
28	B470 5210	Main Motor Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0453 3006N	Tapping Screw - M3x6	
102	0451 3006N	Tapping Screw - M3x6	
103	0632 0120G	Parallel Pin - 2x12	
104	0632 0140G	Parallel Pin	
105	0720 0060E	Retaining Ring - M6	
106	0741 3808	Ball Bearing - 8x16x5mm	
107	0802 5276	Tapping Screw With Washer - M3x6	
108	0720 0040E	Retaining Ring - M4	
109	0805 0089	Retaining Ring - M4	
110	1105 0518	Edge Saddle - LES-1010	
111	1105 0511	Harness Clamp - LWS-0306ZC	
112	1105 0516	Clamp	
113	1105 0489	Harness Clamp - LWS 1316	
114	1607 0704	Ferrite Core - ESD-SR-25	
115	1607 0623	Ferrite Core TFC16-8-13	

7.DECAL AND DOCUMENTS (B470)



7.DECAL AND DOCUMENTS (B470)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B470 4523	Decal - Paper Feed Table	1
2	B470 7101	Decal - Side Fence	1
3	B470 7104	Decal - Misfeed Removal	1
4	B470 7105	Decal - Misfeed Removal	1
5	B470 7102	Decal - Q1	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

[illegible]

Parts Index

Part No.	Description	Page and Index No.
B470 1111	Front Side Plate	11 - 3
B470 1121	Rear Side Plate	11 - 20
B470 1511	Left Stay	9 - 1
B470 1621	Stay - Reverse Roller	9 - 5
B470 1710	Stay - Reverse Roller	9 - 18
B470 1811	Base Frame	9 - 20
B470 2111	Guide Plate - Paper Feed	9 - 10
B470 2112	Upper Guide Plate	9 - 7
B470 2113	Separation Pad Holder	9 - 8
B470 2211	Drive Shaft	7 - 11
B470 2212	Drive Gear - Pick-up	7 - 19
B470 2213	Entrance Guide Plate	7 - 25
B470 2214	Entrance Guide Plate	7 - 15
B470 2261	Pick-up Roller Bracket	7 - 8
B470 2321	Base Shaft	9 - 2
B470 2351	Timing Pulley - T30/Z20	13 - 5
B470 2365	Rear Side Fence	5 - 12
B470 2372	Base - Paper Feed Table	5 - 5
B470 2373	Front Side Fence	5 - 10
B470 2375	Rear Rack	5 - 3
B470 2377	Sensor Bracket	5 - 6
B470 2378	Original Table Holder	5 - 14
B470 2511	Drive Roller	9 - 19
B470 3131	Drive Shaft	13 - 1
B470 3133	Timing Pulley - T48S2M	13 - 11
B470 3134	Gear - 23Z	13 - 15
B470 3141	Reverse Roller Shaft	9 - 17
B470 3151	Gear - 36Z	9 - 21
B470 3161	Timing Belt - B40S2M224	13 - 9
B470 3171	Timing Belt - B40S2M176	13 - 10
B470 3181	Drive Bracket	13 - 12
B470 3211	Idler Pulley - T20/Z30	13 - 16
B470 3250	Timing Belt - B40S3M456	13 - 17
B470 3322	Timing Belt - B40S2M146	13 - 23
B470 4112	Guide Plate - Vertical Transport	11 - 12

Part No.	Description	Page and Index No.
B470 4223	Side Guide Plate MB3 DELETED	11 - 19
B470 4225	Guide Plate Myler	11 - 18
B470 4231	Side Guide Plate MB3 ADDED	11 - 28
B470 4232	Shaft - Side Guide Plate MB3 ADDED	11 - 27
B470 4311	Guide Plate	11 - 9
B470 4511	Cover - Paper Feed	5 - 17
B470 4513	Roller Bracket	5 - 22
B470 4514	Compression Spring	5 - 21
B470 4515	Pressure Plate	5 - 18
B470 4521	Paper Feed Table	3 - 12
B470 4522	Paper Feed Table - Back	3 - 9
B470 4523	Decal - Paper Feed Table	15 - 1
B470 4523	Decal - Paper Feed Table	3 - 8
B470 4531	Upper Front Cover	3 - 6
B470 4541	Upper Rear Cover	3 - 13
B470 4551	Front Door	3 - 5
B470 4552	Door Hinge	3 - 3
B470 4557	Door Stopper	3 - 4
B470 4561	Middle Rear Cover	3 - 14
B470 4571	Lower Cover	3 - 2
B470 4572	Lower Cover Bracket	3 - 1
B470 4581	Base Cover	3 - 15
B470 4591	Spacer Cover	3 - 7
B470 4596	Right Front Spacer Cover	3 - 17
B470 4597	Right Rear Spacer Cover	3 - 18
B470 5120	X/O MB1	13 - 26
B470 5121	Main Control Board	13 - 26
B470 5165	Gasket - Connector Bracket	9 - 27
B470 5170	Connector Bracket	9 - 26
B470 5200	Interface Harness	9 - 25
B470 5210	Main Motor Harness	13 - 28
B470 5220	X/O MB2	13 - 27
B470 5222	Main Sensor Harness	13 - 27
B470 5230	Relay Harness	9 - 11
B470 5240	Relay Harness	9 - 12

Part No.	Description	Page and Index No.
B470 5250	Relay Harness	11 - 11
B470 5260	Relay Harness - Paper Size	5 - 8
B470 5270	Long Relay Harness - Paper Size	3 - 11
B470 5280	X/O MB2	7 - 13
B470 5281	Harness - Paper Near End	7 - 13
B470 5301	Base Bracket	13 - 19
B470 5500	Stepper Motor	13 - 25
B470 5510	Stepper Motor - Paper Feed	13 - 13
B470 7101	Decal - Side Fence	5 - 13
B470 7101	Decal - Side Fence	15 - 2
B470 7102	Decal - Q1	11 - 8
B470 7102	Decal - Q1	15 - 5
B470 7103	Decal - Q2	11 - 17
B470 7104	Decal - Misfeed Removal	5 - 16
B470 7104	Decal - Misfeed Removal	15 - 3
B470 7105	Decal - Misfeed Removal	11 - 1
B470 7105	Decal - Misfeed Removal	15 - 4

Part No.	Description	Page and Index No.
A247 2900	O/O MB4	9 - 16
A294 6700	Torque Limiter - 53mnxm	9 - 16
A300 3151	Support Bracket	13 - 18
A376 1295	Spacer - M6x10x5	11 - 24
A628 1225	Bushing - 8mm	7 - 17
A697 1125	Stepped Screw - Lever	13 - 21
A697 1125	Stepped Screw - Lever	11 - 23
A697 1128	Joint Lever	11 - 22
A806 1292	Feed Belt Bracket	7 - 20
A806 1293	Feed Belt Drive Roller	7 - 18
A806 1294	Feed Belt Driven Roller	7 - 23
A806 1295	Feed Belt	7 - 22
A806 1298	Transport Belt Roller Shaft	7 - 24
A806 1321	Pickup Roller	7 - 4
A806 1342	Base Lever	9 - 3
A806 2151	Timing Pulley - T19/Z23 S2M/M0.6	7 - 9
A806 2153	Timing Pulley - T27 S2M	7 - 1
A806 2271	Gear - Z18	7 - 10
A806 2281	Gear - Z47	9 - 23
A806 2283	Gear - Z20/Z47	13 - 4
A806 2285	Gear - Z20/Z47	13 - 2
A806 2287	Gear - Z20/Z47	13 - 3
A806 2362	Base Bracket	13 - 7
A806 2911	Stepper Motor Ass'y - DC 13W	13 - 8
A806 4117	Timing Belt - B40S2M158	13 - 6
A806 4118	Timing Belt - B40S2M148	7 - 2
A806 4261	Spring Belt Guide Roller	7 - 21
A858 6022	Decal Blue	7 - 5
A859 2241	Reverse Roller	9 - 15
A859 4665	Gear - 16Z	5 - 11
B301 1155	Separation Support Pad	9 - 9
B301 2221	Gear - 31Z	9 - 22
B301 2222	Gear - 20Z	13 - 14
B312 1524	Motor Bracket	13 - 24
B312 1605	Tightener	13 - 22

Part No.	Description	Page and Index No.
B352 1607	Timing Pulley - T20-S3M	11 - 21
B352 2620	Lower Transport Roller	11 - 15
B387 4646	Side Fence Pad	5 - 9
B387 4661	Front Rack - Side Fence	5 - 2
B408 1413	Coupling Stay	11 - 14

Part No.	Description	Page and Index No.
AA06 3315	Spring - Belt Drive Shaft	7 - 27
AA06 3529	Pressure Spring - 14.5mm	11 - 6
AA08 0242	Bushing - 4mm	11 - 25
AA08 0242	Bushing - 4mm	5 - 20
AA13 2013	Spacer	7 - 26
AA13 2171	Spacer - 6x20x1	7 - 3
AA14 3062	Shoulder Screw - M4	3 - 16
AF02 0501	Transport Roller	11 - 16
AF02 2106	Driven Roller	11 - 26
AF02 2106	Driven Roller	5 - 19
AF02 2147	Driven Roller	11 - 5
AG07 0014	Magnet Catch	11 - 4
AG07 0014	Magnet Catch	5 - 15
AW01 0057	Pegistration Sensor	9 - 13
AW01 0057	Pegistration Sensor	5 - 4
AW01 0087	Photo Sensor - Ass'y	3 - 10
AW02 0006	Photointerruptor - EE-SX460-P2	7 - 14
AW02 0086	Photointerruptor	7 - 12
AW02 0086	Photointerruptor	9 - 6
AW02 0086	Photointerruptor	11 - 13
AW02 0086	Photointerruptor	5 - 7
AW02 0095	Photointerruptor	11 - 10
GB03 0032	Timing Pulley - T28-S2M	11 - 7

Part No.	Description	Page and Index No.
0450 3008N	Tapping Screw - M3x8	5 -101
0450 3008N	Tapping Screw - M3x8	3 -101
0450 4008N	Tapping Screw - 4x8	3 -103
0450 4008N	Tapping Screw - 4x8	5 -104
0451 3006N	Tapping Screw - M3x6	3 -104
0451 3006N	Tapping Screw - M3x6	13 -102
0451 3006N	Tapping Screw - M3x6	5 -103
0451 3006N	Tapping Screw - M3x6	11 -101
0451 3006N	Tapping Screw - M3x6	9 -101
0451 3008N	Tapping Screw - M3x8	3 -102
0453 3006N	Tapping Screw - M3x6	13 -101
0632 0120G	Parallel Pin - 2x12	9 -106
0632 0120G	Parallel Pin - 2x12	7 -101
0632 0120G	Parallel Pin - 2x12	13 -103
0632 0140G	Parallel Pin	13 -104
0632 0140G	Parallel Pin	9 -102
0720 0040E	Retaining Ring - M4	7 -102
0720 0040E	Retaining Ring - M4	13 -108
0720 0040E	Retaining Ring - M4	9 -103
0720 0060E	Retaining Ring - M6	9 -104
0720 0060E	Retaining Ring - M6	7 -103
0720 0060E	Retaining Ring - M6	13 -105
0741 3506	Ball Bearing - 6x12x4 mm	9 -108
0741 3706	Ball Bearing - 6x10x3	9 -107
0741 3808	Ball Bearing - 8x16x5mm	9 -105
0741 3808	Ball Bearing - 8x16x5mm	13 -106
0802 5276	Tapping Screw With Washer - M3x6	13 -107
0802 5276	Tapping Screw With Washer - M3x6	9 -109
0805 0089	Retaining Ring - M4	11 -102
0805 0089	Retaining Ring - M4	13 -109
1105 0489	Harness Clamp - LWS 1316	13 -113
1105 0511	Harness Clamp - LWS-0306ZC	11 -103
1105 0511	Harness Clamp - LWS-0306ZC	5 -102
1105 0511	Harness Clamp - LWS-0306ZC	13 -111
1105 0516	Clamp	9 -110

Part No.	Description	Page and Index No.
1105 0516	Clamp	13 -112
1105 0518	Edge Saddle - LES-1010	13 -110
1607 0623	Ferrite Core TFC16-8-13	13 -115
1607 0704	Ferrite Core - ESD-SR-25	13 -114

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	7 - 6
5053 0447	Bushing - 6mm	9 - 4
5053 0447	Bushing - 6mm	11 - 2
5304 1639	Bushing - 8mm	7 - 16
5304 1639	Bushing - 8mm	9 - 24
5442 4121	Spring - Oil Blade	13 - 20
5446 2824	Screw - Duplex Guide Plate	5 - 1
5447 2681	Snap Ring	7 - 7
5447 2681	Snap Ring	9 - 14

Part No.	Description	Page and Index No.