

DF75 (B386)

This parts catalog is includes MB No. 1 to 15

DF75 (B386)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.ARDF 1 (B386)	2
2.ARDF 2 (B386)	4
3.ARDF 3 (B386)	6
4.ARDF 4 (B386)	8
5.ARDF 5 (B386)	10
6.ARDF 6 (B386)	12
7.ARDF 7 (B386)	14
8.Decals And Documents (B386)	16
PARTS INDEX	19

July ,25 ' 2002

1.ARDF 1 (B386)




1.ARDF 1 (B386)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 4811	Front Cover	1
2	A628 3115	Knob Screw - M4	1
3	5446 2824	Screw - Duplex Guide Plate	2
4	B386 4873	Positioning Plate	2
5	A859 4871	Original Sensor Feeler	1
6	A859 4872	Feeler Bracket	1
7	A859 4881	Cushion Paper Feed	1
8	B386 4842	Left Cover	1
	B386 4841	x/o MB3	
9	B386 6013	Misfeed Removal Decal	1
10	B387 6021	Size Indication Decal	1
11	AA06 3311	Transport Roller Spring	2
12	A859 4836	Bushing - Exit Driven Roller	2
13	A859 4837	Exit Driven Roller	1
14	B386 4871	Upper Cover	1
15	B386 4821	Rear Cover	1
16	B386 7102	Original Scale	1
	B386 7101	x/o MB9	
17	AC01 3004	Exposure Glass	1
18	A859 7211	Stepped Screw	2
19	G564 6076	Decal - Exposure Glass	1
	B379 6063	x/o MB11	
20	A628 3118	Screw Driver - DF	1
21	B386 3617	Platen Sheet Mylar	1
22	B387 6053	Original Scale Decal - A4	1
22	B387 6054	Original Scale Decal - LT	1
23	A858 4871	Cover Sponge - Front MB4 ADDED	1
24	A858 4872	Cover Sponge - Front Right MB4 ADDED	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0452 3008B	Tapping Screw - M3x8	
103	0451 3008H	Tapping Screw - M3x8	


2.ARDF 2 (B386)





5

3.ARDF 3 (B386)




3.ARDF 3 (B386)


Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 2220	Reverse Roller Cover	1
2	A859 2241	Reverse Roller	1
3	A247 2900	Torque Limiter - 53mnm	1
4	5053 0447	Bushing - 6mm	1
5	A859 1621	Separation Guide	1
6	B386 1610	Separation Stay	1
7	5304 1639	Bushing - 8mm	2
8	A859 2230	Ball Bearing - 6x13x5	1
9	AW02 0075	Photointerruptor	1
10	B386 1123	Sensor Bracket	1
11	AA13 2013	Spacer	2
12	AA06 3315	Spring - Belt Drive Shaft	1
13	A859 2132	Front Guide - Paper Feed	1
14	A628 1225	Bushing - 8mm	4
15	A859 2141	Belt Paper Feed	1
16	A859 2114	Drive Roller - Paper Feed Belt	1
17	A859 2121	Gear - 22Z	1
18	A859 2131	Rear Guide - Paper Feed	1
19	A859 2120	Drive Shaft - Paper Feed Belt	1
20	A859 2110	Belt Holder	1
21	AA06 3318	Spring - Belt Guide Roller	2
22	A859 2112	Drive Shaft - Paper Feed Belt	1
23	A859 2113	Driven Roller - Paper Feed Belt	1
24	A859 2162	Pick-up Roller Shaft	1
25	A859 2151	Pick-up Holder	1
26	A859 2167	Gear - 22Z	1
27	A859 2168	Pulley - 22Z	1
28	5206 2686	Snap Ring	1
29	B386 2171	Pickup Roller	1
30	A859 2163	Pick-up Collar	1
31	A859 2164	Pulley - 2Z	1
32	A859 2166	Timing Belt - 2XL	1
33	A859 4216	Shaft Electromagnetic Clutch	1
34	A859 2210	Reverse Roller Shaft	1
35	A858 4231	Gear - 20Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A859 4222	Pulley Flange	1
37	A858 4221	Gear - 31Z	1
101	0802 5276	Tapping Screw With Washer - M3x6	
102	0720 0040B	Retaining Ring - M4	
103	0720 0060B	Retaining Ring - M6	
104	1105 0310	Harness Clamp - LWS-1S	
105	0451 3006B	Tapping Screw - M3x6	
106	0632 0100	Parallel Pin - M2x10	
107	0720 0030B	Retaining Ring - M3	

4.ARDF 4 (B386)



5.ARDF 5 (B386)




5.ARDF 5 (B386)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 3210	Guide Plate - Transport Roller	1
2	B386 1322	Spring Plate Guide	2
3	AW01 0093	Photo Reflection Sensor - PS-17N	2
4	A859 5705	Sensor Relay Harness	2
5	B386 1311	Left Stay	1
6	5304 1639	Bushing - 8mm	1
7	5053 0447	Bushing - 6mm	1
8	B386 1320	Bracket - Transport Roller	1
9	A859 3110	Transport Roller	1
10	B386 3121	Middle Transport Roller	1
	A859 3120	x/o MB10	
11	A859 3431	Front Spring	1
12	5447 2681	Snap Ring	2
13	A859 3220	Guide Plate - Upper Exit	1
14	A859 3430	Rear Spring	1
15	A859 3411	Exit Guide Plate	1
16	A859 6023	Decal Green	1
17	A859 3412	Shaft - Exit Guide Plate	2
18	A859 3420	Middle Driven Roller	2
19	A859 3425	Spring Plate	2
20	H511 5006	Stamper	1
21	B386 3413	Cover - Exit Guide Plate	1
22	B386 3231	Reverse Guide Plate	1
23	B386 3236	Discharge Brush - I50	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4014B	Tapping Screw - M4x14	
103	0720 0060B	Retaining Ring - M6	
104	0720 0040B	Retaining Ring - M4	
105	0452 3008B	Tapping Screw - M3x8	

6.ARDF 6 (B386)




6.ARDF 6 (B386)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 5703	Stepper Motor Harness	1
2	B386 5563	Main Control Board	1
	B386 5560	x/o MB8	
	B386 5530	x/o MB7	
	B386 5520	x/o MB5	
3	A859 5700	Main Harness	1
4	A858 5701	Exit Sensor Harness	1
5	B386 5800	Interface Harness	1
6	A859 1131	Insulating Sheet	1
7	A858 4431	DC Solenoid - 24V	1
8	5447 2681	Snap Ring	1
9	B386 1125	APS Feeler Bracket	1
10	B386 1121	APS Feeler	1
11	B387 1951	Spring - Paper Size Sensor	1
12	B386 1811	Left Hinge	1
13	AX21 0071	Electromagnetic Clutch - 30Z	1
14	B386 1315	Bracket - Electromagnetic Clutch	1
15	5304 1639	Bushing - 8mm	1
16	A858 4261	Timing Belt - 2XL	1
17	B386 4251	Pulley - T20/T19	1
18	B386 4252	Flange - Mm16.5	1
19	B386 1831	Right Hinge	1
20	A859 1841	Filler - DF Open Sensor	1
21	A334 4678	Rack Shield Mylar	1
22	B386 4161	Timing Belt - B40S2M158	1
23	B386 1884	Pulley - T20/T37	2
24	B386 4181	Timing Belt - B60S2M198	1
25	AA04 3929	Timing Belt - B40S2M114	1
	B386 4171	o/o MB2	
26	B386 4191	Timing Belt - B40S2M254	1
27	A859 4141	Pulley Idler	1
28	A858 4134	Idler Tension Spring	1
29	B386 4131	Idler Adjusting Pin	1
30	AW02 0075	Photointerruptor	1
31	B386 1122	Right Sensor Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
32	B386 4111	Stepper Motor Bracket	1
33	B386 4121	Stepper Motor - DC2.78V 2A	1
34	B386 4151	Stepper Motor - DC2.4V 1.2A	1
35	A859 4197	Tension Spring - Motor	1
36	5206 2686	Snap Ring	1
37	A859 4421	DC Solenoid	1
38	A028 3264	Stopper Cushion	1
39	B386 4411	Solenoid Bracket	1
40	B386 4141	Spring Plate - Stepper Motor	1
101	0451 3006B	Tapping Screw - M3x6	
102	0951 3006B	Philips Screw With Flat Washer - M3x6	
103	1105 0310	Harness Clamp - LWS-1S	
104	0951 4006B	Philips Screw With Washer - M4x6	
105	0353 0040B	Screw - M3X4	
106	1105 0109	Cord Keep	
107	0720 0040B	Retaining Ring - M4	
108	1105 0460	Clamp	
109	0452 3008B	Tapping Screw - M3x8	

7.ARDF 7 (B386)




7.ARDF 7 (B386)



Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 1221	Spacer	2
2	B386 3620	Sheet Ass'y	1
	G412 3721	x/o MB15	
3	B386 1511	Middle Stay	2
4	A859 3614	Sponge - Left Platen Cover MB15 OBS	1
5	A859 3613	Platen Cover Sponge MB15 OBS	3
6	B386 3615	Base - Platen Cover	1
7	B386 1211	Front Side Plate	1
8	B386 1110	Rear Side Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	

8.Decals And Documents (B386)



8.Decals And Documents (B386)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B387 6053	Original Scale Decal - A4	1
1	B387 6054	Original Scale Decal - LT	1
2	B386 6013	Misfeed Removal Decal	1
3	B387 6021	Size Indication Decal	1
4	A858 6022	Decal Blue	1
4	A859 6023	Decal Green	1
5	B387 6032	Original Orientation Decal	1
6	B386 6042	Side Fence Decal	1
7	G564 6076	Exposure Glass Decal	1
	B379 6063	x/x MB15 OBS	

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
ARDF 3 (B386)	A859 2241	Reverse Roller	Reverse Roller	1	7- 2
	A859 2141	Belt Paper Feed	Belt Paper Feed	1	7- 15
	B386 2171	Pickup Roller	Pickup Roller	1	7- 29

Parts Index

Part No.	Description	Page and Index No.
B386 1110	Rear Side Plate	15 - 8
B386 1121	APS Feeler	13 - 10
B386 1122	Right Sensor Bracket	13 - 31
B386 1123	Sensor Bracket	7 - 10
B386 1125	APS Feeler Bracket	13 - 9
B386 1211	Front Side Plate	15 - 7
B386 1311	Left Stay	11 - 5
B386 1315	Bracket - Electromagnetic Clutch	13 - 14
B386 1320	Bracket - Transport Roller	11 - 8
B386 1322	Spring Plate Guide	11 - 2
B386 1511	Middle Stay	15 - 3
B386 1610	Separation Stay	7 - 6
B386 1710	Left Lower Stay	9 - 16
B386 1811	Left Hinge	13 - 12
B386 1831	Right Hinge	13 - 19
B386 1884	Pulley - T20/T37	13 - 23
B386 2171	Pickup Roller	7 - 29
B386 2351	Original Feed Plate	5 - 17
B386 2353	Pressure Plate - Base	5 - 13
B386 3121	Middle Transport Roller	11 - 10
B386 3130	Exit Drive Roller	9 - 18
B386 3140	Reverse Drive Roller	9 - 27
B386 3231	Reverse Guide Plate	11 - 22
B386 3236	Discharge Brush - I50	11 - 23
B386 3318	Front Torsion Spring	9 - 7
B386 3319	Rear Torsion Spring	9 - 9
B386 3413	Cover - Exit Guide Plate	11 - 21
B386 3615	Base - Platen Cover	15 - 6
B386 3617	Platen Sheet Mylar	3 - 21
B386 3620	Sheet Ass'y	15 - 2
B386 4111	Stepper Motor Bracket	13 - 32
B386 4121	Stepper Motor - DC2.78V 2A	13 - 33
B386 4131	Idler Adjusting Pin	13 - 29
B386 4141	Spring Plate - Stepper Motor	13 - 40
B386 4151	Stepper Moter - DC2.4V 1.2A	13 - 34

Part No.	Description	Page and Index No.
B386 4161	Timing Belt - B40S2M158	13 - 22
B386 4171	o/o MB2	13 - 25
B386 4181	Timing Belt - B60S2M198	13 - 24
B386 4191	Timing Belt - B40S2M254	13 - 26
B386 4251	Pulley - T20/T19	13 - 17
B386 4252	Flange - Mm16.5	13 - 18
B386 4311	Adjusting Pin - M6	9 - 29
B386 4411	Solenoid Bracket	13 - 39
B386 4621	Upper Original Table	5 - 24
B386 4631	Lower Original Table	5 - 7
B386 4691	Mylar Seal - 28x107 MB12 ADDED	5 - 41
B386 4692	Mylar Seal - 16x45 MB12 ADDED	5 - 42
B386 4693	Mylar Seal MB12 ADDED	5 - 40
B386 4710	Front Side Fence	5 - 20
B386 4720	Rear Side Fence	5 - 5
B386 4811	Front Cover	3 - 1
B386 4821	Rear Cover	3 - 15
B386 4841	x/o MB3	3 - 8
B386 4842	Left Cover	3 - 8
B386 4856	Cover - Transport Driven Roller	9 - 13
B386 4861	Reverse Tray	9 - 26
B386 4871	Upper Cover	3 - 14
B386 4873	Positioning Plate	3 - 4
B386 4881	Left Lower Cover	9 - 12
B386 5520	x/o MB5	13 - 2
B386 5530	x/o MB7	13 - 2
B386 5550	Paper Size Sensor Board	5 - 30
B386 5560	x/o MB8	13 - 2
B386 5563	Main Control Board	13 - 2
B386 5703	Stepper Motor Harness	13 - 1
B386 5800	Interface Harness	13 - 5
B386 6013	Misfeed Removal Decal	17 - 2
B386 6013	Misfeed Removal Decal	3 - 9
B386 6042	Side Fence Decal	17 - 6
B386 6042	Side Fence Decal	5 - 21

Part No.	Description	Page and Index No.
B386 7101	x/o MB9	3 - 16
B386 7102	Original Scale	3 - 16

Part No.	Description	Page and Index No.
A028 3264	Stopper Cushion	13 - 38
A247 2900	Torque Limiter - 53mnm	7 - 3
A334 4678	Rack Shield Mylar	13 - 21
A351 4951	Guide Pad - Side Fence	5 - 19
A590 2214	Screw - M3X5	9 - 22
A628 1225	Bushing - 8mm	7 - 14
A628 3115	Knob Screw - M4	3 - 2
A628 3118	Screw Driver - DF	3 - 20
A697 1125	Stepped Screw - Lever	9 - 3
A858 2313	Spring Plate - Pressure Roller	5 - 36
A858 2319	Reverse Sensor Feeler	5 - 34
A858 3140	x/o MB6	9 - 27
A858 3710	Exchange Reverse Powl	9 - 24
A858 3715	Exchange Powl Lever	9 - 31
A858 3717	Tension Spring - Exchange Powl	9 - 30
A858 4134	Idler Tension Spring	13 - 28
A858 4221	Gear - 31Z	7 - 37
A858 4231	Gear - 20Z	7 - 35
A858 4261	Timing Belt - 2XL	13 - 16
A858 4392	Torque Limiter	9 - 23
A858 4431	DC Solenoid - 24V	13 - 7
A858 4671	Roller Driven	5 - 37
A858 4676	Spring Plate - Pressure Roller	5 - 38
A858 4681	Sheet - Paper Tray	5 - 18
A858 4871	Cover Sponge - Front MB4 ADDED	3 - 23
A858 4872	Cover Sponge - Front Right MB4 ADDED	3 - 24
A858 5701	Exit Sensor Harness	13 - 4
A858 5706	Reverse Sensor Harness	5 - 35
A858 6022	Decal Blue	17 - 4
A858 6022	Decal - Blue	5 - 33
A859 1131	Insulating Sheet	13 - 6
A859 1181	o/o MB1	9 - 5
A859 1221	Spacer	15 - 1
A859 1621	Separation Guide	7 - 5
A859 1721	Left Lower Guide	9 - 14

Part No.	Description	Page and Index No.
A859 1722	x/o MB14	9 - 15
A859 1841	Filler - DF Open Sensor	13 - 20
A859 2110	Belt Holder	7 - 20
A859 2112	Drive Shaft - Paper Feed Belt	7 - 22
A859 2113	Driven Roller - Paper Feed Belt	7 - 23
A859 2114	Drive Roller - Paper Feed Belt	7 - 16
A859 2120	Drive Shaft - Paper Feed Belt	7 - 19
A859 2121	Gear - 22Z	7 - 17
A859 2131	Rear Guide - Paper Feed	7 - 18
A859 2132	Front Guide - Paper Feed	7 - 13
A859 2141	Belt Paper Feed	7 - 15
A859 2151	Pick-up Holder	7 - 25
A859 2162	Pick-up Roller Shaft	7 - 24
A859 2163	Pick-up Collar	7 - 30
A859 2164	Pulley - 2Z	7 - 31
A859 2166	Timing Belt - 2XL	7 - 32
A859 2167	Gear - 22Z	7 - 26
A859 2168	Pulley - 22Z	7 - 27
A859 2210	Reverse Roller Shaft	7 - 34
A859 2220	Reverse Roller Cover	7 - 1
A859 2230	Ball Bearing - 6x13x5	7 - 8
A859 2230	Ball Bearing - 6x13x5	9 - 19
A859 2241	Reverse Roller	7 - 2
A859 2311	Guide Plate - Paper Feed	5 - 6
A859 2315	Separation Pad	5 - 10
A859 2317	Guide - Separation Pad	5 - 9
A859 2319	Base Cushion	5 - 8
A859 2352	Pressure Plate Pad	5 - 16
A859 2354	Base Shaft	5 - 14
A859 2355	Pressure Plate Lever	5 - 4
A859 2356	Base Bottom Cushion	5 - 32
A859 3110	Transport Roller	11 - 9
A859 3120	x/o MB10	11 - 10
A859 3130	x/o MB14	9 - 18
A859 3210	Guide Plate - Transport Roller	11 - 1

Part No.	Description	Page and Index No.
A859 3220	Guide Plate - Upper Exit	11 - 13
A859 3225	Discharge Brush	9 - 25
A859 3311	Transport Driven Roller	9 - 10
A859 3313	Pressure Driven Shaft	9 - 11
A859 3316	Pullout Lever	9 - 8
A859 3317	Contact Point Shaft	9 - 6
A859 3318	x/o MB14	9 - 7
A859 3319	x/o MB14	9 - 9
A859 3411	Exit Guide Plate	11 - 15
A859 3412	Shaft - Exit Guide Plate	11 - 17
A859 3420	Middle Driven Roller	11 - 18
A859 3425	Spring Plate	11 - 19
A859 3430	Rear Spring	11 - 14
A859 3431	Front Spring	11 - 11
A859 3511	Exposure Glass Guide	9 - 17
A859 3613	Platen Cover Sponge MB15 OBS	15 - 5
A859 3614	Sponge - Left Platen Cover MB15 OBS	15 - 4
A859 4141	Pulley Idler	13 - 27
A859 4197	Tension Spring - Motor	13 - 35
A859 4216	Shaft Electromagnetic Clutch	7 - 33
A859 4222	Pulley Flange	7 - 36
A859 4271	Pulley - 31/32Z	9 - 20
A859 4272	Flange	9 - 21
A859 4321	Pulley-20z	9 - 28
A859 4331	Timing Belt - 2XL	9 - 2
A859 4341	Tension Spring	9 - 4
A859 4421	DC Solenoid	13 - 37
A859 4661	Rack - Front Side Fence	5 - 28
A859 4662	Rack - Rear Side Fence	5 - 25
A859 4663	Electrode Plate - Side Fence	5 - 26
A859 4664	Sheet - Paper Size Sensor Board	5 - 39
A859 4665	Gear - 16Z	5 - 27
A859 4836	Bushing - Exit Driven Roller	3 - 12
A859 4837	Exit Driven Roller	3 - 13
A859 4871	Original Sensor Feeler	3 - 5

Part No.	Description	Page and Index No.
A859 4872	Feeler Bracket	3 - 6
A859 4876	Left Cushion	5 - 15
A859 4881	Cushion Paper Feed	3 - 7
A859 5700	Main Harness	13 - 3
A859 5702	x/o MB13	5 - 29
A859 5705	Sensor Relay Harness	11 - 4
A859 5705	Sensor Relay Harness	5 - 12
A859 6023	Decal Green	17 - 4
A859 6023	Decal Green	11 - 16
A859 7211	Stepped Screw	3 - 18
B351 4135	Magnet Catch	9 - 5
B379 6063	x/o MB11	3 - 19
B379 6063	x/x MB15 OBS	17 - 7
B387 1951	Spring - Paper Size Sensor	13 - 11
B387 6021	Size Indication Decal	3 - 10
B387 6021	Size Indication Decal	17 - 3
B387 6032	Original Orientation Decal	5 - 23
B387 6032	Original Orientation Decal	17 - 5
B387 6053	Original Scale Decal - A4	3 - 22
B387 6053	Original Scale Decal - A4	17 - 1
B387 6054	Original Scale Decal - LT	3 - 22
B387 6054	Original Scale Decal - LT	17 - 1
B489 5713	Relay Harness - Original Tray x/o MB13 ADDED	5 - 43
B489 5715	Original Tray Harness	5 - 29
G012 1531	Magnet	5 - 22
G412 3611	Guide Mylar	9 - 15
G412 3721	x/o MB15	15 - 2
G564 6076	Decal - Exposure Glass	3 - 19
G564 6076	Exposure Glass Decal	17 - 7
H060 2126	Bushing - M6x7	5 - 2
H511 5006	Stamper	11 - 20

Part No.	Description	Page and Index No.
AA04 3929	Timing Belt - B40S2M114	13 - 25
AA06 3311	Transport Roller Spring	3 - 11
AA06 3315	Spring - Belt Drive Shaft	7 - 12
AA06 3318	Spring - Belt Guide Roller	7 - 21
AA13 2013	Spacer	7 - 11
AC01 3004	Exposure Glass	3 - 17
AW01 0087	Photo Sensor - Ass'y	5 - 31
AW01 0093	Photo Reflection Sensor - PS-17N	11 - 3
AW02 0075	Photointerruptor	7 - 9
AW02 0075	Photointerruptor	5 - 11
AW02 0075	Photointerruptor	13 - 30
AX21 0071	Electromagnetic Clutch - 30Z	13 - 13

Part No.	Description	Page and Index No.
0353 0040B	Screw - M3X4	13 - 105
0450 3008B	Tapping Screw - M3x8	5 - 103
0451 3006B	Tapping Screw - M3x6	7 - 105
0451 3006B	Tapping Screw - M3x6	13 - 101
0451 3006B	Tapping Screw - M3x6	11 - 101
0451 3006B	Tapping Screw - M3x6	3 - 101
0451 3006B	Tapping Screw - M3x6	9 - 101
0451 3006B	Tapping Screw - M3x6	15 - 101
0451 3006B	Tapping Screw - M3x6	5 - 101
0451 3008H	Tapping Screw - M3x8	3 - 103
0451 4014B	Tapping Screw - M4x14	11 - 102
0452 3008B	Tapping Screw - M3x8	13 - 109
0452 3008B	Tapping Screw - M3x8	3 - 102
0452 3008B	Tapping Screw - M3x8	5 - 102
0452 3008B	Tapping Screw - M3x8	11 - 105
0632 0100	Parallel Pin - M2x10	7 - 106
0720 0030B	Retaining Ring - M3	9 - 103
0720 0030B	Retaining Ring - M3	7 - 107
0720 0040B	Retaining Ring - M4	13 - 107
0720 0040B	Retaining Ring - M4	11 - 104
0720 0040B	Retaining Ring - M4	9 - 102
0720 0040B	Retaining Ring - M4	7 - 102
0720 0060B	Retaining Ring - M6	11 - 103
0720 0060B	Retaining Ring - M6	7 - 103
0802 5276	Tapping Screw With Washer - M3x6	7 - 101
0951 3006B	Philips Screw With Flat Washer - M3x6	13 - 102
0951 4006B	Philips Screw With Washer - M4x6	13 - 104
1105 0109	Cord Keep	13 - 106
1105 0310	Harness Clamp - LWS-1S	13 - 103
1105 0310	Harness Clamp - LWS-1S	7 - 104
1105 0460	Clamp	13 - 108

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	7 - 4
5053 0447	Bushing - 6mm	11 - 7
5053 0447	Bushing - 6mm	9 - 33
5206 2686	Snap Ring	7 - 28
5206 2686	Snap Ring	13 - 36
5215 2621	Snap Ring - M6	5 - 3
5304 1639	Bushing - 8mm	11 - 6
5304 1639	Bushing - 8mm	13 - 15
5304 1639	Bushing - 8mm	7 - 7
5446 2824	Screw - Duplex Guide Plate	3 - 3
5446 2824	Screw - Duplex Guide Plate	9 - 1
5447 2681	Snap Ring	11 - 12
5447 2681	Snap Ring	13 - 8
5447 2681	Snap Ring	5 - 1
5447 2681	Snap Ring	9 - 32