

DF78 (B616)

DF78 (B616)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior (B616)	2
2.Original Feed Section 1 (B616)	4
3.Original Feed Section 2 (B616)	6
4.Original Transfer And Frame (B616)	8
5.Electrical Section (B616)	10
6.Decals And Documents (B616)	12
Parts Index	15

August ,31 ' 2006


1.Exterior (B616)



Index No.	Part No.	Description	Q'ty Per Assembly
1	B387 6021	Size Indication Decal	1
2	B387 4873	Positioning Plate	2
3	B387 4841	Left Cover	1
4	G564 6077	Decal:Exposure Glass:5-lang	1
5	B387 4640	Front Side Fence	1
6	B387 4656	Rear Side Fence Ass'y	1
7	B387 6033	Decal - Original Table	1
8	B387 6013	Decal - Removal Misfeed	1
9	B387 4605	Upper Original Table	1
10	A859 2352	Pad Pressure Plate	1
11	B387 2310	Guide Plate - Paper Feed	1
12	B387 6053	Original Scale Decal - A4	1
12	B387 6054	Original Scale Decal - LT	1
13	B387 4875	Left Cover Band	1
14	B387 4812	Front Cover	1
15	AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	1
15	5446 2824	Screw - Duplex Guide Plate	1
16	B387 4661	Front Rack - Side Fence	1
17	A859 4665	Gear - 16Z	1
18	B387 4681	Feeler - Original Trailing Edge	1
19	B387 4671	Rear Rack - Side Fence	1
20	AW02 0141	Photointerruptor (RoHs)	1
20	AW02 0075	Photointerruptor	1
21	AW01 0103	Photo Sensor	1
21	AW01 0112	Photo Reflection Sensor:Original TA (RoHs)	1
22	B616 5706	Harness - Original Tray	1
22	B616 5705	O/O	
23	B387 4822	Rear Cover	1
24	B386 7102	Scale:Machine Or Copier:Adhesion	1
25	AC01 3004	Exposure Glass	1
26	A548 6121	Screw - M4	2
27	5206 2686	Snap Ring	1
28	B387 4621	Lower Original Table	1
29	A859 7211	Stepped Screw	2
30	B387 6043	Decal - Fence Side	1

Index No.	Part No.	Description	Q'ty Per Assembly
31	B387 2321	Separation Guide Mylar	1
32	B386 3118	Standard Screw Driver:Document Feed (RoHs)	1
32	A628 3118	Screw Driver - DF	1
101	0450 3008N	Tapping Screw - M3x8	
102	0452 3008N	Tapping Screw - M3x8	
103	0451 3008N	Tapping Screw - M3x8	

2.Original Feed Section 1 (B616)




2.Original Feed Section 1 (B616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B387 2151	Pickup Holder	1
2	B387 2162	Pickup Roller Shaft	1
3	B387 2113	Roller - Paper Feed Belt	1
4	B386 3320	Spring:Belt:Paper Feed:8N (RoHs)	2
4	AA06 3318	Spring - Belt Guide Roller	2
5	A859 2112	Drive Shaft Paper Feed Belt	1
6	B387 2111	Belt Holder	1
7	B387 2133	Pickup Arm	1
8	B387 2131	Rear Feed Guide	1
9	B387 4216	Feed Clutch Shaft	1
10	B387 2120	Shaft - Paper Feed Belt	1
11	B387 2164	Timing Pulley - 20Z	1
12	B387 2163	Pickup Collar	1
13	G412 3831	Pulley - 22Z	1
14	B387 2161	Pickup Roller	1
15	A859 2167	Gear - 22Z	1
16	B387 4872	Original Sensor Feeler	1
17	AA06 3435	Spring - Belt Drive Shaft	1
17	AA06 3315	O/O	
18	B387 2132	Front Feed Guide	1
19	A859 2114	Drive Roller Paper Feed Belt	1
20	A859 2141	Belt Paper Feed	1
21	A859 2121	Gear - 22Z	1
22	B387 1721	Left Lower Guide	1
23	B387 1722	Entrance Guide	1
24	B387 1711	Left Lower Stay	1
25	5447 2681	Snap Ring	2
26	5304 1639	Bushing - 8mm	2
27	B387 3322	Cover - Transport Driven Roller	1
28	B387 3318	Front Pressure Spring	1
29	B387 3311	Transport Driven Roller	1
30	B387 3313	Shaft - Transport Driven Roller	1
31	B387 3319	Rear Pressure Spring	1
32	B387 3321	Spring Cover	1
33	B387 3317	Main Shaft - Transport Driven	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	A859 2166	Timing Belt - 2XL	1
35	AA13 2013	Spacer	2
36	A628 1225	Bushing - 8mm	4
37	5053 0447	Bushing - 6mm	2
38	B387 1712	Center Bracket - Left Lower Stay	1
39	B387 1713	Outer Bracket - Left Lower Stay	2
40	B813 2105	Belt Unit:Paper Feed:Ass'y (RoHs) MB2	1
40	B387 2100	Belt Unit:Paper Feed:Ass'y	1
101	0451 3006N	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0632 0100G	Pin - 2x10mm	
104	0720 0060E	Retaining Ring - M6	
105	0720 0030E	Retaining Ring - M3	
106	0353 0060N	Bind Screw - M3x6	

3.Original Feed Section 2 (B616)




3.Original Feed Section 2 (B616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B387 3130	Exit Roller	1
2	B387 2421	Original Stopper Cam	1
3	B387 2411	Original Stopper	1
4	B387 1671	Reverse Roller	1
5	B387 2250	Torque Limiter - 40MNXM	1
6	B387 2210	Reverse Roller Shaft	1
7	B387 1612	Bracket - Reverse Roller Shaft	1
8	B387 1331	Original Sensor Bracket	1
9	AW02 0141	Photointerruptor (RoHs)	1
9	AW02 0075	Photointerruptor	1
10	AG07 0513	Magnet Catch (RoHs)	2
10	B387 1181	Magnet Catch	2
11	A859 4321	Pulley - 20Z	1
12	B387 4331	Timing Belt - 2XL	1
13	B387 4342	Adjusting Bracket Spring	1
14	B387 4311	Adjusting Bracket	1
15	AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	2
15	5446 2824	Screw - Duplex Guide Plate	2
16	B387 3110	Left Transport Roller	1
17	B387 3225	Discharge Brush	1
18	B387 3220	Guide Plate - Upper Exit	1
19	B386 3513	Guide:Exposure Glass (RoHs)	1
19	A859 3511	Guide Exposure Glass	1
20	B387 3210	Guide Plate - Transport Roller	1
21	B387 4221	Gear - 28Z	1
22	B387 2435	Original Stopper Spring	1
23	B387 2431	Original Stopper Lever	1
24	B387 4271	Coupled Pulley - 20/30Z	1
25	B387 1221	Exit Grounding Plate	1
26	5053 0447	Bushing - 6mm	1
27	A859 2230	Ball Bearing - 6x13x5	2
28	5215 2621	Snap Ring - M6	1
29	5304 1639	Bushing - 8mm	1
30	AW01 0109	Phot Reflection Sensor:PS117ED1 (RoHs)	1
30	AW01 0093	Photo Sensor - PS-117ND1	1

Index No.	Part No.	Description	Q'ty Per Assembly
31	B386 2214	Screw:M3X5 (RoHs)	1
31	A590 2214	Screw - M3X5	1
32	AA14 3790	Screw:Contact Point (RoHs)	1
32	A697 1125	Stepped Screw - Lever	1
33	B387 2220	Reverse Roller Cover	1
101	0451 3006N	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	0720 0050E	Retaining Ring - M5	
105	1105 0516	Clamp	

4.Original Transfer And Frame (B616)




4.Original Transfer And Frame (B616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B387 1322	Spring Plate	2
2	B387 1320	Transport Roller Bracket	1
3	B813 1811	Left Hinge (RoHs)	1
3	B387 1811	Left Hinge	1
4	B387 3411	Exit Guide Plate	1
5	A859 3420	Middle Driven Roller	2
6	B387 3425	Spring Plate	2
7	B387 3120	Right Transport Roller	1
8	B387 3412	Shaft - Exit Guide Plate	1
9	B387 3430	Rear Spring - Exit Guide Plate	1
10	B387 3431	Front Spring - Exit Guide Plate	1
11	B387 1921	Driven Exit Roller	1
12	A859 4836	Bushing Exit Driven Roller	2
13	AA06 3311	Transport Roller Spring	2
14	B813 1831	Right Hinge (RoHs)	1
14	B387 1831	Right Hinge	1
15	B813 1841	Feeler - On Off Detector	1
15	B387 1841	X/O	
16	B387 3410	Cover - Exit Guide Plate	1
17	B387 1912	Base	1
18	B387 1932	Base - Platen Cover	1
19	5053 0447	Bushing - 6mm	1
20	B714 5006	Stamper	1
20	H511 5006	O/O	
21	5447 2681	Snap Ring	2
22	A859 6023	Decal Green	1
23	B387 3657	Pressure Plate Ass'y (RoHs)	1
23	B387 3600	Platen Sheet	1
24	A334 4678	Rack Shield Mylar	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 4008N	Tapping Screw - 4x8	
102	0451 3006N	Tapping Screw - M3x6	
103	0454 3006Q	Tapping Screw - M3x6	
104	0451 3008N	Tapping Screw - M3x8	
105	0720 0040E	Retaining Ring - M4	
106	0452 3008N	Tapping Screw - M3x8	
107	1105 0516	Clamp	

5.Electrical Section (B616)



5. Electrical Section (B616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B813 5700	Harness - Sensor Main (RoHs)	1
1	B616 5700	Harness - Main Sensor	1
2	B616 5520	PCB:Main Control (RoHs)	1
2	B616 5510	PCB Main Control	1
2	B616 5500	X/O	
3	B813 5710	Harness - Magnetic Clutch (RoHs)	1
3	B616 5710	Harness - Paper Feed Clutch	1
4	AW02 0141	Photointerruptor (RoHs)	2
4	AW02 0075	Photointerruptor	2
5	A859 4171	Timing Belt - 2XL	2
6	A661 1884	Pulley - 20T/48T	1
7	B387 4198	Transport Motor Spring	1
8	B387 4111	Transport Motor Bracket	1
9	B813 4125	Stepper Motor Ass'y (RoHs)	1
9	B387 4121	DC Transport Motor	1
10	B813 5800	Harness - Interface (RoHs)	1
10	B387 5800	Interface Harness	1
11	B616 5715	Harness - Sensor Registration	1
12	B813 4421	DC Solenoid Ass'y (RoHs)	1
12	B387 4421	DC Solenoid	1
13	B387 4222	Flange	1
14	B387 4231	Gear/pulley - 20/21Z	1
15	B387 4241	Gear - 20Z	1
16	AX21 0092	Magnetic Clutch:Z30 (RoHs)	1
16	AX21 0071	Electromagnetic Clutch - 30Z	1
17	B387 2355	Pickup Lever	1
18	B387 2375	Pickup Spring	1
19	B387 2365	Stopper Pawl Lever	1
20	B387 1316	Feed Clutch Bracket	1
21	B387 1123	Bracket - Cover Open Sensor	1
22	5304 1639	Bushing - 8mm	1
23	5447 2681	Snap Ring	2
24	B387 4251	Timing Belt -2XL	1
25	5206 2686	Snap Ring	1
26	C101 2360	Snap Ring	1

Index No.	Part No.	Description	Q'ty Per Assembly
27	B387 1941	Feeler - Paper Size Sensor	1
28	B387 1951	Spring - Paper Size Sensor	1
29	B616 5720	Harness - Sensor Original	1
101	0451 3006N	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0951 3006N	Screw - M3x6	
104	0353 0040N	Screw - M3X4	
105	0452 3008N	Tapping Screw - M3x8	
106	1105 0516	Clamp	

6.Decals And Documents (B616)

1

Please clean the part of the contact glass with a soft cloth as shown when you see black lines on a copy image. >PS<

2

>PS<

3

>PS<

A4 A3 B5 B4 A5 A4 F B5 A5 5 1/2 8 8 1/2 10 11

4

>PS<

Face up
Mit der Schriftseite
nach oben
Face imprimée
dessus
Faccia in su
Boca arriba
原稿面上向き
送信面上向き

5

>PS<

A3 A4 B4 B5 A5 A4 F B5 A5 5 1/2 8 8 1/2 10 11

12

6.Decals And Documents (B616)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G564 6077	Decal:Exposure Glass:5-lang	1
2	B387 6013	Decal - Removal Misfeed	1
3	B387 6021	Size Indication Decal	1
4	B387 6033	Decal - Original Table	1
5	B387 6053	Original Scale Decal - A4	1
5	B387 6054	Original Scale Decal - LT	1
6	A859 6023	Decal Green	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
Original Feed Section 1 (B616)	B387 2161	Pick-up Roller	Pickup Roller	1	5- 14
Original Feed Section 1 (B616)	A859 2141	Feed Belt	Belt Paper Feed	1	5- 20
Original Feed Section 2 (B616)	B387 1671	Separation Roller	Reverse Roller	1	7- 4

Parts Index

Part No.	Description	Page and Index No.
B616 5500	X/O	11 - 2
B616 5510	PCB Main Control	11 - 2
B616 5520	PCB:Main Control (RoHs)	11 - 2
B616 5700	Harness - Main Sensor	11 - 1
B616 5705	O/O	3 - 22
B616 5706	Harness - Original Tray	3 - 22
B616 5710	Harness - Paper Feed Clutch	11 - 3
B616 5715	Harness - Sensor Registration	11 - 11
B616 5720	Harness - Sensor Original	11 - 29

Part No.	Description	Page and Index No.
A334 4678	Rack Shield Mylar	9 - 24
A548 6121	Screw - M4	3 - 26
A590 2214	Screw - M3X5	7 - 31
A628 1225	Bushing - 8mm	5 - 36
A628 3118	Screw Driver - DF	3 - 32
A661 1884	Pulley - 20T/48T	11 - 6
A697 1125	Stepped Screw - Lever	7 - 32
A859 2112	Drive Shaft Paper Feed Belt	5 - 5
A859 2114	Drive Roller Paper Feed Belt	5 - 19
A859 2121	Gear - 22Z	5 - 21
A859 2141	Belt Paper Feed	5 - 20
A859 2166	Timing Belt - 2XL	5 - 34
A859 2167	Gear - 22Z	5 - 15
A859 2230	Ball Bearing - 6x13x5	7 - 27
A859 2352	Pad Pressure Plate	3 - 10
A859 3420	Middle Driven Roller	9 - 5
A859 3511	Guide Exposure Glass	7 - 19
A859 4171	Timing Belt - 2XL	11 - 5
A859 4321	Pulley - 20Z	7 - 11
A859 4665	Gear - 16Z	3 - 17
A859 4836	Bushing Exit Driven Roller	9 - 12
A859 6023	Decal Green	13 - 6
A859 6023	Decal Green	9 - 22
A859 7211	Stepped Screw	3 - 29
B386 2214	Screw:M3X5 (RoHs)	7 - 31
B386 3118	Standard Screw Driver:Document Feed (RoHs)	3 - 32
B386 3320	Spring:Belt:Paper Feed:8N (RoHs)	5 - 4
B386 3513	Guide:Exposure Glass (RoHs)	7 - 19
B386 7102	Scale:Machine Or Copier:Adhesion	3 - 24
B387 1123	Bracket - Cover Open Sensor	11 - 21
B387 1181	Magnet Catch	7 - 10
B387 1221	Exit Grounding Plate	7 - 25
B387 1316	Feed Clutch Bracket	11 - 20
B387 1320	Transport Roller Bracket	9 - 2
B387 1322	Spring Plate	9 - 1

Part No.	Description	Page and Index No.
B387 1331	Original Sensor Bracket	7 - 8
B387 1612	Bracket - Reverse Roller Shaft	7 - 7
B387 1671	Reverse Roller	7 - 4
B387 1711	Left Lower Stay	5 - 24
B387 1712	Center Bracket - Left Lower Stay	5 - 38
B387 1713	Outer Bracket - Left Lower Stay	5 - 39
B387 1721	Left Lower Guide	5 - 22
B387 1722	Entrance Guide	5 - 23
B387 1811	Left Hinge	9 - 3
B387 1831	Right Hinge	9 - 14
B387 1841	X/O	9 - 15
B387 1912	Base	9 - 17
B387 1921	Driven Exit Roller	9 - 11
B387 1932	Base - Platen Cover	9 - 18
B387 1941	Feeler - Paper Size Sensor	11 - 27
B387 1951	Spring - Paper Size Sensor	11 - 28
B387 2100	Belt Unit:Paper Feed:Ass'y	5 - 40
B387 2111	Belt Holder	5 - 6
B387 2113	Roller - Paper Feed Belt	5 - 3
B387 2120	Shaft - Paper Feed Belt	5 - 10
B387 2131	Rear Feed Guide	5 - 8
B387 2132	Front Feed Guide	5 - 18
B387 2133	Pickup Arm	5 - 7
B387 2151	Pickup Holder	5 - 1
B387 2161	Pickup Roller	5 - 14
B387 2162	Pickup Roller Shaft	5 - 2
B387 2163	Pickup Collar	5 - 12
B387 2164	Timing Pulley - 20Z	5 - 11
B387 2210	Reverse Roller Shaft	7 - 6
B387 2220	Reverse Roller Cover	7 - 33
B387 2250	Torque Limiter - 40MNXM	7 - 5
B387 2310	Guide Plate - Paper Feed	3 - 11
B387 2321	Separation Guide Mylar	3 - 31
B387 2355	Pickup Lever	11 - 17
B387 2365	Stopper Pawl Lever	11 - 19

Part No.	Description	Page and Index No.
B387 2375	Pickup Spring	11 - 18
B387 2411	Original Stopper	7 - 3
B387 2421	Original Stopper Cam	7 - 2
B387 2431	Original Stopper Lever	7 - 23
B387 2435	Original Stopper Spring	7 - 22
B387 3110	Left Transport Roller	7 - 16
B387 3120	Right Transport Roller	9 - 7
B387 3130	Exit Roller	7 - 1
B387 3210	Guide Plate - Transport Roller	7 - 20
B387 3220	Guide Plate - Upper Exit	7 - 18
B387 3225	Discharge Brush	7 - 17
B387 3311	Transport Driven Roller	5 - 29
B387 3313	Shaft - Transport Driven Roller	5 - 30
B387 3317	Main Shaft - Transport Driven	5 - 33
B387 3318	Front Pressure Spring	5 - 28
B387 3319	Rear Pressure Spring	5 - 31
B387 3321	Spring Cover	5 - 32
B387 3322	Cover - Transport Driven Roller	5 - 27
B387 3410	Cover - Exit Guide Plate	9 - 16
B387 3411	Exit Guide Plate	9 - 4
B387 3412	Shaft - Exit Guide Plate	9 - 8
B387 3425	Spring Plate	9 - 6
B387 3430	Rear Spring - Exit Guide Plate	9 - 9
B387 3431	Front Spring - Exit Guide Plate	9 - 10
B387 3600	Platen Sheet	9 - 23
B387 3657	Pressure Plate Ass'y (RoHs)	9 - 23
B387 4111	Transport Motor Bracket	11 - 8
B387 4121	DC Transport Motor	11 - 9
B387 4198	Transport Motor Spring	11 - 7
B387 4216	Feed Clutch Shaft	5 - 9
B387 4221	Gear - 28Z	7 - 21
B387 4222	Flange	11 - 13
B387 4231	Gear/pulley - 20/21Z	11 - 14
B387 4241	Gear - 20Z	11 - 15
B387 4251	Timing Belt -2XL	11 - 24

Part No.	Description	Page and Index No.
B387 4271	Coupled Pulley - 20/30Z	7 - 24
B387 4311	Adjusting Bracket	7 - 14
B387 4331	Timing Belt - 2XL	7 - 12
B387 4342	Adjusting Bracket Spring	7 - 13
B387 4421	DC Solenoid	11 - 12
B387 4605	Upper Original Table	3 - 9
B387 4621	Lower Original Table	3 - 28
B387 4640	Front Side Fence	3 - 5
B387 4656	Rear Side Fence Ass'y	3 - 6
B387 4661	Front Rack - Side Fence	3 - 16
B387 4671	Rear Rack - Side Fence	3 - 19
B387 4681	Feeler - Original Trailing Edge	3 - 18
B387 4812	Front Cover	3 - 14
B387 4822	Rear Cover	3 - 23
B387 4841	Left Cover	3 - 3
B387 4872	Original Sensor Feeler	5 - 16
B387 4873	Positioning Plate	3 - 2
B387 4875	Left Cover Band	3 - 13
B387 5800	Interface Harness	11 - 10
B387 6013	Decal - Removal Misfeed	13 - 2
B387 6013	Decal - Removal Misfeed	3 - 8
B387 6021	Size Indication Decal	13 - 3
B387 6021	Size Indication Decal	3 - 1
B387 6033	Decal - Original Table	3 - 7
B387 6033	Decal - Original Table	13 - 4
B387 6043	Decal - Fence Side	3 - 30
B387 6053	Original Scale Decal - A4	3 - 12
B387 6053	Original Scale Decal - A4	13 - 5
B387 6054	Original Scale Decal - LT	3 - 12
B387 6054	Original Scale Decal - LT	13 - 5
B714 5006	Stamper	9 - 20
B813 1811	Left Hinge (RoHs)	9 - 3
B813 1831	Right Hinge (RoHs)	9 - 14
B813 1841	Feeler - On Off Detector	9 - 15
B813 2105	Belt Unit:Paper Feed:Ass'y (RoHs) MB2	5 - 40

Part No.	Description	Page and Index No.
B813 4125	Stepper Motor Ass'y (RoHs)	11 - 9
B813 4421	DC Solenoid Ass'y (RoHs)	11 - 12
B813 5700	Harness - Sensor Main (RoHs)	11 - 1
B813 5710	Harness - Magnetic Clutch (RoHs)	11 - 3
B813 5800	Harness - Interface (RoHs)	11 - 10
C101 2360	Snap Ring	11 - 26
G412 3831	Pulley - 22Z	5 - 13
G564 6077	Decal:Exposure Glass:5-lang	13 - 1
G564 6077	Decal:Exposure Glass:5-lang	3 - 4
H511 5006	O/O	9 - 20

Part No.	Description	Page and Index No.
AA06 3311	Transport Roller Spring	9 - 13
AA06 3315	O/O	5 - 17
AA06 3318	Spring - Belt Guide Roller	5 - 4
AA06 3435	Spring - Belt Drive Shaft	5 - 17
AA13 2013	Spacer	5 - 35
AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	3 - 15
AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	7 - 15
AA14 3790	Screw:Contact Point (RoHs)	7 - 32
AC01 3004	Exposure Glass	3 - 25
AG07 0513	Magnet Catch (RoHs)	7 - 10
AW01 0093	Photo Sensor - PS-117ND1	7 - 30
AW01 0103	Photo Sensor	3 - 21
AW01 0109	Phot Reflection Sensor:PS117ED1 (RoHs)	7 - 30
AW01 0112	Photo Reflection Sensor:Original TA (RoHs)	3 - 21
AW02 0075	Photointerruptor	3 - 20
AW02 0075	Photointerruptor	11 - 4
AW02 0075	Photointerruptor	7 - 9
AW02 0141	Photointerruptor (RoHs)	11 - 4
AW02 0141	Photointerruptor (RoHs)	7 - 9
AW02 0141	Photointerruptor (RoHs)	3 - 20
AX21 0071	Electromagnetic Clutch - 30Z	11 - 16
AX21 0092	Magnetic Clutch:Z30 (RoHs)	11 - 16

Part No.	Description	Page and Index No.
0353 0040N	Screw - M3X4	11 -104
0353 0060N	Bind Screw - M3x6	5 -106
0450 3008N	Tapping Screw - M3x8	3 -101
0450 4008N	Tapping Screw - 4x8	9 -101
0451 3006N	Tapping Screw - M3x6	11 -101
0451 3006N	Tapping Screw - M3x6	5 -101
0451 3006N	Tapping Screw - M3x6	9 -102
0451 3006N	Tapping Screw - M3x6	7 -101
0451 3008N	Tapping Screw - M3x8	3 -103
0451 3008N	Tapping Screw - M3x8	9 -104
0452 3008N	Tapping Screw - M3x8	9 -106
0452 3008N	Tapping Screw - M3x8	11 -105
0452 3008N	Tapping Screw - M3x8	3 -102
0454 3006Q	Tapping Screw - M3x6	9 -103
0632 0100G	Pin - 2x10mm	5 -103
0720 0030E	Retaining Ring - M3	5 -105
0720 0040E	Retaining Ring - M4	7 -102
0720 0040E	Retaining Ring - M4	9 -105
0720 0040E	Retaining Ring - M4	5 -102
0720 0040E	Retaining Ring - M4	11 -102
0720 0050E	Retaining Ring - M5	7 -104
0720 0060E	Retaining Ring - M6	7 -103
0720 0060E	Retaining Ring - M6	5 -104
0951 3006N	Screw - M3x6	11 -103
1105 0516	Clamp	11 -106
1105 0516	Clamp	7 -105
1105 0516	Clamp	9 -107

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	5 - 37
5053 0447	Bushing - 6mm	9 - 19
5053 0447	Bushing - 6mm	7 - 26
5206 2686	Snap Ring	11 - 25
5206 2686	Snap Ring	3 - 27
5215 2621	Snap Ring - M6	7 - 28
5304 1639	Bushing - 8mm	5 - 26
5304 1639	Bushing - 8mm	7 - 29
5304 1639	Bushing - 8mm	11 - 22
5446 2824	Screw - Duplex Guide Plate	7 - 15
5446 2824	Screw - Duplex Guide Plate	3 - 15
5447 2681	Snap Ring	5 - 25
5447 2681	Snap Ring	9 - 21
5447 2681	Snap Ring	11 - 23

Part No.	Description	Page and Index No.