

DF79 (B617)

DF79 (B617)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.ARDF 1 (B617)	2
2.ARDF 2 (B617)	4
3.ARDF 3 (B617)	6
4.ARDF 4 (B617)	8
5.ARDF 5 (B617)	10
6.ARDF 6 (B617)	12
7.ARDF 7 (B617)	14
8.DECAL AND DOCUMENT (B617)	16
PARTS INDEX.....	19

August ,31 ' 2006

1.ARDF 1 (B617)




1.ARDF 1 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 4811	Front Cover	1
2	B714 3115	Knob Screw:Document Feeder:Fix (RoHs)	2
2	A628 3115	Knob Screw - M4	2
3	AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	2
3	5446 2824	Screw - Duplex Guide Plate	2
4	B386 4873	Positioning Plate	2
5	A859 4871	Actuator - Original Sensor	1
6	A859 4872	Actuator Bracket	1
7	A859 4881	Cushion Paper Feed	1
8	B386 4842	Left Cover	1
9	B386 6014	Decal - Removal Misfeed	1
10	B387 6021	Size Indication Decal	1
11	AA06 3311	Transport Roller Spring	2
12	A859 4836	Bushing Exit Driven Roller	2
13	A859 4837	Exit Driven Roller	1
14	B386 4871	Upper Cover	1
15	B386 4821	Rear Cover	1
16	B386 7102	Scale:Machine Or Copier:Adhesion	1
17	AC01 3004	Exposure Glass	1
18	A859 7211	Stepped Screw	2
19	G564 6077	Decal:Exposure Glass:5-lang	1
20	B387 6053	Original Scale Decal - A4	1
20	B387 6054	Original Scale Decal - LT	1
21	B386 4874	Cover Sponge:Front (RoHs)	1
21	A858 4871	Cover Sponge - Front	1
22	B386 4872	Cover Sponge:Front Right (RoHs)	1
22	A858 4872	Cover Sponge - Front Right	1
23	B386 3118	Standard Screw Driver:Document Feed (RoHs)	1
23	A628 3118	Screw Driver - DF	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - M3x6	
102	0452 3008N	Tapping Screw - M3x8	
103	0451 3008N	Tapping Screw - M3x8	

2.ARDF 2 (B617)




2.ARDF 2 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5447 2681	Snap Ring	1
2	H060 2126	Bushing - M6x7	2
3	5215 2621	Snap Ring - M6	1
4	A859 2355	Lever Pressure Plate	1
5	B386 4651	Inner Back Side Fence Ass'y	1
6	A859 2311	Guide Plate Paper Feed	1
7	B386 4631	Lower Original Table	1
8	A859 2319	Cushion Base	2
9	A859 2317	Guide Separation Pad	1
10	A859 2315	Separation Pad	1
11	AW02 0141	Photointerruptor (RoHs)	2
11	AW02 0075	Photointerruptor	2
12	B617 5720	Harness - Registration Sensor	1
13	B386 2353	Pressure Plate - Base	1
14	A859 2354	Shaft Base	1
15	A859 4876	Cushion Left	1
16	A859 2352	Pad Pressure Plate	1
17	B386 2351	Original Feed Plate	1
18	A858 4681	Sheet - Paper Tray	2
19	A351 4951	Left Side Guide Pad	4
20	B386 4641	Front Side Fence Ass'y	1
21	B386 6043	Decal - Side Fence	1
22	G012 1531	Magnet	2
23	B387 6033	Decal - Original Table	1
24	B386 4621	Upper Original Table	1
25	A859 4662	Rack - Rear Side Fence	1
26	A859 4663	Electrode Plate - Side Fence	1
27	A859 4665	Gear - 16Z	1
28	A859 4661	Rack - Front Side Fence	1
29	B617 5715	Harness - Original Tray	1
30	B386 5550	Paper Size Sensor Board	1
31	AW01 0112	Photo Reflection Sensor:Original TA (RoHs)	3
31	AW01 0087	Photo Sensor - Ass'y	3
32	A859 2356	Cushion - Base Bottom	4

Index No.	Part No.	Description	Q'ty Per Assembly
33	A858 6022	Decal - Blue	2
34	A858 2319	Feeler - Reverse	1
35	B617 5706	Harness - Reverse Sensor	1
36	A858 2313	Spring Plate Pressure Roller Feed	4
37	A858 4671	Roller Driven	8
38	A858 4676	Spring Plate Pressure Roller	4
39	A859 4664	Sheet - Paper Size Sensor Board	1
40	B386 4693	Mylar Seal	1
41	B386 4692	Mylar Seal - 16x45	1
42	B386 4691	Mylar Seal - 28x107	1
101	0451 3006N	Tapping Screw - M3x6	
102	0452 3008N	Tapping Screw - M3x8	
103	0450 3008N	Tapping Screw - M3x8	

3.ARDF 3 (B617)




3.ARDF 3 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 2220	Cover Reverse Roller	1
2	A859 2241	Reverse Roller	1
3	A294 6700	Torque Limiter - 53mnm	1
4	5053 0447	Bushing - 6mm	1
5	A859 1621	Separation Guide	1
6	B386 1610	Separation Stay	1
7	5304 1639	Bushing - 8mm	2
8	A859 2230	Ball Bearing - 6x13x5	1
9	AW02 0141	Photointerruptor (RoHs)	1
9	AW02 0075	Photointerruptor	1
10	B386 1123	Sensor Bracket	1
11	AA13 2013	Spacer	2
12	AA06 3315	Spring - Belt Drive Shaft	1
12	AA06 3315	O/O	
13	A859 2132	Front Guide - Paper Feed	1
14	A628 1225	Bushing - 8mm	4
15	A859 2141	Belt Paper Feed	1
16	A859 2114	Drive Roller - Paper Feed Belt	1
17	A859 2121	Gear - 22Z	1
18	A859 2131	Rear Guide - Paper Feed	1
19	A859 2120	Drive Shaft - Paper Feed Belt	1
20	A859 2110	Belt Holder	1
21	B386 3320	Spring:Belt:Paper Feed:8N (RoHs)	2
21	AA06 3318	Spring - Belt Guide Roller	2
22	A859 2112	Drive Shaft - Paper Feed Belt	1
23	B387 2113	Roller - Paper Feed Belt	1
24	A859 2162	Shaft - Pick Up Roller	1
25	G412 3821	Holder - Pick Up	1
26	A859 2167	Gear - 22Z	1
27	G412 3831	Pulley - 22Z	1
28	5206 2686	Snap Ring	1
29	B386 2171	Pickup Roller	1
30	A859 2163	Collar Pick Up	1
31	A859 2164	Pulley - 2Z	1
32	A859 2166	Timing Belt - 2XL	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	A859 4216	Shaft - Electromagnetic Clutch	1
34	A859 2210	Shaft - Reverse Roller	1
35	A858 4231	Gear - 20Z	1
36	A859 4222	Flange - Pulley	1
37	A858 4221	Gear - 31Z	1
38	B386 2105	Belt Unit:Paper Feed:Ass'y (RoHs) MB1	1
38	A859 2100	Belt Unit Paper Feed	1
101	0454 3006Q	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	1105 0109	Cord Keep	
105	0451 3006N	Tapping Screw - M3x6	
106	0632 0100G	Pin - 2x10mm	
107	0720 0030E	Retaining Ring - M3	
108	1106 0193	Bushing - 7.9mm	

4.ARDF 4 (B617)




4.A RDF 4 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	2
1	5446 2824	Screw - Duplex Guide Plate	2
2	A859 4331	Timing Belt - 2XL	1
3	AA14 3790	Screw:Contact Point (RoHs)	1
3	A697 1125	Stepped Screw - Lever	1
4	A859 4341	Tension Spring	1
5	AG07 0513	Magnet Catch (RoHs)	2
5	B351 4135	Magnet Catch - Original Table	2
6	A859 3317	Shaft - Contact Point	1
7	B386 3321	Torsion Spring:Pressure:Rear:20N (RoHs)	1
7	A859 3318	Torsion Spring Front	1
8	A859 3316	Lever - Pullout	1
9	B386 3322	Torsion Spring:Pressure:Front:20N (RoHs)	1
9	A859 3319	Torsion Spring - Rear	1
10	A859 3311	Transport Driven Roller	1
11	A859 3313	Driven Shaft - Pressure	1
12	B386 4881	Left Lower Cover	1
13	B386 4856	Cover - Transport Driven Roller	1
14	A859 1723	Left Lower Guide	1
15	A859 1722	Entrance Guide	1
16	B386 1710	Left Lower Stay	1
17	B386 3513	Guide:Exposure Glass (RoHs)	1
17	A859 3511	Guide - Exposure Glass	1
18	B386 3130	Exit Roller - Drive	1
19	A859 2230	Ball Bearing - 6x13x5	2
20	A859 4271	Pulley - 31/32Z	1
21	A859 4272	Flange	1
22	B386 2214	Screw:M3X5 (RoHs)	1
22	A590 2214	Screw - M3x5	1
23	A858 4392	Torque Limiter	1
24	A858 3710	Exchange Powl - Reverse	1
25	A859 3225	Discharge Brush	1
26	B386 4861	Reverse Tray	1
27	B386 3140	Reverse Roller - Drive	1
28	A859 4321	Pulley-20Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
29	B386 4311	Adjusting Pin - M6	1
30	A858 3717	Tension Spring - Exchange Powl	1
31	A858 3715	Lever - Exchange Powl	1
32	5053 0447	Bushing - 6mm	1
33	5447 2681	Snap Ring	1
101	0451 3006N	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0720 0030E	Retaining Ring - M3	

5.ARDF 5 (B617)




5.ARDF 5 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 3210	Guide Plate - Transport Roller	1
2	A859 1322	Spring Plate	2
3	AW01 0109	Phot Reflection Sensor:PS117ED1 (RoHs)	2
3	AW01 0093	Photo Sensor - PS-117ND1	2
4	B617 5705	Harness - Sensor	2
5	B386 1311	Left Stay	1
6	5304 1639	Bushing - 8mm	1
7	5053 0447	Bushing - 6mm	1
8	B386 1320	Bracket - Transport Roller	1
9	A859 3110	Transport Roller	1
10	B386 3121	Transport Roller - Middle	1
11	A859 3431	Spring Front	1
12	5447 2681	Snap Ring	2
13	A859 3220	Guide Plate - Upper Exit	1
14	A859 3430	Spring Rear	1
15	A859 3411	Exit Guide Plate	1
16	A859 6023	Decal Green	1
17	A859 3412	Shaft - Exit Guide Plate	2
18	A859 3420	Middle Driven Roller	2
19	A859 3425	Spring Plate	2
20	B714 5006	Stamper	1
20	H511 5006	O/O	
21	B386 3413	Cover - Exit Guide Plate	1
22	B386 3234	Guide Plate:Reverse:Ass'y (RoHs)	1
22	B386 3231	Reverse Guide Plate	1
23	A858 3236	Discharge Brush L50	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - M3x6	
102	0451 4014N	Tapping Screw:M4x14	
103	0720 0060E	Retaining Ring - M6	
104	0720 0040E	Retaining Ring - M4	
105	1106 0193	Bushing - 7.9mm	
106	0452 3008N	Tapping Screw - M3x8	

6.ARDF 6 (B617)




6.ARDF 6 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C682 5800	Harness - Interface (RoHs)	1
1	B379 5800	Harness - Interface	1
2	B386 5700	Harness:Sensor:Main (RoHs)	1
2	B617 5700	Harness - Main Sensor	1
3	B386 1832	Hinge:Right:Ass'y	1
3	B386 1831	O/O	1
4	A859 1841	Filler - DF Open Sensor	1
5	A334 4678	Rack Shield Mylar	1
6	B386 1123	Sensor Bracket (RoHs)	1
6	B386 1122	Right Sensor Bracket	1
7	AW02 0141	Photointerruptor (RoHs)	1
7	AW02 0075	Photointerruptor	1
8	B617 5520	PCB:Main Control (RoHs)	1
8	B617 5500	PCB Main Control	1
9	A858 5707	Transport Motor Harness	1
10	B386 4421	DC Solenoid:Base:Ass'y (RoHs)	1
10	A859 4421	DC Solenoid	1
11	A028 3264	Stopper Cushion	1
12	B386 4411	Solenoid Bracket	1
13	5206 2686	Snap Ring	1
14	B814 4121	Stepper Motor - DC2.4W (RoHs)	2
14	A859 4121	Stepper Motor - DC6.2W	2
15	A661 1884	Pulley - 20T/48T	2
16	A859 4171	Timing Belt - 2XL	3
17	A859 1131	Insulating Sheet	1
18	5304 1639	Bushing - 8mm	1
19	B386 1315	Bracket - Electromagnetic Clutch	1
20	AX21 0092	Magnetic Clutch:Z30 (RoHs)	1
20	AX21 0071	Electromagnetic Clutch - 30z	1
21	B379 4111	Bracket - Motor	1
22	B386 1812	Hinge:Left:Ass'y	1
22	B386 1811	O/O	1
23	A859 4197	Tension Spring Motor	1
24	B386 1125	APS Feeller	1
25	A859 2358	Solenoid Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
26	C682 5703	Harness:Stepper Motor (RoHs)	1
26	B617 5703	Harness - Paper Feed Motor	1
27	B386 5701	Harness:Sensor:Exit:Connecting (RoHs)	1
27	B617 5701	Harness - Exit Sensor	1
28	B379 4131	Adjusting Pin - Idler	1
29	A859 4141	Pulley - Idler	1
30	A858 4251	Coupled Pulley - 20/32Z	1
31	A858 4261	Timing Belt - 2XL	1
32	A858 4134	Tension Spring - Idler	1
33	A858 4181	Timing Belt - 2XL	1
34	5447 2681	Snap Ring	1
35	A858 4431	DC Solenoid - 24V	1
36	B387 1951	Spring - Paper Size Sensor	1
37	B386 1121	APS Feeller Bracket	1
38	B386 5713	Harness:Original Tray:Connecting (RoHs)	1
38	B617 5713	Harness - Original Tray	1
101	0451 3006N	Tapping Screw - M3x6	
102	0451 4006N	Tapping Screw - 4x6	
103	0951 3006N	Screw - M3x6	
104	0720 0040E	Retaining Ring - M4	
105	1105 0487	Harness Clamp	
106	0452 3008N	Tapping Screw - M3x8	
107	0353 0040N	Screw - M3X4	

7.ARDF 7 (B617)



7.ARDF 7 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 1221	Spacer	2
2	G412 3721	Platen Cover Sheet	1
3	B386 1511	Middle Stay	2
4	B617 3614	Sponge:Left Pressure Plate (RoHs)	1
4	A859 3614	Sponge Left Platen Cover	1
5	B617 3613	Sponge - Pressure Plate (RoHs)	3
5	A859 3613	Sponge Platen Cover	3
6	B386 3615	Base - Platen Cover	1
7	B386 1211	Front Side Plate	1
8	B386 1110	Rear Side Plate	1
9	B386 3617	Platen Sheet Mylar	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - M3x6	

8.DECAL AND DOCUMENT (B617)

1	2		
3 Please clean the part of the contact glass with a soft cloth as shown when you see black lines on a copy image. >PS<	4		
5 >PS<	6 >PS<	7	8

8.DECAL AND DOCUMENT (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 6014	Decal - Removal Misfeed	1
2	B387 6021	Size Indication Decal	1
3	G564 6077	Decal:Exposure Glass:5-lang	1
4	B387 6053	Original Scale Decal - A4	1
4	B387 6054	Original Scale Decal - LT	1
5	B386 6043	Decal - Side Fence	1
6	B387 6033	Decal - Original Table	1
7	A858 6022	Decal Blue	2
8	A859 6023	Decal Green	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
ARDF 3 (B617)	A859 2141	Feed Belt	Belt Paper Feed	1	7- 15
ARDF 3 (B617)	A859 2241	Separation Belt	Reverse Roller	1	7- 2
ARDF 3 (B617)	B386 2171	Pickup Roller	Pickup Roller	1	7- 29

Parts Index

Part No.	Description	Page and Index No.
B617 3613	Sponge - Pressure Plate (RoHs)	15 - 5
B617 3614	Sponge:Left Pressure Plate (RoHs)	15 - 4
B617 5500	PCB Main Control	13 - 8
B617 5520	PCB:Main Control (RoHs)	13 - 8
B617 5700	Harness - Main Sensor	13 - 2
B617 5701	Harness - Exit Sensor	13 - 27
B617 5703	Harness - Paper Feed Motor	13 - 26
B617 5705	Harness - Sensor	11 - 4
B617 5706	Harness - Reverse Sensor	5 - 35
B617 5713	Harness - Original Tray	13 - 38
B617 5715	Harness - Original Tray	5 - 29
B617 5720	Harness - Registration Sensor	5 - 12

Part No.	Description	Page and Index No.
A028 3264	Stopper Cushion	13 - 11
A294 6700	Torque Limiter - 53mnm	7 - 3
A334 4678	Rack Shield Mylar	13 - 5
A351 4951	Left Side Guide Pad	5 - 19
A590 2214	Screw - M3x5	9 - 22
A628 1225	Bushing - 8mm	7 - 14
A628 3115	Knob Screw - M4	3 - 2
A628 3118	Screw Driver - DF	3 - 23
A661 1884	Pulley - 20T/48T	13 - 15
A697 1125	Stepped Screw - Lever	9 - 3
A858 2313	Spring Plate Pressure Roller Feed	5 - 36
A858 2319	Feeler - Reverse	5 - 34
A858 3236	Discharge Brush L50	11 - 23
A858 3710	Exchange Powl - Reverse	9 - 24
A858 3715	Lever - Exchange Powl	9 - 31
A858 3717	Tension Spring - Exchange Powl	9 - 30
A858 4134	Tension Spring - Idler	13 - 32
A858 4181	Timing Belt - 2XL	13 - 33
A858 4221	Gear - 31Z	7 - 37
A858 4231	Gear - 20Z	7 - 35
A858 4251	Coupled Pulley - 20/32Z	13 - 30
A858 4261	Timing Belt - 2XL	13 - 31
A858 4392	Torque Limiter	9 - 23
A858 4431	DC Solenoid - 24V	13 - 35
A858 4671	Roller Driven	5 - 37
A858 4676	Spring Plate Pressure Roller	5 - 38
A858 4681	Sheet - Paper Tray	5 - 18
A858 4871	Cover Sponge - Front	3 - 21
A858 4872	Cover Sponge - Front Right	3 - 22
A858 5707	Transport Motor Harness	13 - 9
A858 6022	Decal Blue	17 - 7
A858 6022	Decal - Blue	5 - 33
A859 1131	Insulating Sheet	13 - 17
A859 1221	Spacer	15 - 1
A859 1322	Spring Plate	11 - 2

Part No.	Description	Page and Index No.
A859 1621	Separation Guide	7 - 5
A859 1722	Entrance Guide	9 - 15
A859 1723	Left Lower Guide	9 - 14
A859 1841	Filler - DF Open Sensor	13 - 4
A859 2100	Belt Unit Paper Feed	7 - 38
A859 2110	Belt Holder	7 - 20
A859 2112	Drive Shaft - Paper Feed Belt	7 - 22
A859 2114	Drive Roller - Paper Feed Belt	7 - 16
A859 2120	Drive Shaft - Paper Feed Belt	7 - 19
A859 2121	Gear - 22Z	7 - 17
A859 2131	Rear Guide - Paper Feed	7 - 18
A859 2132	Front Guide - Paper Feed	7 - 13
A859 2141	Belt Paper Feed	7 - 15
A859 2162	Shaft - Pick Up Roller	7 - 24
A859 2163	Collar Pick Up	7 - 30
A859 2164	Pulley - 2Z	7 - 31
A859 2166	Timing Belt - 2XL	7 - 32
A859 2167	Gear - 22Z	7 - 26
A859 2210	Shaft - Reverse Roller	7 - 34
A859 2220	Cover Reverse Roller	7 - 1
A859 2230	Ball Bearing - 6x13x5	9 - 19
A859 2230	Ball Bearing - 6x13x5	7 - 8
A859 2241	Reverse Roller	7 - 2
A859 2311	Guide Plate Paper Feed	5 - 6
A859 2315	Separation Pad	5 - 10
A859 2317	Guide Separation Pad	5 - 9
A859 2319	Cushion Base	5 - 8
A859 2352	Pad Pressure Plate	5 - 16
A859 2354	Shaft Base	5 - 14
A859 2355	Lever Pressure Plate	5 - 4
A859 2356	Cushion - Base Bottom	5 - 32
A859 2358	Solenoid Spring	13 - 25
A859 3110	Transport Roller	11 - 9
A859 3210	Guide Plate - Transport Roller	11 - 1
A859 3220	Guide Plate - Upper Exit	11 - 13

Part No.	Description	Page and Index No.
A859 3225	Discharge Brush	9 - 25
A859 3311	Transport Driven Roller	9 - 10
A859 3313	Driven Shaft - Pressure	9 - 11
A859 3316	Lever - Pullout	9 - 8
A859 3317	Shaft - Contact Point	9 - 6
A859 3318	Torsion Spring Front	9 - 7
A859 3319	Torsion Spring - Rear	9 - 9
A859 3411	Exit Guide Plate	11 - 15
A859 3412	Shaft - Exit Guide Plate	11 - 17
A859 3420	Middle Driven Roller	11 - 18
A859 3425	Spring Plate	11 - 19
A859 3430	Spring Rear	11 - 14
A859 3431	Spring Front	11 - 11
A859 3511	Guide - Exposure Glass	9 - 17
A859 3613	Sponge Platen Cover	15 - 5
A859 3614	Sponge Left Platen Cover	15 - 4
A859 4121	Stepper Motor - DC6.2W	13 - 14
A859 4141	Pulley - Idler	13 - 29
A859 4171	Timing Belt - 2XL	13 - 16
A859 4197	Tension Spring Motor	13 - 23
A859 4216	Shaft - Electromagnetic Clutch	7 - 33
A859 4222	Flange - Pulley	7 - 36
A859 4271	Pulley - 31/32Z	9 - 20
A859 4272	Flange	9 - 21
A859 4321	Pulley-20Z	9 - 28
A859 4331	Timing Belt - 2XL	9 - 2
A859 4341	Tension Spring	9 - 4
A859 4421	DC Solenoid	13 - 10
A859 4661	Rack - Front Side Fence	5 - 28
A859 4662	Rack - Rear Side Fence	5 - 25
A859 4663	Electrode Plate - Side Fence	5 - 26
A859 4664	Sheet - Paper Size Sensor Board	5 - 39
A859 4665	Gear - 16Z	5 - 27
A859 4836	Bushing Exit Driven Roller	3 - 12
A859 4837	Exit Driven Roller	3 - 13

Part No.	Description	Page and Index No.
A859 4871	Actuator - Original Sensor	3 - 5
A859 4872	Actuator Bracket	3 - 6
A859 4876	Cushion Left	5 - 15
A859 4881	Cushion Paper Feed	3 - 7
A859 6023	Decal Green	17 - 8
A859 6023	Decal Green	11 - 16
A859 7211	Stepped Screw	3 - 18
B351 4135	Magnet Catch - Original Table	9 - 5
B379 4111	Bracket - Motor	13 - 21
B379 4131	Adjusting Pin - Idler	13 - 28
B379 5800	Harness - Interface	13 - 1
B386 1110	Rear Side Plate	15 - 8
B386 1121	APS Feeller Bracket	13 - 37
B386 1122	Right Sensor Bracket	13 - 6
B386 1123	Sensor Bracket	7 - 10
B386 1123	Sensor Bracket (RoHs)	13 - 6
B386 1125	APS Feeller	13 - 24
B386 1211	Front Side Plate	15 - 7
B386 1311	Left Stay	11 - 5
B386 1315	Bracket - Electromagnetic Clutch	13 - 19
B386 1320	Bracket - Transport Roller	11 - 8
B386 1511	Middle Stay	15 - 3
B386 1610	Separation Stay	7 - 6
B386 1710	Left Lower Stay	9 - 16
B386 1811	O/O	13 - 22
B386 1812	Hinge:Left:Ass'y	13 - 22
B386 1831	O/O	13 - 3
B386 1832	Hinge:Right:Ass'y	13 - 3
B386 2105	Belt Unit:Paper Feed:Ass'y (RoHs) MB1	7 - 38
B386 2171	Pickup Roller	7 - 29
B386 2214	Screw:M3X5 (RoHs)	9 - 22
B386 2351	Original Feed Plate	5 - 17
B386 2353	Pressure Plate - Base	5 - 13
B386 3118	Standard Screw Driver:Document Feed	3 - 23
B386 3121	Transport Roller - Middle	11 - 10

Part No.	Description	Page and Index No.
B386 3130	Exit Roller - Drive	9 - 18
B386 3140	Reverse Roller - Drive	9 - 27
B386 3231	Reverse Guide Plate	11 - 22
B386 3234	Guide Plate:Reverse:Ass'y (RoHs)	11 - 22
B386 3320	Spring:Belt:Paper Feed:8N (RoHs)	7 - 21
B386 3321	Torsion Spring:Pressure:Rear:20N (RoHs)	9 - 7
B386 3322	Torsion Spring:Pressure:Front:20N (RoHs)	9 - 9
B386 3413	Cover - Exit Guide Plate	11 - 21
B386 3513	Guide:Exposure Glass (RoHs)	9 - 17
B386 3615	Base - Platen Cover	15 - 6
B386 3617	Platen Sheet Mylar	15 - 9
B386 4311	Adjusting Pin - M6	9 - 29
B386 4411	Solenoid Bracket	13 - 12
B386 4421	DC Solenoid:Base:Ass'y (RoHs)	13 - 10
B386 4621	Upper Original Table	5 - 24
B386 4631	Lower Original Table	5 - 7
B386 4641	Front Side Fence Ass'y	5 - 20
B386 4651	Inner Back Side Fence Ass'y	5 - 5
B386 4691	Mylar Seal - 28x107	5 - 42
B386 4692	Mylar Seal - 16x45	5 - 41
B386 4693	Mylar Seal	5 - 40
B386 4811	Front Cover	3 - 1
B386 4821	Rear Cover	3 - 15
B386 4842	Left Cover	3 - 8
B386 4856	Cover - Transport Driven Roller	9 - 13
B386 4861	Reverse Tray	9 - 26
B386 4871	Upper Cover	3 - 14
B386 4872	Cover Sponge:Front Right (RoHs)	3 - 22
B386 4873	Positioning Plate	3 - 4
B386 4874	Cover Sponge:Front (RoHs)	3 - 21
B386 4881	Left Lower Cover	9 - 12
B386 5550	Paper Size Sensor Board	5 - 30
B386 5700	Harness:Sensor:Main (RoHs)	13 - 2
B386 5701	Harness:Sensor:Exit:Connecting (RoHs)	13 - 27
B386 5713	Harness:Original Tray:Connecting (RoHs)	13 - 38

Part No.	Description	Page and Index No.
B386 6014	Decal - Removal Misfeed	3 - 9
B386 6014	Decal - Removal Misfeed	17 - 1
B386 6043	Decal - Side Fence	17 - 5
B386 6043	Decal - Side Fence	5 - 21
B386 7102	Scale:Machine Or Copier:Adhesion	3 - 16
B387 1951	Spring - Paper Size Sensor	13 - 36
B387 2113	Roller - Paper Feed Belt	7 - 23
B387 6021	Size Indication Decal	3 - 10
B387 6021	Size Indication Decal	17 - 2
B387 6033	Decal - Original Table	5 - 23
B387 6033	Decal - Original Table	17 - 6
B387 6053	Original Scale Decal - A4	3 - 20
B387 6053	Original Scale Decal - A4	17 - 4
B387 6054	Original Scale Decal - LT	3 - 20
B387 6054	Original Scale Decal - LT	17 - 4
B714 3115	Knob Screw:Document Feeder:Fix (RoHs)	3 - 2
B714 5006	Stamper	11 - 20
B814 4121	Stepper Motor - DC2.4W (RoHs)	13 - 14
C682 5703	Harness:Stepper Motor (RoHs)	13 - 26
C682 5800	Harness - Interface (RoHs)	13 - 1
G012 1531	Magnet	5 - 22
G412 3721	Platen Cover Sheet	15 - 2
G412 3821	Holder - Pick Up	7 - 25
G412 3831	Pulley - 22Z	7 - 27
G564 6077	Decal:Exposure Glass:5-lang	17 - 3
G564 6077	Decal:Exposure Glass:5-lang	3 - 19
H060 2126	Bushing - M6x7	5 - 2
H511 5006	O/O	11 - 20

Part No.	Description	Page and Index No.
AA06 3311	Transport Roller Spring	3 - 11
AA06 3315	O/O	7 - 12
AA06 3315	Spring - Belt Drive Shaft	7 - 12
AA06 3318	Spring - Belt Guide Roller	7 - 21
AA13 2013	Spacer	7 - 11
AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	9 - 1
AA14 3788	Pin:Guide Plate:Paper Feed (RoHs)	3 - 3
AA14 3790	Screw:Contact Point (RoHs)	9 - 3
AC01 3004	Exposure Glass	3 - 17
AG07 0513	Magnet Catch (RoHs)	9 - 5
AW01 0087	Photo Sensor - Ass'y	5 - 31
AW01 0093	Photo Sensor - PS-117ND1	11 - 3
AW01 0109	Phot Reflection Sensor:PS117ED1 (RoHs)	11 - 3
AW01 0112	Photo Reflection Sensor:Original TA	5 - 31
AW02 0075	Photointerruptor	7 - 9
AW02 0075	Photointerruptor	5 - 11
AW02 0075	Photointerruptor	13 - 7
AW02 0141	Photointerruptor (RoHs)	7 - 9
AW02 0141	Photointerruptor (RoHs)	5 - 11
AW02 0141	Photointerruptor (RoHs)	13 - 7
AX21 0071	Electromagnetic Clutch - 30z	13 - 20
AX21 0092	Magnetic Clutch:Z30 (RoHs)	13 - 20

Part No.	Description	Page and Index No.
0353 0040N	Screw - M3X4	13 -107
0450 3008N	Tapping Screw - M3x8	5 -103
0451 3006N	Tapping Screw - M3x6	7 -105
0451 3006N	Tapping Screw - M3x6	13 -101
0451 3006N	Tapping Screw - M3x6	11 -101
0451 3006N	Tapping Screw - M3x6	3 -101
0451 3006N	Tapping Screw - M3x6	9 -101
0451 3006N	Tapping Screw - M3x6	15 -101
0451 3006N	Tapping Screw - M3x6	5 -101
0451 3008N	Tapping Screw - M3x8	3 -103
0451 4006N	Tapping Screw - 4x6	13 -102
0451 4014N	Tapping Screw:M4x14	11 -102
0452 3008N	Tapping Screw - M3x8	11 -106
0452 3008N	Tapping Screw - M3x8	13 -106
0452 3008N	Tapping Screw - M3x8	3 -102
0452 3008N	Tapping Screw - M3x8	5 -102
0454 3006Q	Tapping Screw - M3x6	7 -101
0632 0100G	Pin - 2x10mm	7 -106
0720 0030E	Retaining Ring - M3	9 -103
0720 0030E	Retaining Ring - M3	7 -107
0720 0040E	Retaining Ring - M4	9 -102
0720 0040E	Retaining Ring - M4	11 -104
0720 0040E	Retaining Ring - M4	7 -102
0720 0040E	Retaining Ring - M4	13 -104
0720 0060E	Retaining Ring - M6	7 -103
0720 0060E	Retaining Ring - M6	11 -103
0951 3006N	Screw - M3x6	13 -103
1105 0109	Cord Keep	7 -104
1105 0487	Harness Clamp	13 -105
1106 0193	Bushing - 7.9mm	11 -105
1106 0193	Bushing - 7.9mm	7 -108

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	7 - 4
5053 0447	Bushing - 6mm	9 - 32
5053 0447	Bushing - 6mm	11 - 7
5206 2686	Snap Ring	7 - 28
5206 2686	Snap Ring	13 - 13
5215 2621	Snap Ring - M6	5 - 3
5304 1639	Bushing - 8mm	11 - 6
5304 1639	Bushing - 8mm	13 - 18
5304 1639	Bushing - 8mm	7 - 7
5446 2824	Screw - Duplex Guide Plate	3 - 3
5446 2824	Screw - Duplex Guide Plate	9 - 1
5447 2681	Snap Ring	9 - 33
5447 2681	Snap Ring	11 - 12
5447 2681	Snap Ring	5 - 1
5447 2681	Snap Ring	13 - 34

