

Color Controller E-22C (D730)


Color Controller E-22C (D730)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1	Color Controller (D730)		3P
2	Color Controller Connection Board (D730)		5P
	Parts Index		8P

1. Color Controller (D730)




1. Color Controller (D730)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D7294002	FAN:CPU:COOLERM:DP6-9EDSA0L-GP	1
2	D7294001	CPU:INTEL:G850:2.9GHZ:LGA1155	1
3	D6503057	FAN:CASE:60X60X25	1
4	D7294000	MOTHER BOARD:S5517G2NR-EFI	1
5	D6503604	CABLE:16P:IDC:8_INCH	1
6	D7293041	COVER:CONNECTOR:DVI-D	1
7	D6503042	COVER:CONNECTOR:15P:VGA	1
8	D7293380	PCB:VIDEO:ORANGE	1
9	D7293617	POWER SUPPLY UNIT:SPI180F4BS-EFI:FLEX_ATX	1
10	D7293252	PCB:7SEGMENT_LED_2:ROHS	1
11	D7294003	IC:DDR3:2GB	1
12	D6503264	CABLE:SATA:ROHS	1
13	D6503038	BRACKET:HDD:3.5	1
14	D7291020	HDD:DEPOPULATED:FULL:SUB-ASS'Y	1
15	D6503031	PANEL:SIDE:ASS'Y	1
16	D6503606	CABLE:POWER_S/W:CONNECTOR	1
17	D6503605	CABLE:USB:CONNECTOR	1
18	D6503610	BRACKET:USB:SHADEING PLATE	1
19	D6503634	BEZEL:BASE	1
20	D7304011	BEZEL:CENTER:METIS:EXP:ASS'Y	1
21	D7296791	CD-ROM:PCL:EXP:ASS'Y	1
22	D6503637	BEZEL:POWER_S/W:BUTTON	1
23	R0131050	SPRING:KEY SWITCH	1
24	D6503607	CABLE:LED:GREEN:POWER	1
25	D6503608	CABLE:LED:AMBER:HDD	1
26	D6503034	RUBBER FOOT:3/4	1
27	D6503033	BRACKET:PCI:BLANK	1
28	G8156607	PACK:GRAY_SCALE_KIT	1
29	D3806800	CABLE:NIC:3M:GIGA:ASS'Y	1
30	D1491582	SHEET:APPLICATION:EFI:OFFICE	1
31	D4501053	DECAL:FIERY:SERVER:ENG	1
32	D6503613	SCREW:UNC4X5/8	1
33	D6503632	BRACKET:NIC:VC2:EFI_CNT	1
34	D6503040	SCREW WITH WASHER:FAN:4.88X10	1


[illegible]

2.Color Controller Connection Board (D730)

Color Controller Connection Board Type M4 (D730-04)



Color Controller Connection Board Type M3 (D730-06)



2.Color Controller Connection Board (D730)

[illegible][illegible]

Parts Index

Parts Index

Part No.	Description	Page and Index No.
11050042	WIRE BAND	3 - 107
11050047	TY - WRAP	3 - 106
12060085	PRIMARY LITHIUM CELL:CR2032	3 - 35
16072470	FERRITE CORE:GRFC-10	3 - 108
03530040N	SCREW - M3X4	3 - 101
04523006N	BINDING SELF-TAPPING SCREW:3X6	3 - 102
04523008N	TAPPING SCREW - M3X8	3 - 103
04543006Q	TAPPING SCREW:3X6	5 - 102
04543008N	TAPPING SCREW:ROUND POINT:3X8	5 - 101
08010226	SCREW:UNC:#6-32	3 - 104
11500377	POWER SUPPLY CODE:250V:10A:EU	3 - 105
11500438	POWER SUPPLY CODE:AC125V:15A:NA	3 - 105
B1545865	CAP:CONNECTOR:USB	5 - 5
D1491582	SHEET:APPLICATION:EFI:OFFICE	3 - 30
D1491582	SHEET:APPLICATION:EFI:OFFICE	3 - 37
D3806800	CABLE:NIC:3M:GIGA:ASS'Y	3 - 29
D4501053	DECAL:FIERY:SERVER:ENG	3 - 31
D6503031	PANEL:SIDE:ASS'Y	3 - 15
D6503033	BRACKET:PCI:BLANK	3 - 27
D6503034	RUBBER FOOT:3/4	3 - 26
D6503038	BRACKET:HDD:3.5	3 - 13
D6503040	SCREW WITH WASHER:FAN:4.88X10	3 - 34
D6503042	COVER:CONNECTOR:15P:VGA	3 - 7
D6503057	FAN:CASE:60X60X25	3 - 3
D6503264	CABLE:SATA:ROHS	3 - 12
D6503604	CABLE:16P:IDC:8_INCH	3 - 5
D6503605	CABLE:USB:CONNECTOR	3 - 17
D6503606	CABLE:POWER_S/W:CONNECTOR	3 - 16
D6503607	CABLE:LED:GREEN:POWER	3 - 24
D6503608	CABLE:LED:AMBER:HDD	3 - 25
D6503609	BEZEL:LIGHT_PIPE:LED	3 - 36
D6503610	BRACKET:USB:SHADEING PLATE	3 - 18
D6503613	SCREW:UNC4X5/8	3 - 32
D6503632	BRACKET:NIC:VC2:EFI_CNT	3 - 33
D6503634	BEZEL:BASE	3 - 19

Part No.	Description	Page and Index No.
D6503637	BEZEL:POWER_S/W:BUTTON	3 - 22
D7291020	HDD:DEPOPULATED:FULL:SUB-ASS'Y	3 - 14
D7293041	COVER:CONNECTOR:DVI-D	3 - 6
D7293252	PCB:7SEGMENT_LED_2:ROHS	3 - 10
D7293380	PCB:VIDEO:ORANGE	3 - 8
D7293617	POWER SUPPLY UNIT:SPI180F4BS-EFI: FLEX_ATX	3 - 9
D7294000	MOTHER BOARD:S5517G2NR-EFI	3 - 4
D7294001	CPU:INTEL:G850:2.9GHZ:LGA1155	3 - 2
D7294002	FAN:CPU:COOLERM:DP6-9EDSA0L-GP	3 - 1
D7294003	IC:DDR3:2GB	3 - 11
D7296791	CD-ROM:PCL:EXP:ASS'Y	3 - 21
D7304011	BEZEL:CENTER:METIS:EXP:ASS'Y	3 - 20
D7305801	BRACKET:EFI:C1B	5 - 4
D7305811	BRACKET:EFI:C1D	5 - 2
D7306036	PCB:GIGAETHERNET:PCIE:ASS'Y	5 - 1
D7306730	DVD-ROM:USER_SOFT:C/M:EXP:ASS'Y	3 - 38
D7306750	CD-ROM:DOCUMENT:C/M:EXP:ASS'Y	3 - 39
D7307060	DVD-ROM:SYSTEM:C/M:EXP:ASS'Y	3 - 40
G8156607	PACK:GRAY_SCALE_KIT	3 - 28
G8745000	PCB:GIGA+USB:ASS'Y	5 - 3
R0131050	SPRING:KEY SWITCH	3 - 23