


Color Controller E-43 Color Controller E-83

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

1. Color Controller-1 (E-43)	1 P
2. Color Controller-2 (E-43)	3 P
3. Color Controller-3 (E-83)	5 P
4. Color Controller-4 (E-83)	7 P
5. Parts Index.....	9 P

1. Color Controller-1 (E-43)




2. Color Controller-2 (E-43)




2. Color Controller-2 (E-43)

[illegible][illegible]

3. Color Controller-3 (E-83)



4. Color Controller-4 (E-83)



4. Color Controller-4 (E-83)

[illegible][illegible]

5. Parts Index

Part No.	Description	Page and Index No.
12060085	LITHIUM CELL:CR2032	4 - 104
12060085	LITHIUM CELL:CR2032	8 - 104
A7245282	SCALE:GRAY:STRIP:10012662	2 - 5
A7245282	SCALE:GRAY:STRIP:10012662	6 - 5
D4501053	DECAL:FIERY:SERVER:ENG	2 - 3
D4501053	DECAL:FIERY:SERVER:ENG	6 - 3
D4501060	KIT:FAN:CASE:45053562	4 - 6
D4501071	KIT:DRIVE:DVD_SATA:45086559	4 - 1
D4501071	KIT:DRIVE:DVD_SATA:45086559	8 - 2
D4501090	KIT:PCB:UIB:45064543	2 - 13
D4501090	KIT:PCB:UIB:45064543	6 - 13
D4501100	KIT:CABLE:HDD:SATA:45053218	4 - 5
D4501100	KIT:CABLE:HDD:SATA:45053218	8 - 6
D4501111	KIT:CABLE:DVD:SATA:45090877	4 - 2
D4501111	KIT:CABLE:DVD:SATA:45090877	8 - 1
D4501140	KIT:TOP_BEZEL:45064980	2 - 12
D4501160	KIT:CABLE:UIB29INTCH:45053997	4 - 7
D4501170	KIT:SIDE_PANEL:ACCESS:45079163	2 - 9
D4501180	KIT:SIDE_PANEL:NON_AC:45079519	2 - 10
D4501190	SCREW:M3X.5X6MM:LONG	4 - 102
D4501190	SCREW:M3X.5X6MM:LONG	8 - 103
D4501200	SCREW:#6_32X1/4:LONG	2 - 102
D4501200	SCREW:#6_32X1/4:LONG	4 - 103
D4501200	SCREW:#6_32X1/4:LONG	6 - 102
D4501200	SCREW:#6_32X1/4:LONG	8 - 102
D4501210	SCREW:3MM_DIAX6MM:LONG	2 - 101
D4501210	SCREW:3MM_DIAX6MM:LONG	6 - 101
D4501220	SCREW:M2X.4X3MM:LONG	4 - 101
D4501220	SCREW:M2X.4X3MM:LONG	8 - 101
D4508610	KIT:POWER SUPPLY CORD:NA:45053564	2 - 1
D4508610	KIT:POWER SUPPLY CORD:NA:45053564	6 - 1
D4508611	KIT:POWER SUPPLY CORD:UK:45054061	2 - 1
D4508611	KIT:POWER SUPPLY CORD:UK:45054061	6 - 1
D4508612	KIT:POWER SUPPLY CORD:EU:45053565	2 - 1

Part No.	Description	Page and Index No.
D4508612	KIT:POWER SUPPLY CORD:EU:45053565	6 - 1
D4508613	KIT:POWER SUPPLY CORD:AUS:45053566	2 - 1
D4508613	KIT:POWER SUPPLY CORD:AUS:45053566	6 - 1
M3821060	KIT:FAN:CHASSIS:45064540	8 - 7
M3821140	KIT:TOP_BEZEL:45064557	6 - 12
M3821170	KIT:SIDE_PANEL:ACCESS:45085293	6 - 9
M3821180	KIT:SIDE_PANEL:NON_AC:45085294	6 - 10
M3821230	KIT:CABLE:UIB:45064534	8 - 8
M3828614	KIT:CABLE:GIGA_NIC12M:45083552	2 - 2
M3828614	KIT:CABLE:GIGA_NIC12M:45083552	6 - 2
M3921210	KIT:DRIVE:500G:45092427	8 - 4
M4361040	KIT:RAM:DDR3:2GB:45113008	4 - 11
M4361050	KIT:POWER SUPPLY UNIT:350W:PRO:45110859	4 - 13
M4361080	KIT:DRIVE:HDD:1TB:45110860	4 - 4
M4361080	KIT:DRIVE:HDD:1TB:45110860	8 - 5
M4361095	KIT:BUTTON:UIB:45064547	2 - 14
M4361095	KIT:BUTTON:UIB:45064547	6 - 14
M4361120	KIT:CPU_FAN:45110862	4 - 9
M4361150	KIT:SW_KIT:45110866	8 - 3
M4371040	KIT:RAM:DDR3:2GB:45110858	8 - 13
M4371050	KIT:POWER SUPPLY UNIT:550W_QX:45111705	8 - 14
M4371120	KIT:CPU_FAN:45111704	8 - 10
M4371240	KIT:VIDEO_CARD:45111818	8 - 11
M4371260	KIT:HDD_COVER:45126895	8 - 16
M4651131	KIT:FRONT_BEZEL:EXP:45131439	2 - 11
M4656020	KIT:PCB:CUCUMBER:45131438	4 - 8
M4656020	KIT:PCB:CUCUMBER:45131438	8 - 12
M4656701	PACK:MEDIA_V1.0:EXP:45131038	2 - 4
M4656710	KIT:SERVICE:V1.0:EXP:45131112	2 - 15
M4656730	DVD-ROM:USER:V1.0:EXP:45131104	2 - 6
M4656740	DVD-ROM:SYSTEM:V1.0:EXP:45131106	2 - 7
M4657101	PACK:ANDRO_PRO:EFL_USE:REI:EXP	2 - 8
M4661131	KIT:FRONT_BEZEL:45131441	6 - 11
M4666701	PACK:MEDIA_V1.0:EXP:45131194	6 - 4

