

Color Controller E-7100
(D380)

Color Controller E-7100 (D380)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Controller (D380)	2
Parts Index	6

February 2008

1.Controller (D380)



1.Controller (D380)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5K53 0031	Panel:Side	1
2	5K53 0057	Fan:Case:60x60x25	2
3	5K53 0456	PSU:FSP180PLAR-EFI:Rohs:SAT	1
4	5K53 0252	PCB:7Segment_LED:Rohs	1
5	5K53 0604	Cable:16P:IDC:8_Inch	1
6	5K53 0033	Bracket:PCI:Blank	1
7	5K53 0040	Screw:Fan:4.88x10	8
8	5K53 0606	Cable:Power_S/W:Connector	1
9	5K53 0605	Cable:USB:Connector	1
10	5K53 0610	Bracket:USB:Shadeing Plate	1
11	5K53 0034	Rubber Foot:3/4"	4
12	5K53 0608	Cable:LED:Amber:HDD	1
13	5K53 0607	Cable:LED:Green:Power	1
14	5K53 0634	Bezel:Base	1
15	R013 1050	Spring:Key Switch	1
16	5K53 0637	Bezel:Power_S/W:Button	1
17	5K53 0675	Bezel:Center:EXP	1
18	5K53 0636	Bezel:USB:Door	1
19	5K53 0038	Bracket:HDD:3.5"	1
20	5K53 0257	HDD:HDS721680PLA380:Rohs	1
21	5K53 0264	Cable:SATA:Rohs	1
22	5K53 0600	Mother Board:S5207G2NR-EFI	1
23	5K53 0603	IC:DDR2:1GB:BUFFERD	1
24	5K53 0602	Fan:CPU:EEP-N41ES-02	1
25	5K53 0601	IC:CPU:CELEROM_M:1.86GHz	1
26	N599 7300	PCB:VC1-EFI	1
27	5K53 0631	Bracket:PCI:Parrot	1
28	5K53 0041	Connector Cover - VGA	1
29	5K53 0042	Connector Cover - COM	1
30	5K53 0036	Holder - Wire Binder	2
31	5K53 0609	Bezel:Light_Pipe:LED	2
32	D380 6710	Pack:VC2:Media_Pack(EFIGSD)	1
33	G815 6607	Pack:Gray_Scale_Kit	1
34	G815 1053	Decal:Fiery:ENG	1
35	B237 1545	Keytop:EFI-A	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G178 6033	PCB:Gigaethernet:PCIE	1
37	D377 5852	Bracket:NIC:VC2:Engine	1
38	5K53 0650	Bracket:NIC:VC2:EFI_CNT:Ass'y	1
39	D377 5851	Cable:NIC:3m:Giga	1
40	D380 7050	DVD-ROM:-R:System_VC2:EXP	1
41	5K53 0630	Base:EFI-VC2	1
101	1150 0373	Power Supply Code:125V 15A NA	
101	1150 0377	Power Supply Code:250V:10A:EU	
102	1607 1461	Ferrite Core	
103	1607 1092	Ferrite Core:RFC-10	
104	0352 5080N	Screw:M2.5x8	
105	0353 0040N	Screw - M3x4	
106	1206 0085	Primary Lithium Cell:CR2032	
107	0801 0226	Screw:UNC:#6-32	
108	0452 3006N	Binding Self-Tapping Screw:3x6	
109	0454 3006Q	Tapping Screw - M3x6	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D380 6710	Pack:VC2:Media_Pack(EFIGSD)	3 - 32
D380 7050	DVD-ROM:-R:System_VC2:EXP	3 - 40

Part No.	Description	Page and Index No.
B237 1545	Keytop:EFI-A	3 - 35
D377 5851	Cable:NIC:3m:Giga	3 - 39
D377 5852	Bracket:NIC:VC2:Engine	3 - 37
G178 6033	PCB:Gigaethernet:PCIE	3 - 36
G815 1053	Decal:Fiery:ENG	3 - 34
G815 6607	Pack:Gray_Scale_Kit	3 - 33

Part No.	Description	Page and Index No.
N599 7300	PCB:VC1-EFI	3 - 26
R013 1050	Spring:Key Switch	3 - 15

Part No.	Description	Page and Index No.
0352 5080N	Screw:M2.5x8	3 - 104
0353 0040N	Screw - M3x4	3 - 105
0452 3006N	Binding Self-Tapping Screw:3x6	3 - 108
0454 3006Q	Tapping Screw - M3x6	3 - 109
0801 0226	Screw:UNC:#6-32	3 - 107
1150 0373	Power Supply Code:125V 15A NA	3 - 101
1150 0377	Power Supply Code:250V:10A:EU	3 - 101
1206 0085	Primary Lithium Cell:CR2032	3 - 106
1607 1092	Ferrite Core:RFC-10	3 - 103
1607 1461	Ferrite Core	3 - 102

Part No.	Description	Page and Index No.
5K53 0031	Panel:Side	3 - 1
5K53 0033	Bracket:PCI:Blank	3 - 6
5K53 0034	Rubber Foot:3/4"	3 - 11
5K53 0036	Holder - Wire Binder	3 - 30
5K53 0038	Bracket:HDD:3.5"	3 - 19
5K53 0040	Screw:Fan:4.88x10	3 - 7
5K53 0041	Connector Cover - VGA	3 - 28
5K53 0042	Connector Cover - COM	3 - 29
5K53 0057	Fan:Case:60x60x25	3 - 2
5K53 0252	PCB:7Segment_LED:Rohs	3 - 4
5K53 0257	HDD:HDS721680PLA380:Rohs	3 - 20
5K53 0264	Cable:SATA:Rohs	3 - 21
5K53 0456	PSU:FSP180PLAR-EFI:Rohs:SAT	3 - 3
5K53 0600	Mother Board:S5207G2NR-EFI	3 - 22
5K53 0601	IC:CPU:CELEROM_M:1.86GHz	3 - 25
5K53 0602	Fan:CPU:ECP-N41ES-02	3 - 24
5K53 0603	IC:DDR2:1GB:BUFFERD	3 - 23
5K53 0604	Cable:16P:IDC:8_Inch	3 - 5
5K53 0605	Cable:USB:Connector	3 - 9
5K53 0606	Cable:Power_S/W:Connector	3 - 8
5K53 0607	Cable:LED:Green:Power	3 - 13
5K53 0608	Cable:LED:Amber:HDD	3 - 12
5K53 0609	Bezel:Light_Pipe:LED	3 - 31
5K53 0610	Bracket:USB:Shadeing Plate	3 - 10
5K53 0630	Base:EFI-VC2	3 - 41
5K53 0631	Bracket:PCI:Parrot	3 - 27
5K53 0634	Bezel:Base	3 - 14
5K53 0636	Bezel:USB:Door	3 - 18
5K53 0637	Bezel:Power_S/W:Button	3 - 16
5K53 0650	Bracket:NIC:VC2:EFI_CNT:Ass'y	3 - 38
5K53 0675	Bezel:Center:EXP	3 - 17

Part No.	Description	Page and Index No.