

Color Controller E-42/E-82 (M436/M437)

Color Controller E-42/E-82 (M436/M437)



PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1	Color Controller-1 (M436)	 2P
2	Color Controller-2 (M436)	 4P
3	Color Controller-3 (M437)	 6P
4	Color Controller-4 (M437)	 8P
	Parts Index	 10P

1. Color Controller-1 (M436)


Color Controller E-42 (M436-02,03)



1. Color Controller-1 (M436)

[illegible][illegible]


2. Color Controller-2 (M436)




2. Color Controller-2 (M436)

[illegible][illegible]

3. Color Controller-3 (M437)




Color Controller E-82 (M437-01)



3. Color Controller-3 (M437)

[illegible][illegible]

4. Color Controller-4 (M437)



4. Color Controller-4 (M437)

[illegible][illegible]

Parts Index

Parts Index

Part No.	Description	Page and Index No.
A7245282	GRAYSCALE STRIP; 10012662	3 - 4
A7245282	GRAYSCALE STRIP; 10012662	7 - 5
D4501053	DECAL:FIERY:SERVER:ENG	3 - 2
D4501060	FAN:CASE:45053562	5 - 6
D4501071	DRIVE:DVD_SATA:45086559	5 - 1
D4501071	DRIVE:DVD_SATA:45086559	9 - 2
D4501090	PCB:UIB:45064543	3 - 9
D4501090	PCB:UIB:45064543	7 - 10
D4501100	CABLE:HDD:SATA:45053218	5 - 5
D4501100	CABLE:HDD:SATA:45053218	9 - 6
D4501111	CABLE:DVD:SATA:45090877	9 - 1
D4501111	CABLE:DVD:SATA:45090877	5 - 2
D4501140	TOP_BEZEL:45064980	3 - 6
D4501150	SW:45064981	9 - 3
D4501160	CABLE:UIB29INTCH:45053997	5 - 7
D4501170	SIDE_PANEL:ACCESS:45079163	3 - 7
D4501180	SIDE_PANEL:NON_AC:45079519	3 - 8
D4501190	SCREW:M3X6MM	5 - 102
D4501190	SCREW:M3X6MM	9 - 103
D4501200	SCREW:#6_32X1/4	3 - 102
D4501200	SCREW:#6_32X1/4	7 - 102
D4501200	SCREW:#6_32X1/4	9 - 102
D4501200	SCREW:#6_32X1/4	5 - 103
D4501210	SCREW:3MMX6MM	3 - 101
D4501210	SCREW:3MMX6MM	7 - 101
D4501220	SCREW:M2X3MM	5 - 101
D4501220	SCREW:M2X3MM	9 - 101
D4508610	POWER SUPPLY CORD:NA:45053564	3 - 1
D4508610	POWER SUPPLY CORD:NA:45053564	7 - 1
D4508611	POWER SUPPLY CORD:UK:45054061	3 - 1
D4508611	POWER SUPPLY CORD:UK:45054061	7 - 1
D4508612	POWER SUPPLY CORD:EU:45053565	3 - 1
D4508612	POWER SUPPLY CORD:EU:45053565	7 - 1

Part No.	Description	Page and Index No.
D4508613	POWER SUPPLY CORD:AUS:45053566	3 - 1
D4508613	POWER SUPPLY CORD:AUS:45053566	7 - 1
M3821060	FAN:CHASSIS:45064540	9 - 7
M3821140	TOP_BEZEL:45064557	7 - 6
M3821170	SIDE_PANEL:ACCESS:45085293	7 - 7
M3821180	SIDE_PANEL:NON_AC:45085294	7 - 8
M3821230	CABLE:UIB:45064534	9 - 8
M3828614	CABLE:GIGA_NIC12M:45083552	7 - 2
M3918615	POWER SUPPLY CORD:CHN:45096959	3 - 1
M3921210	HD DRIVE:500G:45092427	9 - 4
M4361010	MOTHER BOARD:S5515:45110855	5 - 12
M4361020	PCB:ORANGE:45110856	5 - 8
M4361020	PCB:ORANGE:45110856	9 - 12
M4361030	IC:CPU:I5-2400:45110857	5 - 10
M4361040	RAM:DDR3:2GB:45113008	5 - 11
M4361050	POWER SUPPLY UNIT:350W:PRO:45110859	5 - 13
M4361080	DRIVE:HDD:1TB:45110860	5 - 4
M4361080	DRIVE:HDD:1TB:45110860	9 - 5
M4361120	CPU_FAN:45110862	5 - 9
M4361131	FRONT_BEZEL:EXP:45110864	3 - 10
M4361150	SW:45110866	5 - 3
M4366702	MEDIA_PACK:V1.0:DVD 4PC/CD 1PC:45113332	3 - 3
M4366703	MEDIA_PACK:V1.0:DVD 4PCS/CD 1PC:CHN:45113335	3 - 3
M4366710	SERVICE PAKC:V1.0:DVD 4PC/CD 1PC:45113351	3 - 5
M4366711	SERVICE PACK:V1.0:DVD 4PCS/CD 1PC:CHN:45113353	3 - 5
M4371010	MOTHER BOARD:S7050:45111707	9 - 15
M4371030	IC:CPU:E5-2643:45111703	9 - 9
M4371040	RAM:DDR3:2GB:45110858	9 - 13
M4371050	POWER SUPPLY UNIT:550W_QX:45111705	9 - 14
M4371120	CPU_FAN:45111704	9 - 10
M4371131	FRONT_BEZEL:45111706	7 - 9
M4371240	VIDEO_CARD:45111818	9 - 11
M4376702	MEDIA PACK:V1.0:DVD 4PCS/CD 1PC:45113366	7 - 4

