PCL 6/5e Printer Driver Installation Guide

This manual assumes that you are familiar with general Windows procedures and practices. If you are not, see the documentation that comes with Windows for details.

∰Important

- Before starting this installation, close all documents and applications. In a network environment, confirm that users who are logged on are disconnected.
 Be sure to do this when it will create the least interference with other users.
- □ After installing a printer driver, you must restart the computer.

🖉 Note

- Available operating systems are as follows: Windows 95/98/Me, Windows 2000/XP, Windows Server 2003, Windows NT 4.0
- □ If the "plug and play" function is started, click[Cancel] in the [New Hardware Found], [Device Driver Wizard] or [Found New Hardware Wizard] dialog box, and then insert the CD-ROM. The [New Hardware Found], [Device Driver Wizard] or [Found New Hardware Wizard] dialog box appears depending on the system version of the Windows 95/98/Me, Windows 2000/XP, Windows Server 2003.

Installing the PCL 6/5e Printer Driver

Auto Run starts the installer automatically when you load the CD-ROM in the CD-ROM drive.

Two kinds of PCL printer drivers, PCL 6 and PCL 5e, are provided with this machine. We recommend PCL 6 as your first choice.

TCP/IP requires the following:

- This machine must be connected to the network through the network interface cable.
- This machine must be turned on.
- The TCP/IP protocol must be configured.
- An IP address must be allocated to this machine and to the computer.

Limitation

If your system is Windows 2000/XP, Windows Server 2003, or Windows NT 4.0, installing a printer driver by Auto Run requires Administrators permission. When you install a printer driver by Auto Run, log on using an account that has Administrators permission.

∰Important

When updating the printer driver by installing the latest version, you should uninstall that of former version if any.

🖉 Note

□ Auto Run might not automatically work with certain OS settings. In this case, launch "Setup.exe" located on the CD-ROM root directory.

If you want to cancel Auto Run, hold down the **[Shift]** key (when your system is Windows 2000, hold down the left **[Shift]** key) while inserting the CD-ROM. Keep the **[Shift]** key held down until the computer has finished accessing the CD-ROM.

1 Close all applications that are running.

2 Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

3 Select a language to change the interface language, and then click [OK].

The following languages are available: Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Nederlands (Dutch) Default interface language is English.

4 Select [PCL Printer Drivers].

5 The software license agreement appears in the [License Agreement] dialog box. After reading through all of the contents, click [l accept the agreement.] to agree with the License Agreement, and then click [Next].

6 Select the printer driver you want to install when the [Select Program] dialog box appears.

7 Follow the instructions on the screen.

🖉 Note

- □ During installation in Windows 2000, the **[Digital Signature Not Found]** dialog box may appear. In this case, click **[Yes]** to continue the installation.
- During installation in Windows XP, Windows Server 2003, the [Hardware Installation] dialog box may appear. In this case, click [Continue Anyway] to continue the installation.

Setting up options

∰Important

□ If the machine is equipped with certain options, you should set up the options with the printer driver.

Limitation

In Windows 2000/XP, Windows Server 2003, changing the printer settings requires Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.

In Windows NT 4.0, changing the setting of the printer requires Full Control access permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default. When you set up options, log on using an account that has Full Control permission.

🖉 Note

When setting up options, you should access the printer properties dialog box from Windows. You cannot set up options by accessing the printer properties dialog box from an application.

Click [Start] on the taskbar, point to [Settings], and then click [Printers].

The [Printers] window appears.

🖉 Note

- □ In Windows XP Professional, Windows Server 2003, access the **[Printers and Faxes]** window from **[Start]** on the taskbar.
- In Windows XP Home Edition, access the [Printers and Faxes] window. Click [Start] on the taskbar, click [Control Panel], [Printers and Other Hardware] and then [Printers and Faxes].

2 Click to select the icon of the printer you want to use.

3 On the [File] menu, click [Properties].

The printer properties dialog box appear.

- ⁴ Click the [Accessories] tab.
- Select options you have installed from the [Options] group.
- **6** Click **[0K]** .

Trademarks

 $Microsoft^{\$}$, Windows^{\\$} and Windows $NT^{\$}$ are registered trademarks of Microsoft Corporation in the United States and/or other countries.

PCL[®] is a registered trademark of Hewlett-Packard Company.

The proper names of the Windows operating systems are as follows:

- The product name of Windows[®] 95 is Microsoft[®] Windows[®] 95
- The product name of Windows[®] 98 is Microsoft[®] Windows[®] 98
- The product name of Windows[®] Me is Microsoft[®] Windows[®] Millennium Edition (Windows Me)
- The product names of Windows[®] 2000 are as follows: Microsoft[®] Windows[®] 2000 Professional Microsoft[®] Windows[®] 2000 Server Microsoft[®] Windows[®] 2000 Advanced Server
- The product names of Windows[®] XP are as follows: Microsoft[®] Windows[®] XP Professional Microsoft[®] Windows[®] XP Home Edition
- The product names of Windows ServerTM 2003 are as follows: Microsoft[®] Windows ServerTM 2003 Standard Edition. Microsoft[®] Windows ServerTM 2003 Enterprise Edition. Microsoft[®] Windows ServerTM 2003 Web Edition.
- The product names of Windows NT[®] 4.0 are as follows: Microsoft[®] Windows NT[®] Server 4.0 Microsoft[®] Windows NT[®] Workstation 4.0

Symbols

In this manual, the following symbols are used:

∰Important

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

🖉 Note

This symbol indicates precautions for operation, or actions to take after misoperation.

Limitation

1

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

[

Keys that appear on the machine's display panel.

Keys and buttons that appear on the computer's display.

[

Keys built into the machine's control panel.

Keys on the computer's keyboard.



Copyright © 2004