

Printer Controller EB-1357
(D473)

Printer Controller EB-1357 (D473)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Controller 1 (D473)	2
2.Controller 2 (D473)	4
3.FACI Furniture Bundle (D473-03)	6
Parts Index.....	10

July 7, 2009

1.Controller 1 (D473)




1.Controller 1 (D473)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D450 8614	Cable:GIGA_NIC5M:45072552	1
2	G178 6033	PCB:GIGAETHERNET:PCIE	1
3	D473 6715	Media Pack:NA:45076601	1
3	D473 6716	Media Pack:EU:45076603	1
4	D450 1190	Screw:M3x6MM	6
5	D473 5001	SD-Card:SCN	1
6	G178 6072	PCB:PC4200:RAWCARD-A:1GB	1
7	D450 1053	Decal:Fiery:Server:ENG	1
8	B234 1584	Keytop - EFI Other Function	1
8	B234 1585	Keytop - EFI Other Function EU	1
9	B234 1582	Keytop - EFI Normal	1
10	D450 8610	Power Supply Cord:NA:45053564	1
10	D450 8612	Power Supply Cord:EU:45053565	1
10	D450 8611	Power Supply Cord:UK:45054061	1
10	D450 8613	Power Supply Cord:AUS:45053566	1
11	D473 1130	Side_panel:45081318	1
12	D473 1110	Top_BEZEL:45072542	1
13	D473 1190	Button:UIB:45081328	1
14	D473 1101	Front_BEZEL:45072540	1
15	D473 1102	Labels:FR_BEZEL:45072541	1
16	D473 1050	PCB:UIB:45072551	1
17	D473 1140	Cable:UIB20Inch:45081319	1
18	D473 6713	Media Set:Service:45082066	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	

2.Controller 2 (D473)




2.Controller 2 (D473)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D473 1020	PCB:Sandhill:45072557	1
2	D473 1040	Cooling:CPU:45072546	1
3	D473 1030	IC:CPU:CD_T2500:45072545	1
4	D473 1060	DIMM:PC2:1G:45072549	2
5	D473 1010	Mother Board:S5179:45082653	1
6	D473 1080	Fan:Case:45072547	1
7	D473 1170	Cable:HDD:SATA:45081325	1
8	D473 1200	Cable:CD_DVD:SATA:45081329	1
9	D473 1090	HDD:80G:45072544	1
10	D473 1150	ASM:Power_W:45081320	1
11	D473 1160	ASM:Reset_W:45081321	1
12	D473 1180	Cable:USB2.0:12IN:45081327	1
13	D473 1120	Drive:CD_DVD:45072556	1
14	D473 1070	PSU:220W:12V:45072548	1
15	D450 1190	Screw:M3x6MM	17
16	D450 1200	Screw:#6_32x1/4	4

Index No.	Part No.	Description	Q'ty Per Assembly

3.FACI Furniture Bundle (D473-03)



3.FACI Furniture Bundle (D473-03)

Index No.	Part No.	Description	Q'ty Per Assembly
1	M382 8620	Keyboard:Black:PS/2-USB: Low Profile:Generic:45060165	1
2	M382 8630	Mouse:Black:PS/2-USB: Lighted Scroll Wheel:Generic:45060166	1
3	M382 8601	CBL:Power Cord:EUROPE:ROHS:45052215	1
3	M382 8602	CBL:Power Cord:U.K.:ROHS:45052216	1
3	M382 8604	CBL:Power Cord:AUS:ROHS:45053111	1
4	D473 8610	Monitor:19 In:Widescreen:LCD: Flat Panel:45050351	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D473 1010	Mother Board:S5179:45082653	5 - 5
D473 1020	PCB:Sandhill:45072557	5 - 1
D473 1030	IC:CPU:CD_T2500:45072545	5 - 3
D473 1040	Cooling:CPU:45072546	5 - 2
D473 1050	PCB:UIB:45072551	3 - 16
D473 1060	DIMM:PC2:1G:45072549	5 - 4
D473 1070	PSU:220W:12V:45072548	5 - 14
D473 1080	Fan:Case:45072547	5 - 6
D473 1090	HDD:80G:45072544	5 - 9
D473 1101	Front_BEZEL:45072540	3 - 14
D473 1102	Labels:FR_BEZEL:45072541	3 - 15
D473 1110	Top_BEZEL:45072542	3 - 12
D473 1120	Drive:CD_DVD:45072556	5 - 13
D473 1130	Side_panel:45081318	3 - 11
D473 1140	Cable:UIB20Inch:45081319	3 - 17
D473 1150	ASM:Power_W:45081320	5 - 10
D473 1160	ASM:Reset_W:45081321	5 - 11
D473 1170	Cable:HDD:SATA:45081325	5 - 7
D473 1180	Cable:USB2.0:12IN:45081327	5 - 12
D473 1190	Button:UIB:45081328	3 - 13
D473 1200	Cable:CD_DVD:SATA:45081329	5 - 8
D473 5001	SD-Card:SCN	3 - 5
D473 6713	Media Set:Service:45082066	3 - 18
D473 6715	Media Pack:NA:45076601	3 - 3
D473 6716	Media Pack:EU:45076603	3 - 3
D473 8610	Monitor:19 In:Widescreen:LCD: Flat Panel:45050351	7 - 4

Part No.	Description	Page and Index No.
B234 1582	Keytop - EFI Normal	3 - 9
B234 1584	Keytop - EFI Other Function	3 - 8
B234 1585	Keytop - EFI Other Function EU	3 - 8
D450 1053	Decal:Fiery:Server:ENG	3 - 7
D450 1190	Screw:M3x6MM	5 - 15
D450 1190	Screw:M3x6MM	3 - 4
D450 1200	Screw:#6_32x1/4	5 - 16
D450 8610	Power Supply Cord:NA:45053564	3 - 10
D450 8611	Power Supply Cord:UK:45054061	3 - 10
D450 8612	Power Supply Cord:EU:45053565	3 - 10
D450 8613	Power Supply Cord:AUS:45053566	3 - 10
D450 8614	Cable:GIGA_NIC5M:45072552	3 - 1
G178 6033	PCB:GIGAETHERNET:PCIE	3 - 2
G178 6072	PCB:PC4200:RAWCARD-A:1GB	3 - 6

Part No.	Description	Page and Index No.
M382 8601	CBL:Power Cord:EUROPE:ROHS:45052215	7 - 3
M382 8602	CBL:Power Cord:U.K.:ROHS:45052216	7 - 3
M382 8604	CBL:Power Cord:AUS:ROHS:45053111	7 - 3
M382 8620	Keyboard:Black:PS/2-USB: Low Profile:Generic:45060165	7 - 1
M382 8630	Mouse:Black:PS/2-USB: Lighted Scroll Wheel:Generic:45060166	7 - 2

Part No.	Description	Page and Index No.
0454 3006Q	Tapping Screw - M3x6	3 - 101