

Envelope Feeder Type 400 (G362)

Envelope Feeder Type 400 (G362)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.ENVELOPE FEEDER (G362)	2
2.DECALS AND DOCUMENTS (G362)	4
PARTS INDEX.....	7

August ,31 ' 2006

1.ENVELOPE FEEDER (G362)




1.ENVELOPE FEEDER (G362)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G362 3050	Paper Tray Ass'y	1
2	G096 3094	Tape - Sheet : Tray	5
3	G360 3091		3
3	G096 3091	Sheet - Tray 1	3
4	G360 3092		2
4	G096 3092	Sheet - Tray 2	2
5	G360 3093		2
5	G096 3093	Sheet - Tray 3	2
6	G096 3052	Paper Tray Cover	1
7	G362 3082	Paper Size Sensor Board	1
8	G096 3071	Paper Tray Arm	2
9	G362 3083	Tension Spring Base	2
10	G362 3144	Paper Set Direction Label	1
11	G362 3061	Left Side Fence	1
12	A267 2869	Gear - 16Z	1
13	G362 3062	Right Side Fence	1
14	G362 3043	Tray Bottom Plate (RoHs)	1
	G362 3053	X/O MB1	
15	5215 2713	Bottom Plate pad (RoHs)	1
	G029 2608	X/O MB1	
16	G362 3069	Separation Compression Spring	1
17	G096 3066	Friction Pad Adhesion	1
18	G362 3066	Cassette Protection	2
19	G096 3088	End Fence Pressure	1
20	G096 3087	End Fence Protection	1
21	G096 3090	End Fence Tension Spring 12n	1
22	G096 3089	End Fence Compression Spring 3.5n	1
23	G096 3086	End Fence Lever	1
24	G096 3085	End Fence	1
25	G096 3063	Paper Tray Cap	1
26	G362 3088	Scale Label - End Fence	1
27	G096 3060	Rear Paper Tray	1
28	G096 3065	Paper Tray Supporting Plate	1
29	G096 3070	Paper Volume Sensor Board	1
30	G096 3051	Paper Tray	1


Index No.	Part No.	Description	Q'ty Per Assembly
31	G556 3078	Release Spring	1
32	G362 3059	Paper Tray Stopper Pawl	1
101	0450 3008N	Tapping Screw - M3x8	

2.DECALS AND DOCUMENTS (G362)

1



2



2.DECALS AND DOCUMENTS (G362)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G362 3144	Paper Set Direction Label	1
2	G362 3088	Scale Label - End Fence	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
ENVELOPE FEEDER (G362)	G096 3066	Friction Pad	Friction Pad Adhesion	1	3- 17

Parts Index

Part No.	Description	Page and Index No.
G362 3043	Tray Bottom Plate (RoHs)	3 - 14
G362 3050	Paper Tray Ass'y	3 - 1
G362 3053	X/O MB1	3 - 14
G362 3059	Paper Tray Stopper Pawl	3 - 32
G362 3061	Left Side Fence	3 - 11
G362 3062	Right Side Fence	3 - 13
G362 3066	Cassette Protection	3 - 18
G362 3069	Separation Compression Spring	3 - 16
G362 3082	Paper Size Sensor Board	3 - 7
G362 3083	Tension Spring Base	3 - 9
G362 3088	Scale Label - End Fence	3 - 26
G362 3088	Scale Label - End Fence	5 - 2
G362 3144	Paper Set Direction Label	3 - 10
G362 3144	Paper Set Direction Label	5 - 1

Part No.	Description	Page and Index No.
A267 2869	Gear - 16Z	3 - 12
G029 2608	X/O MB1	3 - 15
G096 3051	Paper Tray	3 - 30
G096 3052	Paper Tray Cover	3 - 6
G096 3060	Rear Paper Tray	3 - 27
G096 3063	Paper Tray Cap	3 - 25
G096 3065	Paper Tray Supporting Plate	3 - 28
G096 3066	Friction Pad Adhesion	3 - 17
G096 3070	Paper Volume Sensor Board	3 - 29
G096 3071	Paper Tray Arm	3 - 8
G096 3085	End Fence	3 - 24
G096 3086	End Fence Lever	3 - 23
G096 3087	End Fence Protection	3 - 20
G096 3088	End Fence Pressure	3 - 19
G096 3089	End Fence Compression Spring 3.5n	3 - 22
G096 3090	End Fence Tension Spring 12n	3 - 21
G096 3091	Sheet - Tray 1	3 - 3
G096 3092	Sheet - Tray 2	3 - 4
G096 3093	Sheet - Tray 3	3 - 5
G096 3094	Tape - Sheet : Tray	3 - 2
G360 3091		3 - 3
G360 3092		3 - 4
G360 3093		3 - 5
G556 3078	Release Spring	3 - 31

