

Fax Option Type M19 (D3BV)
G3 Interface Unit Type M19 (D3BV)
Fax Option Type M20 (D3BT)
G3 Interface Unit Type M20 (D3BT)
FAX Memory Unit Type M19 64MB (D3BZ)
Fax Connection Unit Type M19 (D3BD)
Fax Connection Unit Type M20 (D3BC)
Handset HS3020 (D739)




PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1	Fax Option Type M19		3P
2	G3 Interface Unit Type M19		5P
3	Fax Option Type M20		7P
4	G3 Interface Unit Type M20		9P
5	Fax Option		11P
	Parts Index		13P

1. Fax Option Type M19


Fax Option Type M19
(D3BV-01,02,03,04,05)



1. Fax Option Type M19

[illegible][illegible]

2. G3 Interface Unit Type M19




2. G3 Interface Unit Type M19

[illegible][illegible]

3. Fax Option Type M20



Fax Option Type M20
(D3BT-01,02,03,04,05)




3. Fax Option Type M20

[illegible][illegible]

4. G3 Interface Unit Type M20



G3 Interface Unit Type M20
(D3BT-07,08,12)




4. G3 Interface Unit Type M20

[illegible][illegible]

5. Fax Option

FAX Memory Unit Type M19 64MB (D3BZ-17)









Fax Connection Unit Type M19
(D3BD-01,02,03)



Fax Connection Unit Type M20
(D3BC-01,02,03)



Handset HS3020 (D739-17)
NA only



[illegible][illegible]

Parts Index

Parts Index

Part No.	Description	Page and Index No.
03530050N	SCREW:M3X5	3-101
03530050N	SCREW:M3X5	7-101
03530050N	SCREW:M3X5	11-101
03603006N	SCREW:M3X6	11-102
03603012N	SCREW:M3X12	11-103
03604012N	SCREW:M4X12	11-104
04543006N	TAPPING SCREW:ROUND POINT:3X6	3-102
04543006Q	TAPPING SCREW:3X6	5-101
04543006Q	TAPPING SCREW:3X6	7-102
04543006Q	TAPPING SCREW:3X6	9-101
04543006Q	TAPPING SCREW:3X6	11-105
04583010N	HEXAGON HEAD TAPPING SCREW:3X10	11-106
11040702	CONNECTOR	3-103
11040702	CONNECTOR	7-103
11050042	WIRE BINDER:(NA)	3-104
11050042	WIRE BINDER:(NA)	5-102
11050042	WIRE BINDER:(NA)	7-104
11050042	WIRE BINDER:(NA)	9-102
11050638	CLAMP:RFC-33V0	5-103
11050638	CLAMP:RFC-33V0	9-103
11050692	CLAMP:LES-0503	7-105
11050758	CLAMP:LWSM-0306A	3-105
11050758	CLAMP:LWSM-0306A	7-106
11050758	CLAMP:LWSM-0306A	11-107
11050780	CLAMP:LWST-1012	3-106
11050780	CLAMP:LWST-1012	7-107
16072251	FERRITE CORE:K3 NF-75(N)BK0	3-107
16072251	FERRITE CORE:K3 NF-75(N)BK0	5-104
16072251	FERRITE CORE:K3 NF-75(N)BK0	7-108
16072251	FERRITE CORE:K3 NF-75(N)BK0	9-104
16072251	FERRITE CORE:K3 NF-75(N)BK0	11-108
B1345050	SPEAKER:B134	3-2
B1345050	SPEAKER:B134	7-1
D1505634	PCB:CCUIF-A:ASS'Y	5-2
D1505634	PCB:CCUIF-A:ASS'Y	9-2

Part No.	Description	Page and Index No.
D1675630	PCB:GWFCU-IF14E:ASS'Y	7-2
D1675740	PCB:MBOARD:ASS'Y	11-2
D2388201	FCU:SERVICE:(NA)	3-1
D2388201	FCU:SERVICE:(NA)	7-6
D2388202	FCU:SERVICE:(EU/AA/KOR/CHN)	3-1
D2388202	FCU:SERVICE:(EU/AA/KOR/CHN)	7-6
D2388203	FCU:SERVICE:(TWN)	3-1
D2388203	FCU:SERVICE:(TWN)	7-6
D2395885	INSULATING SHEET:FCU3.8E	3-4
D2395886	BRACKET:SAFETY:FCU3.8E	3-5
D2395887	BRACKET:FCU	3-3
D2395897	BRACKET:G3/G4	5-3
D2415896	BRACKET:G3/G4	9-3
D2415897	BRACKET:FCU	7-3
D2415898	BRACKET:SPEAKER	7-4
D2415899	SUPPORTING PLATE:FCU	7-5
D3BC5001	SD-CARD:CONNECTION:ASS'Y	11-6
D3BD5001	SD-CARD:CONNECTION:ASS'Y	11-5
D3BT5241	HARNESS:FCU-CCU	9-1
D3BV5172	PCB:SG3-ND:ASS'Y:(NA)	5-4
D3BV5172	PCB:SG3-ND:ASS'Y:(NA)	9-4
D3BV5174	PCB:SG3-ND:ASS'Y:(EU/AA/KOR/CHN)	5-4
D3BV5174	PCB:SG3-ND:ASS'Y:(EU/AA/KOR/CHN)	9-4
D3BV5176	PCB:SG3-ND:ASS'Y:(TWN)	5-4
D3BV5176	PCB:SG3-ND:ASS'Y:(TWN)	9-4
D3BV5241	HARNESS:FCU-CCU	5-1
D3BZ5899	BRACKET:MEMORY	11-1
D5931012	BRACKET:HAND SET	11-3
D7395005	HAND SET:ASS'Y:(NA)	11-4
H5235350	MODULER CORD:(NA)	3-6
H5235350	MODULER CORD:(NA)	5-5
H5235350	MODULER CORD:(NA)	7-7
H5235350	MODULER CORD:(NA)	9-5