Notes for Users


These notes provide additional information on the use of this product. Read these notes together with the Troubleshooting.

Section: "When N6 - N22 is Displayed" in Troubleshooting


Correction: When paper becomes jammed inside the N10 cover, take the following

actions


If "N10" appears, release the lock by pulling the lever, open the N10 cover, and then remove any jammed paper from inside.



1 Pull the lever toward you, and then check the lock is released



2 Leaving the N10 cover in its open position, remove any jammed paper from inside.



Copyright © 2009

Printed in Japan

EN (GB) EN (US

D454-8674

