

FS104H (G850)

FS104H (G850)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Main Frame (G850)	2
2.Cover (G850)	4
3.Shift Unit (G850)	6
4.Paper Conveyance 1 (G850)	8
5.Paper Conveyance 2 (G850)	10
6.Paper Exit Unit (G850)	12
7.Shift Tray (G850)	14
8.Drive Section (G850)	16
9.Stacker Unit (G850)	18
10.Stapler Unit (G850)	20
PARTS INDEX	23

September ,1 ' 2005

1.Main Frame (G850)




1.Main Frame (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1246	Side Cover - Right	1
2	G850 1247	Paper Exit Opening Cover	1
3	G850 1248	Side Cover - Left	1
4	G850 1249	Fixed Side Plate - Front	1
5	G850 1148	Support Stay	21
6	G850 1043	Connecting Stay	1
7	G850 1250	Stay	1
8	G850 1251	Fixed Side Plate	1
9	G850 1056	FS-104H P/K	1
10	G850 1252	Slide Stay	1
11	G850 1149	Paper Exit Stopper	1
12	G850 1014	Screw With Washer M4x6	1
13	G850 1150	Cover	1
14	G850 1151	Actuator	1
15	G850 1152	Wire	1
16	G850 1057	Interlock Switch	1
17	G850 1153	Switch Insulating Sheet	1
18	G850 1154	Magnet Catch	1
19	G850 1253	RF Stay	1
20	G850 1046	Main Mt Plate	1
21	G850 1055	Support Plate	2
22	G155 1036	Bind Screw M3x10	1
23	G850 1254	Main Support Shaft	2
24	G850 1255	Main Support Spacer	2
25	G850 1155	Carriage Roller	2
26	G850 1156	Carriage Roller	2
27	G850 1157	EPROM:Ass'y	1
28	G850 1256	Front Door Rf Plate	1
29	G850 1158	Fixed Plate	1
30	G850 1257	Sensor MT Plate	1
31	G850 1058	Photo Sensor	1
32	G850 1159	Driven Shaft Holder	2
33	G850 1258	Support Plate	2
34	G850 1059	Paper Exit Up-down Actuator	1
35	G850 1014	Screw With Washer M4x6	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1160	Stopper Rubber	1
37	G850 1049	Guide Plate	1
38	G850 1047	Guide Plate Ass'y	1
39	G155 1044	Bind Screw M5x8	6
40	G850 1013	Screw With Washer M4x6	9
41	G850 1029	Flexible Grommet	1
42	G850 1019	Bolt	2
43	G850 1023	Spring Washer	2
44	G850 1021	Nut M12	2
45	G850 1008	Screw With Washer M3x6	6
46	G850 1009	Screw With Washer M3x6	4
47	G150 1007	Bind Screw M2x10	1
48	G850 1012	Screw With Washer M3x16	1
49	G150 1009	Bind Screw M3x6	1
50	G850 1036	Locking Wire Saddle	1
51	G850 1035	Nylon Clamp	2
52	G850 1030	Locking Support	1
53	G150 1160	Screw M4x8	1
54	G850 1000	Screw M3x10	3

2.Cover (G850)




2.Cover (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G150 1014	Bind Screw M4x8	4
2	G850 1161	Top Cover	1
3	G850 1260	Paper Exit Stopper Plate	1
4	G850 1060	Spring/Lower	2
5	G850 1061	Paper Exit Driven Roller	4
6	G850 1261	Shaft/Lower	2
7	G850 1162	Cover	2
8	G850 1016	Tapping Screw With Washer M3x8	6
9	G850 1163	Support Stay	1
10	G850 1164	Front Side Plate	1
11	G850 1262	Side Mt Plate	1
12	G850 1165	Front Cover	1
13	G850 1263	Hinge Shaft	2
14	G850 1264	Hinge MT Plate	2
15	G850 1265	Hinge Stay	2
16	G850 1166	Collar	1
17	G850 1167	Actuator	1
18	G850 1168	Magnet Catch Plate	2
19	G850 1266	Rear Cover	1
20	G850 1267	Rear Mt Plate	1
21	G850 1053	Staple Operation Label	1
22	G850 1360	Label	1
23	G850 1052	Jam Operation Label	1
24	G850 1169	Paper Exit Pressure Sheet	1
25	G850 1062	Discharge Brush	1
26	G850 1170	Neutralizing Plate	1
27	G850 1054	Lever Operation Label	1
28	G850 1268	Rear Mt Plate	1
29	G850 1039	Conecting Cover(F)	1
30	G850 1040	Conecting Cover(R)	1
31	G850 1050	Rear Mt Plate	2
32	G850 1037	Screw M4x6	6
33	G150 1153	Screw M3x6	2
34	G850 1025	D3 Retaining Ring-E	4
35	G850 1008	Screw With Washer M3x6	7

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1017	Tapping Screw With Washer M4x8	3
37	G850 1018	Tapping Screw With Washer M4x10	1

3.Shift Unit (G850)




3.Shift Unit (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1063	Shift Motor - DC2W	1
2	G850 1269	Motor Mt Plate	1
3	G850 1058	Photo Sensor	1
4	G850 1270	Bracket	1
5	G850 1271	Slide Stay/A Ass'y	1
6	G850 1272	Guide Plate	1
7	G850 1064	Shaft Holder	6
8	G850 1065	Gear	2
9	G850 1066	Gear	1
10	G850 1171	Slide Arm	1
11	G850 1172	Lever Spring	2
12	G850 1173	Spring Mt Plate	2
13	G850 1174	Spring Lever	2
14	G850 1175	Stopper Rubber	4
15	G850 1108	Pressure Roller	3
16	G850 1273	Rotary Shaft	1
17	G850 1274	Slide Shaft	2
18	G850 1148	Support Stay	5
19	G850 1176	Shaft Holder	6
20	G850 1275	Stopper Plate	3
21	G850 1276	Slide Stay Ass'y	1
22	G850 1277	Slide Shaft	1
23	G850 1177	Stopper Sheet	6
24	G850 1109	Pressure Roller	1
25	G850 1178	Guide Plate - Upper	1
26	G850 1278	Conveyance Shaftass'y	1
27	G850 1067	Entrance Roller	2
28	G850 1279	Conveyance Pressure Plate	1
29	G850 1280	Release Shaft	1
30	G850 1068	Driving Pulley	1
31	G850 1179	Solenoid Lever	1
32	G850 1281	Guide Plate - Lower	1
33	G850 1069	Fns Solenoid Ass'y	1
34	G850 1282	Slide Stay	1
35	G850 1180	Conveyance Pressure Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1181	Aux Lever	2
37	G850 1283	Slide Plate Ass'y	2
38	G850 1182	Conveyance Pressure Spring	1
39	G850 1284	Shaft Holder ADJ Plate	1
40	G850 1022	Snap Ring	6
41	G850 1026	D4 Retaining Ring-E	10
42	G850 1025	D3 Retaining Ring-E	7
43	G850 1024	D2 Retaining Ring-E	2
44	G850 1008	Screw With Washer M3x6	16
45	G850 1027	D6 Retaining Ring-E	1
46	G150 1153	Screw M3x6	1
47	G850 1017	Tapping Screw With Washer M4x8	1
48	G850 1004	Screw M2.6x4	1
49	G155 1036	Bind Screw M3x10	1
50	G850 1036	Locking Wire Saddle	1
51	G850 1000	Screw M3x10	2
52	G850 1002	Screw M4x6	1

4.Paper Conveyance 1 (G850)




4. Paper Conveyance 1 (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1015	Screw With Washer M4x14	1
2	G850 1359	Conveyance Pressure Spring	1
3	G850 1042	Guide Plate	1
4	G850 1184	Release Lever Knob	1
5	G850 1185	Lift-up Stay	1
6	G850 1186	Magnet Catch	2
7	G850 1067	Entrance Roller	2
8	G150 1009	Bind Screw M3x6	2
9	G850 1285	Conveyance Shaft/B Ass'y	1
10	G850 1286	Rear Guide Plate	1
11	G850 1041	Guide Plate	1
12	G850 1175	Stopper Rubber	2
13	G850 1187	Wire	1
14	G850 1070	Photo Sensor	1
15	G850 1188	Detecting Sensor	1
16	G850 1189	Conveyance Guide Sheet	2
17	G850 1190	Sub-tray Gate	1
18	G850 1191	Solenoid Spring	1
19	G850 1071	Exit Roller	1
20	G850 1072	Transport Roller	1
21	G850 1073	Transport Roller	1
22	G850 1074	Metal Clamp	3
23	G850 1064	Shaft Holder	3
24	G850 1192	Guide Shaft	1
25	G150 1008	Bind Screw M3x5	2
26	G850 1008	Screw With Washer M3x6	5
27	G850 1287	RF Plate	1
28	G850 1361	E Ring	4
29	G850 1027	D6 Retaining Ring-E	2
30	G850 1024	D2 Retaining Ring-E	2
31	G850 1007	Screw With Washer M3x4	2
32	G850 1017	Tapping Screw With Washer M4x8	1

Index No.	Part No.	Description	Q'ty Per Assembly

5. Paper Conveyance 2 (G850)




5.Paper Conveyance 2 (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1007	Screw With Washer M3x4	2
1	G850 1188	Detecting Sensor	1
2	G850 1070	Photo Sensor	1
3	G850 1288	Guide Plate	1
4	G850 1175	Stopper Rubber	4
5	G850 1193	Hinge Spring	1
6	G850 1194	Hinge Spring	1
7	G850 1289	Guide Plate	1
8	G850 1184	Release Lever Knob	2
9	G850 1185	Lift-up Stay	1
10	G850 1067	Entrance Roller	2
11	G850 1183	Conveyance Pressure Spring	4
13	G850 1290	Conveyance Shaft Ass'y	1
14	G850 1291	Guide Plate	1
15	G850 1285	Conveyance Shaft/B Ass'y	1
16	G150 1008	Bind Screw M3x5	2
17	G850 1292	Guide Plate	1
18	G850 1154	Magnet Catch	2
19	G850 1075	Conveyance Roller	1
20	G850 1195	Paper Route Switching Gate	1
21	G850 1196	Solenoid Spring	2
22	G850 1197	By-pass Gate	1
23	G850 1074	Metal Clamp	3
24	G850 1064	Shaft Holder	2
25	G850 1076	Middle Sponge Roller	4
26	G850 1017	Tapping Screw With Washer M4x8	2
27	G850 1293	Conveyance Shaft	1
28	G850 1294	RF Plate	1
29	G850 1295	RF Plate	1
30	G850 1024	D2 Retaining Ring-e	4
31	G850 1077	Conveyance Roller	2
32	G850 1026	D4 Retaining Ring-e	6
33	G850 1008	Screw With Washer M3x6	7
34	G850 1027	D6 Retaining Ring-E	3
35	G850 1005	Screw M3x6	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1015	Screw With Washer M4x14	1

6.Paper Exit Unit (G850)




6.Paper Exit Unit (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1079	Solenoid Ass'y	1
2	G850 1016	Tapping Screw With Washer M3x8	1
3	G850 1296	Solenoid Mt Plate	1
4	G850 1198	Solenoid Spring	1
5	G850 1199	Solenoid Lever	1
6	G850 1297	Paper Exit Guide Stay	1
7	G850 1171	Slide Arm	1
8	G850 1148	Support Stay	3
9	G850 1080	Pin	6
10	G850 1298	Paper Exit Conveyance Shaft	1
11	G850 1299	Paper Exit Support Shaft	1
12	G850 1110	Paper Exit Roller	3
13	G850 1034	Nylon Clamp	1
14	G850 1200	Rotary Stopper	2
15	G850 1064	Shaft Holder	5
16	G850 1081	Shaft Holder	2
17	G850 1201	Paper Exit Pressure Spring	2
18	G850 1300	Paper Exit Guide Stay	1
19	G850 1082	Discharge Brush	1
20	G850 1044	Guide Plate	1
21	G850 1301	Paper Exit Guide Sheet	3
22	G850 1045	Lower Guide Plate	1
23	G850 1302	Stopper	2
24	G850 1070	Photo Sensor	1
25	G850 1357	Sensor Cover Ass'y	1
26	G850 1017	Tapping Screw With Washer M4x8	1
27	G850 1303	Paper Exit Driving Shaft	1
28	G850 1111	Paper Exit Roller	8
29	G850 1304	Lower Guide Plate	1
30	G850 1305	Rotary Disk Ass'y	2
31	G850 1083	Exit Roller	3
32	G850 1084	Paper Exit Pulley	1
33	G850 1112	Conveyance Motor - DC20W	1
34	G850 1085	Motor Pulley	1
35	G850 1086	Belt	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1087	Belt	1
37	G850 1088	Shaft Holder	4
38	G850 1074	Metal Clamp	4
39	G850 1068	Driving Pulley	1
40	G850 1089	Belt	1
41	G850 1090	Driving Pulley	1
42	G850 1091	Paper Exit Pulley	1
43	G850 1202	Collar	2
44	G850 1092	Paper Exit Spring	1
45	G850 1306	Paper Exit Opening Unit	1
46	G850 1307	Paper Exit Guide Plate	1
47	G850 1308	Paper Exit Guide Stay	1
48	G850 1027	D6 Retaining Ring-E	9
49	G850 1020	Set Screw M3x6	1
50	G850 1011	Screw With Washer M3x10	1
51	G850 1031	Locking Board Spacer	1
52	G850 1008	Screw With Washer M3x6	10
53	G850 1015	Screw With Washer M4x14	1
54	G150 1009	Bind Screw M3x6	1
55	G850 1026	D4 Retaining Ring-E	9
56	G150 1153	Screw M3x6	2

7.Shift Tray (G850)




7.Shift Tray (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1309	Slide Shaft	4
2	G850 1093	Roller	4
3	G850 1203	Slide Stopper	2
4	G850 1310	Up-down Stay	1
5	G850 1311	Up-down Cover/R	1
6	G850 1312	Up-down Cover/F	1
7	G850 1094	Shift Tray	1
8	G850 1000	Screw M3x10	1
9	G850 1313	Mt Plate Ass'y	1
10	G850 1204	Staple Paper Exit Actuator	1
11	G850 1058	Photo Sensor	2
12	G850 1205	Fns Wiring	3
13	G850 1095	Tension Pulley	2
14	G850 1314	Tension Plate Ass'y	2
15	G850 1096	Up-down Wire	1
16	G850 1097	Tray Up-down Motor	1
17	G850 1315	Motor Mt Plate	1
18	G850 1025	D3 Retaining Ring-e	1
19	G850 1074	Metal Clamp	4
20	G850 1206	Up-down Gear	1
21	G850 1207	Up-down Gear	1
22	G850 1316	Motor Fixed Plate Ass'y	1
23	G850 1098	Up-down Pulley	2
24	G850 1113	Metal	2
25	G850 1208	Up-down Gear	1
26	G850 1209	Pin	2
27	G850 1317	Up-down Shaft	1
28	G850 1099	Up-down Wire	1
29	G850 1318	Aux Plate	2
30	G850 1358	Paper Exit Pressure Sheet	2
31	G850 1082	Discharge Brush	1
32	G850 1210	Protect Block	1
33	G850 1211	Paper Exit Pressure Sheet	6
34	G850 1027	D6 Retaining Ring-E	6
35	G150 1160	Screw M4x8	4

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1028	D8 Retaining Ring-E	3
37	G155 1036	Bind Screw M3x10	2
38	G850 1013	Screw With Washer M4x6	9
39	G850 1028	D8 Retaining Ring-E	4
40	G850 1008	Screw With Washer M3x6	2
41	G850 1009	Screw With Washer M3x6	3

8. Drive Section (G850)




8. Drive Section (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1114	Conveyance Motor - DC23W	1
2	G850 1085	Motor Pulley	1
3	G850 1089	Belt	1
4	G850 1088	Shaft Holder	4
5	G850 1115	Driving Pulley - Z24	1
6	G850 1100	Driving Gear - Z24	1
7	G850 1064	Shaft Holder	1
8	G850 1212	Spring	8
9	G850 1319	Tension Plate Ass'y	1
10	G850 1116	Driving Pulley	2
11	G850 1202	Collar	1
12	G850 1101	Belt	1
13	G850 1320	Solenoid Mt Plate	1
14	G850 1179	Solenoid Lever	3
15	G850 1069	Fns Solenoid Ass'y	3
16	G850 1025	D3 Retaining Ring-E	1
17	G850 1321	Solenoid Mt Plate	2
18	G850 1148	Support Stay	2
19	G850 1006	Screw M3x10	1
20	G850 1058	Photo Sensor	1
21	G850 1270	Bracket	1
22	G850 1102	Paper Exit Gear	2
23	G850 1066	Gear	1
24	G850 1117	Driving Pulley	2
25	G850 1001	Screw M3x6	6
26	G850 1026	D4 Retaining Ring-E	2
27	G850 1063	Shift Motor - DC2W	1
28	G850 1103	Belt	1
29	G850 1068	Driving Pulley	1
30	G850 1003	Screw M2.6x4	1
31	G850 1104	Pulley	1
32	G850 1105	Gear	1
33	G850 1074	Metal Clamp	2
34	G850 1031	Locking Board Spacer	1
35	G850 1322	Tension Plate Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1051	Idler Pulley - Z27	1
37	G850 1106	Pulley	1
38	G850 1323	Tension Plate Ass'y	1
39	G850 1107	Belt	1
40	G850 1087	Belt	1
41	G850 1118	Tension Roller	1
42	G850 1324	Tension Plate Ass'y	1
43	G850 1119	Tension Roller	1
44	G850 1120	Driving Spacer	2
45	G850 1027	D6 Retaining Ring-E	7
46	G850 1020	Set Screw M3x6	1
47	G850 1008	Screw With Washer M3x6	8

9.Stacker Unit (G850)




9.Stacker Unit (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1213	Alignment Plate	1
2	G850 1214	Alignment Plate	1
3	G850 1027	D6 Retaining Ring-E	1
4	G850 1020	Set Screw M3x6	1
5	G850 1070	Photo Sensor	2
6	G850 1215	Guide Plate/Middle	1
7	G850 1074	Metal Clamp	8
8	G850 1080	Pin	10
9	G850 1325	Driving Shaft	1
10	G850 1121	Driving Pulley - Z43	1
11	G850 1122	Belt Detction Gear	1
12	G850 1216	Belt Detecting Screw	1
13	G850 1326	Bottom Plate Ass'y	1
14	G850 1217	Rocking Block Ass'y	2
15	G850 1218	Belt Holder Plate	2
16	G850 1327	Slide Shaft	2
17	G850 1177	Stopper Sheet	2
18	G850 1219	Belt Holder	4
19	G850 1123	Paper Exit Belt	2
20	G850 1124	Belt Driving Pulley	4
21	G850 1125	Regulation Gear	1
22	G850 1126	Belt	1
23	G850 1220	Belt Holder	2
24	G850 1127	Idler Pulley	1
25	G850 1328	Tension Plate Ass'y	1
26	G850 1128	Fns Correction Motor - DC9W	1
27	G850 1221	Wire	1
28	G850 1359	Conveyance Pressure Spring	1
29	G850 1129	Pin	1
30	G850 1290	Conveyance Shaft Ass'y	1
31	G850 1067	Entrance Roller	2
32	G850 1082	Discharge Brush	1
33	G850 1329	Guide Plate A	1
34	G850 1330	Guide Plate	1
35	G850 1331	Tension Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1332	Driven Shaft	1
37	G850 1130	Drive Pulley	1
38	G850 1131	Belt	1
39	G850 1085	Motor Pulley	1
40	G850 1132	Stacker Entrance Motor	1
41	G850 1333	Mount Plate	1
42	G850 1357	Sensor Cover Ass'y	1
43	G850 1222	Belt Holder	4
44	G850 1133	Entrance Guide Pulley	4
45	G850 1134	Driving Roller	1
46	G850 1334	Belt Driven Shaft	1
47	G850 1135	Entrance Guide Pulley	4
48	G850 1136	Guide Belt	4
49	G850 1137	Belt	4
50	G850 1138	Paper Conveyance Rubber	2
51	G850 1223	Aux Roller	2
52	G850 1064	Shaft Holder	2
53	G850 1335	Oscillate Plate Ass'y	1
54	G850 1139	Oscillate Pulley - Z20	1
55	G850 1336	Pressure Plate	2
56	G850 1140	Sponge Roller	1
57	G850 1141	Belt	1
58	G850 1142	Fixing Ring	1
59	G850 1224	Holding Part	1
60	G850 1337	Conveyance Pressure Part	2
61	G850 1225	Conveyance Aux Collar	2
62	G850 1226	Conveyance Aux Sheet	2
63	G850 1027	D6 Retaining Ring-e	21
64	G150 1153	Screw M3x6	4
65	G150 1009	Bind Screw M3x6	3
66	G850 1025	D3 Retaining Ring-e	2
67	G155 1036	Bind Screw M3x10	1
68	G850 1015	Screw With Washer M4x14	2
69	G850 1008	Screw With Washer M3x6	2
70	G850 1024	D2 Retaining Ring-E	2

10.Stapler Unit (G850)



10.Stapler Unit (G850)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1338	Fulcrum Shaft	1
2	G850 1227	Knob	1
3	G850 1228	Fns Wiring	2
4	G850 1058	Photo Sensor	3
5	G850 1339	Driving Board Ass'y	1
6	G850 1229	Staple Rotary Gear - Z100	2
7	G850 1230	Motor Ass'y	1
8	G850 1231	Paper Lift-up Gear	2
9	G850 1232	Paper Lift-up Gear	2
10	G850 1012	Screw With Washer M3x16	2
11	G850 1143	Driving Board Ass'y	1
12	G850 1233	Cover	4
13	G850 1128	Fns Correction Motor - DC9W	1
14	G850 1340	Staple Plate Ass'y	1
15	G850 1234	Tension Spring	2
16	G850 1125	Regulation Gear	1
17	G850 1144	Staple Driving Gear	1
18	G850 1235	Ps Block	1
19	G850 1145	Release Spring	1
20	G850 1341	Release Shaft	1
21	G850 1328	Tension Plate Ass'y	1
22	G850 1127	Idler Pulley	1
23	G850 1126	Belt	1
24	G850 1220	Belt Holder	2
25	G850 1342	Shaft Rail	1
26	G850 1343	Cam Lever	2
27	G850 1344	Fulcrum Shaft	2
28	G850 1236	Guide Block	2
29	G850 1108	Pressure Roller	6
30	G850 1345	Mt Plate Ass'y	2
31	G850 1237	Fns Wiring	2
32	G850 1238	Shaft Holder	4
33	G850 1346	Rotary Disk	2
34	G850 1239	Spring	2
35	G850 1240	Stopper	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1241	Fixed Block	2
37	G850 1347	Belt Fixed Plate	2
38	G850 1038	Fulcrum Plate	2
39	G850 1348	Guide Plate	2
40	G850 1242	Staple Guide Block	2
41	G850 1146	Stapler	2
42	G850 1147	Cartridge Case	2
43	G150 1153	Screw M3x6	4
44	G850 1349	Staple Cover	2
45	G850 1350	Rotary Disk	2
46	G850 1351	PS Pin	6
47	G850 1352	Idler Shaft	4
48	G850 1353	Staple MT Plate	2
49	G850 1243	Staple Guide Sheet	2
50	G850 1148	Support Stay	4
51	G850 1354	Stopper	4
52	G850 1355	Support Panel Ass'y	1
53	G850 1356	Staple RF Stopper	2
54	G850 1244	Staple Changeable Stopper	2
55	G850 1362	Staple Guide Block - Upper	2
56	G850 1245	Stopper Sheet	4
57	G850 1032	Screw With Washer M4x6	13
58	G850 1027	D6 Retaining Ring-E	12
59	G150 1153	Screw M3x6	7
60	G850 1008	Screw With Washer M3x6	34
61	G155 1036	Bind Screw M3x10	3
62	G850 1026	D4 Retaining Ring-E	9
63	G150 1009	Bind Screw M3x6	1
64	G850 1004	Screw M2.6x4	1

Parts Index

Parts Index

Part No.	Description	Page and Index No.
G850 1000	Screw M3x10	3 - 54
G850 1000	Screw M3x10	15 - 8
G850 1000	Screw M3x10	7 - 51
G850 1001	Screw M3x6	17 - 25
G850 1002	Screw M4x6	7 - 52
G850 1003	Screw M2.6x4	17 - 30
G850 1004	Screw M2.6x4	21 - 64
G850 1004	Screw M2.6x4	7 - 48
G850 1005	Screw M3x6	11 - 35
G850 1006	Screw M3x10	17 - 19
G850 1007	Screw With Washer M3x4	19 - 71
G850 1007	Screw With Washer M3x4	9 - 31
G850 1007	Screw With Washer M3x4	11 - 1
G850 1008	Screw With Washer M3x6	17 - 47
G850 1008	Screw With Washer M3x6	13 - 52
G850 1008	Screw With Washer M3x6	15 - 40
G850 1008	Screw With Washer M3x6	7 - 44
G850 1008	Screw With Washer M3x6	3 - 45
G850 1008	Screw With Washer M3x6	5 - 35
G850 1008	Screw With Washer M3x6	19 - 69
G850 1008	Screw With Washer M3x6	21 - 60
G850 1008	Screw With Washer M3x6	9 - 26
G850 1008	Screw With Washer M3x6	11 - 33
G850 1009	Screw With Washer M3x6	15 - 41
G850 1009	Screw With Washer M3x6	3 - 46
G850 1011	Screw With Washer M3x10	13 - 50
G850 1012	Screw With Washer M3x16	3 - 48
G850 1012	Screw With Washer M3x16	21 - 10
G850 1013	Screw With Washer M4x6	3 - 40
G850 1013	Screw With Washer M4x6	15 - 38
G850 1014	Screw With Washer M4x6	3 - 12
G850 1014	Screw With Washer M4x6	3 - 35
G850 1015	Screw With Washer M4x14	9 - 1
G850 1015	Screw With Washer M4x14	11 - 36
G850 1015	Screw With Washer M4x14	13 - 53

Part No.	Description	Page and Index No.
G850 1015	Screw With Washer M4x14	19 - 68
G850 1016	Tapping Screw With Washer M3x8	5 - 8
G850 1016	Tapping Screw With Washer M3x8	13 - 2
G850 1017	Tapping Screw With Washer M4x8	5 - 36
G850 1017	Tapping Screw With Washer M4x8	13 - 26
G850 1017	Tapping Screw With Washer M4x8	7 - 47
G850 1017	Tapping Screw With Washer M4x8	11 - 26
G850 1017	Tapping Screw With Washer M4x8	9 - 32
G850 1018	Tapping Screw With Washer M4x10	5 - 37
G850 1019	Bolt	3 - 42
G850 1020	Set Screw M3x6	17 - 46
G850 1020	Set Screw M3x6	19 - 4
G850 1020	Set Screw M3x6	13 - 49
G850 1021	Nut M12	3 - 44
G850 1022	Snap Ring	7 - 40
G850 1023	Spring Washer	3 - 43
G850 1024	D2 Retaining Ring-E	7 - 43
G850 1024	D2 Retaining Ring-e	11 - 30
G850 1024	D2 Retaining Ring-E	9 - 30
G850 1024	D2 Retaining Ring-E	19 - 70
G850 1025	D3 Retaining Ring-e	19 - 66
G850 1025	D3 Retaining Ring-e	15 - 18
G850 1025	D3 Retaining Ring-E	17 - 16
G850 1025	D3 Retaining Ring-E	7 - 42
G850 1025	D3 Retaining Ring-E	5 - 34
G850 1026	D4 Retaining Ring-E	21 - 62
G850 1026	D4 Retaining Ring-e	11 - 32
G850 1026	D4 Retaining Ring-E	17 - 26
G850 1026	D4 Retaining Ring-E	13 - 55
G850 1026	D4 Retaining Ring-E	7 - 41
G850 1027	D6 Retaining Ring-E	21 - 58
G850 1027	D6 Retaining Ring-E	17 - 45
G850 1027	D6 Retaining Ring-E	19 - 3
G850 1027	D6 Retaining Ring-E	13 - 48
G850 1027	D6 Retaining Ring-E	15 - 34

Part No.	Description	Page and Index No.
G850 1027	D6 Retaining Ring-E	9 - 29
G850 1027	D6 Retaining Ring-E	7 - 45
G850 1027	D6 Retaining Ring-e	19 - 63
G850 1027	D6 Retaining Ring-E	11 - 34
G850 1028	D8 Retaining Ring-E	15 - 39
G850 1028	D8 Retaining Ring-E	15 - 36
G850 1029	Flexible Grommet	3 - 41
G850 1030	Locking Support	3 - 52
G850 1031	Locking Board Spacer	13 - 51
G850 1031	Locking Board Spacer	17 - 34
G850 1032	Screw With Washer M4x6	21 - 57
G850 1034	Nylon Clamp	13 - 13
G850 1035	Nylon Clamp	3 - 51
G850 1036	Locking Wire Saddle	3 - 50
G850 1036	Locking Wire Saddle	7 - 50
G850 1037	Screw M4x6	5 - 32
G850 1038	Fulcrum Plate	21 - 38
G850 1039	Conecting Cover(F)	5 - 29
G850 1040	Conecting Cover(R)	5 - 30
G850 1041	Guide Plate	9 - 11
G850 1042	Guide Plate	9 - 3
G850 1043	Connecting Stay	3 - 6
G850 1044	Guide Plate	13 - 20
G850 1045	Lower Guide Plate	13 - 22
G850 1046	Main Mt Plate	3 - 20
G850 1047	Guide Plate Ass'y	3 - 38
G850 1049	Guide Plate	3 - 37
G850 1050	Rear Mt Plate	5 - 31
G850 1051	Idler Pulley - Z27	17 - 36
G850 1052	Jam Operation Label	5 - 23
G850 1053	Staple Operation Label	5 - 21
G850 1054	Lever Operation Label	5 - 27
G850 1055	Support Plate	3 - 21
G850 1056	FS-104H P/K	3 - 9
G850 1057	Interlock Switch	3 - 16

Part No.	Description	Page and Index No.
G850 1058	Photo Sensor	21 - 4
G850 1058	Photo Sensor	17 - 20
G850 1058	Photo Sensor	7 - 3
G850 1058	Photo Sensor	15 - 11
G850 1058	Photo Sensor	3 - 31
G850 1059	Paper Exit Up-down Actuator	3 - 34
G850 1060	Spring/Lower	5 - 4
G850 1061	Paper Exit Driven Roller	5 - 5
G850 1062	Discharge Brush	5 - 25
G850 1063	Shift Motor - DC2W	17 - 27
G850 1063	Shift Motor - DC2W	7 - 1
G850 1064	Shaft Holder	11 - 24
G850 1064	Shaft Holder	19 - 52
G850 1064	Shaft Holder	17 - 7
G850 1064	Shaft Holder	7 - 7
G850 1064	Shaft Holder	13 - 15
G850 1064	Shaft Holder	9 - 23
G850 1065	Gear	7 - 8
G850 1066	Gear	7 - 9
G850 1066	Gear	17 - 23
G850 1067	Entrance Roller	9 - 7
G850 1067	Entrance Roller	11 - 10
G850 1067	Entrance Roller	19 - 31
G850 1067	Entrance Roller	7 - 27
G850 1068	Driving Pulley	13 - 39
G850 1068	Driving Pulley	17 - 29
G850 1068	Driving Pulley	7 - 30
G850 1069	Fns Solenoid Ass'y	7 - 33
G850 1069	Fns Solenoid Ass'y	17 - 15
G850 1070	Photo Sensor	9 - 14
G850 1070	Photo Sensor	11 - 2
G850 1070	Photo Sensor	13 - 24
G850 1070	Photo Sensor	19 - 5
G850 1071	Exit Roller	9 - 19
G850 1072	Transport Roller	9 - 20

Part No.	Description	Page and Index No.
G850 1073	Transport Roller	9 - 21
G850 1074	Metal Clamp	11 - 23
G850 1074	Metal Clamp	9 - 22
G850 1074	Metal Clamp	17 - 33
G850 1074	Metal Clamp	19 - 7
G850 1074	Metal Clamp	15 - 19
G850 1074	Metal Clamp	13 - 38
G850 1075	Conveyance Roller	11 - 19
G850 1076	Middle Sponge Roller	11 - 25
G850 1077	Conveyance Roller	11 - 31
G850 1079	Solenoid Ass'y	13 - 1
G850 1080	Pin	13 - 9
G850 1080	Pin	19 - 8
G850 1081	Shaft Holder	13 - 16
G850 1082	Discharge Brush	15 - 31
G850 1082	Discharge Brush	13 - 19
G850 1082	Discharge Brush	19 - 32
G850 1083	Exit Roller	13 - 31
G850 1084	Paper Exit Pulley	13 - 32
G850 1085	Motor Pulley	13 - 34
G850 1085	Motor Pulley	19 - 39
G850 1085	Motor Pulley	17 - 2
G850 1086	Belt	13 - 35
G850 1087	Belt	13 - 36
G850 1087	Belt	17 - 40
G850 1088	Shaft Holder	17 - 4
G850 1088	Shaft Holder	13 - 37
G850 1089	Belt	17 - 3
G850 1089	Belt	13 - 40
G850 1090	Driving Pulley	13 - 41
G850 1091	Paper Exit Pulley	13 - 42
G850 1092	Paper Exit Spring	13 - 44
G850 1093	Roller	15 - 2
G850 1094	Shift Tray	15 - 7
G850 1095	Tension Pulley	15 - 13

Part No.	Description	Page and Index No.
G850 1096	Up-down Wire	15 - 15
G850 1097	Tray Up-down Motor	15 - 16
G850 1098	Up-down Pulley	15 - 23
G850 1099	Up-down Wire	15 - 28
G850 1100	Driving Gear - Z24	17 - 6
G850 1101	Belt	17 - 12
G850 1102	Paper Exit Gear	17 - 22
G850 1103	Belt	17 - 28
G850 1104	Pulley	17 - 31
G850 1105	Gear	17 - 32
G850 1106	Pulley	17 - 37
G850 1107	Belt	17 - 39
G850 1108	Pressure Roller	21 - 29
G850 1108	Pressure Roller	7 - 15
G850 1109	Pressure Roller	7 - 24
G850 1110	Paper Exit Roller	13 - 12
G850 1111	Paper Exit Roller	13 - 28
G850 1112	Conveyance Motor - DC20W	13 - 33
G850 1113	Metal	15 - 24
G850 1114	Conveyance Motor - DC23W	17 - 1
G850 1115	Driving Pulley - Z24	17 - 5
G850 1116	Driving Pulley	17 - 10
G850 1117	Driving Pulley	17 - 24
G850 1118	Tension Roller	17 - 41
G850 1119	Tension Roller	17 - 43
G850 1120	Driving Spacer	17 - 44
G850 1121	Driving Pulley - Z43	19 - 10
G850 1122	Belt Detction Gear	19 - 11
G850 1123	Paper Exit Belt	19 - 19
G850 1124	Belt Driving Pulley	19 - 20
G850 1125	Regulation Gear	21 - 16
G850 1125	Regulation Gear	19 - 21
G850 1126	Belt	21 - 23
G850 1126	Belt	19 - 22
G850 1127	Idler Pulley	21 - 22

Part No.	Description	Page and Index No.
G850 1127	Idler Pulley	19 - 24
G850 1128	Fns Correction Motor - DC9W	19 - 26
G850 1128	Fns Correction Motor - DC9W	21 - 13
G850 1129	Pin	19 - 29
G850 1130	Drive Pulley	19 - 37
G850 1131	Belt	19 - 38
G850 1132	Stacker Entrance Motor	19 - 40
G850 1133	Entrance Guide Pulley	19 - 44
G850 1134	Driving Roller	19 - 45
G850 1135	Entrance Guide Pulley	19 - 47
G850 1136	Guide Belt	19 - 48
G850 1137	Belt	19 - 49
G850 1138	Paper Conveyance Rubber	19 - 50
G850 1139	Oscillate Pulley - Z20	19 - 54
G850 1140	Sponge Roller	19 - 56
G850 1141	Belt	19 - 57
G850 1142	Fixing Ring	19 - 58
G850 1143	Driving Board Ass'y	21 - 11
G850 1144	Staple Driving Gear	21 - 17
G850 1145	Release Spring	21 - 19
G850 1146	Stapler	21 - 41
G850 1147	Cartridge Case	21 - 42
G850 1148	Support Stay	7 - 18
G850 1148	Support Stay	3 - 5
G850 1148	Support Stay	21 - 50
G850 1148	Support Stay	17 - 18
G850 1148	Support Stay	13 - 8
G850 1149	Paper Exit Stopper	3 - 11
G850 1150	Cover	3 - 13
G850 1151	Actuator	3 - 14
G850 1152	Wire	3 - 15
G850 1153	Switch Insulating Sheet	3 - 17
G850 1154	Magnet Catch	3 - 18
G850 1154	Magnet Catch	11 - 18
G850 1155	Carriage Roller	3 - 25

Part No.	Description	Page and Index No.
G850 1156	Carriage Roller	3 - 26
G850 1157	EPROM:Ass'y	3 - 27
G850 1158	Fixed Plate	3 - 29
G850 1159	Driven Shaft Holder	3 - 32
G850 1160	Stopper Rubber	3 - 36
G850 1161	Top Cover	5 - 2
G850 1162	Cover	5 - 7
G850 1163	Support Stay	5 - 9
G850 1164	Front Side Plate	5 - 10
G850 1165	Front Cover	5 - 12
G850 1166	Collar	5 - 16
G850 1167	Actuator	5 - 17
G850 1168	Magnet Catch Plate	5 - 18
G850 1169	Paper Exit Pressure Sheet	5 - 24
G850 1170	Neutralizing Plate	5 - 26
G850 1171	Slide Arm	13 - 7
G850 1171	Slide Arm	7 - 10
G850 1172	Lever Spring	7 - 11
G850 1173	Spring Mt Plate	7 - 12
G850 1174	Spring Lever	7 - 13
G850 1175	Stopper Rubber	7 - 14
G850 1175	Stopper Rubber	9 - 12
G850 1175	Stopper Rubber	11 - 4
G850 1176	Shaft Holder	7 - 19
G850 1177	Stopper Sheet	19 - 17
G850 1177	Stopper Sheet	7 - 23
G850 1178	Guide Plate - Upper	7 - 25
G850 1179	Solenoid Lever	17 - 14
G850 1179	Solenoid Lever	7 - 31
G850 1180	Conveyance Pressure Spring	7 - 35
G850 1181	Aux Lever	7 - 36
G850 1182	Conveyance Pressure Spring	7 - 38
G850 1183	Conveyance Pressure Spring	11 - 11
G850 1184	Release Lever Knob	11 - 8
G850 1184	Release Lever Knob	9 - 4

Part No.	Description	Page and Index No.
G850 1185	Lift-up Stay	11 - 9
G850 1185	Lift-up Stay	9 - 5
G850 1186	Magnet Catch	9 - 6
G850 1187	Wire	9 - 13
G850 1188	Detecting Sensor	11 - 1
G850 1188	Detecting Sensor	9 - 15
G850 1189	Conveyance Guide Sheet	9 - 16
G850 1190	Sub-tray Gate	9 - 17
G850 1191	Solenoid Spring	9 - 18
G850 1192	Guide Shaft	9 - 24
G850 1193	Hinge Spring	11 - 5
G850 1194	Hinge Spring	11 - 6
G850 1195	Paper Route Switching Gate	11 - 20
G850 1196	Solenoid Spring	11 - 21
G850 1197	By-pass Gate	11 - 22
G850 1198	Solenoid Spring	13 - 4
G850 1199	Solenoid Lever	13 - 5
G850 1200	Rotary Stopper	13 - 14
G850 1201	Paper Exit Pressure Spring	13 - 17
G850 1202	Collar	17 - 11
G850 1202	Collar	13 - 43
G850 1203	Slide Stopper	15 - 3
G850 1204	Staple Paper Exit Actuator	15 - 10
G850 1205	Fns Wiring	15 - 12
G850 1206	Up-down Gear	15 - 20
G850 1207	Up-down Gear	15 - 21
G850 1208	Up-down Gear	15 - 25
G850 1209	Pin	15 - 26
G850 1210	Protect Block	15 - 32
G850 1211	Paper Exit Pressure Sheet	15 - 33
G850 1212	Spring	17 - 8
G850 1213	Alignment Plate	19 - 1
G850 1214	Alignment Plate	19 - 2
G850 1215	Guide Plate/Middle	19 - 6
G850 1216	Belt Detecting Screw	19 - 12

Part No.	Description	Page and Index No.
G850 1217	Rocking Block Ass'y	19 - 14
G850 1218	Belt Holder Plate	19 - 15
G850 1219	Belt Holder	19 - 18
G850 1220	Belt Holder	19 - 23
G850 1220	Belt Holder	21 - 24
G850 1221	Wire	19 - 27
G850 1222	Belt Holder	19 - 43
G850 1223	Aux Roller	19 - 51
G850 1224	Holding Part	19 - 59
G850 1225	Conveyance Aux Collar	19 - 61
G850 1226	Conveyance Aux Sheet	19 - 62
G850 1227	Knob	21 - 2
G850 1228	Fns Wiring	21 - 3
G850 1229	Staple Rotary Gear - Z100	21 - 6
G850 1230	Motor Ass'y	21 - 7
G850 1231	Paper Lift-up Gear	21 - 8
G850 1232	Paper Lift-up Gear	21 - 9
G850 1233	Cover	21 - 12
G850 1234	Tension Spring	21 - 15
G850 1235	Ps Block	21 - 18
G850 1236	Guide Block	21 - 28
G850 1237	Fns Wiring	21 - 31
G850 1238	Shaft Holder	21 - 32
G850 1239	Spring	21 - 34
G850 1240	Stopper	21 - 35
G850 1241	Fixed Block	21 - 36
G850 1242	Staple Guide Block	21 - 40
G850 1243	Staple Guide Sheet	21 - 49
G850 1244	Staple Changeable Stopper	21 - 54
G850 1245	Stopper Sheet	21 - 56
G850 1246	Side Cover - Right	3 - 1
G850 1247	Paper Exit Opening Cover	3 - 2
G850 1248	Side Cover - Left	3 - 3
G850 1249	Fixed Side Plate - Front	3 - 4
G850 1250	Stay	3 - 7

Part No.	Description	Page and Index No.
G850 1251	Fixed Side Plate	3 - 8
G850 1252	Slide Stay	3 - 10
G850 1253	RF Stay	3 - 19
G850 1254	Main Support Shaft	3 - 23
G850 1255	Main Support Spacer	3 - 24
G850 1256	Front Door Rf Plate	3 - 28
G850 1257	Sensor MT Plate	3 - 30
G850 1258	Support Plate	3 - 33
G850 1260	Paper Exit Stopper Plate	5 - 3
G850 1261	Shaft/Lower	5 - 6
G850 1262	Side Mt Plate	5 - 11
G850 1263	Hinge Shaft	5 - 13
G850 1264	Hinge MT Plate	5 - 14
G850 1265	Hinge Stay	5 - 15
G850 1266	Rear Cover	5 - 19
G850 1267	Rear Mt Plate	5 - 20
G850 1268	Rear Mt Plate	5 - 28
G850 1269	Motor Mt Plate	7 - 2
G850 1270	Bracket	7 - 4
G850 1270	Bracket	17 - 21
G850 1271	Slide Stay/A Ass'y	7 - 5
G850 1272	Guide Plate	7 - 6
G850 1273	Rotary Shaft	7 - 16
G850 1274	Slide Shaft	7 - 17
G850 1275	Stopper Plate	7 - 20
G850 1276	Slide Stay Ass'y	7 - 21
G850 1277	Slide Shaft	7 - 22
G850 1278	Conveyance Shaftass'y	7 - 26
G850 1279	Conveyance Pressure Plate	7 - 28
G850 1280	Release Shaft	7 - 29
G850 1281	Guide Plate - Lower	7 - 32
G850 1282	Slide Stay	7 - 34
G850 1283	Slide Plate Ass'y	7 - 37
G850 1284	Shaft Holder ADJ Plate	7 - 39
G850 1285	Conveyance Shaft/B Ass'y	9 - 9

Part No.	Description	Page and Index No.
G850 1285	Conveyance Shaft/B Ass'y	11 - 15
G850 1286	Rear Guide Plate	9 - 10
G850 1287	RF Plate	9 - 27
G850 1288	Guide Plate	11 - 3
G850 1289	Guide Plate	11 - 7
G850 1290	Conveyance Shaft Ass'y	19 - 30
G850 1290	Conveyance Shaft Ass'y	11 - 13
G850 1291	Guide Plate	11 - 14
G850 1292	Guide Plate	11 - 17
G850 1293	Conveyance Shaft	11 - 27
G850 1294	RF Plate	11 - 28
G850 1295	RF Plate	11 - 29
G850 1296	Solenoid Mt Plate	13 - 3
G850 1297	Paper Exit Guide Stay	13 - 6
G850 1298	Paper Exit Conveyance Shaft	13 - 10
G850 1299	Paper Exit Support Shaft	13 - 11
G850 1300	Paper Exit Guide Stay	13 - 18
G850 1301	Paper Exit Guide Sheet	13 - 21
G850 1302	Stopper	13 - 23
G850 1303	Paper Exit Driving Shaft	13 - 27
G850 1304	Lower Guide Plate	13 - 29
G850 1305	Rotary Disk Ass'y	13 - 30
G850 1306	Paper Exit Opening Unit	13 - 45
G850 1307	Paper Exit Guide Plate	13 - 46
G850 1308	Paper Exit Guide Stay	13 - 47
G850 1309	Slide Shaft	15 - 1
G850 1310	Up-down Stay	15 - 4
G850 1311	Up-down Cover/R	15 - 5
G850 1312	Up-down Cover/F	15 - 6
G850 1313	Mt Plate Ass'y	15 - 9
G850 1314	Tension Plate Ass'y	15 - 14
G850 1315	Motor Mt Plate	15 - 17
G850 1316	Motor Fixed Plate Ass'y	15 - 22
G850 1317	Up-down Shaft	15 - 27
G850 1318	Aux Plate	15 - 29

Part No.	Description	Page and Index No.
G850 1319	Tension Plate Ass'y	17 - 9
G850 1320	Solenoid Mt Plate	17 - 13
G850 1321	Solenoid Mt Plate	17 - 17
G850 1322	Tension Plate Ass'y	17 - 35
G850 1323	Tension Plate Ass'y	17 - 38
G850 1324	Tension Plate Ass'y	17 - 42
G850 1325	Driving Shaft	19 - 9
G850 1326	Bottom Plate Ass'y	19 - 13
G850 1327	Slide Shaft	19 - 16
G850 1328	Tension Plate Ass'y	21 - 21
G850 1328	Tension Plate Ass'y	19 - 25
G850 1329	Guide Plate A	19 - 33
G850 1330	Guide Plate	19 - 34
G850 1331	Tension Plate	19 - 35
G850 1332	Driven Shaft	19 - 36
G850 1333	Mount Plate	19 - 41
G850 1334	Belt Driven Shaft	19 - 46
G850 1335	Oscillate Plate Ass'y	19 - 53
G850 1336	Pressure Plate	19 - 55
G850 1337	Conveyance Pressure Part	19 - 60
G850 1338	Fulcrum Shaft	21 - 1
G850 1339	Driving Board Ass'y	21 - 5
G850 1340	Staple Plate Ass'y	21 - 14
G850 1341	Release Shaft	21 - 20
G850 1342	Shaft Rail	21 - 25
G850 1343	Cam Lever	21 - 26
G850 1344	Fulcrum Shaft	21 - 27
G850 1345	Mt Plate Ass'y	21 - 30
G850 1346	Rotary Disk	21 - 33
G850 1347	Belt Fixed Plate	21 - 37
G850 1348	Guide Plate	21 - 39
G850 1349	Staple Cover	21 - 44
G850 1350	Rotary Disk	21 - 45
G850 1351	PS Pin	21 - 46
G850 1352	Idler Shaft	21 - 47

Part No.	Description	Page and Index No.
G850 1353	Staple MT Plate	21 - 48
G850 1354	Stopper	21 - 51
G850 1355	Support Panel Ass'y	21 - 52
G850 1356	Staple RF Stopper	21 - 53
G850 1357	Sensor Cover Ass'y	19 - 42
G850 1357	Sensor Cover Ass'y	13 - 25
G850 1358	Paper Exit Pressure Sheet	15 - 30
G850 1359	Conveyance Pressure Spring	9 - 2
G850 1359	Conveyance Pressure Spring	19 - 28
G850 1360	Label	5 - 22
G850 1361	E Ring	9 - 28
G850 1362	Staple Guide Block - Upper	21 - 55

Part No.	Description	Page and Index No.
G150 1007	Bind Screw M2x10	3 - 47
G150 1008	Bind Screw M3x5	11 - 16
G150 1008	Bind Screw M3x5	9 - 25
G150 1009	Bind Screw M3x6	9 - 8
G150 1009	Bind Screw M3x6	19 - 65
G150 1009	Bind Screw M3x6	13 - 54
G150 1009	Bind Screw M3x6	21 - 63
G150 1009	Bind Screw M3x6	3 - 49
G150 1014	Bind Screw M4x8	5 - 1
G150 1153	Screw M3x6	7 - 46
G150 1153	Screw M3x6	5 - 33
G150 1153	Screw M3x6	13 - 56
G150 1153	Screw M3x6	19 - 64
G150 1153	Screw M3x6	21 - 43
G150 1153	Screw M3x6	21 - 59
G150 1160	Screw M4x8	3 - 53
G150 1160	Screw M4x8	15 - 35
G155 1036	Bind Screw M3x10	7 - 49

Part No.	Description	Page and Index No.
G155 1036	Bind Screw M3x10	15 - 37
G155 1036	Bind Screw M3x10	19 - 67
G155 1036	Bind Screw M3x10	21 - 61
G155 1036	Bind Screw M3x10	3 - 22
G155 1044	Bind Screw M5x8	3 - 39