

FS108H/FS108HBM
(G857/G858)

Important Notes Regarding RoHS Compliant Parts in this Catalog

- The material of some parts used on the Standard Finisher was changed in accordance with the RoHS Directive. This Parts Catalog contains parts from before the changes (**non-RoHS compliant parts**) and after the changes (**RoHS-compliant parts**).
- RoHS-compliant parts have “(RoHS)” at the end of their description, together with “X/X” for X/X interchangeability or no mark for X/O interchangeability. RoHS-compliant parts are listed together with their non-RoHS compliant parts. **See below.**

Example: Exterior 1 (G150)

Index:	Part No.	Description:
1	G150 1024	Tapping Screw M3x8
2	G150 1521	Ozone Chamber Ass’y
3	G150 1198	Ozone Chamber
4	G150 5590	CBDC Sirocco Fan Ass’y (RoHS)
	G150 1590	CBDC Sirocco Fan Ass’y
47	G150 8875	Controller Bpard (70) Ass’y (RoHS) X/X
	G150 1875	Controller Bpard (70) Ass’y

Important Notes Regarding RoHS Compliant Parts in this Catalog

- **Interchangeability:**

- **X/O:**

	RoHS compliant machines:	Non-RoHS compliant machines:
RoHS compliant parts	Usable	Usable
Non-RoHS compliant parts	Do not use	Usable

- **X/X:**

	RoHS compliant machines:	Non-RoHS compliant machines:
RoHS compliant parts	Usable	Do not use
Non-RoHS compliant parts	Do not use	Usable

FS108H/FS108HBM (G857/G858)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Main Frame (G857/G858)	2	18.Stacker Unit 5 (G857/G858)	36
2.Cover (G857/G858)	4	19.Stacker Unit 6 (G857/G858)	38
3.Paper Cpnveyance 1 (G857/G858)	6	20.Folding Unit 1 (G857/G858).....	40
4.Paper Cpnveyance 2 (G857/G858)	8	21.Folding Unit 2 (G857/G858).....	42
5.Paper Cpnveyance 3 (G857/G858)	10	22.Folding Unit 3 (G857/G858).....	44
6.Main Tray (G857/G858).....	12	23.Folding Unit 4 (G857/G858).....	46
7.Shift Unit (G857/G858)	14	24.Folding Unit 5 (G857/G858).....	48
8.Paper Exit Unit 1 (G857/G858).....	16	25.Haness 1 (G857/G858).....	50
9.Paper Exit Unit 2 (G857/G858).....	18	26.Haness 2 (G857/G858).....	52
10.Driveing Unit 1 (G857/G858)	20	27.Haness 3 (G857/G858).....	54
11.Driveing Unit 2 (G857/G858)	22	Parts Index.....	57
12.Stacker Unit 1 (G857/G858)	24		
13.Stacker Unit 2 (G857/G858)	26		
14.Stacker Unit 3 (G857/G858)	28		
15.Stapler Unit 1 (G857/G858).....	30		
16.Stapler Unit 2 (G857/G858).....	32		
17.Stacker Unit 4 (G857/G858)	34		

June ,15 ' 2006


[illegible]

1.Main Frame (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1216	Booklet Tray	1
2	G850 1160	Stopper Rubber	2
3	G850 1163	Support Stay	1
4	G858 1306	Paper Exit Stopper Plate	1
5	G858 1159	Paper Exit Side Plate	1
6	G858 1160	Paper Exit Side Plate	1
7	G850 1253	RF Stay	1
8	G858 1215	FS-108HBM Package	1
9	G858 1093	Carriage Roller	2
10	G850 1156	Carriage Roller	2
11	G858 1094	Actuator	1
12	G858 1092	Slide Rail	1
13	G858 1091	Slide Rail	1
14	G850 8070	Photo Sensor (RoHS) XX	2
	G850 1070	Photo Sensor	2
15	G858 1437	PE Stopper Sheet	6
16	G858 1388	Magnet Catch	2
17	G858 8084	Rom Ass'y (RoHS) XX	1
	G858 1084	Rom Ass'y	1
18	G850 1082	Discharge Brush	1
19	G858 1087	Wiring Guide Arm	2
20	G858 1364	Lock Lever	1
21	G858 1054	Roller	1
22	G858 1090	Lock Spring	1
23	G858 1410	Pressure Roller	1
24	G858 1393	Flat Screw	2
25	G850 1210	Protect Block	1
26	G858 1435	PE Stopper Sheet	3
27	G858 1063	Main Fixed Plate	1
28	G858 5354	Joint Cover (RoHS)	1
	G858 1354	Joint Cover	1
29	G858 5353	Joint Cover (RoHS)	1
	G858 1353	Joint Cover	1
30	G858 5352	Joint Cover (RoHS)	1
	G858 1352	Joint Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
31	G858 8082	FS-108H Package (RoHS) XX	1
	G858 1082	FS-108H Package	1
32	G858 1015	Screw M5x8	6
33	G850 1021	Nut M12	2
34	G850 1014	Screw With Washer M4x6	4
35	G850 1013	Screw With Washer M4x6	14
36	G858 1033	Wire Saddle	2
37	G850 1006	Screw M3x10	2
38	G858 1016	Screw With Washer M3x20	1
39	G850 1008	Screw With Washer M3x6	6
40	G858 1047	Locking Board Spacer	1
41	G850 1005	Screw M3x6	2
42	G850 1025	D3 Retaining Ring-e	2
43	G850 1026	D4 Retaining Ring-e	4
44	G850 1027	D6 Retaining Ring-e	3
45	G858 1034	Wire Saddle	1
46	G858 1036	Locking Wire Saddle	2
47	G858 1038	Edging	1
48	G858 1040	Band	1
49	G858 1043	Flexible Grommet	1
50	G850 1029	Flexible Grommet	1
51	G858 1041	Band	1

2.Cover (G857/G858)




2.Cover (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1102	Side Cover	1
2	G858 1103	Side Cover	1
3	G858 1101	Side Cover	1
4	G858 1104	Hinge Plate	1
5	G858 1098	Front Side Cover	1
6	G858 1106	Seal	1
7	G858 1105	Hinge Plate	1
8	G858 1100	Knob	1
9	G850 1167	Actuator	1
10	G850 1168	Magnet Catch Plate	1
11	G858 1097	Front Door	1
12	G850 1154	Magnet Catch	1
13	G858 1096	Top Cover	1
14	G850 1252	Slide Stay	1
15	G858 1099	Rear Cover	1
16	G858 1402	Sub-Tray	1
17	G858 1401	Sub-Tray	1
18	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
19	G858 1018	Screw With Washer M4x8	1
20	G858 1002	Truss Screw M4x6	2
21	G858 1077	Paper Exit Cover Ass'y	1
22	G850 1082	Discharge Brush	1
23	G850 1061	Paper Exit Driven Roller	2
24	G850 1261	Shaft/Lower	1
25	G858 1168	Neutralizing Plate	1
26	G858 1169	Earth Plate	1
27	G850 1159	Driven Shaft Holder	2
28	G850 1258	Support Plate	2
29	G858 1086	Paper Exit Up-down Actuator	1
30	G850 1267	Rear Mt Plate	1
31	G858 1375	External Aux Panel	1
32	G850 1153	Switch Insulating Sheet	1
33	G850 5057	Interlock Switch (RoHS)	1
	G850 1057	Interlock Switch	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	G858 1205	Fns Wiring	1
35	G850 1151	Actuator	1
36	G850 1150	Cover	1
37	G858 1095	Paper Exit Pressing Lever	1
38	G858 1425	Cover	1
39	G858 1212	Caution Label	1
40	G858 1167	Spring	2
41	G858 1441	Sticking Part	2
42	G858 1211	Jam Handling Label	1
43	G858 1376	Key Counter Cover	1
44	G858 1436	Preventing Sheet	1
45	G858 1431	PE Pressure Plate	2
46	G858 1430	PE Pressure Plate	2
47	G858 1432	Shaft Hold Plate	2
48	G850 1013	Screw With Washer M4x6	4
49	G858 1005	Screw M3x5	3
50	G850 1025	D3 Retaining Ring-E	2
51	G850 1008	Screw With Washer M3x6	5
52	G850 1016	Tapping Screw With Washer M3x8	4
53	G850 1010	Screw With Washer M3x8	2
54	G850 1014	Screw With Washer M4x6	2
55	G858 1009	Screw M2x10	1
56	G850 1012	Screw With Washer M3x16	1
57	G850 1018	Tapping Screw With Washer M4x10	1
58	G858 1011	Screw M3x6	1
59	G858 1032	Nylon Clamp	1
60	G858 1046	Flexible Grommet	1
61	G850 1026	D4 Retaining Ring-E	2
62	G850 1006	Screw M3x10	1
63	G850 1005	Screw M3x6	1
64	G850 1018	Tapping Screw With Washer M4x10	1
65	G850 1017	Tapping Screw With Washer M4x8	1

3. Paper Conveyance 1 (G857/G858)



3.Paper Cpnveyance 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1055	Ball Bearing	4
2	G858 1165	Sub-tray Paper Exit Roller	1
3	G858 1451	Adu Shaft Holder	2
4	G858 1164	Sub-tray Paper Exit Roller	1
5	G850 8070	Photo Sensor (RoHS) XX	2
	G850 1070	Photo Sensor	2
6	G858 1061	Pin	2
7	G858 1166	Sub-tray Paper Exit Roller	1
8	G858 1357	Driving Pulley	1
9	G858 1196	Paper Exit Driving Belt	1
10	G858 1448	Sensor Mount Plate Assembly	1
11	G858 1192	Belt	1
12	G858 1173	Conveyance Guide Plate	1
13	G858 1174	Conveyance Pressure Spring	1
14	G858 1172	Conveyance Guide Plate	1
15	G858 1311	DFF Collar	2
16	G858 1163	Paper Exit Guide Plate	1
17	G858 1171	Conveyance Guide Plate	1
18	G858 1170	Lever	2
19	G858 1368	Open-close Lever	1
20	G858 1161	Paper Exit Guide Plate	1
21	G858 1362	Shoulder Screw	4
22	G858 1162	Paper Exit Guide Plate	1
23	G858 1358	Open-close Lever	1
24	G858 1369	Paper Exit Driving Pulley	2
25	G850 1067	Entrance Roller	4
26	G850 1285	Conveyance Shaft/B Ass'y	2
27	G858 1175	Conveyance Pressure Spring	1
28	G858 1176	Tension Shaft Holder	2
29	G850 1175	Stopper Rubber	2
30	G858 8078	Paper Exit Sensor Ass'y (RoHS) XX	1
	G858 1078	Paper Exit Sensor Ass'y	1
31	G858 8203	Fns Wiring (RoHS) XX	2
	G858 1203	Fns Wiring	2
32	G850 8058	Photo Sensor (RoHS) XX	1

Index No.	Part No.	Description	Q'ty Per Assembly
	G850 1058	Photo Sensor	1
33	G858 1061	Pin	2
34	G858 1157	Conveyance Guide Sheet	2
35	G858 1445	Torque Limiter	1
36	G858 1446	Pin	1
37	G858 1438	Guide Spring	2
38	G858 1429	Ped Actuator	1
39	G850 1025	D3 Retaining Ring-E	7
40	G858 1039	Band	1
41	G850 1027	D6 Retaining Ring-E	11
42	G850 1008	Screw With Washer M3x6	4
43	G850 1006	Screw M3x10	1
44	G850 1026	D4 Retaining Ring-E	6
45	G858 1021	Screw With Washer M4x14	1
46	G850 1005	Screw M3x6	1
47	G858 1014	Screw M4x12	1
48	G850 1007	Screw With Washer M3x4	5

This exploded view diagram illustrates the assembly of a mechanical unit, likely a shredder or a similar processing machine. The components are numbered 1 through 31, and specific sub-assemblies are labeled with letters A through H. The diagram shows the following parts and their assembly relationships:


- Parts 1-31:** Individual components including screws (e.g., 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 30, 31), washers (e.g., 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27), and structural components (e.g., 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 30, 31).
- Lettered Callouts (A-H):** Indicate specific sub-assemblies or stages of assembly.
 - A:** Points to the main body of the unit.
 - B:** Points to the top cover or lid.
 - C:** Points to the internal mechanism, including the shredding blades.
 - D:** Points to the base or support structure.
 - E:** Points to the internal mechanism, including the shredding blades.
 - F:** Points to the internal mechanism, including the shredding blades.
 - G:** Points to the internal mechanism, including the shredding blades.
 - H:** Points to the internal mechanism, including the shredding blades.

4.Paper Cpnyance 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1074	Metal Clamp	2
2	G850 1191	Solenoid Spring	1
3	G858 1154	Conveyance Roller	1
4	G858 1149	Conveyance Roller	1
5	G858 1356	Conveyance Pressure Spring	1
6	G850 1186	Magnet Catch	2
7	G858 1452	pF Shaft Holder	2
8	G858 1440	Sensor Plate	1
9	G850 1184	Release Lever Knob	1
10	G858 8444	Photo Sensor (RoHS) XX	1
	G858 1444	Photo Sensor	1
11	G858 1056	Release Knob	1
12	G850 1067	Entrance Roller	2
13	G858 1355	Conveyance Guide Plate	1
14	G850 1285	Conveyance Shaft/B Ass'y	1
15	G858 1150	Sub-tray Gate	1
16	G858 1457	Conveyance Guide Plate/a	1
17	G850 1175	Stopper Rubber	2
18	G850 1006	Screw M3x10	1
19	G858 1039	Band	1
20	G858 1022	Set Screw M4x4	1
21	G850 1005	Screw M3x6	3
22	G850 1008	Screw With Washer M3x6	2
23	G850 1017	Tapping Screw With Washer M4x8	1
24	G850 1007	Screw With Washer M3x4	3
25	G850 1026	D4 Retaining Ring-E	4
26	G850 1027	D6 Retaining Ring-E	2
27	G850 1024	D2 Retaining Ring-E	2

Index No.	Part No.	Description	Q'ty Per Assembly

5. Paper Conveyance 3 (G857/G858)




5.Paper Cpnveyance 3 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1184	Release Lever Knob	2
2	G858 1158	Conveyance Guide Sheet	1
3	G850 1154	Magnet Catch	2
4	G850 1290	Conveyance Shaft Ass'y	1
5	G858 1064	Conveyance Pressure Spring	5
6	G850 1077	Conveyance Roller	6
7	G850 1175	Stopper Rubber	4
8	G858 1146	Conveyance Guide Plate	1
9	G850 8188	Detecting Sensor (RoHS) XX	1
	G850 1188	Detecting Sensor	1
10	G858 1419	Sensor Cover	1
11	G850 8070	Photo Sensor (RoHS) XX	1
	G850 1070	Photo Sensor	1
12	G858 1148	Conveyance Guide Plate	1
13	G850 1193	Hinge Spring	1
14	G858 1156	Hinge Spring	1
15	G858 1147	Conveyance Guide Plate	1
16	G858 1145	Conveyance Guide Plate	2
17	G850 1196	Solenoid Spring	2
18	G850 1195	Paper Route Switching Gate	1
19	G850 1197	By-pass Gate	1
20	G850 1285	Conveyance Shaft/B Ass'y	2
21	G850 1111	Paper Exit Roller	4
22	G858 1452	pF Shaft Holder	4
23	G850 1074	Metal Clamp	3
24	G850 1075	Conveyance Roller	1
25	G858 1151	Pressure Rubber	2
26	G850 1225	Conveyance Aux Collar	2
27	G850 1080	Pin	2
28	G850 1017	Tapping Screw With Washer M4x8	2
29	G850 1007	Screw With Washer M3x4	3
30	G850 1024	D2 Retaining Ring-E	6
31	G858 1039	Band	1
32	G850 1008	Screw With Washer M3x6	9
33	G850 1005	Screw M3x6	2

Index No.	Part No.	Description	Q'ty Per Assembly
34	G850 1015	Screw With Washer M4x14	1
35	G850 1026	D4 Retaining Ring-E	8
36	G850 1027	D6 Retaining Ring-E	4

6.Main Tray (G857/G858)




6.Main Tray (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1309	Slide Shaft	4
2	G850 1093	Roller	4
3	G850 1203	Slide Stopper	2
4	G850 1310	Up-down Stay	1
5	G850 1311	Up-down Cover/R	1
6	G850 1312	Up-down Cover/F	1
7	G858 1067	Main Tray	1
8	G858 1068	Main Tray	1
9	G858 1071	Paper Exit Reinforcing Stay	1
10	G858 1406	Belt Tension Roller	2
11	G850 1208	Up-down Gear	1
12	G850 1209	Pin	2
13	G850 1095	Tension Pulley	2
14	G850 1314	Tension Plate Ass'y	2
15	G858 5088	UP-Down Wire (RoHS)	1
	G858 1088	UP-Down Wire	1
16	G858 5089	UP-Down Wire (RoHS)	1
	G858 1089	UP-Down Wire	1
17	G858 1085	AUX Plate	2
18	G850 1082	Discharge Brush	1
19	G850 1074	Metal Clamp	4
20	G850 1206	UP-Down Gear	1
21	G850 1207	UP-Down Gear	1
22	G858 5074	Tray Up-down Motor (RoHS)	1
	G858 1074	Tray Up-down Motor	1
23	G850 1098	UP-Down Pulley	2
24	G858 1011	Screw M3x6	4
25	G858 1040	Band	1
26	G850 1008	Screw With Washer M3x6	2
27	G850 1017	Tapping Screw With Washer M4x8	4
28	G850 1028	D8 Retaining Ring-e	4
29	G850 1013	Screw With Washer M4x6	7
30	G850 1027	D6 Retaining Ring-E	6
31	G858 1007	Screw M4x8	3
32	G850 1028	D8 Retaining Ring-E	3

Index No.	Part No.	Description	Q'ty Per Assembly
33	G858 1001	Screw M3x6	1

7.Shift Unit (G857/G858)




7.Shift Unit (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 5063	Shift Motor - DC2W (RoHS)	1
	G850 1063	Shift Motor - DC2W	1
2	G850 1269	Motor Mt Plate	1
3	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
4	G850 1176	Shaft Holder	2
5	G850 1271	Slide Stay/A Ass'y	1
6	G858 1066	Guide Plate	1
7	G850 1064	Shaft Holder	2
8	G858 1183	Slide Gear	1
9	G858 1073	Slide Gear	1
10	G850 1171	Slide Arm	1
11	G850 1183	Conveyance Pressure Spring	1
12	G850 1177	Stopper Sheet	2
13	G858 1152	Conveyance Slide Shaft	1
14	G850 1290	Conveyance Shaft Ass'y	1
15	G850 1108	Pressure Roller	1
16	G858 1184	Slide Gear	1
17	G858 1065	Guide Plate	1
18	G850 1067	Entrance Roller	2
19	G858 1447	Solenoid Assembly	1
20	G858 1434	Solenoid Release Spring	1
21	G858 1433	Solenoid Lever	1
22	G850 1148	Support Stay	1
23	G858 1452	pF Shaft Holder	2
24	G858 1039	Band	1
25	G850 1006	Screw M3x10	1
26	G850 1004	Screw M2.6x4	1
27	G850 1017	Tapping Screw With Washer M4x8	1
28	G858 1006	Screw M3x8	1
29	G850 1026	D4 Retaining Ring-E	4
30	G850 1025	D3 Retaining Ring-E	5
31	G858 1036	Locking Wire Saddle	1
32	G850 1024	D2 Retaining Ring-E	2
33	G850 1008	Screw With Washer M3x6	8

Index No.	Part No.	Description	Q'ty Per Assembly
34	G850 1007	Screw With Washer M3x4	1
35	G850 1027	D6 Retaining Ring-E	3
36	G850 1001	Screw M3x6	1
37	G858 1459	Support stay	1
38	G850 1013	M4x6 pan hd. screw with W	2

8. Paper Exit Unit 1 (G857/G858)




8.Paper Exit Unit 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 5079	Solenoid Ass'y (RoHS)	1
	G850 1079	Solenoid Ass'y	1
2	G850 8306	Paper Exit Opening Unit (RoHS) XX	1
	G850 1306	Paper Exit Opening Unit	1
3	G850 1296	Solenoid MT Plate	1
4	G850 1198	Solenoid Spring	1
5	G850 1199	Solenoid Lever	1
6	G850 1297	Paper Exit Guide Stay	1
7	G850 1171	Slide Arm	1
8	G850 1148	Support Stay	3
9	G850 1080	Pin	3
10	G850 1298	Paper Exit Conveyance Shaft	1
11	G850 1299	Paper Exit Support Shaft	1
12	G850 1110	Paper Exit Roller	3
13	G850 1308	Paper Exit Guide Stay	1
14	G850 1200	Rotary Stopper	2
15	G850 1064	Shaft Holder	3
16	G850 1081	Shaft Holder	2
17	G850 1201	Paper Exit Pressure Spring	2
18	G850 1300	Paper Exit Guide Stay	1
19	G850 1082	Discharge Brush	1
20	G858 1050	Paper Exit Guide Plate/M	1
21	G850 1301	Paper Exit Guide Sheet	3
22	G858 1051	Plate	1
23	G850 1302	Stopper	2
24	G850 8070	Photo Sensor (RoHS) XX	1
	G850 1070	Photo Sensor	1
25	G850 8357	Sensor Cover Ass'y (RoHS) XX	1
	G850 1357	Sensor Cover Ass'y	1
26	G850 1307	Paper Exit Guide Plate	1
27	G850 1074	Metal Clamp	2
28	G850 1016	Tapping Screw With Washer M3x8	1
29	G858 1031	Nylon Clamp	1
30	G850 1017	Tapping Screw With Washer M4x8	1
31	G850 1008	Screw With Washer M3x6	8

Index No.	Part No.	Description	Q'ty Per Assembly
32	G850 1015	Screw With Washer M4x14	1
33	G850 1005	Screw M3x6	1
35	G850 1001	Screw M3x6	2

9.Paper Exit Unit 2 (G857/G858)




9.Paper Exit Unit 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1426	Sensor Stopper Part	1
2	G850 1064	Shaft Holder	2
3	G858 1069	Paper Exit Roller	1
4	G850 1111	Paper Exit Roller	10
5	G858 1070	Paper Exit Guide Plate	1
6	G850 1305	Rotary Disk Ass'y	2
7	G850 1084	Paper Exit Pulley	1
8	G858 5424	Paper Exit Roller Motor (RoHS) XX	1
	G858 1424	Paper Exit Roller Motor	1
9	G850 1085	Motor Pulley	1
10	G850 1086	Belt	1
11	G858 1193	Belt	1
12	G850 1088	Shaft Holder	2
13	G850 1074	Metal Clamp	4
14	G850 1068	Driving Pulley	1
15	G850 1091	Paper Exit Pulley	1
16	G850 1202	Collar	1
17	G850 1092	Paper Exit Spring	1
18	G850 1027	D6 Retaining Ring-E	5
19	G850 1020	Set Screw M3x6	1
20	G858 1016	Screw With Washer M3x20	1
21	G850 1031	Locking Board Spacer	1
22	G850 1008	Screw With Washer M3x6	2
23	G850 1026	D4 Retaining Ring-E	2
24	G850 1011	Screw With Washer M3x10	1

Index No.	Part No.	Description	Q'ty Per Assembly

10. Driveing Unit 1 (G857/G858)




10. Driveing Unit 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 8198	Conveyance Motor - DC39W (RoHS) XX	1
	G858 1198	Conveyance Motor - DC39W	1
2	G850 1085	Motor Pulley	1
3	G858 1188	Belt	1
4	G850 1074	Metal Clamp	2
5	G858 1182	Slide Gear	1
6	G858 1177	Conveyance Driving Pulley	1
7	G858 1189	Belt	1
8	G850 1102	Paper Exit Gear	2
9	G858 1392	Pin	1
10	G850 1117	Driving Pulley	2
11	G858 1360	Gear	2
12	G858 1153	Pulley Holder	1
13	G858 1178	Slide Pulley	1
14	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
15	G858 1187	Connecting Gear	1
16	G858 1179	Paper Exit Pulley	1
17	G850 1119	Tension Roller	2
18	G858 1197	Paper Exit Driving Belt	1
19	G850 1089	Belt	1
20	G850 1202	Collar	1
21	G850 1088	Shaft Holder	2
22	G858 1180	Driving Pulley	1
23	G850 5063	Shift Motor - DC2W (RoHS)	1
	G850 1063	Shift Motor - DC2W	1
24	G858 1403	Belt Tension Roller	1
25	G858 1036	Locking Wire Saddle	1
26	G858 1048	Locking Board Spacer	1
27	G850 1001	Screw M3x6	1
28	G850 1027	D6 Retaining Ring-E	9
29	G850 1013	Screw With Washer M4x6	1
30	G850 1026	D4 Retaining Ring-E	3
31	G858 1045	Flexible Grommet	1
32	G850 1025	D3 Retaining Ring-E	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	G850 1008	Screw With Washer M3x6	3
34	G850 1020	Set Screw M3x6	1
35	G850 1005	Screw M3x6	1
36	G850 1006	Screw M3x10	1

11.Driveing Unit 2 (G857/G858)




11.Driveing Unit 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1116	Driving Pulley	3
2	G850 1074	Metal Clamp	2
3	G858 1062	Driving Pulley	2
4	G850 1068	Driving Pulley	3
5	G858 1191	Belt	1
6	G858 1190	Belt	1
7	G858 1155	Belt Tension Spring	1
8	G850 1148	Support Stay	3
9	G850 1212	Spring	2
10	G850 5069	Fns Solenoid Ass'y (RoHS)	3
	G850 1069	Fns Solenoid Ass'y	3
11	G850 1088	Shaft Holder	3
12	G858 1189	Belt	1
13	G858 1197	Paper Exit Driving Belt	1
14	G850 1179	Solenoid Lever	3
15	G850 1027	D6 Retaining Ring-E	5
16	G850 1001	Screw M3x6	8
17	G850 1008	Screw With Washer M3x6	4
18	G858 1040	Band	1

Index No.	Part No.	Description	Q'ty Per Assembly

12.Stacker Unit 1 (G857/G858)




12.Stacker Unit 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1118	Cartridge Guide Seal	1
2	G858 1112	Wiring Rotary Plate	1
3	G858 1439	Staple Processing Label	1
4	G858 1140	Carriage Cover	1
5	G858 1107	Panel	1
6	G858 1361	Knob	1
7	G858 1366	Lock Cam	1
8	G858 1108	Panel	1
9	G858 1109	Shaft Support Plate	2
10	G858 5083	R/B Package (RoHS)	1
	G858 1083	R/B Package	1
11	G858 1138	Carriage Cover	1
12	G858 1122	Belt Fixed Block	2
13	G858 1123	Staple Rotary Roller	2
14	G858 1110	Shaft Support Plate	1
15	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
16	G850 1006	Screw M3x10	1
17	G850 1014	Screw With Washer M4x6	18
18	G850 1025	D3 Retaining Ring-E	6
19	G850 1010	Screw With Washer M3x8	4
20	G858 1047	Locking Board Spacer	1
21	G850 1013	Screw With Washer M4x6	4
22	G858 1003	Truss Screw M4x6	3
23	G858 1007	Screw M4x8	1

Index No.	Part No.	Description	Q'ty Per Assembly

13.Stacker Unit 2 (G857/G858)




13.Stacker Unit 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1124	Guide Plate	1
2	G850 1219	Belt Holder	4
3	G850 1124	Belt Driving Pulley	4
4	G850 1074	Metal Clamp	4
5	G858 8208	Fns Wiring (RoHS) XX	1
	G858 1208	Fns Wiring	1
6	G850 1080	Pin	3
7	G858 1079	Alignment Plate	1
8	G850 1177	Stopper Sheet	4
9	G850 8058	Photo Sensor (RoHS) XX	2
	G850 1058	Photo Sensor	2
10	G858 5199	Fns Correction Motor - DC13W (RoHS)	1
	G858 1199	Fns Correction Motor - DC13W	1
11	G858 1185	Coupling Gear	1
12	G850 1122	Belt Detction Gear	1
13	G850 1216	Belt Detecting Screw	1
14	G850 1123	Paper Exit Belt	2
15	G850 1148	Support Stay	1
16	G850 1126	Belt	1
17	G850 1220	Belt Holder	2
18	G850 1125	Regulation Gear	1
19	G850 1328	Tension Plate Ass'y	1
20	G850 8357	Sensor Cover Ass'y (RoHS) XX	1
	G850 1357	Sensor Cover Ass'y	1
21	G850 8070	Photo Sensor (RoHS) XX	1
	G850 1070	Photo Sensor	1
22	G850 1215	Guide Plate/Middle	2
23	G858 1129	Paper Exit Guide Sheet	4
24	G858 1076	Alignment Plate/R Ass'y	1
25	G850 1217	Rocking Block Ass'y	2
26	G858 1075	Alignment Plate/F Ass'y	1
27	G850 1218	Belt Holder Plate	2
28	G850 1127	Idler Pulley	1
29	G858 1428	Holding Sheet	2
30	G850 1027	D6 Retaining Ring-E	7

Index No.	Part No.	Description	Q'ty Per Assembly
31	G850 1001	Screw M3x6	4
32	G850 1005	Screw M3x6	3
33	G850 1025	D3 Retaining Ring-E	4
34	G850 1006	Screw M3x10	2
35	G850 1015	Screw With Washer M4x14	1
36	G850 1008	Screw With Washer M3x6	8
37	G850 1026	D4 Retaining Ring-E	1
38	G858 1013	Screw M4x6	1

14.Stacker Unit 3 (G857/G858)




14.Stacker Unit 3 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1222	Belt Holder	2
2	G850 1133	Entrance Guide Pulley	2
3	G850 1225	Conveyance Aux Collar	2
4	G850 1080	Pin	5
5	G858 1132	Driving Roller	1
6	G850 1135	Entrance Guide Pulley	5
7	G850 1136	Guide Belt	5
8	G850 1074	Metal Clamp	6
9	G858 1126	Shaft Holder Plate	1
10	G850 1137	Belt	2
11	G858 1136	Regulating Belt	4
12	G858 1135	Belt Mount Roller	2
13	G858 1137	Regulating Belt	1
14	G858 1144	Conveyance Guide Sheet	2
15	G850 1148	Support Stay	1
16	G858 1133	Oscillate Pulley	1
17	G850 1141	Belt	1
18	G858 1134	Oscillate Pulley	1
19	G850 1089	Belt	1
20	G858 1072	Motor Pulley	1
21	G850 1129	Pin	3
22	G858 1060	Pin	1
23	G858 5314	Stacker Entrance Motor (RoHS)	1
	G858 1314	Stacker Entrance Motor	1
24	G850 1068	Driving Pulley	1
25	G858 1210	Fns Wiring	1
26	G850 1290	Conveyance Shaft Ass'y	1
27	G850 1077	Conveyance Roller	2
28	G850 1183	Conveyance Pressure Spring	1
29	G850 1082	Discharge Brush	1
30	G850 1329	Guide Plate A	1
31	G858 1125	Conveyance Guide Plate	1
32	G858 1309	Collar	1
33	G850 1027	D6 Retaining Ring-E	12
34	G858 1008	Screw M3x6	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	G850 1013	Screw With Washer M4x6	1
36	G850 1010	Screw With Washer M3x8	1
37	G850 1024	D2 Retaining Ring-E	2
38	G850 1007	Screw With Washer M3x4	1
39	G850 1008	Screw With Washer M3x6	5
40	G850 1026	D4 Retaining Ring-E	2

15. Stapler Unit 1 (G857/G858)




15.Stapler Unit 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 5213	Cartridge Case (RoHS)	1
	G858 1213	Cartridge Case	1
2	G858 1111	Staple Slide Shaft Holder	4
3	G850 1025	D3 Retaining Ring-E	4
4	G850 1352	Idler Shaft	4
5	G850 1108	Pressure Roller	4
6	G858 1119	Lock Block	1
7	G850 1241	Fixed Block	2
8	G858 1194	Belt	1
9	G858 1120	Lock Spring	1
10	G858 1116	Stopper Spring	2
11	G858 1130	Stopper Bottom Plate/F	1
12	G858 1141	Conveyance Guide Sheet	1
13	G858 1121	Lock Pin	1
14	G858 1115	Stopper	1
15	G858 1131	Stopper Bottom Plate/R	1
16	G858 1117	Stopper	1
17	G858 1142	Slide Sheet	1
18	G858 1143	Slide Sheet	1
19	G858 5127	Stapler (RoHS)	1
	G858 1127	Stapler	1
20	G858 1307	ADF Pressure Part	1
21	G850 1008	Screw With Washer M3x6	5
22	G858 1027	D2 Retaining Ring	4
23	G850 1026	D4 Retaining Ring-E	2
24	G858 1026	D1 Retaining Ring	1
25	G850 1016	Tapping Screw With Washer M3x8	2
26	G858 1020	Screw With Washer M6x10	2
27	G850 1013	Screw With Washer M4x6	5

Index No.	Part No.	Description	Q'ty Per Assembly

16. Stapler Unit 2 (G857/G858)




16.Stapler Unit 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1142	Slide Sheet	1
2	G850 1241	Fixed Block	2
3	G858 1194	Belt	1
4	G858 1119	Lock Block	1
5	G858 1111	Staple Slide Shaft Holder	4
6	G858 1113	Staple Guide Plate	1
7	G858 1128	Wiring Regulating Plate	1
8	G858 1139	Staple Cover	2
9	G850 1352	Idler Shaft	4
10	G850 1108	Pressure Roller	4
11	G858 1121	Lock Pin	1
12	G858 1120	Lock Spring	1
13	G858 1143	Slide Sheet	1
14	G858 1307	ADF Pressure Part	1
15	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
16	G858 1114	Staple Guide Plate	1
17	G858 5127	Stapler (RoHS)	1
	G858 1127	Stapler	1
18	G858 5213	Cartridge Case (RoHS)	1
	G858 1213	Cartridge Case	1
19	G850 1008	Screw With Washer M3x6	5
20	G858 1027	D2 Retaining Ring	4
21	G850 1026	D4 Retaining Ring-E	2
22	G858 1028	D10 Retaining Ring	1
23	G850 1016	Tapping Screw With Washer M3x8	2
24	G850 1006	Screw M3x10	1
25	G858 1020	Screw With Washer M6x10	2
26	G850 1007	Screw With Washer M3x4	2
27	G850 1013	Screw With Washer M4x6	3
28	G858 1049	Edge Saddle	1
29	G850 1010	Screw With Washer M3x8	2

Index No.	Part No.	Description	Q'ty Per Assembly

17.Stacker Unit 4 (G857/G858)




17.Stacker Unit 4 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1127	Idler Pulley	4
2	G850 1220	Belt Holder	5
3	G858 1194	Belt	2
4	G858 5080	Driving Shaft/A Ass'y (RoHS)	1
	G858 1080	Driving Shaft/A Ass'y	1
5	G858 1398	Paper Feed Shaft Holder	4
6	G850 1144	Staple Driving Gear	2
7	G858 5200	Correction Motor - DC13W (RoHS)	2
	G858 1200	Correction Motor - DC13W	2
8	G858 1195	Belt	2
9	G850 1125	Regulation Gear	1
10	G858 5081	Driving Shaft/B Ass'y (RoHS)	1
	G858 1081	Driving Shaft/B Ass'y	1
11	G850 1027	D6 Retaining Ring-E	9
12	G850 1002	Screw M4x6	2
13	G858 1006	Screw M3x8	2
14	G850 1026	D4 Retaining Ring-E	2
15	G858 1010	Screw M3x4	2
16	G858 1043	Flexible Grommet	1

Index No.	Part No.	Description	Q'ty Per Assembly

18.Stacker Unit 5 (G857/G858)



18.Stacker Unit 5 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 5199	Fns Correction Motor - DC13W (RoHS)	1
	G858 1199	Fns Correction Motor - DC13W	1
2	G850 1177	Stopper Sheet	4
3	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
4	G858 1227	Sensor Cover	1
5	G858 1214	Alignment Plate	1
6	G850 1217	Rocking Block Ass'y	2
7	G850 1218	Belt Holder Plate	2
8	G858 1228	Lower Alignment Plate	1
9	G858 1229	Lower Alignment Plate	1
10	G858 1230	Guide Plate	1
11	G850 1328	Tension Plate Ass'y	1
12	G850 1127	Idler Pulley	1
13	G850 1220	Belt Holder	2
14	G850 1126	Belt	1
15	G850 1125	Regulation Gear	1
16	G858 1302	Fns Wiring	1
17	G858 1232	Conveyance Guide Plate	1
18	G858 1233	Release Part	1
19	G858 1234	Release Spring	1
20	G858 1308	Belt Pressure Spring	1
21	G858 1236	Conveyance Guide Sheet	2
22	G858 1231	Conveyance Guide Plate	1
23	G858 1040	Band	1
24	G858 1033	Wire Saddle	1
25	G850 1008	Screw With Washer M3x6	3
26	G850 1014	Screw With Washer M4x6	6
27	G850 1007	Screw With Washer M3x4	1
28	G850 1027	D6 Retaining Ring-E	4
29	G850 1001	Screw M3x6	3
30	G850 1005	Screw M3x6	2
31	G850 1025	D3 Retaining Ring-E	4
32	G850 1006	Screw M3x10	1
33	G858 1013	Screw M4x6	1

Index No.	Part No.	Description	Q'ty Per Assembly


This diagram illustrates the exploded view of a mechanical assembly, showing the relationship between various components. The parts are numbered 1 through 37, and specific sub-assemblies are labeled A, B, C, and D. The diagram shows the main housing (1) and the internal mechanism (2) which includes a motor (20) and a drive shaft (13). The assembly is secured with various fasteners including screws (34), bolts (36), and nuts (30). The diagram also shows the installation of a cover (3) and a handle (10). The exploded view shows the sequence of assembly from the main housing to the internal components and finally to the external housing and handle.

19.Stacker Unit 6 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1223	Shaft Support Collar	1
2	G858 1222	Lever Locking Gear	1
3	G858 1235	Conveyance Guide Sheet	1
4	G858 1061	Pin	2
5	G858 1218	Slide Part	2
6	G850 1241	Fixed Block	1
7	G858 1217	Stopper Board	1
8	G858 1221	Lever Locking Cam	1
9	G858 1296	Stepper Motor - DC1W	1
10	G858 1295	Belt	1
11	G858 1226	Release Spring	1
12	G850 1127	Idler Pulley	1
13	G858 1220	Stopper Spring	1
14	G858 1219	Release Stopper	1
15	G858 1225	Stopper Sheet	2
16	G850 1220	Belt Holder	1
17	G858 1059	Photo Sensor	1
18	G858 1303	Fns Wiring	1
19	G858 1398	Paper Feed Shaft Holder	2
20	G858 5200	Correction Motor - DC13W (RoHS)	1
	G858 1200	Correction Motor - DC13W	1
21	G858 1186	Staple Slide Gear	1
22	G858 1224	Release Lever	1
23	G858 1181	Staple Slide Pulley	1
24	G850 1144	Staple Driving Gear	1
25	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
26	G850 1148	Support Stay	1
27	G850 1005	Screw M3x6	2
28	G850 1006	Screw M3x10	1
29	G858 1044	Flexible Grommet	1
30	G850 1026	D4 Retaining Ring-E	4
31	G858 1029	D3x12 Spring Pin	2
32	G850 1027	D6 Retaining Ring-E	2
33	G850 1025	D3 Retaining Ring-E	5

Index No.	Part No.	Description	Q'ty Per Assembly
34	G850 1008	Screw With Washer M3x6	6
35	G850 1007	Screw With Washer M3x4	1
36	G850 1013	Screw With Washer M4x6	2

20.Folding Unit 1 (G857/G858)




20.Folding Unit 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1267	Adjusting Cover	1
2	G858 1266	Paper Exit Guide Plate	1
3	G850 1175	Stopper Rubber	4
4	G858 1254	Pressure Roller	1
5	G858 1253	Pressure Roller	1
6	G858 1271	Folding Roller	1
7	G858 1269	Regulating Rubber	1
8	G858 1260	Actuator	1
9	G858 1265	Paper Exit Guide Plate	1
10	G858 1263	Sensor Mount Stay	1
11	G858 1251	Pressure Arm	1
12	G858 1255	Fold Down Spring	2
13	G858 1252	Pressure Arm	1
14	G858 1249	Fold Down Arm	2
15	G858 1256	Fold Down Spring	2
16	G858 1250	Fold Down Arm	2
17	G858 1257	Pressure Spring	2
18	G858 1393	Flat Screw	1
19	G858 1258	Jam Release Knob	1
20	G858 1059	Photo Sensor	2
21	G858 1259	Sensor Mount Plate	1
22	G858 1304	Fns Wiring	1
23	G858 1262	Sensor Pressure Spring	2
24	G858 1055	Ball Bearing	8
25	G858 1261	Actuator	1
26	G858 1310	Discharge Brush	4
27	G858 1443	Folding Roller	1
28	G850 1027	D6 Retaining Ring-e	14
29	G850 1008	Screw With Washer M3x6	10
30	G850 1013	Screw With Washer M4x6	3
31	G850 1005	Screw M3x6	1
32	G850 1007	Screw With Washer M3x4	1
33	G858 1025	D2.5 Retaining Ring-E	2
34	G858 1035	Wire Saddle	1
35	G858 1033	Wire Saddle	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G858 1040	Band	3
37	G858 1038	Edging	1
38	G858 1044	Flexible Grommet	1

21.Folding Unit 2 (G857/G858)




21.Folding Unit 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1154	Magnet Catch	2
2	G858 1242	Conveyance Fulcrum Plate	2
3	G858 1243	Guide Sheet	4
4	G858 1241	Guide Plate	1
5	G850 1184	Release Lever Knob	1
6	G850 1064	Shaft Holder	2
7	G850 8070	Photo Sensor (RoHS) XX	1
	G850 1070	Photo Sensor	1
8	G858 1409	Pin	2
9	G858 1359	Jam Release Lever	1
10	G858 1404	Belt Tension Roller	2
11	G858 1245	Conveyance Roller	1
12	G858 1290	Folding Conveyance Belt	2
13	G858 1244	Folding Conveyance Roller	1
14	G850 1074	Metal Clamp	4
15	G858 1416	Sensor Pressure Spring	1
16	G858 1387	Actuator	1
17	G858 1386	Sensor Fixed Plate	1
18	G850 1027	D6 Retaining Ring-E	4
19	G850 1026	D4 Retaining Ring-E	4
20	G850 1006	Screw M3x10	1
21	G850 1017	Tapping Screw With Washer M4x8	1
22	G850 1008	Screw With Washer M3x6	2
23	G850 1013	Screw With Washer M4x6	6
24	G858 1040	Band	1
25	G858 1018	Screw With Washer M4x8	1
26	G858 1013	Screw M4x6	2
27	G858 1019	Screw With Washer M4x10	1
28	G858 1043	Flexible Grommet	1

Index No.	Part No.	Description	Q'ty Per Assembly

22.Folding Unit 3 (G857/G858)




22.Folding Unit 3 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 5200	Correction Motor - DC13W (RoHS)	1
	G858 1200	Correction Motor - DC13W	1
2	G858 1299	Fns Wiring	1
3	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
4	G858 1416	Sensor Pressure Spring	1
5	G850 1125	Regulation Gear	1
6	G850 1144	Staple Driving Gear	1
7	G850 8070	Photo Sensor (RoHS) XX	1
	G850 1070	Photo Sensor	1
8	G850 1127	Idler Pulley	1
9	G858 1287	Belt	1
10	G850 1220	Belt Holder	2
11	G858 1237	Stopper Bottom Plate	1
12	G858 1238	Guide Plate	1
13	G858 1218	Slide Part	2
14	G858 1240	Paper Stopper	1
15	G858 1239	Paper Stopper Holder	1
16	G850 1241	Fixed Block	1
17	G858 1272	Guide Sheet	1
18	G858 1386	Sensor Fixed Plate	1
19	G858 1387	Actuator	1
20	G858 1449	Adjusting Cam	1
21	G858 1453	Adjusting Spring	1
22	G858 1034	Wire Saddle	1
23	G858 1040	Band	2
24	G858 1038	Edging	2
25	G850 1006	Screw M3x10	1
26	G850 1005	Screw M3x6	2
27	G850 1025	D3 Retaining Ring-E	2
28	G850 1013	Screw With Washer M4x6	7
29	G850 1026	D4 Retaining Ring-E	2
30	G850 1027	D6 Retaining Ring-E	2
31	G858 1004	Screw M4x8	1
32	G850 1008	Screw With Washer M3x6	3

Index No.	Part No.	Description	Q'ty Per Assembly
33	G858 1017	Screw With Washer M4x4	1

23.Folding Unit 4 (G857/G858)




23.Folding Unit 4 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1201	Folding Knife Motor - DC35W	1
2	G858 1247	Guide Shaft Holder	2
3	G850 8058	Photo Sensor (RoHS) XX	1
	G850 1058	Photo Sensor	1
4	G858 1246	Folding Knife	1
5	G858 1456	Blade Driving Cam Ass'y	2
6	G858 1283	Blade Idler Gear	2
7	G858 1268	Cam Follower Shaft Holder	1
8	G858 1248	Guide Shaft Holder	2
9	G858 1305	Fns Relay Wiring	1
10	G858 1312	Up-down Worm	1
11	G850 1008	Screw With Washer M3x6	6
12	G850 1026	D4 Retaining Ring-E	1
13	G850 1013	Screw With Washer M4x6	2
14	G850 1028	D8 Retaining Ring-E	4
15	G850 1027	D6 Retaining Ring-E	4
16	G850 1013	Screw With Washer M4x6	5
17	G858 1022	Set Screw M4x4	1
18	G858 1042	Band	1
19	G858 1001	Screw M3x6	1
20	G850 1006	Screw M3x10	1
21	G858 1039	Band	2
22	G858 1038	Edging	1
23	G858 1037	Mini Saddle	1
24	G858 1017	Screw With Washer M4x4	1

Index No.	Part No.	Description	Q'ty Per Assembly

24.Folding Unit 5 (G857/G858)




24.Folding Unit 5 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G850 1202	Collar	3
2	G858 1288	Belt	1
3	G858 1275	Conveyance Pulley	1
4	G850 1129	Pin	1
5	G858 1269	Regulating Rubber	1
6	G858 1274	Conveyance Pulley	1
7	G858 1409	Pin	1
8	G850 1220	Belt Holder	3
9	G858 1276	Conveyance Pulley	2
10	G858 1282	Reversal Pulley	1
11	G858 1273	Conveyance Pulley	1
12	G858 1289	Reversal Belt	1
13	G858 1291	Driving Belt	1
14	G858 1294	Driving Belt	1
15	G858 1057	Shaft Holder	1
16	G858 1280	Idler Pulley	1
17	G858 1396	Slide Shaft Holder	3
18	G858 1292	Driving Belt	1
19	G858 1264	Idler Collar	1
20	G858 1281	Idler Pulley	2
21	G858 1270	Spring	2
22	G858 1279	Driving Pulley	1
23	G858 1297	Folding Conveyance Motor	1
24	G858 1284	Pressure Gear	2
25	G850 1209	Pin	4
26	G858 1286	Pressure Idler	1
27	G858 1398	Paper Feed Shaft Holder	4
28	G858 1285	Pressure Idler	1
29	G858 1278	Pressure Pulley	1
30	G858 1277	Fold Down Pulley	2
31	G858 1367	Belt Holder Plate	2
32	G858 1293	Driving Belt	1
33	G858 1363	Roller Collar	1
34	G850 1027	D6 Retaining Ring-E	15
35	G850 1026	D4 Retaining Ring-E	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	G850 1013	Screw With Washer M4x6	3
37	G858 1023	Set Screw M4x6	1
38	G858 1007	Screw M4x8	1
39	G858 1004	Screw M4x8	2

25.Haness 1 (G857/G858)




25.Haness 1 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 8202	FNS Wiring (RoHS) XX	1
	G858 1202	FNS Wiring	1
2	G858 8203	Fns Wiring (RoHS) XX	1
	G858 1203	FNS Wiring	1
3	G858 8204	FNS Wiring (RoHS) XX	1
	G858 1204	FNS Wiring	1

Index No.	Part No.	Description	Q'ty Per Assembly

26.Haness 2 (G857/G858)








26.Haness 2 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1205	FNS Wiring	1
2	G858 1206	FNS Wiring	1
3	G858 8207	FNS Wiring (RoHS) XX	1
	G858 1207	FNS Wiring	1
4	G858 8208	Fns Wiring (RoHS) XX	1
	G858 1208	FNS Wiring	1
5	G858 8209	FNS Wiring (RoHS) XX	1
	G858 1209	FNS Wiring	1
6	G858 1210	FNS Wiring	1
7	G858 1442	FNS Wiring	1

Index No.	Part No.	Description	Q'ty Per Assembly

27.Haness 3 (G857/G858)



27.Haness 3 (G857/G858)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G858 1298	FNS Wiring	1
2	G858 1300	FNS Wiring	1
3	G858 1301	FNS Wiring	1
4	G858 1302	FNS Wiring	1
5	G858 1299	FNS Wiring	1
6	G858 1303	FNS Wiring	1
7	G858 1304	FNS Wiring	1
8	G858 1305	FNS Relay Wiring	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
Paper Cpnveyance 3 (G857/G858)	G850 1111	Paper Exit Roller	Paper Exit Roller	4	11 - 21
Paper Cpnveyance 3 (G857/G858)	G850 1111	Paper Exit Roller inthe stacker	Paper Exit Roller	4	11 - 21
Main Tray (G857/G858)	G858 1074	Tray Up-down Motor	Tray Up-down Motor	1	13 - 22
Main Tray (G857/G858)	G858 5074	Tray Up-down Motor	Tray Up-down Motor (RoHS)	1	13 - 22
Paper Exit Unit 1 (G857/G858)	G850 1079	Paper Exit Opening Solenoid	Solenoid Ass'y	1	17 - 1
Paper Exit Unit 1 (G857/G858)	G850 5079	Paper Exit Opening Solenoid	Solenoid Ass'y (RoHS)	1	17 - 1
Stacker Unit 2 (G857/G858)	G858 1127	Stapler	Idler Pulley	1	27 - 28

Parts Index

Part No.	Description	Page and Index No.
G850 1001	Screw M3x6	15 - 36
G850 1001	Screw M3x6	17 - 35
G850 1001	Screw M3x6	37 - 29
G850 1001	Screw M3x6	21 - 27
G850 1001	Screw M3x6	23 - 16
G850 1001	Screw M3x6	27 - 31
G850 1002	Screw M4x6	35 - 12
G850 1004	Screw M2.6x4	15 - 26
G850 1005	Screw M3x6	3 - 41
G850 1005	Screw M3x6	45 - 26
G850 1005	Screw M3x6	17 - 33
G850 1005	Screw M3x6	5 - 63
G850 1005	Screw M3x6	27 - 32
G850 1005	Screw M3x6	37 - 30
G850 1005	Screw M3x6	9 - 21
G850 1005	Screw M3x6	21 - 35
G850 1005	Screw M3x6	11 - 33
G850 1005	Screw M3x6	39 - 27
G850 1005	Screw M3x6	7 - 46
G850 1005	Screw M3x6	41 - 31
G850 1006	Screw M3x10	25 - 16
G850 1006	Screw M3x10	37 - 32
G850 1006	Screw M3x10	7 - 43
G850 1006	Screw M3x10	33 - 24
G850 1006	Screw M3x10	3 - 37
G850 1006	Screw M3x10	15 - 25
G850 1006	Screw M3x10	9 - 18
G850 1006	Screw M3x10	27 - 34
G850 1006	Screw M3x10	5 - 62
G850 1006	Screw M3x10	47 - 20
G850 1006	Screw M3x10	21 - 36
G850 1006	Screw M3x10	45 - 25
G850 1006	Screw M3x10	39 - 28
G850 1006	Screw M3x10	43 - 20
G850 1007	Screw With Washer M3x4	41 - 32

Part No.	Description	Page and Index No.
G850 1007	Screw With Washer M3x4	39 - 35
G850 1007	Screw With Washer M3x4	7 - 48
G850 1007	Screw With Washer M3x4	11 - 29
G850 1007	Screw With Washer M3x4	33 - 26
G850 1007	Screw With Washer M3x4	15 - 34
G850 1007	Screw With Washer M3x4	9 - 24
G850 1007	Screw With Washer M3x4	37 - 27
G850 1007	Screw With Washer M3x4	29 - 38
G850 1008	Screw With Washer M3x6	13 - 26
G850 1008	Screw With Washer M3x6	37 - 25
G850 1008	Screw With Washer M3x6	43 - 22
G850 1008	Screw With Washer M3x6	47 - 11
G850 1008	Screw With Washer M3x6	19 - 22
G850 1008	Screw With Washer M3x6	17 - 31
G850 1008	Screw With Washer M3x6	39 - 34
G850 1008	Screw With Washer M3x6	3 - 39
G850 1008	Screw With Washer M3x6	15 - 33
G850 1008	Screw With Washer M3x6	33 - 19
G850 1008	Screw With Washer M3x6	7 - 42
G850 1008	Screw With Washer M3x6	45 - 32
G850 1008	Screw With Washer M3x6	31 - 21
G850 1008	Screw With Washer M3x6	29 - 39
G850 1008	Screw With Washer M3x6	27 - 36
G850 1008	Screw With Washer M3x6	23 - 17
G850 1008	Screw With Washer M3x6	9 - 22
G850 1008	Screw With Washer M3x6	41 - 29
G850 1008	Screw With Washer M3x6	21 - 33
G850 1008	Screw With Washer M3x6	11 - 32
G850 1008	Screw With Washer M3x6	5 - 51
G850 1010	Screw With Washer M3x8	33 - 29
G850 1010	Screw With Washer M3x8	29 - 36
G850 1010	Screw With Washer M3x8	5 - 53
G850 1010	Screw With Washer M3x8	25 - 19
G850 1011	Screw With Washer M3x10	19 - 24
G850 1012	Screw With Washer M3x16	5 - 56

Part No.	Description	Page and Index No.
G850 1013	Screw With Washer M4x6	31 - 27
G850 1013	Screw With Washer M4x6	33 - 27
G850 1013	Screw With Washer M4x6	43 - 23
G850 1013	Screw With Washer M4x6	29 - 35
G850 1013	Screw With Washer M4x6	45 - 28
G850 1013	Screw With Washer M4x6	3 - 35
G850 1013	Screw With Washer M4x6	41 - 30
G850 1013	Screw With Washer M4x6	25 - 21
G850 1013	Screw With Washer M4x6	49 - 36
G850 1013	Screw With Washer M4x6	39 - 36
G850 1013	M4x6 pan hd. screw with W	15 - 38
G850 1013	Screw With Washer M4x6	21 - 29
G850 1013	Screw With Washer M4x6	5 - 48
G850 1013	Screw With Washer M4x6	47 - 13
G850 1013	Screw With Washer M4x6	47 - 16
G850 1013	Screw With Washer M4x6	13 - 29
G850 1014	Screw With Washer M4x6	3 - 34
G850 1014	Screw With Washer M4x6	25 - 17
G850 1014	Screw With Washer M4x6	37 - 26
G850 1014	Screw With Washer M4x6	5 - 54
G850 1015	Screw With Washer M4x14	27 - 35
G850 1015	Screw With Washer M4x14	17 - 32
G850 1015	Screw With Washer M4x14	11 - 34
G850 1016	Tapping Screw With Washer M3x8	17 - 28
G850 1016	Tapping Screw With Washer M3x8	31 - 25
G850 1016	Tapping Screw With Washer M3x8	33 - 23
G850 1016	Tapping Screw With Washer M3x8	5 - 52
G850 1017	Tapping Screw With Washer M4x8	13 - 27
G850 1017	Tapping Screw With Washer M4x8	9 - 23
G850 1017	Tapping Screw With Washer M4x8	11 - 28
G850 1017	Tapping Screw With Washer M4x8	43 - 21
G850 1017	Tapping Screw With Washer M4x8	17 - 30
G850 1017	Tapping Screw With Washer M4x8	15 - 27
G850 1017	Tapping Screw With Washer M4x8	5 - 65
G850 1018	Tapping Screw With Washer M4x10	5 - 64

Part No.	Description	Page and Index No.
G850 1018	Tapping Screw With Washer M4x10	5 - 57
G850 1020	Set Screw M3x6	19 - 19
G850 1020	Set Screw M3x6	21 - 34
G850 1021	Nut M12	3 - 33
G850 1024	D2 Retaining Ring-E	15 - 32
G850 1024	D2 Retaining Ring-E	9 - 27
G850 1024	D2 Retaining Ring-E	11 - 30
G850 1024	D2 Retaining Ring-E	29 - 37
G850 1025	D3 Retaining Ring-E	27 - 33
G850 1025	D3 Retaining Ring-E	39 - 33
G850 1025	D3 Retaining Ring-e	3 - 42
G850 1025	D3 Retaining Ring-E	45 - 27
G850 1025	D3 Retaining Ring-E	15 - 30
G850 1025	D3 Retaining Ring-E	31 - 3
G850 1025	D3 Retaining Ring-E	7 - 39
G850 1025	D3 Retaining Ring-E	25 - 18
G850 1025	D3 Retaining Ring-E	21 - 32
G850 1025	D3 Retaining Ring-E	37 - 31
G850 1025	D3 Retaining Ring-E	5 - 50
G850 1026	D4 Retaining Ring-E	45 - 29
G850 1026	D4 Retaining Ring-E	47 - 12
G850 1026	D4 Retaining Ring-e	3 - 43
G850 1026	D4 Retaining Ring-E	17 - 34
G850 1026	D4 Retaining Ring-E	39 - 30
G850 1026	D4 Retaining Ring-E	33 - 21
G850 1026	D4 Retaining Ring-E	7 - 44
G850 1026	D4 Retaining Ring-E	9 - 25
G850 1026	D4 Retaining Ring-E	15 - 29
G850 1026	D4 Retaining Ring-E	43 - 19
G850 1026	D4 Retaining Ring-E	31 - 23
G850 1026	D4 Retaining Ring-E	49 - 35
G850 1026	D4 Retaining Ring-E	21 - 30
G850 1026	D4 Retaining Ring-E	35 - 14
G850 1026	D4 Retaining Ring-E	29 - 40
G850 1026	D4 Retaining Ring-E	27 - 37

Part No.	Description	Page and Index No.
G850 1026	D4 Retaining Ring-E	19 - 23
G850 1026	D4 Retaining Ring-E	5 - 61
G850 1026	D4 Retaining Ring-E	11 - 35
G850 1027	D6 Retaining Ring-E	35 - 11
G850 1027	D6 Retaining Ring-E	45 - 30
G850 1027	D6 Retaining Ring-E	39 - 32
G850 1027	D6 Retaining Ring-e	3 - 44
G850 1027	D6 Retaining Ring-E	37 - 28
G850 1027	D6 Retaining Ring-E	47 - 15
G850 1027	D6 Retaining Ring-E	21 - 28
G850 1027	D6 Retaining Ring-E	15 - 35
G850 1027	D6 Retaining Ring-E	29 - 33
G850 1027	D6 Retaining Ring-E	13 - 30
G850 1027	D6 Retaining Ring-E	11 - 36
G850 1027	D6 Retaining Ring-E	23 - 15
G850 1027	D6 Retaining Ring-E	49 - 34
G850 1027	D6 Retaining Ring-E	9 - 26
G850 1027	D6 Retaining Ring-E	27 - 30
G850 1027	D6 Retaining Ring-E	19 - 18
G850 1027	D6 Retaining Ring-E	7 - 41
G850 1027	D6 Retaining Ring-E	43 - 18
G850 1027	D6 Retaining Ring-e	41 - 28
G850 1028	D8 Retaining Ring-E	47 - 14
G850 1028	D8 Retaining Ring-e	13 - 28
G850 1028	D8 Retaining Ring-E	13 - 32
G850 1029	Flexible Grommet	3 - 50
G850 1031	Locking Board Spacer	19 - 21
G850 1057	Interlock Switch	5 - 33
G850 1058	Photo Sensor	33 - 15
G850 1058	Photo Sensor	15 - 3
G850 1058	Photo Sensor	7 - 32
G850 1058	Photo Sensor	37 - 3
G850 1058	Photo Sensor	27 - 9
G850 1058	Photo Sensor	45 - 3
G850 1058	Photo Sensor	21 - 14

Part No.	Description	Page and Index No.
G850 1058	Photo Sensor	39 - 25
G850 1058	Photo Sensor	25 - 15
G850 1058	Photo Sensor	47 - 3
G850 1058	Photo Sensor	5 - 18
G850 1061	Paper Exit Driven Roller	5 - 23
G850 1063	Shift Motor - DC2W	15 - 1
G850 1063	Shift Motor - DC2W	21 - 23
G850 1064	Shaft Holder	15 - 7
G850 1064	Shaft Holder	43 - 6
G850 1064	Shaft Holder	17 - 15
G850 1064	Shaft Holder	19 - 2
G850 1067	Entrance Roller	7 - 25
G850 1067	Entrance Roller	15 - 18
G850 1067	Entrance Roller	9 - 12
G850 1068	Driving Pulley	23 - 4
G850 1068	Driving Pulley	19 - 14
G850 1068	Driving Pulley	29 - 24
G850 1069	Fns Solenoid Ass'y	23 - 10
G850 1070	Photo Sensor	45 - 7
G850 1070	Photo Sensor	43 - 7
G850 1070	Photo Sensor	3 - 14
G850 1070	Photo Sensor	11 - 11
G850 1070	Photo Sensor	7 - 5
G850 1070	Photo Sensor	27 - 21
G850 1070	Photo Sensor	17 - 24
G850 1074	Metal Clamp	11 - 23
G850 1074	Metal Clamp	17 - 27
G850 1074	Metal Clamp	29 - 8
G850 1074	Metal Clamp	21 - 4
G850 1074	Metal Clamp	27 - 4
G850 1074	Metal Clamp	13 - 19
G850 1074	Metal Clamp	43 - 14
G850 1074	Metal Clamp	23 - 2
G850 1074	Metal Clamp	19 - 13
G850 1074	Metal Clamp	9 - 1

Part No.	Description	Page and Index No.
G850 1075	Conveyance Roller	11 - 24
G850 1077	Conveyance Roller	29 - 27
G850 1077	Conveyance Roller	11 - 6
G850 1079	Solenoid Ass'y	17 - 1
G850 1080	Pin	29 - 4
G850 1080	Pin	27 - 6
G850 1080	Pin	17 - 9
G850 1080	Pin	11 - 27
G850 1081	Shaft Holder	17 - 16
G850 1082	Discharge Brush	29 - 29
G850 1082	Discharge Brush	3 - 18
G850 1082	Discharge Brush	5 - 22
G850 1082	Discharge Brush	13 - 18
G850 1082	Discharge Brush	17 - 19
G850 1084	Paper Exit Pulley	19 - 7
G850 1085	Motor Pulley	19 - 9
G850 1085	Motor Pulley	21 - 2
G850 1086	Belt	19 - 10
G850 1088	Shaft Holder	21 - 21
G850 1088	Shaft Holder	23 - 11
G850 1088	Shaft Holder	19 - 12
G850 1089	Belt	29 - 19
G850 1089	Belt	21 - 19
G850 1091	Paper Exit Pulley	19 - 15
G850 1092	Paper Exit Spring	19 - 17
G850 1093	Roller	13 - 2
G850 1095	Tension Pulley	13 - 13
G850 1098	UP-Down Pulley	13 - 23
G850 1102	Paper Exit Gear	21 - 8
G850 1108	Pressure Roller	31 - 5
G850 1108	Pressure Roller	15 - 15
G850 1108	Pressure Roller	33 - 10
G850 1110	Paper Exit Roller	17 - 12
G850 1111	Paper Exit Roller	11 - 21
G850 1111	Paper Exit Roller	19 - 4

Part No.	Description	Page and Index No.
G850 1116	Driving Pulley	23 - 1
G850 1117	Driving Pulley	21 - 10
G850 1119	Tension Roller	21 - 17
G850 1122	Belt Detction Gear	27 - 12
G850 1123	Paper Exit Belt	27 - 14
G850 1124	Belt Driving Pulley	27 - 3
G850 1125	Regulation Gear	35 - 9
G850 1125	Regulation Gear	37 - 15
G850 1125	Regulation Gear	27 - 18
G850 1125	Regulation Gear	45 - 5
G850 1126	Belt	37 - 14
G850 1126	Belt	27 - 16
G850 1127	Idler Pulley	37 - 12
G850 1127	Idler Pulley	35 - 1
G850 1127	Idler Pulley	39 - 12
G850 1127	Idler Pulley	27 - 28
G850 1127	Idler Pulley	45 - 8
G850 1129	Pin	29 - 21
G850 1129	Pin	49 - 4
G850 1133	Entrance Guide Pulley	29 - 2
G850 1135	Entrance Guide Pulley	29 - 6
G850 1136	Guide Belt	29 - 7
G850 1137	Belt	29 - 10
G850 1141	Belt	29 - 17
G850 1144	Staple Driving Gear	45 - 6
G850 1144	Staple Driving Gear	35 - 6
G850 1144	Staple Driving Gear	39 - 24
G850 1148	Support Stay	23 - 8
G850 1148	Support Stay	15 - 22
G850 1148	Support Stay	17 - 8
G850 1148	Support Stay	27 - 15
G850 1148	Support Stay	29 - 15
G850 1148	Support Stay	39 - 26
G850 1150	Cover	5 - 36
G850 1151	Actuator	5 - 35

Part No.	Description	Page and Index No.
G850 1153	Switch Insulating Sheet	5 - 32
G850 1154	Magnet Catch	5 - 12
G850 1154	Magnet Catch	43 - 1
G850 1154	Magnet Catch	11 - 3
G850 1156	Carriage Roller	3 - 10
G850 1159	Driven Shaft Holder	5 - 27
G850 1160	Stopper Rubber	3 - 2
G850 1163	Support Stay	3 - 3
G850 1167	Actuator	5 - 9
G850 1168	Magnet Catch Plate	5 - 10
G850 1171	Slide Arm	17 - 7
G850 1171	Slide Arm	15 - 10
G850 1175	Stopper Rubber	9 - 17
G850 1175	Stopper Rubber	41 - 3
G850 1175	Stopper Rubber	7 - 29
G850 1175	Stopper Rubber	11 - 7
G850 1176	Shaft Holder	15 - 4
G850 1177	Stopper Sheet	27 - 8
G850 1177	Stopper Sheet	15 - 12
G850 1177	Stopper Sheet	37 - 2
G850 1179	Solenoid Lever	23 - 14
G850 1183	Conveyance Pressure Spring	15 - 11
G850 1183	Conveyance Pressure Spring	29 - 28
G850 1184	Release Lever Knob	43 - 5
G850 1184	Release Lever Knob	9 - 9
G850 1184	Release Lever Knob	11 - 1
G850 1186	Magnet Catch	9 - 6
G850 1188	Detecting Sensor	11 - 9
G850 1191	Solenoid Spring	9 - 2
G850 1193	Hinge Spring	11 - 13
G850 1195	Paper Route Switching Gate	11 - 18
G850 1196	Solenoid Spring	11 - 17
G850 1197	By-pass Gate	11 - 19
G850 1198	Solenoid Spring	17 - 4
G850 1199	Solenoid Lever	17 - 5

Part No.	Description	Page and Index No.
G850 1200	Rotary Stopper	17 - 14
G850 1201	Paper Exit Pressure Spring	17 - 17
G850 1202	Collar	19 - 16
G850 1202	Collar	21 - 20
G850 1202	Collar	49 - 1
G850 1203	Slide Stopper	13 - 3
G850 1206	UP-Down Gear	13 - 20
G850 1207	UP-Down Gear	13 - 21
G850 1208	Up-down Gear	13 - 11
G850 1209	Pin	49 - 25
G850 1209	Pin	13 - 12
G850 1210	Protect Block	3 - 25
G850 1212	Spring	23 - 9
G850 1215	Guide Plate/Middle	27 - 22
G850 1216	Belt Detecting Screw	27 - 13
G850 1217	Rocking Block Ass'y	27 - 25
G850 1217	Rocking Block Ass'y	37 - 6
G850 1218	Belt Holder Plate	37 - 7
G850 1218	Belt Holder Plate	27 - 27
G850 1219	Belt Holder	27 - 2
G850 1220	Belt Holder	35 - 2
G850 1220	Belt Holder	49 - 8
G850 1220	Belt Holder	37 - 13
G850 1220	Belt Holder	27 - 17
G850 1220	Belt Holder	45 - 10
G850 1220	Belt Holder	39 - 16
G850 1222	Belt Holder	29 - 1
G850 1225	Conveyance Aux Collar	11 - 26
G850 1225	Conveyance Aux Collar	29 - 3
G850 1241	Fixed Block	45 - 16
G850 1241	Fixed Block	31 - 7
G850 1241	Fixed Block	33 - 2
G850 1241	Fixed Block	39 - 6
G850 1252	Slide Stay	5 - 14
G850 1253	RF Stay	3 - 7

Part No.	Description	Page and Index No.
G850 1258	Support Plate	5 - 28
G850 1261	Shaft/Lower	5 - 24
G850 1267	Rear Mt Plate	5 - 30
G850 1269	Motor Mt Plate	15 - 2
G850 1271	Slide Stay/A Ass'y	15 - 5
G850 1285	Conveyance Shaft/B Ass'y	7 - 26
G850 1285	Conveyance Shaft/B Ass'y	9 - 14
G850 1285	Conveyance Shaft/B Ass'y	11 - 20
G850 1290	Conveyance Shaft Ass'y	15 - 14
G850 1290	Conveyance Shaft Ass'y	11 - 4
G850 1290	Conveyance Shaft Ass'y	29 - 26
G850 1296	Solenoid MT Plate	17 - 3
G850 1297	Paper Exit Guide Stay	17 - 6
G850 1298	Paper Exit Conveyance Shaft	17 - 10
G850 1299	Paper Exit Support Shaft	17 - 11
G850 1300	Paper Exit Guide Stay	17 - 18
G850 1301	Paper Exit Guide Sheet	17 - 21
G850 1302	Stopper	17 - 23
G850 1305	Rotary Disk Ass'y	19 - 6
G850 1306	Paper Exit Opening Unit	17 - 2
G850 1307	Paper Exit Guide Plate	17 - 26
G850 1308	Paper Exit Guide Stay	17 - 13
G850 1309	Slide Shaft	13 - 1
G850 1310	Up-down Stay	13 - 4
G850 1311	Up-down Cover/R	13 - 5
G850 1312	Up-down Cover/F	13 - 6
G850 1314	Tension Plate Ass'y	13 - 14
G850 1328	Tension Plate Ass'y	27 - 19
G850 1328	Tension Plate Ass'y	37 - 11
G850 1329	Guide Plate A	29 - 30
G850 1352	Idler Shaft	31 - 4
G850 1352	Idler Shaft	33 - 9
G850 1357	Sensor Cover Ass'y	27 - 20
G850 1357	Sensor Cover Ass'y	17 - 25
G850 5057	Interlock Switch (RoHS)	5 - 33

Part No.	Description	Page and Index No.
G850 5063	Shift Motor - DC2W (RoHS)	15 - 1
G850 5063	Shift Motor - DC2W (RoHS)	21 - 23
G850 5069	Fns Solenoid Ass'y (RoHS)	23 - 10
G850 5079	Solenoid Ass'y (RoHS)	17 - 1
G850 8058	Photo Sensor (RoHS) XX	33 - 15
G850 8058	Photo Sensor (RoHS) XX	45 - 3
G850 8058	Photo Sensor (RoHS) XX	15 - 3
G850 8058	Photo Sensor (RoHS) XX	39 - 25
G850 8058	Photo Sensor (RoHS) XX	37 - 3
G850 8058	Photo Sensor (RoHS) XX	7 - 32
G850 8058	Photo Sensor (RoHS) XX	21 - 14
G850 8058	Photo Sensor (RoHS) XX	47 - 3
G850 8058	Photo Sensor (RoHS) XX	5 - 18
G850 8058	Photo Sensor (RoHS) XX	27 - 9
G850 8058	Photo Sensor (RoHS) XX	25 - 15
G850 8070	Photo Sensor (RoHS) XX	7 - 5
G850 8070	Photo Sensor (RoHS) XX	27 - 21
G850 8070	Photo Sensor (RoHS) XX	11 - 11
G850 8070	Photo Sensor (RoHS) XX	43 - 7
G850 8070	Photo Sensor (RoHS) XX	3 - 14
G850 8070	Photo Sensor (RoHS) XX	45 - 7
G850 8070	Photo Sensor (RoHS) XX	17 - 24
G850 8188	Detecting Sensor (RoHS) XX	11 - 9
G850 8306	Paper Exit Opening Unit (RoHS) XX	17 - 2
G850 8357	Sensor Cover Ass'y (RoHS) XX	27 - 20
G850 8357	Sensor Cover Ass'y (RoHS) XX	17 - 25
G858 1001	Screw M3x6	13 - 33
G858 1001	Screw M3x6	47 - 19
G858 1002	Truss Screw M4x6	5 - 20
G858 1003	Truss Screw M4x6	25 - 22
G858 1004	Screw M4x8	45 - 31
G858 1004	Screw M4x8	49 - 39
G858 1005	Screw M3x5	5 - 49
G858 1006	Screw M3x8	35 - 13
G858 1006	Screw M3x8	15 - 28

Part No.	Description	Page and Index No.
G858 1007	Screw M4x8	25 - 23
G858 1007	Screw M4x8	49 - 38
G858 1007	Screw M4x8	13 - 31
G858 1008	Screw M3x6	29 - 34
G858 1009	Screw M2x10	5 - 55
G858 1010	Screw M3x4	35 - 15
G858 1011	Screw M3x6	13 - 24
G858 1011	Screw M3x6	5 - 58
G858 1013	Screw M4x6	27 - 38
G858 1013	Screw M4x6	37 - 33
G858 1013	Screw M4x6	43 - 26
G858 1014	Screw M4x12	7 - 47
G858 1015	Screw M5x8	3 - 32
G858 1016	Screw With Washer M3x20	3 - 38
G858 1016	Screw With Washer M3x20	19 - 20
G858 1017	Screw With Washer M4x4	45 - 33
G858 1017	Screw With Washer M4x4	47 - 24
G858 1018	Screw With Washer M4x8	43 - 25
G858 1018	Screw With Washer M4x8	5 - 19
G858 1019	Screw With Washer M4x10	43 - 27
G858 1020	Screw With Washer M6x10	33 - 25
G858 1020	Screw With Washer M6x10	31 - 26
G858 1021	Screw With Washer M4x14	7 - 45
G858 1022	Set Screw M4x4	9 - 20
G858 1022	Set Screw M4x4	47 - 17
G858 1023	Set Screw M4x6	49 - 37
G858 1025	D2.5 Retaining Ring-E	41 - 33
G858 1026	D1 Retaining Ring	31 - 24
G858 1027	D2 Retaining Ring	31 - 22
G858 1027	D2 Retaining Ring	33 - 20
G858 1028	D10 Retaining Ring	33 - 22
G858 1029	D3x12 Spring Pin	39 - 31
G858 1031	Nylon Clamp	17 - 29
G858 1032	Nylon Clamp	5 - 59
G858 1033	Wire Saddle	37 - 24

Part No.	Description	Page and Index No.
G858 1033	Wire Saddle	41 - 35
G858 1033	Wire Saddle	3 - 36
G858 1034	Wire Saddle	3 - 45
G858 1034	Wire Saddle	45 - 22
G858 1035	Wire Saddle	41 - 34
G858 1036	Locking Wire Saddle	21 - 25
G858 1036	Locking Wire Saddle	3 - 46
G858 1036	Locking Wire Saddle	15 - 31
G858 1037	Mini Saddle	47 - 23
G858 1038	Edging	3 - 47
G858 1038	Edging	45 - 24
G858 1038	Edging	47 - 22
G858 1038	Edging	41 - 37
G858 1039	Band	15 - 24
G858 1039	Band	47 - 21
G858 1039	Band	11 - 31
G858 1039	Band	7 - 40
G858 1039	Band	9 - 19
G858 1040	Band	13 - 25
G858 1040	Band	41 - 36
G858 1040	Band	23 - 18
G858 1040	Band	37 - 23
G858 1040	Band	45 - 23
G858 1040	Band	43 - 24
G858 1040	Band	3 - 48
G858 1041	Band	3 - 51
G858 1042	Band	47 - 18
G858 1043	Flexible Grommet	3 - 49
G858 1043	Flexible Grommet	35 - 16
G858 1043	Flexible Grommet	43 - 28
G858 1044	Flexible Grommet	39 - 29
G858 1044	Flexible Grommet	41 - 38
G858 1045	Flexible Grommet	21 - 31
G858 1046	Flexible Grommet	5 - 60
G858 1047	Locking Board Spacer	25 - 20

Part No.	Description	Page and Index No.
G858 1047	Locking Board Spacer	3 - 40
G858 1048	Locking Board Spacer	21 - 26
G858 1049	Edge Saddle	33 - 28
G858 1050	Paper Exit Guide Plate/M	17 - 20
G858 1051	Plate	17 - 22
G858 1054	Roller	3 - 21
G858 1055	Ball Bearing	7 - 1
G858 1055	Ball Bearing	41 - 24
G858 1056	Release Knob	9 - 11
G858 1057	Shaft Holder	49 - 15
G858 1059	Photo Sensor	39 - 17
G858 1059	Photo Sensor	41 - 20
G858 1060	Pin	29 - 22
G858 1061	Pin	7 - 6
G858 1061	Pin	39 - 4
G858 1061	Pin	7 - 33
G858 1062	Driving Pulley	23 - 3
G858 1063	Main Fixed Plate	3 - 27
G858 1064	Conveyance Pressure Spring	11 - 5
G858 1065	Guide Plate	15 - 17
G858 1066	Guide Plate	15 - 6
G858 1067	Main Tray	13 - 7
G858 1068	Main Tray	13 - 8
G858 1069	Paper Exit Roller	19 - 3
G858 1070	Paper Exit Guide Plate	19 - 5
G858 1071	Paper Exit Reinforcing Stay	13 - 9
G858 1072	Motor Pulley	29 - 20
G858 1073	Slide Gear	15 - 9
G858 1074	Tray Up-down Motor	13 - 22
G858 1075	Alignment Plate/F Ass'y	27 - 26
G858 1076	Alignment Plate/R Ass'y	27 - 24
G858 1077	Paper Exit Cover Ass'y	5 - 21
G858 1078	Paper Exit Sensor Ass'y	7 - 30
G858 1079	Alignment Plate	27 - 7
G858 1080	Driving Shaft/A Ass'y	35 - 4

Part No.	Description	Page and Index No.
G858 1081	Driving Shaft/B Ass'y	35 - 10
G858 1082	FS-108H Package	3 - 31
G858 1083	R/B Package	25 - 10
G858 1084	Rom Ass'y	3 - 17
G858 1085	AUX Plate	13 - 17
G858 1086	Paper Exit Up-down Actuator	5 - 29
G858 1087	Wiring Guide Arm	3 - 19
G858 1088	UP-Down Wire	13 - 15
G858 1089	UP-Down Wire	13 - 16
G858 1090	Lock Spring	3 - 22
G858 1091	Slide Rail	3 - 13
G858 1092	Slide Rail	3 - 12
G858 1093	Carriage Roller	3 - 9
G858 1094	Actuator	3 - 11
G858 1095	Paper Exit Pressing Lever	5 - 37
G858 1096	Top Cover	5 - 13
G858 1097	Front Door	5 - 11
G858 1098	Front Side Cover	5 - 5
G858 1099	Rear Cover	5 - 15
G858 1100	Knob	5 - 8
G858 1101	Side Cover	5 - 3
G858 1102	Side Cover	5 - 1
G858 1103	Side Cover	5 - 2
G858 1104	Hinge Plate	5 - 4
G858 1105	Hinge Plate	5 - 7
G858 1106	Seal	5 - 6
G858 1107	Panel	25 - 5
G858 1108	Panel	25 - 8
G858 1109	Shaft Support Plate	25 - 9
G858 1110	Shaft Support Plate	25 - 14
G858 1111	Staple Slide Shaft Holder	33 - 5
G858 1111	Staple Slide Shaft Holder	31 - 2
G858 1112	Wiring Rotary Plate	25 - 2
G858 1113	Staple Guide Plate	33 - 6
G858 1114	Staple Guide Plate	33 - 16

Part No.	Description	Page and Index No.
G858 1115	Stopper	31 - 14
G858 1116	Stopper Spring	31 - 10
G858 1117	Stopper	31 - 16
G858 1118	Cartridge Guide Seal	25 - 1
G858 1119	Lock Block	31 - 6
G858 1119	Lock Block	33 - 4
G858 1120	Lock Spring	31 - 9
G858 1120	Lock Spring	33 - 12
G858 1121	Lock Pin	31 - 13
G858 1121	Lock Pin	33 - 11
G858 1122	Belt Fixed Block	25 - 12
G858 1123	Staple Rotary Roller	25 - 13
G858 1124	Guide Plate	27 - 1
G858 1125	Conveyance Guide Plate	29 - 31
G858 1126	Shaft Holder Plate	29 - 9
G858 1127	Stapler	31 - 19
G858 1127	Stapler	33 - 17
G858 1128	Wiring Regulating Plate	33 - 7
G858 1129	Paper Exit Guide Sheet	27 - 23
G858 1130	Stopper Bottom Plate/F	31 - 11
G858 1131	Stopper Bottom Plate/R	31 - 15
G858 1132	Driving Roller	29 - 5
G858 1133	Oscillate Pulley	29 - 16
G858 1134	Oscillate Pulley	29 - 18
G858 1135	Belt Mount Roller	29 - 12
G858 1136	Regulating Belt	29 - 11
G858 1137	Regulating Belt	29 - 13
G858 1138	Carriage Cover	25 - 11
G858 1139	Staple Cover	33 - 8
G858 1140	Carriage Cover	25 - 4
G858 1141	Conveyance Guide Sheet	31 - 12
G858 1142	Slide Sheet	33 - 1
G858 1142	Slide Sheet	31 - 17
G858 1143	Slide Sheet	31 - 18
G858 1143	Slide Sheet	33 - 13

Part No.	Description	Page and Index No.
G858 1144	Conveyance Guide Sheet	29 - 14
G858 1145	Conveyance Guide Plate	11 - 16
G858 1146	Conveyance Guide Plate	11 - 8
G858 1147	Conveyance Guide Plate	11 - 15
G858 1148	Conveyance Guide Plate	11 - 12
G858 1149	Conveyance Roller	9 - 4
G858 1150	Sub-tray Gate	9 - 15
G858 1151	Pressure Rubber	11 - 25
G858 1152	Conveyance Slide Shaft	15 - 13
G858 1153	Pulley Holder	21 - 12
G858 1154	Conveyance Roller	9 - 3
G858 1155	Belt Tension Spring	23 - 7
G858 1156	Hinge Spring	11 - 14
G858 1157	Conveyance Guide Sheet	7 - 34
G858 1158	Conveyance Guide Sheet	11 - 2
G858 1159	Paper Exit Side Plate	3 - 5
G858 1160	Paper Exit Side Plate	3 - 6
G858 1161	Paper Exit Guide Plate	7 - 20
G858 1162	Paper Exit Guide Plate	7 - 22
G858 1163	Paper Exit Guide Plate	7 - 16
G858 1164	Sub-tray Paper Exit Roller	7 - 4
G858 1165	Sub-tray Paper Exit Roller	7 - 2
G858 1166	Sub-tray Paper Exit Roller	7 - 7
G858 1167	Spring	5 - 40
G858 1168	Neutralizing Plate	5 - 25
G858 1169	Earth Plate	5 - 26
G858 1170	Lever	7 - 18
G858 1171	Conveyance Guide Plate	7 - 17
G858 1172	Conveyance Guide Plate	7 - 14
G858 1173	Conveyance Guide Plate	7 - 12
G858 1174	Conveyance Pressure Spring	7 - 13
G858 1175	Conveyance Pressure Spring	7 - 27
G858 1176	Tension Shaft Holder	7 - 28
G858 1177	Conveyance Driving Pulley	21 - 6
G858 1178	Slide Pulley	21 - 13

Part No.	Description	Page and Index No.
G858 1179	Paper Exit Pulley	21 - 16
G858 1180	Driving Pulley	21 - 22
G858 1181	Staple Slide Pulley	39 - 23
G858 1182	Slide Gear	21 - 5
G858 1183	Slide Gear	15 - 8
G858 1184	Slide Gear	15 - 16
G858 1185	Coupling Gear	27 - 11
G858 1186	Staple Slide Gear	39 - 21
G858 1187	Connecting Gear	21 - 15
G858 1188	Belt	21 - 3
G858 1189	Belt	21 - 7
G858 1189	Belt	23 - 12
G858 1190	Belt	23 - 6
G858 1191	Belt	23 - 5
G858 1192	Belt	7 - 11
G858 1193	Belt	19 - 11
G858 1194	Belt	35 - 3
G858 1194	Belt	33 - 3
G858 1194	Belt	31 - 8
G858 1195	Belt	35 - 8
G858 1196	Paper Exit Driving Belt	7 - 9
G858 1197	Paper Exit Driving Belt	23 - 13
G858 1197	Paper Exit Driving Belt	21 - 18
G858 1198	Conveyance Motor - DC39W	21 - 1
G858 1199	Fns Correction Motor - DC13W	37 - 1
G858 1199	Fns Correction Motor - DC13W	27 - 10
G858 1200	Correction Motor - DC13W	45 - 1
G858 1200	Correction Motor - DC13W	35 - 7
G858 1200	Correction Motor - DC13W	39 - 20
G858 1201	Folding Knife Motor - DC35W	47 - 1
G858 1202	FNS Wiring	51 - 1
G858 1203	FNS Wiring	51 - 2
G858 1203	Fns Wiring	7 - 31
G858 1204	FNS Wiring	51 - 3
G858 1205	FNS Wiring	53 - 1

Part No.	Description	Page and Index No.
G858 1205	Fns Wiring	5 - 34
G858 1206	FNS Wiring	53 - 2
G858 1207	FNS Wiring	53 - 3
G858 1208	FNS Wiring	53 - 4
G858 1208	Fns Wiring	27 - 5
G858 1209	FNS Wiring	53 - 5
G858 1210	FNS Wiring	53 - 6
G858 1210	Fns Wiring	29 - 25
G858 1211	Jam Handling Label	5 - 42
G858 1212	Caution Label	5 - 39
G858 1213	Cartridge Case	31 - 1
G858 1213	Cartridge Case	33 - 18
G858 1214	Alignment Plate	37 - 5
G858 1215	FS-108HBM Package	3 - 8
G858 1216	Booklet Tray	3 - 1
G858 1217	Stopper Board	39 - 7
G858 1218	Slide Part	45 - 13
G858 1218	Slide Part	39 - 5
G858 1219	Release Stopper	39 - 14
G858 1220	Stopper Spring	39 - 13
G858 1221	Lever Locking Cam	39 - 8
G858 1222	Lever Locking Gear	39 - 2
G858 1223	Shaft Support Collar	39 - 1
G858 1224	Release Lever	39 - 22
G858 1225	Stopper Sheet	39 - 15
G858 1226	Release Spring	39 - 11
G858 1227	Sensor Cover	37 - 4
G858 1228	Lower Alignment Plate	37 - 8
G858 1229	Lower Alignment Plate	37 - 9
G858 1230	Guide Plate	37 - 10
G858 1231	Conveyance Guide Plate	37 - 22
G858 1232	Conveyance Guide Plate	37 - 17
G858 1233	Release Part	37 - 18
G858 1234	Release Spring	37 - 19
G858 1235	Conveyance Guide Sheet	39 - 3

Part No.	Description	Page and Index No.
G858 1236	Conveyance Guide Sheet	37 - 21
G858 1237	Stopper Bottom Plate	45 - 11
G858 1238	Guide Plate	45 - 12
G858 1239	Paper Stopper Holder	45 - 15
G858 1240	Paper Stopper	45 - 14
G858 1241	Guide Plate	43 - 4
G858 1242	Conveyance Fulcrum Plate	43 - 2
G858 1243	Guide Sheet	43 - 3
G858 1244	Folding Conveyance Roller	43 - 13
G858 1245	Conveyance Roller	43 - 11
G858 1246	Folding Knife	47 - 4
G858 1247	Guide Shaft Holder	47 - 2
G858 1248	Guide Shaft Holder	47 - 8
G858 1249	Fold Down Arm	41 - 14
G858 1250	Fold Down Arm	41 - 16
G858 1251	Pressure Arm	41 - 11
G858 1252	Pressure Arm	41 - 13
G858 1253	Pressure Roller	41 - 5
G858 1254	Pressure Roller	41 - 4
G858 1255	Fold Down Spring	41 - 12
G858 1256	Fold Down Spring	41 - 15
G858 1257	Pressure Spring	41 - 17
G858 1258	Jam Release Knob	41 - 19
G858 1259	Sensor Mount Plate	41 - 21
G858 1260	Actuator	41 - 8
G858 1261	Actuator	41 - 25
G858 1262	Sensor Pressure Spring	41 - 23
G858 1263	Sensor Mount Stay	41 - 10
G858 1264	Idler Collar	49 - 19
G858 1265	Paper Exit Guide Plate	41 - 9
G858 1266	Paper Exit Guide Plate	41 - 2
G858 1267	Adjusting Cover	41 - 1
G858 1268	Cam Follower Shaft Holder	47 - 7
G858 1269	Regulating Rubber	41 - 7
G858 1269	Regulating Rubber	49 - 5

Part No.	Description	Page and Index No.
G858 1270	Spring	49 - 21
G858 1271	Folding Roller	41 - 6
G858 1272	Guide Sheet	45 - 17
G858 1273	Conveyance Pulley	49 - 11
G858 1274	Conveyance Pulley	49 - 6
G858 1275	Conveyance Pulley	49 - 3
G858 1276	Conveyance Pulley	49 - 9
G858 1277	Fold Down Pulley	49 - 30
G858 1278	Pressure Pulley	49 - 29
G858 1279	Driving Pulley	49 - 22
G858 1280	Idler Pulley	49 - 16
G858 1281	Idler Pulley	49 - 20
G858 1282	Reversal Pulley	49 - 10
G858 1283	Blade Idler Gear	47 - 6
G858 1284	Pressure Gear	49 - 24
G858 1285	Pressure Idler	49 - 28
G858 1286	Pressure Idler	49 - 26
G858 1287	Belt	45 - 9
G858 1288	Belt	49 - 2
G858 1289	Reversal Belt	49 - 12
G858 1290	Folding Conveyance Belt	43 - 12
G858 1291	Driving Belt	49 - 13
G858 1292	Driving Belt	49 - 18
G858 1293	Driving Belt	49 - 32
G858 1294	Driving Belt	49 - 14
G858 1295	Belt	39 - 10
G858 1296	Stepper Motor - DC1W	39 - 9
G858 1297	Folding Conveyance Motor	49 - 23
G858 1298	FNS Wiring	55 - 1
G858 1299	FNS Wiring	55 - 5
G858 1299	Fns Wiring	45 - 2
G858 1300	FNS Wiring	55 - 2
G858 1301	FNS Wiring	55 - 3
G858 1302	FNS Wiring	55 - 4
G858 1302	Fns Wiring	37 - 16

Part No.	Description	Page and Index No.
G858 1303	FNS Wiring	55 - 6
G858 1303	Fns Wiring	39 - 18
G858 1304	FNS Wiring	55 - 7
G858 1304	Fns Wiring	41 - 22
G858 1305	FNS Relay Wiring	55 - 8
G858 1305	Fns Relay Wiring	47 - 9
G858 1306	Paper Exit Stopper Plate	3 - 4
G858 1307	ADF Pressure Part	31 - 20
G858 1307	ADF Pressure Part	33 - 14
G858 1308	Belt Pressure Spring	37 - 20
G858 1309	Collar	29 - 32
G858 1310	Discharge Brush	41 - 26
G858 1311	DFF Collar	7 - 15
G858 1312	Up-down Worm	47 - 10
G858 1314	Stacker Entrance Motor	29 - 23
G858 1352	Joint Cover	3 - 30
G858 1353	Joint Cover	3 - 29
G858 1354	Joint Cover	3 - 28
G858 1355	Conveyance Guide Plate	9 - 13
G858 1356	Conveyance Pressure Spring	9 - 5
G858 1357	Driving Pulley	7 - 8
G858 1358	Open-close Lever	7 - 23
G858 1359	Jam Release Lever	43 - 9
G858 1360	Gear	21 - 11
G858 1361	Knob	25 - 6
G858 1362	Shoulder Screw	7 - 21
G858 1363	Roller Collar	49 - 33
G858 1364	Lock Lever	3 - 20
G858 1366	Lock Cam	25 - 7
G858 1367	Belt Holder Plate	49 - 31
G858 1368	Open-close Lever	7 - 19
G858 1369	Paper Exit Driving Pulley	7 - 24
G858 1375	External Aux Panel	5 - 31
G858 1376	Key Counter Cover	5 - 43
G858 1386	Sensor Fixed Plate	45 - 18

Part No.	Description	Page and Index No.
G858 1386	Sensor Fixed Plate	43 - 17
G858 1387	Actuator	45 - 19
G858 1387	Actuator	43 - 16
G858 1388	Magnet Catch	3 - 16
G858 1392	Pin	21 - 9
G858 1393	Flat Screw	41 - 18
G858 1393	Flat Screw	3 - 24
G858 1396	Slide Shaft Holder	49 - 17
G858 1398	Paper Feed Shaft Holder	35 - 5
G858 1398	Paper Feed Shaft Holder	39 - 19
G858 1398	Paper Feed Shaft Holder	49 - 27
G858 1401	Sub-Tray	5 - 17
G858 1402	Sub-Tray	5 - 16
G858 1403	Belt Tension Roller	21 - 24
G858 1404	Belt Tension Roller	43 - 10
G858 1406	Belt Tension Roller	13 - 10
G858 1409	Pin	43 - 8
G858 1409	Pin	49 - 7
G858 1410	Pressure Roller	3 - 23
G858 1416	Sensor Pressure Spring	43 - 15
G858 1416	Sensor Pressure Spring	45 - 4
G858 1419	Sensor Cover	11 - 10
G858 1424	Paper Exit Roller Motor	19 - 8
G858 1425	Cover	5 - 38
G858 1426	Sensor Stopper Part	19 - 1
G858 1428	Holding Sheet	27 - 29
G858 1429	Ped Actuator	7 - 38
G858 1430	PE Pressure Plate	5 - 46
G858 1431	PE Pressure Plate	5 - 45
G858 1432	Shaft Hold Plate	5 - 47
G858 1433	Solenoid Lever	15 - 21
G858 1434	Solenoid Release Spring	15 - 20
G858 1435	PE Stopper Sheet	3 - 26
G858 1436	Preventing Sheet	5 - 44
G858 1437	PE Stopper Sheet	3 - 15

Part No.	Description	Page and Index No.
G858 1438	Guide Spring	7 - 37
G858 1439	Steple Processing Label	25 - 3
G858 1440	Sensor Plate	9 - 8
G858 1441	Sticking Part	5 - 41
G858 1442	FNS Wiring	53 - 7
G858 1443	Folding Roller	41 - 27
G858 1444	Photo Sensor	9 - 10
G858 1445	Torque Limiter	7 - 35
G858 1446	Pin	7 - 36
G858 1447	Solenoid Assembly	15 - 19
G858 1448	Sensor Mount Plate Assembly	7 - 10
G858 1449	Adjusting Cam	45 - 20
G858 1451	Adu Shaft Holder	7 - 3
G858 1452	pF Shaft Holder	15 - 23
G858 1452	pF Shaft Holder	11 - 22
G858 1452	pF Shaft Holder	9 - 7
G858 1453	Adjusting Spring	45 - 21
G858 1456	Blade Driving Cam Ass'y	47 - 5
G858 1457	Conveyance Guide Plate/a	9 - 16
G858 1459	Support stay	15 - 37
G858 5074	Tray Up-down Motor (RoHS)	13 - 22
G858 5080	Driving Shaft/A Ass'y (RoHS)	35 - 4
G858 5081	Driving Shaft/B Ass'y (RoHS)	35 - 10
G858 5083	R/B Package (RoHS)	25 - 10
G858 5088	UP-Down Wire (RoHS)	13 - 15
G858 5089	UP-Down Wire (RoHS)	13 - 16
G858 5127	Stapler (RoHS)	31 - 19
G858 5127	Stapler (RoHS)	33 - 17
G858 5199	Fns Correction Motor - DC13W (RoHS)	37 - 1
G858 5199	Fns Correction Motor - DC13W (RoHS)	27 - 10
G858 5200	Correction Motor - DC13W (RoHS)	45 - 1
G858 5200	Correction Motor - DC13W (RoHS)	39 - 20
G858 5200	Correction Motor - DC13W (RoHS)	35 - 7
G858 5213	Cartridge Case (RoHS)	33 - 18
G858 5213	Cartridge Case (RoHS)	31 - 1

Part No.	Description	Page and Index No.
G858 5314	Stacker Entrance Motor (RoHS)	29 - 23
G858 5352	Joint Cover (RoHS)	3 - 30
G858 5353	Joint Cover (RoHS)	3 - 29
G858 5354	Joint Cover (RoHS)	3 - 28
G858 5424	Paper Exit Roller Motor (RoHS) XX	19 - 8
G858 8078	Paper Exit Sensor Ass'y (RoHS) XX	7 - 30
G858 8082	FS-108H Package (RoHS) XX	3 - 31
G858 8084	Rom Ass'y (RoHS) XX	3 - 17
G858 8198	Conveyance Motor - DC39W (RoHS) XX	21 - 1
G858 8202	FNS Wiring (RoHS) XX	51 - 1
G858 8203	Fns Wiring (RoHS) XX	51 - 2
G858 8203	Fns Wiring (RoHS) XX	7 - 31
G858 8204	FNS Wiring (RoHS) XX	51 - 3
G858 8207	FNS Wiring (RoHS) XX	53 - 3
G858 8208	Fns Wiring (RoHS) XX	27 - 5
G858 8208	Fns Wiring (RoHS) XX	53 - 4
G858 8209	FNS Wiring (RoHS) XX	53 - 5
G858 8444	Photo Sensor (RoHS) XX	9 - 10