RICOH

Technical Bulletin

PAGE: 1/3

Model:Z-C1 Fax Option TypeC400 D			Dat	Date: 05-Nov-12		No.: RD483001	
Subject: G3 Decal Deletion			Prepared by: T. Kiyohara				
From: 2nd Tech S	Service Sect., MFP/P Tech Ser	vice Dept.					
Classification: Troubleshooting		Part information		Action required			
	🗌 Mechanical	Electrical			🛛 Service manual revision		
	Paper path			eive	e 🗌 Retrofit information		
	Product Safety	Other ()	Tier 2		


Note: These corrections were made because the G3 decal was deleted in September 2011.

Service Manual Correction

D596 Service Manual

- 1. Installation
 - Fax Unit (D483)
 - Accessory

No.	Description	Q'ty
1	FCU	1
2	Harness: TEL and LINE	1
3	Bracket	1
4	Relay Board	1
5	Screw: M3x6	9
6	Clamp	7
7	Serial Number Decal	1
9	C3 Detal	1
9	Telephone Cord (NA only)	1
10	FCC Decal (NA only)	1
11	EMC Address Decal (EU only)	1
12	Multi-Language Decals (EU only)	1



Parts Catalog Correction

Fax Option Type C400 (D483-01/02/03)

Deleted Part Number	Description	Page	Index	Note
B4043861	DECAL:SG3	3	16	

RICOH


Technical Bulletin

Model:Z-C1 Fax Option TypeC400

Date: 05-Nov-12

No.: RD483001

1.Fax Unit (D483)



2

RICOH

Technical Bulletin

PAGE: 1/1

Model: Z-C1 FAX	odel: Z-C1 FAX Option TypeC400 Date:			8-Aug-14	No.: RD483002	
Subject: Service manual correction (Fax Option (D483) Installation)				Prepared by: K.Kunimatsu		
From: 1st Tech S	Service Sect., MFP/P Tech Serv	ice Dept.				
Classification:	 Troubleshooting Mechanical Paper path Product Safety 	Part info Electric Transm	al	Servic	n required ce manual revision fit information	

Service Manual Revision

The description for Installation procedure on page 13 was corrected as follows.

- 19. Attach FCC decal on the [A] of the rear lower cover (NA only).
- 20. Plug in the machine and turn on the main power switch.

() Important

- After you turn the machine on, if you see a message that tells you the SRAM has been formatted due to a problem with SRAM, turn the machine off and on again to clear the message.
- 21. Enter the "User Tools" mode and set date and time.
- 22. Do SP1000-001 in the fax SP mode and enter the serial number for the fax unit. ---- SP3102-000
- 23. Enter the correct country code with SP1401-001 (NCU Country/ Area Code Setting). ----> SP1101-016
- 24. Exit the SP mode, and turn the machine off and on.