

Interface Board Type 850 (B327)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.INTERFACE BOARD (327)	2
PARTS INDEX	5

1.INTERFACE BOARD (327)



1.INTERFACE BOARD (327)

Index No.	Part No.	Description	Qty Per Assembly
1	B327 1051	Interface Board Bracket	1
2	B327 5120	NTTR Board	1
			

Index No.	Part No.	Description	Qty Per Assembly
101	0951 3006B	Polished Round Screw - M3X6	

PARTS INDEX

Part No.	Description	Page and Index No.
B327 1051	Interface Board Bracket	3- 1
B327 5120	NTTR Board	3- 2

Part No.	Description	Page and Index No
0951 3006B	Polished Round Screw - M3X6	3-101