

What You Can Do with This Product

RICOH PJ Interactive Kit Type 2

RICOH



For safe and correct use, be sure to read the Safety Information in "Read This First" before using the product.
Some illustrations in this manual might be slightly different from the product.

With this product, you can operate a computer screen projected on the screen. With RICOH PJ Interactive Software, the software that comes with this product, you can write information and perform various other operations on the screen. RICOH PJ Interactive Software incorporates a launcher, which can switch the computer screen projected on the screen, and the whiteboard, which allows you to perform writing or various other operations on the screen.

You cannot use RICOH PJ Interactive Software if computer USB adapter is not installed into the computer.

This product includes the following accessories.



Electronic Pen



Projector Adapter




Computer USB Adapter


For details about how to configure the product, see "Read This First".
For details about how to use RICOH PJ Interactive Software, see "Operating Instructions".

Sharing the Whiteboard

You can share the whiteboard with other devices connected via a network.



CWE020



CWE023


Other Things You Can Do

◆ Erase



CWE026

◆ Edit




CWE027

◆ Manipulate the Whiteboard Screen

- Enlarge and reduce the screen.
- Add, copy, and remove pages.
- Write on and edit added pages.


◆ Save/Import

- You can save the written information to a computer.
- You can import PDF files.



CWE021

Switching with the Launcher




When you start a computer, the launcher starts automatically.
You can switch the projected screen by using the launcher, depending on the function you want to use.



Using the Electronic Pen as a Pointer

Switches a computer screen projected on the screen to the desktop.
You can operate the pointer on the screen with the electronic pen.




CWE022



Writing on the Desktop Screen

Captures a screen displayed on the desktop to the whiteboard.
You can write information on the captured screen.




CWE025



Writing Memos on the Screen

Switches a computer screen projected on the screen to the whiteboard.
You can use the screen as a whiteboard.



CWE024