

Paper Feed Unit (G512)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.PAPER FEED UNIT 1 (G512)	2
2.PAPER FEED UNIT 2 (G512)	4
PARTS INDEX	7

1.PAPER FEED UNIT 1 (G512)




1.PAPER FEED UNIT 1 (G512)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G512 3112	Coil Spring - Bottom Plate	2
2	G512 3110	Pad - Bottom Plate	2
3	G512 3105	Bottom Plate	1
4	G512 3107	Right Separation Finger	1
5	G512 3109	Groung Plate - Bottom Plate	1
6	G512 3101	Tray - Paper Feed Unit	1
7	G512 3108	Spring Plate - Paper Fence	1
8	G512 3102	Paper Fence	1
9	G512 3104	Stop Lever - Bottom Plate	1
10	G512 3111	Spring - Stop Lever	1
11	G512 3103	Paper Guide Plate	1
12	G512 3106	Left Separation Finger	1

Index No.	Part No.	Description	Q'ty Per Assembly

2.PAPER FEED UNIT 2 (G512)



Index No.	Part No.	Description	Q'ty Per Assembly
1	G512 6041	PCB - OPDB	1
2	G512 3019	PCB Bracket	1
3	G512 3021	Grounding Plate - Main Unit	1
4	AW50 0012	Push Switch	1
5	G512 3011	Bushing - Paper Feed Roller	2
6	G512 3030	Paper Feed Roller	1
7	G512 3034	Torque Limiter	1
8	G512 3018	Gear 16z	1
9	G512 2575	Paper Pick-up Roller	2
10	G512 3023	Bracket - Pick-up Roller	1
11	G512 3013	Left Bracket - Pick-up Roller	1
12	G512 3010	Bushing - Paper Pick-up Roller	1
13	G512 3012	Right Bracket - Pick-up Roller	1
14	G512 3007	Clutch Hub	1
15	G512 3008	Sleeve	1
16	G512 3027	Spring - Clutch Hub	1
17	G512 3006	Clutch Hub/gear 37z	1
18	G512 3024	Grounding Plate - Roller Shafts	1
19	G512 3009	Gear Cover	1
20	G512 3015	Coupled Gear - 20z/70z	1
21	G512 3016	Coupled Gear - 27z/39z	1
22	G512 3017	Gear 50z	1
23	G512 5002	DC Solenoid	1
24	G512 3057	Ground Plate - Front	1
25	G512 3022	Motor Bracket	1
26	G512 5001	Motor - DC24V 0.33A	1
27	G512 3004	Guide Rail - Right	1
28	G512 3026	Grounding Plate - Stay	1
29	G512 3003	Guide Rail - Left	1
30	G512 3020	Front Stay	1
31	G512 3029	Rubber Foot	4
32	G512 3002	Actuator	1
33	AW02 0086	Photointerruptor	1
34	G512 3025	Plate Spring - Roller	2
35	G512 3005	Roller	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	G512 3028	Polyester Film	2
37	G512 3114	Exit Tray - Option	1
38	G512 5003	Harness - Cassette Sensor	1
39	G512 5005	Harness - Paper End Sensor	1
101	0451 3006B	Tapping Screw - M3x6	
102	0452 3008B	Tapping Screw - M3x8	
103	0453 3006B	Tapping Screw - M3x6	

PARTS INDEX

Part No.	Description	Page and Index No.
G512 2575	Paper Pick-up Roller	5- 9
G512 3002	Actuator	5- 32
G512 3003	Guide Rail - Left	5- 29
G512 3004	Guide Rail - Right	5- 27
G512 3005	Roller	5- 35
G512 3006	Clutch Hub/gear 37z	5- 17
G512 3007	Clutch Hub	5- 14
G512 3008	Sleeve	5- 15
G512 3009	Gear Cover	5- 19
G512 3010	Bushing - Paper Pick-up Roller	5- 12
G512 3011	Bushing - Paper Feed Roller	5- 5
G512 3012	Right Bracker - Pick-up Roller	5- 13
G512 3013	Left Bracket - Pick-up Roller	5- 11
G512 3015	Coupled Gear - 20z/70z	5- 20
G512 3016	Coupled Gear - 27z/39z	5- 21
G512 3017	Gear 50z	5- 22
G512 3018	Gear 16z	5- 8
G512 3019	PCB Bracket	5- 2
G512 3020	Front Stay	5- 30
G512 3021	Groung Plate - Main Unit	5- 3
G512 3022	Motor Bracket	5- 25
G512 3023	Bracket - Pick-up Roller	5- 10
G512 3024	Groung Plate - Roller Shafts	5- 18
G512 3025	Plate Spring - Roller	5- 34
G512 3026	Groung Plate - Stay	5- 28
G512 3027	Spring - Clutch Hub	5- 16
G512 3028	Polyester Film	5- 36
G512 3029	Rubber Foot	5- 31
G512 3030	Paper Feed Roller	5- 6
G512 3034	Torque Limitter	5- 7
G512 3057	Ground Plate - Front	5- 24
G512 3101	Tray - Paper Feed Unit	3- 6
G512 3102	Paper Fence	3- 8
G512 3103	Paper Guide Plate	3- 11
G512 3104	Stop Lever - Bottom Plate	3- 9

Part No.	Description	Page and Index No
G512 3105	Bottom Plate	3- 3
G512 3106	Left Separation Finger	3- 12
G512 3107	Right Separation Finger	3- 4
G512 3108	Spring Plate - Paper Fence	3- 7
G512 3109	Groung Plate - Bottom Plate	3- 5
G512 3110	Pad - Bottom Plate	3- 2
G512 3111	Spring - Stop Lever	3- 10
G512 3112	Coil Spring - Bottom Plate	3- 1
G512 3114	Exit Tray - Option	5- 37
G512 5001	Motor - DC24V 0.33A	5- 26
G512 5002	DC Solenoid	5- 23
G512 5003	Harness - Cassette Sensor	5- 38
G512 5005	Harness - Paper End Sensor	5- 39
G512 6041	PCB - OPDB	5- 1

Part No.	Description	Page and Index No.
AW02 0086	Photointerruptor	5- 33
AW50 0012	Push Switch	5- 4

Part No.	Description	Page and Index No
0451 3006B	Tapping Screw - M3x6	5-101
0452 3008B	Tapping Screw - M3x8	5-102
0453 3006B	Tapping Screw - M3x6	5-103