

Paper Feed Unit
(G567 17/26/27/57/66/67)

Paper Feed Unit (G567 17/26/27/57/66/67)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior (G567).....	2
2.Paper Cassette (G567)	4
3.Paper Feed Section (G567)	6
4.Drive And Electrical (G567)	8
5.Interface Board (G567 17/26/27)	10
6.Interface Board (G567 57/66/67)	13
7.Decals And Documents (G567)	14
Parts Index.....	1

September , 20 ' 2006

1.Exterior (G567)



1.Exterior (G567)


Index No.	Part No.	Description	Q'ty Per Assembly
1	G568 1160	Sheet - Base	2
2	B598 1286	STOPPER:LEFT (RoHs)	1
2	G568 1286	Left Stopper	1
3	G567 1272	Left Cover	1
4	B600 6161	STAND:REAR:ASS'Y (17/26/27)(RoHs)	1
4	G569 6161	Rear Stand (17/26/27)	1
5	B542 1067	STAY:UPPER:PROTECT (RoHs)	1
5	A682 1067	Upper Middle Stay	1
6	B600 6160	STAND:FRONT:ASS'Y (17/26/27)(RoHs)	1
6	G569 6160	Front Stand (17/26/27)	1
7	B598 5320	HARNESS:INTERFACE:ASS'Y (RoHs)	1
7	G568 5320	Harness - Interface	1
8	B600 1078	BRACKET:DRAWER (RoHs)	1
8	G569 1078	Drawer Bracket	1
9	G567 1280	Raer Cover	1
10	A048 2838	Nylon Rivet	1
11	G567 2563	Band - Stopper	1
12	B542 2559	STOPPER:LEVER:VERTICAL TRANSPORT (RoHs)	1
12	A682 2559	Lever Stopper	1
13	AA06 0715	Pressure Spring	1
14	AA14 0670	Un Lock Shaft	1
15	G568 2551	Lever - Vertical Transport	1
16	G567 2562	Guide - Grip Guard	1
17	A682 2553	Rear Hook - Vertical Transport Cover	1
18	G567 2560	Vertical Transport Cover	1
19	A682 2552	Front Hook - Vertical Transport	1
20	B542 2862	ROLLER:DRIVEN:ASS'Y	1
20	A232 2862	X/O	1
21	AA08 0254	Bushing - M4	2
22	AA06 3573	Compression Spring	2
23	G567 1255	Cover:Right	1
24	G568 6220	Fixing Screw	1

Index No.	Part No.	Description	Q'ty Per Assembly
25	B601 6310	BRACKET:COUPLING:PAPER BANK (RoHs)	1
25	G567 6310	Bracket:Coupling:Paper Bank	1
26	B601 6311	BRACKET:COUPLING:2 (RoHs)	1
26	G567 6311	Bracket:Coupling:2	1
27	AH01 2013	Stopper Caster - 60kgf	2
28	A507 1096	Philips Screw - M5x6	8
29	AH01 2014	Caster - 60kgf	2
30	GA00 3056	Decal - Heater Warning (17/26/27)	1
30	GA00 3056	Decal - Heater Warning (57/58/66/67/68)	1
31	B598 6560	HEAT SINK:HEATER (RoHs)	1
31	G568 6560	Heater Sink Plate (17/26/27)	1
32	A230 2525	Stopper - Heater	1
33	G568 5350	HARNESS:HEATER:ASS'Y (RoHs)	1
33	G568 5340	Heater Harness	1
34	AX40 0109	Heater - 120V 9W (17)	1
34	AX40 0110	Heater - 230V 9W (26/27)	1
35	G568 1080	Anchor Clip - 1026	2
36	B600 6168	BRACKET:STAND:REAR LEFT (RoHs)	1
36	G569 6168	Rear Left Stand Bracket	1
37	A548 6121	Screw - M4	2
38	G567 2565	Grouding Plate - Vertical Tranport	1
39	B600 6169	BRACKET:STAND:REAR RIGHT (RoHs)	1
39	G569 6169	Rear Right Stand Bracket	1
40	G313 5560	Heater - 13w 100mm NA/EU (57/58/66/67/68)	1
41	G568 6570	Decal - Hightemperature 120BC (57/58/66/67/68)	1
42	B600 6170	BRACKET:STAND (RoHs)	1
42	G569 6170	Bracket - Stand	1
43	G569 6207	Screw - Stand Long	1
44	G569 6206	Screw - Stand Short	1
45	G569 6200	Side Stand (57/58/66/67/68)	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0450 3012N	Tapping Screw -3x12	
103	0451 3006N	Tapping Screw - M3x6	
104	0805 0088	Retaining Ring - M6	
105	0450 3008N	Tapping Screw - M3x8	
106	0353 0060N	Philips Pan Head Screw - M3x6	
107	0951 4008Z	Double Sens Screw - M4X8	
108	1105 0487	Harness Clamp	

Index No.	Part No.	Description	Q'ty Per Assembly

2.Paper Cassette (G567)




2.Paper Cassette (G567)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B598 2953	PAPER TRAY:PAPER BANK:DOM:ASS'Y (RoHs)	1
1	G568 2952	Paper Tray - Paper Bank (17/26/27)	1
1	G568 2953	Paper Tray Paper Bank Ass'y (57/66/67)	1
2	B598 2790	COVER:PAPER SIZE SENSOR:PEEN (RoHs)	1
2	G568 2790	Paper Size Sensor Cover	1
3	G568 2796	Link - Paper Size Detection Plate	1
4	G568 2783	Side Fence:Front:Ass'y	1
5	GA00 3053	Decal:Paper Tray:No.2:Left (17/26/27)	1
5	GA00 3067	Decal:Paper Tray:No.2:Left (57/58/66/67/68)	1
6	A134 2976	Stopper Lever	1
7	A134 2978	Spring Plate	1
8	G568 2789	Front Paper Holder (17/26/27)	1
9	B598 2770	TRAY BOTTOM PLATE:HLTR:ASS'Y (RoHs)	1
9	G568 2770	Tray Bottom Plate:Hltr:Ass'y	1
10	AF01 3014	Bottom Plate Pad	1
11	G568 2784	End Fence	1
12	AB01 3868	Gear - 16Z	1
13	G568 2800	Flange - Paper Size Detection Plate	1
14	G568 2797	Paper Size Sensor Board	1
15	B598 2786	SIDE FENCE:REAR:ASS'Y (RoHs)	1
15	G568 2786	Side Fence:Rear:Ass'y	1
16	GA00 3054	Decal:Paper Tray:No.2:Right (17/26/27)	1
16	GA00 3068	Decal:Paper Tray:No.2:Right (57/58/66/67/68)	1
17	G568 2792	Rear Paper Holder (17/26/27)	1
18	A267 2857	Spring Plate - Side Fence	1
19	A267 2860	Rear Lever Stopper	1
20	A267 2859	Side Fence Stopper	1
21	G313 2775	Spring Plate	1
22	A232 2987	Roller - Paper Tray	1
23	G060 2774	Lift Shaft	1
24	B180 2972	LEVER:RISE:TRAY BOTTOM PLATE(RoHs)	1

Index No.	Part No.	Description	Q'ty Per Assembly
24	A204 2972	Bottom Lift Lever	1
25	G313 2783	Tension Spring - Paper Size Detect	1
26	G568 2794	Lower Shield	1
27	G313 2782	Shield	1
28	G568 2925	Shield:Side Fence:Ass'y (57/58/66/67/68)	2
29	B598 2788	CUSHION:BASE:2 (RoHs)	1
29	G313 2788	Cushion:Base:2	1
30	G313 2787	Cushion:Tray Bottom Plate	1
31	B598 2758	PAPER STOPPER:SIDE FENCE (RoHs)	1
31	G568 2758	Paper Stopper:Side Fence	1
101	0450 3008N	Tapping Screw - M3x8	
102	0450 4010N	Tapping Screw - 4x10	
103	0720 0060E	Retaining Ring - M6	
104	0314 0060N	Philips Pan Head Screw - M4x6	

3.Paper Feed Section (G567)



3.Paper Feed Section (G567)


Index No.	Part No.	Description	Q'ty Per Assembly
*	B598 2670	PAPER FEED UNIT:PAPER BANK: FLORIDA-B2:ASS'Y (17/26/27/58/68)(RoHs)	1
*	G568 2650	Paper Feed Unit (17/26/27)	1
*	B598 2660	PAPER FEED UNIT:PAPER BANK:ASS'Y (57/66/67)(RoHs)	1
*	G568 2660	Paper Feed Unit Ass'y (57/66/67)	1
1	B077 2781	BRACKET:SENSOR (RoHs)	1
1	A232 2781	Sensor Bracket	1
2	AW02 0161	PHOTOINTERRUPTOR:VERTICAL TRANSPORT (RoHs)	1
2	AW02 0131	Photo-interruptor-vertical Transp.	1
3	AA06 0691	Tension Spring	1
4	A232 2763	Pick-up Arm	1
5	AF03 0049	Pick-up Roller (17/26/27/58/68)	1
5	AF03 0085	Paper Feed Roller - Pickup (57/66/67)	1
6	AB01 1188	Gear - 21Z	1
7	AA10 0014	Retaining Ring C - Separate	2
8	AF03 1049	Feed Roller (17/26/27/58/68)	1
8	AF03 1085	Paper Feed Roller - Feed (57/66/67)	1
9	AB01 1218	Gear - ROLLER CLUTCH	1
10	G313 2765	Front Grounding Plate	1
11	G568 2857	Housing:Paper Feed Unit:Florida-b	1
12	AW02 0160	PAPER FEED SENSOR (RoHs)	2
12	AW02 0056	Photointerruptor - EE-SX4235A-P1	2
13	B598 5370	HARNESS:PAPER FEED UNIT:ASS'Y (RoHs)	1
13	G568 5370	Harness - Paper Feed Unit	1
14	AF02 0648	TRANSPORT ROLLER:DRIVE (RoHs)	1
14	AF02 0404	Transport Roller	1
15	B180 2780	STAY:FEED (RoHs)	1
15	A232 2780	Stay - Paper Feed	1
16	AA08 3014	One-way Clutch	1
	AA08 3017	X/O MB1	
17	AA14 0743	Shaft - Feed	1
18	AA08 2070	Bushing - 8x16x7	1

Index No.	Part No.	Description	Q'ty Per Assembly
19	G313 2764	Rear Grounding Plate	1
20	AA08 2072	Bushing - M6	2
21	5206 2686	Snap Ring	2
22	AB01 0107	Gear - 23Z	1
23	G065 2776	Release Lever	1
24	AA06 0693	Tension Spring	1
25	G065 2775	Link Lever	1
26	G065 2774	Pressure Lever	1
27	AA06 0908	Release Spring	1
28	AA14 0656	Shaft - Gear	1
29	AB01 0106	Gear - 24Z	1
30	B004 2782	Rear Feed Mylar	1
31	A232 2762	Paper End Feeler	1
32	B598 2689	SHAFT:SEPARATE:DRIVEN:BANK:ASS'Y (RoHs)	1
32	G568 2689	Bank Separate Driven Shaft	1
33	B180 2900	TORQUE LIMITER:40MN.M:MM18 (RoHs)	1
33	G060 2900	Torque Limiter - 40mn¥m:mm18	1
34	AF03 2049	Separation Roller (17/26/27/58/68)	1
34	AF03 2085	Paper Feed Roller - Separate (57/66/67)	1
35	B180 2725	STAY:SEPARATE:NO.2:ASS'Y(RoHs)	1
35	G060 2725	Stay - Paper Separation	1
36	B082 2785	GUIDE PLATE:SWIVEL:ADHESION	1
36	A232 2785	X/O	
36	A232 2786	X/O	
37	A232 2787	Vertical Transport Guide	1
38	A232 2766	Feed Mylar	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0805 0089	Retaining Ring - M4	
103	0805 3480	Bushing - 6mm	
104	0720 0040E	Retaining Ring - M4	
105	0720 0060E	Retaining Ring - M6	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	0450 3008N	Tapping Screw - M3x8	

Index No.	Part No.	Description	Q'ty Per Assembly

4. Drive And Electrical (G567)



4. Drive And Electrical (G567)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B598 2881	MICRO SWITCH:ON OFF DETECTOR: ASS'Y (RoHs)	1
1	A232 2881	Micro Switch - On-off Detector	1
2	AW02 0160	PAPER FEED SENSOR (RoHs)	2
2	AW02 0056	Photointerruptor - EE-SX4235A-P1	2
3	AB03 0565	Timing Pulley - 20T	1
4	G569 2724	Gear - Z24	1
5	G568 2838	Timing Pulley - 20T	1
6	G569 2819	Timing Belt - S3M 222	1
7	AB01 4038	Gear - 22Z	1
8	AX20 0279	MAGNETIC CLUTCH:PAPER FEED:28Z (RoHs)	1
8	AX20 0221	Magnetic Clutch - Paper Feed	1
9	G569 2822	Gear - Z30	1
10	G568 2836	Gear - Z28/20T	1
11	B600 2846	DRUM STAY:FEED ROLLER:UPPER (RoHs)	1
11	G569 2846	Upper Drum Stay - Feed Roller	1
12	G568 2692	Cover - Drive	1
13	AX04 0211	DC MOTOR:RISE (RoHs)	1
13	AX04 0128	DC Motor - 2.16W	1
14	G569 2829	Gear - 31Z	1
15	5215 2621	Snap Ring - M6	1
16	G569 2850	Timing Belt - S3M150	1
17	G568 2835	Gear - Z19/29T	1
18	B598 2703	STEPPER MOTOR:MM56:BANK:ASS'Y (RoHs)	1
18	G568 2702	Stepper Motor - DC4.42W	1
19	B601 5300	HARNESS:MAIN:ASS'Y (RoHs)	1
19	G567 5300	Harness - Main	1
20	B601 5310	HARNESS:PAPER SIZE SENSOR:ASS'Y (RoHs)	1
20	G567 5310	Harness - Paper Size Sensor	1
21	G567 5116	PCB:BANK1:ASS'Y (RoHs)	1
	G567 5115	X/O MB4	

Index No.	Part No.	Description	Q'ty Per Assembly
	G567 5110	X/O MB3	
22	G376 1186	BRACKET:INTERFACE BOARD (RoHs)	1
22	G567 1186	Bracket - Interface Board	1
23	AW50 0023	Push Switch	4
24	B180 2801	HOLDER:PAPER TRAY (RoHs)	1
24	G060 2801	Holder - Paper Tray	1
25	AA16 1131	Cushion - Stepper Motor	1
26	B598 2830	BRACKET:STEPPER MOTOR:PEEN (RoHs)	1
26	G568 2830	Bracket - Stepper Motor	1
27	B598 2990	SUPPORTER:PAPER TRAY:ASS'Y (RoHs)	1
27	G568 2990	Paper Tray Supporter	1
101	1105 0487	Harness Clamp	
102	1105 0192	Locking Support	
103	0451 3006N	Tapping Screw - M3x6	
104	0805 3480	Bushing - 6mm	
105	0451 3008N	Tapping Screw - M3x8	
106	0314 0080N	Philips Pan Head Screw - M4x8	

5.Interface Board (G567 17/26/27)

CAPACITOR

SYMBOL NO.	INDEX NO.
C100	136
C101	136
C102	136
C103	135
C104	141
C105	140
C106	140
C107	140
C108	140
C109	140

SYMBOL NO.	INDEX NO.
C110	140
C111	140
C112	140
C113	140
C114	140
C115	140
C116	140
C117	140
C118	139
C119	139

SYMBOL NO.	INDEX NO.
C120	139
C121	139
C122	139
C123	139
C124	139
C125	139
C126	139
C127	139
C128	138
C129	138

SYMBOL NO.	INDEX NO.
C130	137
C131	137
C132	139
C133	139
C134	139
C135	139

CONNECTOR

SYMBOL NO.	INDEX NO.
CN100	104
CN101	102
CN102	101
CN103	107
CN104	103
CN105	105
CN200	106

SYMBOL NO.	INDEX NO.
IC100	1
IC101	116
IC102	113
IC103	112
IC104	117
IC105	114
IC106	115

JP

SYMBOL NO.	INDEX NO.
JP100	131

OSC

SYMBOL NO.	INDEX NO.
OSC100	118

PC

SYMBOL NO.	INDEX NO.
PC100	111

RESISTOR

SYMBOL NO.	INDEX NO.
R100	121
R101	124
R102	124
R103	124
R104	124
R105	124
R106	124
R107	124
R108	124
R109	130

SYMBOL NO.	INDEX NO.
R110	130
R111	129
R112	129
R113	129
R114	129
----	---
R116	128
R117	127
R118	127
R119	123

SYMBOL NO.	INDEX NO.
R120	123
R121	126
R122	125
R123	125
R124	122
R125	122
R126	134
R127	132
R128	133
R129	127

RN

SYMBOL NO.	INDEX NO.
RN100	120
RN101	120
RN102	120
RN103	120
RN104	120
RN105	120
RN106	120
RN107	120
RN108	120
RN109	120

SYMBOL NO.	INDEX NO.
RN110	119
RN111	119
RN112	119

ZD

SYMBOL NO.	INDEX NO.
ZD100	110
ZD101	109

Q

SYMBOL NO.	INDEX NO.
Q100	108

5.Interface Board (G567 17/26/27)

Index No.	Part No.	Description	Q'ty Per Assembly
*	G567 5116	PCB:BANK1:ASS'Y (RoHs)	1
*	G567 5110	Interface Board	1
1	G567 5550	IC - I/O Control (RoHs)	1
1	G567 5510	IC - I/O Control	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 6299	Connector - 6P	
102	1102 6300	Connector - 7P	
103	1102 6302	Connector - 9P	
104	1102 6307	Connector - 14P	
105	1102 6308	Connector - 15P	
106	1102 6321	Connector	
107	1102 7244	Connector	
108	1400 0398	Transistor - 2SC2412K	
109	1402 1663	DIODE - ZTP12B	
109	1402 1378	Diode - PTZ12A	
110	1402 1662	DIODE:PTZ6.2B	
110	1402 1380	Diode - PTZ 6.2A	
111	1403 0520	Photocoupler - Tlp521-1	
112	1407 1596	TTLIC - SN74LS14NS	
113	1407 2187	TTLIC - SN74LS07NS	
114	1407 2231	IC - TD62308AF	
115	1407 4687	IC - TA8083F	
116	1408 0611	IC - 3771	
117	1408 1394	IC - STK672-110	
118	1503 0865	Oscillator - 9.8304MHZ	
119	1601 7751	Resistor - 4.7K Ω $\pm$ 5%	
120	1601 7752	Resistor Array - 10K Ω $\pm$ 5%	
121	1611 9222	Resistor - 2.2K Ω $\pm$ 5% 1/2W	
122	1650 4100	RESISTOR - 10 Ω $\pm$ 5% 1/10W	
122	1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	
123	1650 4102	RESISTOR - 1K Ω $\pm$ 5% 1/10W	
123	1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	
124	1650 4103	RESISTOR - 10K Ω $\pm$ 5% 1/10W	
124	1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	
125	1650 4161	RESISTOR - 160 Ω $\pm$ 5% 1/10W	
125	1630 4161	Resistor - 160 Ω $\pm$ 5% 1/16W	
126	1650 4201	RESISTOR - 200 Ω $\pm$ 5%1/10W	
126	1630 4201	Resistor - 200 Ω $\pm$ 5% 1/16W	
127	1650 4222	RESISTOR - 2.2K Ω $\pm$ 5%1/10W	
127	1630 4222	Resistor - 2.2K Ω $\pm$ 5%	

Index No.	Part No.	Description	Q'ty Per Assembly
128	1650 4392	CHIP RESISTOR - 3.9K Ω ±5% 1/10W	
128	1630 4392	Resistor - 3.9 Ω ±5% 1/16W	
129	1650 4472	RESISTOR - 4.7K Ω ±5% 1/10W	
129	1630 4472	Resistor - 4.7K Ω ±5% 1/16W	
130	1650 4562	RESISTOR - 5.6K Ω ±5% 1/10W	
130	1630 4562	Resistor - 5.6k Ω - ±5% - 1/16W	
131	1633 0000	Resistor - 0 Ω 1/10W	
132	1654 5100	RESISTOR:510 Ω :±1%:1/10W	
132	1634 5100	Resistor - 510 Ω ±1% 1/16W	
133	1654 5109	RESISTOR:51 Ω :±1%:1/10W	
133	1634 5109	Resistor - 51.0 Ω ±1% 1/16W	
133	1634 5109	Resistor - 51.0 Ω ±1% 1/16W	
134	1654 8201	RESISTOR - 8.2K Ω ±1% 1/10W	
134	1634 8201	Resistor - 8.2K Ω ±1% 1/16W	
135	1640 5100	Capacitor - 10 μ F+20% 50	
136	1640 5470	Capacitor - 47 μ F±20% 50V	
137	1660 2220	Capacitor - 22pF ±20% 35V	
138	1660 2471	Capacitor - 470pF - ±5% - 50V	
139	1660 4102	Capacitor - 1000pF ±10% 50V	
140	1660 4103	Capacitor - 10000pF - ±10% - 50V	
141	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	

Index No.	Part No.	Description	Q'ty Per Assembly

6.Interface Board (G567 57/66/67)

CAPACITOR

SYMBOL NO.	INDEX NO.
C100	121
C101	125
C102	120
C103	124
C104	141
C105	140
C106	140
C107	140
C108	140
C109	138

SYMBOL NO.	INDEX NO.
C110	140
C111	140
C112	140
C113	140
C114	140
C115	140
C116	140
C117	140
C118	139
C119	139

SYMBOL NO.	INDEX NO.
C120	139
C121	139
C122	139
C123	139
C124	139
C125	139
C126	139
C127	139
C128	138
C129	138

SYMBOL NO.	INDEX NO.
C130	137
C131	137
C132	139
C133	139
C134	139
C135	139
C136	138
C137	141
C138	141
C139	141

SYMBOL NO.	INDEX NO.
C140	141
C141	141
C142	141
C143	141
C144	141

CONNECTOR IC

SYMBOL NO.	INDEX NO.
CN100	103
CN101	101
CN102	100
CN103	106
CN104	102
CN105	104
---	---
---	---
---	---
CN200	105

SYMBOL NO.	INDEX NO.
IC100	1
IC101	115
IC102	112
IC103	111
IC104	116
IC105	113
IC106	114

JP

SYMBOL NO.	INDEX NO.
JP100	123

PC

SYMBOL NO.	INDEX NO.
PC100	110

RESISTOR

SYMBOL NO.	INDEX NO.
R100	122
R101	128
---	---
R103	128
R104	128
R105	128
R106	128
R107	128
R108	128
R109	133

SYMBOL NO.	INDEX NO.
R110	133
R111	132
R112	132
R113	132
R114	132
---	---
R116	139
R117	131
R118	131
R119	127

SYMBOL NO.	INDEX NO.
R120	127
R121	130
R122	129
R123	129
R124	126
R125	126
R126	136
R127	134
R128	135
R129	131

RN

SYMBOL NO.	INDEX NO.
RN100	119
RN101	119
RN102	119
RN103	119
RN104	119
RN105	119
RN106	119
RN107	119
RN108	119
RN109	119

SYMBOL NO.	INDEX NO.
RN110	118
RN111	118
RN112	118

OSC

SYMBOL NO.	INDEX NO.
OSC100	117

Q

SYMBOL NO.	INDEX NO.
Q100	107

ZD

SYMBOL NO.	INDEX NO.
ZD100	108
ZD101	109

6.Interface Board (G567 57/66/67)

Index No.	Part No.	Description	Q'ty Per Assembly
*	G567 5116	PCB:BANK1:ASS'Y (RoHs)	1
*	G567 5115	PCB Ass'y	1
1	G567 5550	MPU:I/O:MAJORCA:P3(RoHs)	1
1	G567 5540	MPU:I/O:MAJORCA:P3	1


Index No.	Part No.	Description	Q'ty Per Assembly
100	1102 6299	Connector - 6P	
101	1102 6300	Connector - 7P	
102	1102 6302	Connector - 9P	
103	1102 6307	Connector - 14P	
104	1102 6308	Connector - 15P	
105	1102 6321	Connector	
106	1102 7244	Connector	
107	1400 0398	Transistor - 2SC2412K	
108	1402 1662	Diode:Ptz6.2b	
109	1402 1663	Diode - ZTP12B	
110	1403 0520	Photocoupler - TLP521-1	
111	1407 1596	TTLIC - SN74LS14NS	
112	1407 2187	TTLIC - SN74LS07NS	
113	1407 2231	IC - TD62308AF	
114	1407 4687	IC - TA8083F	
115	1408 0611	IC - 3771	
116	1408 1394	IC - STK672-110	
117	1503 0865	Oscillator - 9.8304MHZ	
118	1601 7751	Resistor - 4.7K Ω $\pm$ 5%	
119	1601 7752	Resistor Array - 10K Ω $\pm$ 5%	
120	1604 2522	Capacitor - 220 μ F $\pm$ 20%	
121	1604 4659	Capacitor - 120 μ F $\pm$ 20% 50V	
122	1611 9222	Resistor - 2.2K Ω $\pm$ 5% 1/2W	
123	1633 0000	Resistor - 0 Ω 1/10W	
124	1640 5100	Capacitor - 10 μ F+20% 50	
125	1640 5470	Capacitor - 47 μ F $\pm$ 20% 50V	
126	1650 4100	Resistor - 10 Ω $\pm$ 5% 1/10W	
127	1650 4102	Resistor - 1K Ω $\pm$ 5% 1/10W	
128	1650 4103	Resistor - 10K Ω $\pm$ 5% 1/10W	
129	1650 4161	Resistor - 160 Ω $\pm$ 5% 1/10W	
130	1650 4201	Resistor - 200 Ω $\pm$ 5%1/10W	
131	1650 4222	Resistor - 2.2K Ω $\pm$ 5%1/10W	
132	1650 4472	Resistor - 4.7K Ω $\pm$ 5% 1/10W	
133	1650 4562	Resistor - 5.6K Ω $\pm$ 5% 1/10W	
134	1654 5100	Resistor:510 Ω : $\pm$ 1%:1/10w	

Index No.	Part No.	Description	Q'ty Per Assembly
135	1654 5109	Resistor:51Ω:±1%:1/10w	
136	1654 8201	Resistor - 8.2KΩ ±1% 1/10W	
137	1660 2220	Capacitor - 22pF ±20% 35V	
138	1660 2471	Capacitor - 470pF - ±5% - 50V	
139	1660 4102	Capacitor - 1000pF ±10% 50V	
140	1660 4103	Capacitor - 10000pF - ±10% - 50V	
141	1660 8104	Capacitor - 0.1μF+80-20% 25V	


Index No.	Part No.	Description	Q'ty Per Assembly

7.Decals And Documents (G567)

1




2



3



4



7.Decals And Documents (G567)

Index No.	Part No.	Description	Q'ty Per Assembly
1	GA00 3053	Decal:Paper Tray:No.2:Left (17/26/27)	1
1	GA00 3067	Decal:Paper Tray:No.2:Left (57/58/66/67/68)	1
2	GA00 3054	Decal:Paper Tray:No.2:Right (17/26/27)	1
2	GA00 3068	Decal:Paper Tray:No.2:Right (57/58/66/67/68)	1
3	GA00 3056	Decal - Heater Warning	1
4	GA00 3040	Decal - Front	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
G567 1186	Bracket - Interface Board	9 - 22
G567 1255	Cover:Right	3 - 23
G567 1272	Left Cover	3 - 3
G567 1280	Raer Cover	3 - 9
G567 2560	Vertical Transport Cover	3 - 18
G567 2562	Guide - Grip Guard	3 - 16
G567 2563	Band - Stopper	3 - 11
G567 2565	Grouding Plate - Vertical Tranport	3 - 38
G567 5110	Interface Board	11 - *
G567 5110	X/O MB3	9 - 21
G567 5115	PCB Ass'y	13 - *
G567 5115	X/O MB4	9 - 21
G567 5116	PCB:BANK1:ASS'Y (RoHs)	13 - *
G567 5116	PCB:BANK1:ASS'Y (RoHs)	11 - *
G567 5116	PCB:BANK1:ASS'Y (RoHs)	9 - 21
G567 5300	Harness - Main	9 - 19
G567 5310	Harness - Paper Size Sensor	9 - 20
G567 5510	IC - I/O Control	11 - 1
G567 5540	MPU:I/O:MAJORCA:P3	13 - 1
G567 5550	IC - I/O Control (RoHs)	11 - 1
G567 5550	MPU:I/O:MAJORCA:P3(RoHs)	13 - 1
G567 6310	Bracket:Coupling:Paper Bank	3 - 25
G567 6311	Bracket:Coupling:2	3 - 26

Part No.	Description	Page and Index No.
A048 2838	Nylon Rivet	3 - 10
A134 2976	Stopper Lever	5 - 6
A134 2978	Spring Plate	5 - 7
A204 2972	Bottom Lift Lever	5 - 24
A230 2525	Stopper - Heater	3 - 32
A232 2762	Paper End Feeler	7 - 31
A232 2763	Pick-up Arm	7 - 4
A232 2766	Feed Mylar	7 - 38
A232 2780	Stay - Paper Feed	7 - 15
A232 2781	Sensor Bracket	7 - 1
A232 2785	X/O	7 - 36
A232 2786	X/O	7 - 36
A232 2787	Vertical Transport Guide	7 - 37
A232 2862	X/O	3 - 20
A232 2881	Micro Switch - On-off Detector	9 - 1
A232 2987	Roller - Paper Tray	5 - 22
A267 2857	Spring Plate - Side Fence	5 - 18
A267 2859	Side Fence Stopper	5 - 20
A267 2860	Rear Lever Stopper	5 - 19
A507 1096	Philips Screw - M5x6	3 - 28
A548 6121	Screw - M4	3 - 37
A682 1067	Upper Middle Stay	3 - 5
A682 2552	Front Hook - Vertical Transport	3 - 19
A682 2553	Rear Hook - Vertical Transport Cover	3 - 17
A682 2559	Lever Stopper	3 - 12
B004 2782	Rear Feed Mylar	7 - 30
B077 2781	BRACKET:SENSOR (RoHs)	7 - 1
B082 2785	GUIDE PLATE:SWIVEL:ADHESION	7 - 36
B180 2725	STAY:SEPARATE:NO.2:ASS'Y(RoHs)	7 - 35
B180 2780	STAY:FEED (RoHs)	7 - 15
B180 2801	HOLDER:PAPER TRAY (RoHs)	9 - 24
B180 2900	TORQUE LIMITER:40MN.M:MM18 (RoHs)	7 - 33
B180 2972	LEVER:RISE:TRAY BOTTOM PLATE(RoHs)	5 - 24
B542 1067	STAY:UPPER:PROTECT (RoHs)	3 - 5
B542 2559	STOPPER:LEVER:VERTICAL TRANSPORT	3 - 12

Part No.	Description	Page and Index No.
B542 2862	ROLLER:DRIVEN:ASS'Y	3 - 20
B598 1286	STOPPER:LEFT (RoHs)	3 - 2
B598 2660	PAPER FEED UNIT:PAPER BANK:ASS'Y	7 - *
B598 2670	PAPER FEED UNIT:PAPER BANK:	7 - *
B598 2689	SHAFT:SEPARATE:DRIVEN:BANK:ASS'Y	7 - 32
B598 2703	STEPPER MOTOR:MM56:BANK:ASS'Y	9 - 18
B598 2758	PAPER STOPPER:SIDE FENCE (RoHs)	5 - 31
B598 2770	TRAY BOTTOM PLATE:HLTR:ASS'Y (RoHs)	5 - 9
B598 2786	SIDE FENCE:REAR:ASS'Y (RoHs)	5 - 15
B598 2788	CUSHION:BASE:2 (RoHs)	5 - 29
B598 2790	COVER:PAPER SIZE SENSOR:PEEN	5 - 2
B598 2830	BRACKET:STEPPER MOTOR:PEEN (RoHs)	9 - 26
B598 2881	MICRO SWITCH:ON OFF DETECTOR:	9 - 1
B598 2953	PAPER TRAY:PAPER BANK:DOM:ASS'Y	5 - 1
B598 2990	SUPPORTER:PAPER TRAY:ASS'Y (RoHs)	9 - 27
B598 5320	HARNESS:INTERFACE:ASS'Y (RoHs)	3 - 7
B598 5370	HARNESS:PAPER FEED UNIT:ASS'Y	7 - 13
B598 6560	HEAT SINK:HEATER (RoHs)	3 - 31
B600 1078	BRACKET:DRAWER (RoHs)	3 - 8
B600 2846	DRUM STAY:FEED ROLLER:UPPER	9 - 11
B600 6160	STAND:FRONT:ASS'Y (17/26/27)(RoHs)	3 - 6
B600 6161	STAND:REAR:ASS'Y (17/26/27)(RoHs)	3 - 4
B600 6168	BRACKET:STAND:REAR LEFT (RoHs)	3 - 36
B600 6169	BRACKET:STAND:REAR RIGHT (RoHs)	3 - 39
B600 6170	BRACKET:STAND (RoHs)	3 - 42
B601 5300	HARNESS:MAIN:ASS'Y (RoHs)	9 - 19
B601 5310	HARNESS:PAPER SIZE SENSOR:ASS'Y	9 - 20
B601 6310	BRACKET:COUPLING:PAPER BANK	3 - 25
B601 6311	BRACKET:COUPLING:2 (RoHs)	3 - 26
G060 2725	Stay - Paper Separation	7 - 35
G060 2774	Lift Shaft	5 - 23
G060 2801	Holder - Paper Tray	9 - 24
G060 2900	Torque Limiter - 40mn¥m:mm18	7 - 33
G065 2774	Pressure Lever	7 - 26
G065 2775	Link Lever	7 - 25

Part No.	Description	Page and Index No.
G065 2776	Release Lever	7 - 23
G313 2764	Rear Grounding Plate	7 - 19
G313 2765	Front Grounding Plate	7 - 10
G313 2775	Spring Plate	5 - 21
G313 2782	Shield	5 - 27
G313 2783	Tension Spring - Paper Size Detect	5 - 25
G313 2787	Cushion:Tray Bottom Plate	5 - 30
G313 2788	Cushion:Base:2	5 - 29
G313 5560	Heater - 13w 100mm NA/EU	3 - 40
G376 1186	BRACKET:INTERFACE BOARD (RoHs)	9 - 22
G568 1080	Anchor Clip - 1026	3 - 35
G568 1160	Sheet - Base	3 - 1
G568 1286	Left Stopper	3 - 2
G568 2551	Lever - Vertical Transport	3 - 15
G568 2650	Paper Feed Unit (17/26/27)	7 - *
G568 2660	Paper Feed Unit Ass'y (57/66/67)	7 - *
G568 2689	Bank Separate Driven Shaft	7 - 32
G568 2692	Cover - Drive	9 - 12
G568 2702	Stepper Motor - DC4.42W	9 - 18
G568 2758	Paper Stopper:Side Fence	5 - 31
G568 2770	Tray Bottom Plate:HLtr:Ass'y	5 - 9
G568 2783	Side Fence:Front:Ass'y	5 - 4
G568 2784	End Fence	5 - 11
G568 2786	Side Fence:Rear:Ass'y	5 - 15
G568 2789	Front Paper Holder (17/26/27)	5 - 8
G568 2790	Paper Size Sensor Cover	5 - 2
G568 2792	Rear Paper Holder (17/26/27)	0 - 17
G568 2792	Rear Paper Holder (17/26/27)	5 - 17
G568 2794	Lower Shield	5 - 26
G568 2796	Link - Paper Size Detection Plate	5 - 3
G568 2797	Paper Size Sensor Board	5 - 14
G568 2800	Flange - Paper Size Detection Plate	5 - 13
G568 2830	Bracket - Stepper Motor	9 - 26
G568 2835	Gear - Z19/29T	9 - 17
G568 2836	Gear - Z28/20T	9 - 10

Part No.	Description	Page and Index No.
G568 2838	Timing Pulley - 20T	9 - 5
G568 2857	Housing:Paper Feed Unit:Florida-b	7 - 11
G568 2925	Shield:Side Fence:Ass'y	5 - 28
G568 2952	Paper Tray - Paper Bank (17/26/27)	5 - 1
G568 2953	Paper Tray Paper Bank Ass'y (57/66/67)	5 - 1
G568 2990	Paper Tray Supporter	9 - 27
G568 5320	Harness - Interface	3 - 7
G568 5340	Heater Harness	3 - 33
G568 5350	HARNESS:HEATER:ASS'Y (RoHs)	3 - 33
G568 5370	Harness - Paper Feed Unit	7 - 13
G568 6220	Fixing Screw	3 - 24
G568 6560	Heater Sink Plate (17/26/27)	3 - 31
G568 6570	Decal - Hightemperature 120BC	3 - 41
G569 1078	Drawer Bracket	3 - 8
G569 2724	Gear - Z24	9 - 4
G569 2819	Timing Belt - S3M 222	9 - 6
G569 2822	Gear - Z30	9 - 9
G569 2829	Gear - 31Z	9 - 14
G569 2846	Upper Drum Stay - Feed Roller	9 - 11
G569 2850	Timing Belt - S3M150	9 - 16
G569 6160	Front Stand (17/26/27)	3 - 6
G569 6161	Rear Stand (17/26/27)	3 - 4
G569 6168	Rear Left Stand Bracket	3 - 36
G569 6169	Rear Right Stand Bracket	3 - 39
G569 6170	Bracket - Stand	3 - 42
G569 6200	Side Stand (57/58/66/67/68)	3 - 45
G569 6206	Screw - Stand Short	3 - 44
G569 6207	Screw - Stand Long	3 - 43

Part No.	Description	Page and Index No.
AA06 0691	Tension Spring	7 - 3
AA06 0693	Tension Spring	7 - 24
AA06 0715	Pressure Spring	3 - 13
AA06 0908	Release Spring	7 - 27
AA06 3573	Compression Spring	3 - 22
AA08 0254	Bushing - M4	3 - 21
AA08 2070	Bushing - 8x16x7	7 - 18
AA08 2072	Bushing - M6	7 - 20
AA08 3014	One-way Clutch	7 - 16
AA08 3017	X/O MB1	7 - 16
AA10 0014	Retaining Ring C - Separate	7 - 7
AA14 0656	Shaft - Gear	7 - 28
AA14 0670	Un Lock Shaft	3 - 14
AA14 0743	Shaft - Feed	7 - 17
AA16 1131	Cushion - Stepper Motor	9 - 25
AB01 0106	Gear - 24Z	7 - 29
AB01 0107	Gear - 23Z	7 - 22
AB01 1188	Gear - 21Z	7 - 6
AB01 1218	Gear - ROLLER CLUTCH	7 - 9
AB01 3868	Gear - 16Z	5 - 12
AB01 4038	Gear - 22Z	9 - 7
AB03 0565	Timing Pulley - 20T	9 - 3
AF01 3014	Bottom Plate Pad	5 - 10
AF02 0404	Transport Roller	7 - 14
AF02 0648	TRANSPORT ROLLER:DRIVE (RoHs)	7 - 14
AF03 0049	Pick-up Roller (17/26/27/58/68)	7 - 5
AF03 0085	Paper Feed Roller - Pickup (57/66/67)	7 - 5
AF03 1049	Feed Roller (17/26/27/58/68)	7 - 8
AF03 1085	Paper Feed Roller - Feed (57/66/67)	7 - 8
AF03 2049	Separation Roller (17/26/27/58/68)	7 - 34
AF03 2085	Paper Feed Roller - Separate (57/66/67)	7 - 34
AH01 2013	Stopper Caster - 60kgf	3 - 27
AH01 2014	Caster - 60kgf	3 - 29
AW02 0056	Photointerruptor - EE-SX4235A-P1	7 - 12
AW02 0056	Photointerruptor - EE-SX4235A-P1	9 - 2

Part No.	Description	Page and Index No.
AW02 0131	Photo-interruptor-vertical Transp.	7 - 2
AW02 0160	PAPER FEED SENSOR (RoHs)	7 - 12
AW02 0160	PAPER FEED SENSOR (RoHs)	9 - 2
AW02 0161	PHOTOINTERRUPTOR:VERTICAL	7 - 2
AW50 0023	Push Switch	9 - 23
AX04 0128	DC Motor - 2.16W	9 - 13
AX04 0211	DC MOTOR:RISE (RoHs)	9 - 13
AX20 0221	Magnetic Clutch - Paper Feed	9 - 8
AX20 0279	MAGNETIC CLUTCH:PAPER FEED:28Z	9 - 8
AX40 0109	Heater - 120V 9W (17)	3 - 34
AX40 0110	Heater - 230V 9W (26/27)	3 - 34
GA00 3040	Decal - Front	15 - 4
GA00 3053	Decal:Paper Tray:No.2:Left (17/26/27)	5 - 5
GA00 3053	Decal:Paper Tray:No.2:Left (17/26/27)	15 - 1
GA00 3054	Decal:Paper Tray:No.2:Right (17/26/27)	5 - 16
GA00 3054	Decal:Paper Tray:No.2:Right (17/26/27)	15 - 2
GA00 3056	Decal - Heater Warning (57/58/66/67/68)	3 - 30
GA00 3056	Decal - Heater Warning	15 - 3
GA00 3056	Decal - Heater Warning (17/26/27)	3 - 30
GA00 3067	Decal:Paper Tray:No.2:Left	5 - 5
GA00 3067	Decal:Paper Tray:No.2:Left	15 - 1
GA00 3068	Decal:Paper Tray:No.2:Right	5 - 16
GA00 3068	Decal:Paper Tray:No.2:Right	15 - 2

Part No.	Description	Page and Index No.
0314 0060N	Philips Pan Head Screw - M4x6	5 - 104
0314 0080N	Philips Pan Head Screw - M4x8	9 - 106
0353 0060N	Philips Pan Head Screw - M3x6	3 - 106
0450 3008N	Tapping Screw - M3x8	3 - 105
0450 3008N	Tapping Screw - M3x8	7 - 107
0450 3008N	Tapping Screw - M3x8	5 - 101
0450 3012N	Tapping Screw -3x12	3 - 102
0450 4010N	Tapping Screw - 4x10	5 - 102
0451 3006N	Tapping Screw - M3x6	9 - 103
0451 3006N	Tapping Screw - M3x6	3 - 103
0451 3008N	Tapping Screw - M3x8	9 - 105
0451 3008N	Tapping Screw - M3x8	7 - 101
0451 3008N	Tapping Screw - M3x8	3 - 101
0720 0040E	Retaining Ring - M4	7 - 104
0720 0060E	Retaining Ring - M6	5 - 103
0720 0060E	Retaining Ring - M6	7 - 105
0805 0088	Retaining Ring - M6	3 - 104
0805 0089	Retaining Ring - M4	7 - 102
0805 3480	Bushing - 6mm	7 - 103
0805 3480	Bushing - 6mm	9 - 104
0951 4008Z	Double Sens Screw - M4X8	3 - 107
1102 6299	Connector - 6P	13 - 100
1102 6299	Connector - 6P	11 - 101
1102 6300	Connector - 7P	11 - 102
1102 6300	Connector - 7P	13 - 101
1102 6302	Connector - 9P	11 - 103
1102 6302	Connector - 9P	13 - 102
1102 6307	Connector - 14P	11 - 104
1102 6307	Connector - 14P	13 - 103
1102 6308	Connector - 15P	11 - 105
1102 6308	Connector - 15P	13 - 104
1102 6321	Connector	11 - 106
1102 6321	Connector	13 - 105
1102 7244	Connector	13 - 106
1102 7244	Connector	11 - 107

Part No.	Description	Page and Index No.
1105 0192	Locking Support	9 - 102
1105 0487	Harness Clamp	9 - 101
1105 0487	Harness Clamp	3 - 108
1105 0511	Harness Clamp - LWS-0306ZC	7 - 106
1400 0398	Transistor - 2SC2412K	11 - 108
1400 0398	Transistor - 2SC2412K	13 - 107
1402 1378	Diode - PTZ12A	11 - 109
1402 1380	Diode - PTZ 6.2A	11 - 110
1402 1662	Diode:Ptz6.2b	13 - 108
1402 1662	DIODE:PTZ6.2B	11 - 110
1402 1663	Diode - ZTP12B	13 - 109
1402 1663	DIODE - ZTP12B	11 - 109
1403 0520	Photocoupler - Tlp521-1	11 - 111
1403 0520	Photocoupler - TLP521-1	13 - 110
1407 1596	TTLIC - SN74LS14NS	11 - 112
1407 1596	TTLIC - SN74LS14NS	13 - 111
1407 2187	TTLIC - SN74LS07NS	13 - 112
1407 2187	TTLIC - SN74LS07NS	11 - 113
1407 2231	IC - TD62308AF	13 - 113
1407 2231	IC - TD62308AF	11 - 114
1407 4687	IC - TA8083F	13 - 114
1407 4687	IC - TA8083F	11 - 115
1408 0611	IC - 3771	13 - 115
1408 0611	IC - 3771	11 - 116
1408 1394	IC - STK672-110	13 - 116
1408 1394	IC - STK672-110	11 - 117
1503 0865	Oscillator - 9.8304MHZ	13 - 117
1503 0865	Oscillator - 9.8304MHZ	11 - 118
1601 7751	Resistor - 4.7K Ω $\pm$ 5%	11 - 119
1601 7751	Resistor - 4.7K Ω $\pm$ 5%	13 - 118
1601 7752	Resistor Array - 10K Ω $\pm$ 5%	11 - 120
1601 7752	Resistor Array - 10K Ω $\pm$ 5%	13 - 119
1604 2522	Capacitor - 220 μ F $\pm$ 20%	13 - 120
1604 4659	Capacitor - 120 μ F $\pm$ 20% 50V	13 - 121
1611 9222	Resistor - 2.2K Ω $\pm$ 5% 1/2W	13 - 122

Part No.	Description	Page and Index No.
1611 9222	Resistor - 2.2K Ω $\pm$ 5% 1/2W	11 - 121
1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	11 - 122
1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	11 - 123
1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	11 - 124
1630 4161	Resistor - 160 Ω $\pm$ 5% 1/16W	11 - 125
1630 4201	Resistor - 200 Ω $\pm$ 5% 1/16W	11 - 126
1630 4222	Resistor - 2.2K Ω $\pm$ 5%	11 - 127
1630 4392	Resistor - 3.9 Ω $\pm$ 5% 1/16W	11 - 128
1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/16W	11 - 129
1630 4562	Resistor - 5.6k Ω - $\pm$ 5% - 1/16W	11 - 130
1633 0000	Resistor - 0 Ω 1/10W	13 - 123
1633 0000	Resistor - 0 Ω 1/10W	11 - 131
1634 5100	Resistor - 510 Ω $\pm$ 1% 1/16W	11 - 132
1634 5109	Resistor - 51.0 Ω $\pm$ 1% 1/16W	11 - 133
1634 8201	Resistor - 8.2K Ω $\pm$ 1% 1/16W	11 - 134
1640 5100	Capacitor - 10 μ F +20% 50	13 - 124
1640 5100	Capacitor - 10 μ F +20% 50	11 - 135
1640 5470	Capacitor - 47 μ F $\pm$ 20% 50V	11 - 136
1640 5470	Capacitor - 47 μ F $\pm$ 20% 50V	13 - 125
1650 4100	RESISTOR - 10 Ω $\pm$ 5% 1/10W	11 - 122
1650 4100	Resistor - 10 Ω $\pm$ 5% 1/10W	13 - 126
1650 4102	Resistor - 1K Ω $\pm$ 5% 1/10W	13 - 127
1650 4102	RESISTOR - 1K Ω $\pm$ 5% 1/10W	11 - 123
1650 4103	RESISTOR - 10K Ω $\pm$ 5% 1/10W	11 - 124
1650 4103	Resistor - 10K Ω $\pm$ 5% 1/10W	13 - 128
1650 4161	RESISTOR - 160 Ω $\pm$ 5% 1/10W	11 - 125
1650 4161	Resistor - 160 Ω $\pm$ 5% 1/10W	13 - 129
1650 4201	RESISTOR - 200 Ω $\pm$ 5% 1/10W	11 - 126
1650 4201	Resistor - 200 Ω $\pm$ 5% 1/10W	13 - 130
1650 4222	RESISTOR - 2.2K Ω $\pm$ 5% 1/10W	11 - 127
1650 4222	Resistor - 2.2K Ω $\pm$ 5% 1/10W	13 - 131
1650 4392	CHIP RESISTOR - 3.9K Ω $\pm$ 5% 1/10W	11 - 128
1650 4472	RESISTOR - 4.7K Ω $\pm$ 5% 1/10W	11 - 129
1650 4472	Resistor - 4.7K Ω $\pm$ 5% 1/10W	13 - 132
1650 4562	RESISTOR - 5.6K Ω $\pm$ 5% 1/10W	11 - 130

Part No.	Description	Page and Index No.
1650 4562	Resistor - 5.6K Ω $\pm$ 5% 1/10W	13 - 133
1654 5100	RESISTOR:510 Ω : $\pm$ 1%:1/10W	11 - 132
1654 5100	Resistor:510 Ω : $\pm$ 1%:1/10w	13 - 134
1654 5109	RESISTOR:51 Ω : $\pm$ 1%:1/10W	11 - 133
1654 5109	Resistor:51 Ω : $\pm$ 1%:1/10w	13 - 135
1654 8201	RESISTOR - 8.2K Ω $\pm$ 1% 1/10W	11 - 134
1654 8201	Resistor - 8.2K Ω $\pm$ 1% 1/10W	13 - 136
1660 2220	Capacitor - 22pF $\pm$ 20% 35V	11 - 137
1660 2220	Capacitor - 22pF $\pm$ 20% 35V	13 - 137
1660 2471	Capacitor - 470pF - $\pm$ 5% - 50V	13 - 138
1660 2471	Capacitor - 470pF - $\pm$ 5% - 50V	11 - 138
1660 4102	Capacitor - 1000pF $\pm$ 10% 50V	13 - 139
1660 4102	Capacitor - 1000pF $\pm$ 10% 50V	11 - 139
1660 4103	Capacitor - 10000pF - $\pm$ 10% - 50V	13 - 140
1660 4103	Capacitor - 10000pF - $\pm$ 10% - 50V	11 - 140
1660 8104	Capacitor - 0.1 μ F +80-20% 25V	13 - 141
1660 8104	Capacitor - 0.1 μ F +80-20% 25V	11 - 141

Part No.	Description	Page and Index No.
5206 2686	Snap Ring	7 - 21
5215 2621	Snap Ring - M6	9 - 15