

Printer Scanner Options

Controller Options

**Printer Scanner Options
Controller Options**

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

1. Controller Option1 (D595)	2
2. Controller Option2 (D595)	4
Parts Index	8


August 30, 2011

1.Controller Option1 (D595)


Printer/Scanner Unit Type 3352/
Printer Unit Type 3352
(D595-21/22/23/31/32/33)
Hard Disk Drive Option Type 3352 (D549-11)
Memory Unit Type L 512MB (D594-11/21)




Scanner Enhance Option Type 3352
(D595-41/42/43)



PostScript3 Unit Type 3352
(D595-51/52/53)




IPDS Unit Type 3352 (D595-71/72/73)



VM CARD Type N (D594-51/52/53)




Copy Data Security Unit Type F (B829-07)




Browser Unit Type D (D377-08/17/18)




IEEE802.11A/G Interface Unit Type J/K
(D377-01/02/19)




Bluetooth Interface Unit Type D (D566-01)




Gigabit Ethernet Board Type A (G874-01)



IEEE 1284 Interface Board Type A
(B679-17)



File Format Converter Type E (D377-04)




1.Controller Option1 (D595)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D120 5522	SD-Card:PRT/SCN:EXP:Ass'y	1
1	D595 5061	SD-Card:PRINTER:EXP:Ass'y	1
2	M052 5391	PCB:Memory:512MB	1
3	D120 1528	Keytop:Copy:NA	1
3	D120 1534	Keytop:Copy:EU	1
4	D120 1529	Keytop:Doc:NA	1
4	D120 1535	Keytop:Doc:EU	1
5	D120 1532	Keytop:Scanner:NA	1
5	D120 1538	Keytop:Scanner:EU	1
6	D120 1531	Keytop:Printer:NA	1
6	D120 1537	Keytop:Printer:EU	1
7	D120 5692	Bracket:SATIE2	1
8	D129 5710	PCB:SATIE2	1
9	AA14 3848	Stepped Screw - M3	4
10	AA16 1125	Rubber Cushion	4
11	D129 5713	Cable:HDD:SATA:135	1
12	D129 5719	Cable:HDD:SATA:Power:2P	1
13	D105 5705	HDD:160GB:MK1665GSX	1
14	D120 5691	Bracket:HDD	1
16	D595 5041	SD-Card:SCN_UPG:NA:Ass'y	1
16	D595 5042	SD-Card:SCN_UPG:EU:Ass'y	1
16	D595 5043	SD-Card:SCN_UPG:Ass'y (AA/CHN)	1
17	D595 5053	SD-Card:PS3:EXP:Ass'y	1
18	D595 5073	SD-Card:IPDS:EXP:Ass'y	1
19	D120 1533	Keytop:Function:NA	1
19	D120 1539	Keytop:Function:EU	1
20	D594 5053	SD-Card:D594-53:EXP:Ass'y	1
21	B829 5106	PCB:ICIB-3	1
22	D120 5851	Bracket:ICIB:Orval-C1	1
23	B770 5432	Harness:FFC:ICIB:Russian	1
24	B770 5435	Harness:Power Source:ICIB	1
25	B229 5739	Harness:ICIB	1
26	B229 5740	Harness:ICIB:Power Source	1
27	D377 5008	SD-Card - Browser Unit AA	1
28	D377 5603	PCB:MLB32	1

Index No.	Part No.	Description	Q'ty Per Assembly
29	D377 5521	PCB:W-LAN1S:EXT:NA:Ass'y (NA)	1
29	D377 5522	PCB:W-LAN1S:EXT:EU:Ass'y (EU)	1
29	D377 5542	PCB:W-LAN1S:G-EXT:EU:Ass'y (AA/CHN)	1
30	D377 5698	Velcro Fastener:Cover:Antenna:250	1
31	D566 5400	Module:Bluetooth:USB	1
32	B595 5670	PCB Ass'y - IEEE1284	1
33	G874 5000	PCB:GIGA+USB	1
34	B129 5008	Cap - Lan Connector	1
35	B154 5865	Cap:Connector:USB	1
101	1607 2251	Ferrite Core:K3 NF-75(N)BK0	
102	1105 0688	Clamp:KS-15	
103	1607 1092	Ferrite Core:RFC-10	
104	0451 3006N	Tapping Screw - 3x6	
105	1105 0516	Clamp	
106	0360 3006N	Screw - M3x6	

2.Controller Option2 (D595)

USB2.0/SD Slot Type H (D594-31)



2.Controller Option2 (D595)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D594 1278	Cover:Guard:SD:EXP	1
2	D594 1277	Panel:USB:EXP	1
3	D594 1281	Panel:SD:EXP	1
4	D422 1264	Lens:SD/USB	1
5	D594 1275	Case:SD/USB:EXP:Ass'y	1
6	D594 5112	Decal:SD/USB:EXP	1
7	D594 5108	Decal:SD-Card:Operate:EXP	1
7	D594 5110	Decal:SD-Card:Operate:EXP2	1
8	D422 5025	Shield Tape:CU10S:Front	1
9	D422 5701	PCB:Fusion:Ass'y	1
10	D422 1265	Shielding Plate:LED	1
11	D422 5030	Gasket:65TSV:Front	1
12	D422 5020	Discharge Brush:12F:P025:Front	1
13	D422 1267	Bracket:PCB:Ass'y	1
14	D422 5052	Spring Plate:Base	1
15	D422 1280	Bracket:SD/USB:Main:EXP	1
16	D594 5000	Cable:USB:Short:1000	1
17	D422 1284	Bracket:Cover:Left	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060N	Bind Screw - M3x6	
102	0450 3010N	Tapping Screw - M3x10	
103	0454 3006Q	Tapping Screw - M3x6	
104	0456 3008N	Tapping Screw - M3x8	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D595 5041	SD-Card:SCN_UPG:NA:Ass'y	3 - 16
D595 5042	SD-Card:SCN_UPG:EU:Ass'y	3 - 16
D595 5043	SD-Card:SCN_UPG:Ass'y (AA/CHN)	3 - 16
D595 5053	SD-Card:PS3:EXP:Ass'y	3 - 17
D595 5061	SD-Card:PRINTER:EXP:Ass'y	3 - 1
D595 5073	SD-Card:IPDS:EXP:Ass'y	3 - 18

Part No.	Description	Page and Index No.
B129 5008	Cap - Lan Connector	3 - 6
B154 5865	Cap:Connector:USB	3 - 6
B229 5739	Harness:ICIB	3 - 25
B229 5740	Harness:ICIB:Power Source	3 - 26
B595 5670	PCB Ass'y - IEEE1284	3 - 32
B770 5432	Harness:FFC:ICIB:Russian	3 - 23
B770 5435	Harness:Power Source:ICIB	3 - 24
B829 5106	PCB:ICIB-3	3 - 21
D105 5705	HDD:160GB:MK1665GSX	3 - 13
D120 1528	Keytop:Copy:NA	3 - 3
D120 1529	Keytop:Doc:NA	3 - 4
D120 1532	Keytop:Scanner:NA	3 - 5
D120 1533	Keytop:Function:NA	3 - 19
D120 1534	Keytop:Copy:EU	3 - 3
D120 1535	Keytop:Doc:EU	3 - 4
D120 1538	Keytop:Scanner:EU	3 - 5
D120 1539	Keytop:Function:EU	3 - 19
D120 5522	SD-Card:PRT/SCN:EXP:Ass'y	3 - 1
D120 5691	Bracket:HDD	3 - 14
D120 5692	Bracket:SATIE2	3 - 7
D120 5851	Bracket:ICIB:Orval-C1	3 - 22
D129 5710	PCB:SATIE2	3 - 8
D129 5713	Cable:HDD:SATA:135	3 - 11
D129 5719	Cable:HDD:SATA:Power:2P	3 - 12
D377 5008	SD-Card - Browser Unit AA	3 - 27
D377 5521	PCB:W-LAN1S:EXT:NA:Ass'y (NA)	3 - 29
D377 5522	PCB:W-LAN1S:EXT:EU:Ass'y (EU)	3 - 29
D377 5542	PCB:W-LAN1S:G-EXT:EU:Ass'y (AA/CHN)	3 - 29
D377 5603	PCB:MLB32	3 - 28
D377 5698	Velcro Fastener:Cover:Antenna:250	3 - 30
D422 1264	Lens:SD/USB	5 - 4
D422 1265	Shielding Plate:LED	5 - 10
D422 1267	Bracket:PCB:Ass'y	5 - 13
D422 1280	Bracket:SD/USB:Main:EXP	5 - 15
D422 1284	Bracket:Cover:Left	5 - 17

Part No.	Description	Page and Index No.
D422 5020	Discharge Brush:12F:P025:Front	5 - 12
D422 5025	Shield Tape:CU10S:Front	5 - 8
D422 5030	Gasket:65TSV:Front	5 - 11
D422 5052	Spring Plate:Base	5 - 14
D422 5701	PCB:Fusion:Ass'y	5 - 9
D566 5400	Module:Bluetooth:USB	3 - 31
D594 1275	Case:SD/USB:EXP:Ass'y	5 - 5
D594 1277	Panel:USB:EXP	5 - 2
D594 1278	Cover:Guard:SD:EXP	5 - 1
D594 1281	Panel:SD:EXP	5 - 3
D594 5000	Cable:USB:Short:1000	5 - 16
D594 5053	SD-Card:D594-53:EXP:Ass'y	3 - 20
D594 5108	Decal:SD-Card:Operate:EXP	5 - 7
D594 5110	Decal:SD-Card:Operate:EXP2	5 - 7
D594 5112	Decal:SD/USB:EXP	5 - 6
G874 5000	PCB:GIGA+USB	3 - 33

Part No.	Description	Page and Index No.
M052 5391	PCB:Memory:512MB	3 - 2

Part No.	Description	Page and Index No.
AA14 3848	Stepped Screw - M3	3 - 9
AA16 1125	Rubber Cushion	3 - 10

Part No.	Description	Page and Index No.
0353 0060N	Bind Screw - M3x6	5 - 101
0360 3006N	Screw - M3x6	3 - 106
0450 3010N	Tapping Screw - M3x10	5 - 102
0451 3006N	Tapping Screw - 3x6	3 - 104
0454 3006Q	Tapping Screw - M3x6	5 - 103
0456 3008N	Tapping Screw - M3x8	5 - 104
1105 0516	Clamp	3 - 105
1105 0688	Clamp:KS-15	3 - 102
1607 1092	Ferrite Core:RFC-10	3 - 103
1607 2251	Ferrite Core:K3 NF-75(N)BK0	3 - 101