

Printer/Scanner Option Type 5000
(B829/D362/D377/D381)

Printer/Scanner Option Type 5000 (B829/D362/D377/D381)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Printer/Scanner Option 1 (B829 /D381).....	2
2.Printer/Scanner Option 2 (D362/D377/D381).....	4
Parts Index	8

December 24, 2009

1.Printer/Scanner Option 1 (B829/D381)

RPCS Printer Unit Type 5000 (D381-01/02/03/06/08/09/10)
(D009/D012 only)




Scanner Enhance Option Type 5000 (D381-66/67/68)
(D009/D012 only)







IPDS Unit Type 5000 (D381-76/77/78)




Copy Data Security Unit Type F (B829)



Printer Unit (D381-21/22/23/26/28/29/30)
Printer/Scanner Unit Type 5000 (D381-41/42/43/46/48/49/50)
(D009/D012 only)



Printer Enhance Option Type 5000 (D381-62/63/66)
(D009/D012 only)




1.Printer/Scanner Option 1 (B829/D381)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D381 5010	SD-Card - RPCS	1
2	B223 1528	Keytop - Copy NA	1
2	B223 1534	Keytop:Copy:EU	1
2	B223 1531	Keytop:Printer:NA	1
2	B223 1537	Keytop:Printer:EU	1
3	D381 5066	SD-Card:SCN_UPG:AL-C1:EXP:Ass'y	1
4	B223 1532	Keytop:Scanner:NA	1
4	B223 1538	Keytop:Scanner:EU	1
5	M308 5130	HDD:80GB:MHz2080BH:FUJITSU	1
6	D362 1140	HDD Bracket	1
7	AA16 1125	Rubber Cushion	4
8	AA14 3848	Stepped Screw - M3	4
9	D362 5170	PCB - HDD	1
10	D362 5132	Harness - HDD	1
11	D362 5131	Cable - HDD Power	1
12	B223 1529	Keytop - Doc NA	1
12	B223 1535	Keytop:DOC:EU	1
13	D381 5076	SD-Card - IPDS	1
14	D381 5030	SD-Card - Printer Unit	1
15	D381 5050	SD-Card - P/S Unit	1
16	D381 5061	SD-Card - PCL Upgrade	1
17	B829 5106	PCB:ICIB-3	1
18	B229 5739	Harness:ICID	1
18	B770 5432	Harness:FFC:ICIB:Russian	1
19	B229 5740	Harness:ICID:Power Source	1
19	B770 5435	Harness:Power Source:ICIB	1


Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 3006N	Screw - M3x6	
102	0454 3006Q	Tapping Screw - M3x6	
103	0451 3006N	Tapping Screw - 3x6	
104	1105 0516	Clamp	

2.Printer/Scanner Option 2 (D362/D377/D381)


Hard Disk Drive Option Type 5000 (D362-01)
(D009/D012 only)




VM Card Type F (D377-10/11/12)
(D009/D011/D012/D013 only)




HDD Encryption Unit Type A (D377-16)




DataOverwriteSecurity Unit Type I (D362-11)




File Format Converter Type E (D377-04)




IEEE802.11g Interface Unit Type K (D377-19)




IEEE802.11a/g Interface Unit Type J (D377-01/02)



Browser Unit Type D (D377-08/17/18)



Memory Unit Type G 256MB (D362-21)
(D009/D012 only)



2.Printer/Scanner Option 2 (D362/D377/D381)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B223 1528	Keytop - Copy NA	1
1	B223 1534	Keytop:Copy:EU	1
1	B223 1529	Keytop - DOC NA	1
1	B223 1535	Keytop:DOC:EU	1
2	M308 5130	HDD:80GB:MHz2080BH:FUJITSU	1
3	D362 1140	HDD Bracket	1
4	AA16 1125	Rubber Cushion	4
5	AA14 3848	Stepped Screw - M3	4
6	D362 5170	PCB - HDD	1
7	D362 5132	Harness - HDD	1
8	D362 5131	Cable - HDD Power	1
9	D362 0581	SD-Card:Data Overwrite:Service	1
10	D377 5701	Wireless LAN Board - NA	1
10	D377 5702	Wireless LAN Board - EU/AA	1
11	G690 8639	Installation Procedure	1
12	D377 5698	Velcro Fastener:Cover:Antenna:250	2
14	B585 5130	PCB:DDR1-DIMM-32B:256MB:Ass'y	1
15	D377 5603	PCB:MLB32	1
16	B223 1533	Keytop:Function:NA	1
16	B223 1539	Keytop:Function:EU	1
17	D377 5008	SD-Card - Browser Unit AA	1
18	D377 5010	SD-Card - VM	1
19	D377 5016	SD-Card - HDD Encryption Unit	1
20	D377 5719	Wireless LAN Board - G	1
21	B585 5130	PCB:DDR1-DIMM-32B:256MB:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 3006N	Screw - M3x6	
102	0454 3006Q	Tapping Screw - M3x6	
103	1105 0688	Clamp:KS-15	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B829 5106	PCB:ICIB-3	3 - 17
D362 0581	SD-Card:Data Overwrite:Service	5 - 9
D362 1140	HDD Bracket	3 - 6
D362 1140	HDD Bracket	5 - 3
D362 5131	Cable - HDD Power	3 - 11
D362 5131	Cable - HDD Power	5 - 8
D362 5132	Harness - HDD	3 - 10
D362 5132	Harness - HDD	5 - 7
D362 5170	PCB - HDD	3 - 9
D362 5170	PCB - HDD	5 - 6
D377 5008	SD-Card - Browser Unit AA	5 - 17
D377 5010	SD-Card - VM	5 - 18
D377 5016	SD-Card - HDD Encryption Unit	5 - 19
D377 5603	PCB:MLB32	5 - 15
D377 5698	Velcro Fastener:Cover:Antenna:250	5 - 12
D377 5701	Wireless LAN Board - NA	5 - 10
D377 5702	Wireless LAN Board - EU/AA	5 - 10
D377 5719	Wireless LAN Board - G	5 - 20
D381 5010	SD-Card - RPCS	3 - 1
D381 5030	SD-Card - Printer Unit	3 - 14
D381 5050	SD-Card - P/S Unit	3 - 15
D381 5061	SD-Card - PCL Upgrade	3 - 16
D381 5066	SD-Card:SCN_UPG:AL-C1:EXP:Ass'y	3 - 3
D381 5076	SD-Card - IPDS	3 - 13

Part No.	Description	Page and Index No.
B223 1528	Keytop - Copy NA	3 - 2
B223 1528	Keytop - Copy NA	5 - 1
B223 1529	Keytop - Doc NA	3 - 12
B223 1529	Keytop - DOC NA	5 - 1
B223 1531	Keytop:Printer:NA	3 - 2
B223 1532	Keytop:Scanner:NA	3 - 4
B223 1533	Keytop:Function:NA	5 - 16
B223 1534	Keytop:Copy:EU	3 - 2
B223 1534	Keytop:Copy:EU	5 - 1
B223 1535	Keytop:DOC:EU	5 - 1
B223 1535	Keytop:DOC:EU	3 - 12
B223 1537	Keytop:Printer:EU	3 - 2
B223 1538	Keytop:Scanner:EU	3 - 4
B223 1539	Keytop:Function:EU	5 - 16
B229 5739	Harness:ICID	3 - 18
B229 5740	Harness:ICID:Power Source	3 - 19
B585 5130	PCB:DDR1-DIMM-32B:256MB:Ass'y	5 - 14
B585 5130	PCB:DDR1-DIMM-32B:256MB:Ass'y	5 - 21
B770 5432	Harness:FFC:ICIB:Russian	3 - 18
B770 5435	Harness:Power Source:ICIB	3 - 19
G690 8639	Installation Procedure	5 - 11

Part No.	Description	Page and Index No.
M308 5130	HDD:80GB:MHZ2080BH:FUJITSU	3 - 5
M308 5130	HDD:80GB:MHZ2080BH:FUJITSU	5 - 2

Part No.	Description	Page and Index No.
AA14 3848	Stepped Screw - M3	3 - 8
AA14 3848	Stepped Screw - M3	5 - 5
AA16 1125	Rubber Cushion	3 - 7
AA16 1125	Rubber Cushion	5 - 4

Part No.	Description	Page and Index No.
0360 3006N	Screw - M3x6	3 - 101
0360 3006N	Screw - M3x6	5 - 101
0451 3006N	Tapping Screw - 3x6	3 - 103
0454 3006Q	Tapping Screw - M3x6	3 - 102
0454 3006Q	Tapping Screw - M3x6	5 - 102
1105 0516	Clamp	3 - 104
1105 0688	Clamp:KS-15	5 - 103

Part No.	Description	Page and Index No.