

PS410 (A860)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.EXTERIOR (A860)	2
2.PAPER TRAY (A860)	4
3.PAPER FEED/TRANSFER (A860).....	6
4.ELECTRICAL SECTION 1 (A860).....	8
5.ELECTRICAL SECTION 2 (A860).....	10
6.ELECTRICAL SECTION 3 (A860).....	12
7.DECAL AND DOCUMENT (A860)	16
PARTS INDEX.....	17

1.EXTERIOR (A860)




1.EXTERIOR (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A860 1290	Cover - Front Lower	1
2	A860 1110	Stay - Upper Front	1
3	A860 1208	Cover - Front Upper	1
4	A860 1250	Left Cover	1
5	A860 6300	Tray Heater	1
6	A860 1195	Film - Guard	2
7	A860 1197	Film - Guard	1
8	A860 1120	Stay - Front Rear	2
9	A267 2589	Seal - Supporter	2
10	A860 1114	Shoe - Upper Rear	1
11	H519 4547	Grounding Plate	2
12	A860 1170	Harness Protector	1
13	A860 1117	Bracket - Upper Right Rear Stay	1
14	A860 6140	Bracket - Joint	2
15	A860 1270	Rear Cover	1
16	AH01 2026	Caster	2
17	A507 1096	Philips Screw - M5x6	16
18	AH01 2025	Stopper Caster	2
19	A860 1260	Right Cover	1
20	A860 2600	Cover - Vertical Transport	1
21	A860 2610	Cover - Vertical Transport	1
22	A860 2620	Guide Plate - Entrance	1
23	AA08 0249	Bushing - Vertical Transport	2
24	AG07 0014	Magnet Catch	2
25	AA06 3334	Spring - Vertical Transport	2
26	AF02 2118	Pull Out Roller - Option Tray	1
27	A860 2626	Spring Plate - Grounding	1
28	A860 2625	Vertical Transfer Guide Plate	1
29	AA14 3508	Flat Knob Screw - M4x10	10
30	A860 6260	Bracket Stand - LF/RR	2
31	A860 6280	Stand Paper Bank	4
32	A860 6270	Bracket Stand - RF/LR	2
33	A193 1759	Stepped Screw	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 3008H	Tapping Screw - 3x8	
103	0453 3008B	Bind Tapping Screw - M3x8	
104	0594 0080Z	Bolt - M4x8	
105	0314 0050B	Philips Pan Head Screw - M4x5	

2.PAPER TRAY (A860)




2.PAPER TRAY (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A860 7341	Paper Tray Assembly	2
2	A267 2850	Paper Tray	1
3	A267 2851	Front Side Fence	1
4	A267 2858	Front Stopper Lever	1
5	G697 2677	Spring Plate - Side Fence	1
6	A267 2874	Base Slider	1
7	A267 2853	End Fence	1
8	A267 2866	Upper Slider	1
9	A267 2861	Tray Bottom Plate - Ass'y	1
10	G029 2608	Base Pad	1
11	A267 2869	Gear - 16Z	1
12	A232 2987	Roller - Paper Tray	2
13	A267 2878	Spring Plate - Grounding	1
14	A267 2860	Rear Lever Stopper	1
15	A267 2859	Side Fence Stopper	1
16	A267 2857	Spring Plate - Side Fence	1
17	A267 2852	Rear Side Fence	1
18	A267 2856	Bracket - Rising	1
19	A267 2865	Shaft - Roller	1
20	A267 2864	Roller - Bracket	1
21	A267 2854	Shaft - Tray Raising	1
22	A860 2831	Friction Pad	1
23	A267 2834	Compression Spring:friction Pad	1
24	A267 2868	Spring Plate	1
25	A267 7343	Paper Size Sensor Board	1
26	A267 2892	Decal Paper Set Direction	1
27	A267 2897	Shield Side Fence	2
28	A267 2898	Sheet Holder - Paper Tray	1
29	A267 2884	Front Side Fence - Ass'y	1
30	A267 2885	Rear Side Fence - Ass'y	1
31	A267 2900	Seal - End Fence	1
32	A267 2899	Sponge - Paper Feed Tray	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 4008B	Tapping Screw - 4x8	
102	0360 4006B	Hexagonal Head Screw - M4x6	
103	0720 0030E	Retaining Ring - M3	
104	0720 0060E	Retaining Ring - M6	
105	0805 0083	Retaining Ring - M4	

3.PAPER FEED/TRANSFER (A860)




3.PAPER FEED/TRANSFER (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G020 2620	Push Switch - Paper Size	2
2	A267 2751	Paper Feed Roller	1
3	5053 0447	Bushing - 6mm	3
4	A860 2559	Cushion Guide Plate	1
5	AA14 0713	Shaft - Paper Feed Roller	1
6	A267 2803	Feeler - Paper End Sensor	1
7	A267 2805	Bracker - Paper End Sensor	1
8	AW02 0075	Photointerruptor	1
9	A860 2555	Guide Plate-paper Feed Roller Ass'y	1
10	A860 2560	Roller - Guide	1
11	A860 2641	Guide Plate - Vertical Transport	1
12	AA14 0714	Shaft - Paper Feed Roller 2	1
13	A267 2660	Bracket - Photointerruptor	1
14	AW02 0111	Photointerruptor	1
15	G020 5626	Push Switch	1
16	A267 2588	Shoe - Right Rail	2
17	A860 1090	Right Rail	2
18	A267 2842	Guide Plate - Pressure Release	2
19	AA08 0252	Bushing - M4	1
20	AF02 0476	Vertical Transport Roller	1
21	5447 2681	Snap Ring	1
22	A860 2558	Torsion Spring Lever	1
23	A267 2786	Grip Shaft Lock	1
24	A267 2787	Tension Spring - Shaft Lock	1
25	A267 2847	Bushing - Motor Shaft	2
26	A267 2785	Shaft:lock:paper Feed Roller	1
27	A860 2910	Inner Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5276	Tapping Screw With Waser - M3x6	
102	0805 0092	Retaining Ring - 3M	
103	1105 0267	Harness Clamp - YMC-10-0	
104	0451 3006B	Tapping Screw - M3x6	
105	0720 0040E	Retaining Ring - M4	
106	0314 0140B	Philips Pan Head Screw - M4x14	
107	0720 0060E	Retaining Ring - M6	
108	1105 0328	Harness Clamp - ES-0505	
109	1105 0283	Clamp	

4.ELECTRICAL SECTION 1 (A860)




4.ELECTRICAL SECTION 1 (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA13 2207	Spacer - M7	4
2	A267 2771	Tension Spring - Main	2
3	A860 2709	Lever Lift Motor-paper Bank Ass'y	1
4	A267 2847	Bushing - Motor Shaft	2
5	A860 2728	Stopper - Spring Holder	2
6	A267 2846	Holder - Spring	2
7	A267 2844	Compression Spring - Return	2
8	A267 2845	Bushing - DC Motor Shaft	2
9	A267 2840	Shaft - DC Motor	2
10	A860 2726	Bracket - DC Motor	2
11	AX04 0119	DC Motor - 1.92W	2
12	A267 2908	Bracket - Paper Tray Holder	2
13	G697 1082	Tray Holder	2
14	AW02 0075	Photointerruptor	2
15	A860 2720	Bracket - DC Motor	1
16	A860 2715	Shutter:photointerruptor:2	1
17	A267 2823	Lever - DC Motor	1
18	A860 1161	Bracket - Interface Board	1
19	A860 5320	DC Harness - Paper Size Sensor	1
20	A860 5310	DC Main Harness	1
21	A860 5350	DC Harness - Motor	1
22	A860 5330	DC Harness - Interface	1
23	A860 5110	Interface Board	1
24	A860 2714	Shutter:photointerruptor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060B	Retaining Ring - M6	
102	0450 4020B	Tapping Screw - 4x20	
103	0801 0150	Philips Screw - M4x8	
104	0451 3006B	Tapping Screw - M3x6	
105	1105 0310	Harness Clamp - LWS-1S	
106	1105 0290	Harness Clamp - HORIZONTAL	
107	1105 0267	Harness Clamp - YMC-10-0	

5.ELECTRICAL SECTION 2 (A860)




5.ELECTRICAL SECTION 2 (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A860 2821	Tensioner	1
2	AA06 0821	Tension Spring - Drive	1
3	AB03 0564	Pulley - M17	1
4	A267 2765	Stopper - Pressure Lever	2
5	A267 2766	Tension Spring - Stopper	2
6	A267 2770	Vibrating Plate	2
7	AB01 7506	Gear - 59Z/33Z	1
8	AA08 2070	Bushing - 8x16x7	4
9	A267 2815	Bracket Rise-1 Ass'y	2
10	A267 2759	Lever - Paper Volume Sensor	2
11	A267 2767	Torsion Spring - Joint	2
12	A267 2773	Bracket - Rising 2	2
13	AW02 0075	Photointerruptor	4
14	AA13 2207	Spacer - M7	2
15	A267 2772	Tension Spring - Sub	2
16	A267 2794	Pressure Lever - Sub	2
17	A267 2781	Bracket - Pressure Lever	2
18	5215 2621	Snap Ring - M6	2
19	AB03 0636	Timing Pulley - Drive	1
20	AA13 2205	Spacer - Timing Belt	1
21	AX06 0184	DC Motor - 11.3W	1
22	A860 2810	Bracket - DC Motor	1
23	A267 2761	Joint - Shaft	2
24	A267 2762	Shaft	2
25	A860 1190	Guard:spring:paper Bank	2
26	A860 1196	Film - Guard	2
27	A860 1197	Film - Guard	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0720 0040E	Retaining Ring - M4	
103	0451 3006B	Tapping Screw - M3x6	
104	0801 0150	Philips Screw - M4x8	
105	1105 0267	Harness Clamp - YMC-10-0	
106	1105 0462	Harness Clamp	
107	0720 0060B	Retaining Ring - M6	
108	0623 0140E	Spring Pin - 3x14mm	
109	0451 3008B	Tapping Screw - M3x8	

6.ELECTRICAL SECTION 3 (A860)




6.ELECTRICAL SECTION 3 (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5215 2621	Snap Ring - M6	3
2	AB01 1410	Gear - 44Z	1
3	AB03 0637	Timing Pulley - 24T/25Z	2
4	AA04 3530	Timing Belt	1
5	AA13 2205	Spacer - Timing Belt	3
6	AB01 7507	Gear - 30Z/24Z	2
7	A860 2830	Stopper - M6	2
8	AB01 1409	Gear - 23Z	4
9	AX20 0167	Electromagnetic Clutch - 38Z	1
10	AX20 0170	Electromagnetic Clutch - 39Z	2
11	A860 2840	Paper Feed Stay	1
12	5053 0447	Bushing - 6mm	1
13	AA06 0799	Tension Spring	1
14	AB03 0627	Timing Pulley - 18T	1
15	A267 2602	Tensioner	1
16	A267 2596	Right Drive Guard	1
17	AB03 0635	Timing Pulley - Paper Feed	1
18	A860 2860	Drive Stay	1
19	A860 2850	Paper Feed Stay 2	1
20	AA04 3529	Timing Belt - Drive	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	1105 0310	Harness Clamp - LWS-1S	
103	1105 0267	Harness Clamp - YMC-10-0	
104	0451 3006B	Tapping Screw - M3x6	
105	0951 3006B	Philips Screw With Flat Washer - M3x6	

7.DECAL AND DOCUMENT (A860)

1



7.DECAL AND DOCUMENT (A860)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A267 2892	Decal Paper Set Direction	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No
PAPER TRAY (A860)	A860 2831	Friction Pad	Friction Pad	1	5- 22
PAPER FEED/TRANSFER (A860)	A267 2751	Paper Feed Roller	Paper Feed Roller	1	7- 2

Parts Index

Part No.	Description	Page and Index No.
A860 1090	Right Rail	7- 17
A860 1110	Stay - Upper Front	3- 2
A860 1114	Shoe - Upper Rear	3- 10
A860 1117	Bracket - Upper Right Rear Stay	3- 13
A860 1120	Stay - Front Rear	3- 8
A860 1161	Bracket - Interface Board	9- 18
A860 1170	Harness Protector	3- 12
A860 1190	Guard:spring:paper Bank	11- 25
A860 1195	Film - Guard	3- 6
A860 1196	Film - Guard	11- 26
A860 1197	Film - Guard	11- 27
A860 1197	Film - Guard	3- 7
A860 1208	Cover - Front Upper	3- 3
A860 1250	Left Cover	3- 4
A860 1260	Right Cover	3- 19
A860 1270	Rear Cover	3- 15
A860 1290	Cover - Front Lower	3- 1
A860 2555	Guide Plate-paper Feed Roller Ass'y	7- 9
A860 2558	Torsion Spring Lever	7- 22
A860 2559	Cushion Guide Plate	7- 4
A860 2560	Roller - Guide	7- 10
A860 2600	Cover - Vertical Transport	3- 20
A860 2610	Cover - Vertical Transport	3- 21
A860 2620	Guide Plate - Entrance	3- 22
A860 2625	Vertical Transfer Guide Plate	3- 28
A860 2626	Spring Plate - Grounding	3- 27
A860 2641	Guide Plate - Vertical Transport	7- 11
A860 2709	Lever Lift Motor-paper Bank Ass'y	9- 3
A860 2714	Shutter:photointerruptor	9- 24
A860 2715	Shutter:photointerruptor:2	9- 16
A860 2720	Bracket - DC Motor	9- 15
A860 2726	Bracket - DC Motor	9- 10
A860 2728	Stopper - Spring Holder	9- 5
A860 2810	Bracket - DC Motor	11- 22
A860 2821	Tensioner	11- 1

Part No.	Description	Page and Index No
A860 2830	Stopper - M6	13- 7
A860 2831	Friction Pad	5- 22
A860 2840	Paper Feed Stay	13- 11
A860 2850	Paper Feed Stay 2	13- 19
A860 2860	Drive Stay	13- 18
A860 2910	Inner Cover	7- 27
A860 5110	Interface Board	9- 23
A860 5310	DC Main Harness	9- 20
A860 5320	DC Harness - Paper Size Sensor	9- 19
A860 5330	DC Harness - Interface	9- 22
A860 5350	DC Harness - Motor	9- 21
A860 6140	Bracket - Joint	3- 14
A860 6260	Bracket Stand - LF/RR	3- 30
A860 6270	Bracket Stand - RF/LR	3- 32
A860 6280	Stand Paper Bank	3- 31
A860 6300	Tray Heater	3- 5
A860 7341	Paper Tray Assembly	5- 1

Part No.	Description	Page and Index No.
AA04 3529	Timing Belt - Drive	13- 20
AA04 3530	Timing Belt	13- 4
AA06 0799	Tension Spring	13- 13
AA06 0821	Tension Spring - Drive	11- 2
AA06 3334	Spring - Vertical Transport	3- 25
AA08 0249	Bushing - Vertical Transport	3- 23
AA08 0252	Bushing - M4	7- 19
AA08 2070	Bushing - 8x16x7	11- 8
AA13 2205	Spacer - Timing Belt	11- 20
AA13 2205	Spacer - Timing Belt	13- 5
AA13 2207	Spacer - M7	11- 14
AA13 2207	Spacer - M7	9- 1
AA14 0713	Shaft - Paper Feed Roller	7- 5
AA14 0714	Shaft - Paper Feed Roller 2	7- 12
AA14 3508	Flat Knob Screw - M4x10	3- 29
AB01 1409	Gear - 23Z	13- 8
AB01 1410	Gear - 44Z	13- 2
AB01 7506	Gear - 59Z/33Z	11- 7
AB01 7507	Gear - 30Z/24Z	13- 6
AB03 0564	Pulley - M17	11- 3
AB03 0627	Timing Pulley - 18T	13- 14
AB03 0635	Timing Pulley - Paper Feed	13- 17
AB03 0636	Timing Pulley - Drive	11- 19
AB03 0637	Timing Pulley - 24T/25Z	13- 3
AF02 0476	Vertical Transport Roller	7- 20
AF02 2118	Pull Out Roller - Option Tray	3- 26
AG07 0014	Magnet Catch	3- 24
AH01 2025	Stopper Caster	3- 18
AH01 2026	Caster	3- 16
AW02 0075	Photointerruptor	9- 14
AW02 0075	Photointerruptor	11- 13
AW02 0075	Photointerruptor	7- 8
AW02 0111	Photointerruptor	7- 14
AX04 0119	DC Motor - 1.92W	9- 11
AX06 0184	DC Motor - 11.3W	11- 21

Part No.	Description	Page and Index No
AX20 0167	Electromagnetic Clutch - 38Z	13- 9
AX20 0170	Electromagnetic Clutch - 39Z	13- 10
G020 2620	Push Switch - Paper Size	7- 1
G020 5626	Push Switch	7- 15
G029 2608	Base Pad	5- 10
G697 1082	Tray Holder	9- 13
G697 2677	Spring Plate - Side Fence	5- 5
H519 4547	Grounding Plate	3- 11

Part No.	Description	Page and Index No.
A193 1759	Stepped Screw	3- 33
A232 2987	Roller - Paper Tray	5- 12
A267 2588	Shoe - Right Rail	7- 16
A267 2589	Seal - Supporter	3- 9
A267 2596	Right Drive Guard	13- 16
A267 2602	Tensioner	13- 15
A267 2660	Bracket - Photointerruptor	7- 13
A267 2751	Paper Feed Roller	7- 2
A267 2759	Lever - Paper Volume Sensor	11- 10
A267 2761	Joint - Shaft	11- 23
A267 2762	Shaft	11- 24
A267 2765	Stopper - Pressure Lever	11- 4
A267 2766	Tension Spring - Stopper	11- 5
A267 2767	Torsion Spring - Joint	11- 11
A267 2770	Vibrating Plate	11- 6
A267 2771	Tension Spring - Main	9- 2
A267 2772	Tension Spring - Sub	11- 15
A267 2773	Bracket - Rising 2	11- 12
A267 2781	Bracket - Pressure Lever	11- 17
A267 2785	Shaft:lock:paper Feed Roller	7- 26
A267 2786	Grip Shaft Lock	7- 23
A267 2787	Tension Spring - Shaft Lock	7- 24
A267 2794	Pressure Lever - Sub	11- 16
A267 2803	Feeler - Paper End Sensor	7- 6
A267 2805	Bracker - Paper End Sensor	7- 7
A267 2815	Bracket Rise-1 Ass'y	11- 9
A267 2823	Lever - DC Motor	9- 17
A267 2834	Compression Spring:friction Pad	5- 23
A267 2840	Shaft - DC Motor	9- 9
A267 2842	Guide Plate - Pressure Release	7- 18
A267 2844	Compression Spring - Return	9- 7
A267 2845	Bushing - DC Motor Shaft	9- 8
A267 2846	Holder - Spring	9- 6
A267 2847	Bushing - Motor Shaft	7- 25
A267 2847	Bushing - Motor Shaft	9- 4

Part No.	Description	Page and Index No
A267 2850	Paper Tray	5- 2
A267 2851	Front Side Fence	5- 3
A267 2852	Rear Side Fence	5- 17
A267 2853	End Fence	5- 7
A267 2854	Shaft - Tray Raising	5- 21
A267 2856	Bracket - Rising	5- 18
A267 2857	Spring Plate - Side Fence	5- 16
A267 2858	Front Stopper Lever	5- 4
A267 2859	Side Fence Stopper	5- 15
A267 2860	Rear Lever Stopper	5- 14
A267 2861	Tray Bottom Plate - Ass'y	5- 9
A267 2864	Roller - Bracket	5- 20
A267 2865	Shaft - Roller	5- 19
A267 2866	Upper Slider	5- 8
A267 2868	Spring Plate	5- 24
A267 2869	Gear - 16Z	5- 11
A267 2874	Base Slider	5- 6
A267 2878	Spring Plate - Grounding	5- 13
A267 2884	Front Side Fence - Ass'y	5- 29
A267 2885	Rear Side Fence - Ass'y	5- 30
A267 2892	Decal Paper Set Direction	5- 26
A267 2892	Decal Paper Set Direction	15- 1
A267 2897	Shield Side Fence	5- 27
A267 2898	Sheet Holder - Paper Tray	5- 28
A267 2899	Sponge - Paper Feed Tray	5- 32
A267 2900	Seal - End Fence	5- 31
A267 2908	Bracket - Paper Tray Holder	9- 12
A267 7343	Paper Size Sensor Board	5- 25
A507 1096	Philips Screw - M5x6	3- 17

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	7- 3
5053 0447	Bushing - 6mm	13- 12
5215 2621	Snap Ring - M6	11- 18
5215 2621	Snap Ring - M6	13- 1
5447 2681	Snap Ring	7- 21

Part No.	Description	Page and Index No
0314 0050B	Philips Pan Head Screw - M4x5	3-105
0314 0140B	Philips Pan Head Screw - M4x14	7-106
0360 4006B	Hexagonal Head Screw - M4x6	5-102
0450 4008B	Tapping Screw - 4x8	5-101
0450 4020B	Tapping Screw - 4x20	9-102
0451 3006B	Tapping Screw - M3x6	9-104
0451 3006B	Tapping Screw - M3x6	7-104
0451 3006B	Tapping Screw - M3x6	11-103
0451 3006B	Tapping Screw - M3x6	3-101
0451 3006B	Tapping Screw - M3x6	13-104
0451 3008B	Tapping Screw - M3x8	11-109
0451 3008H	Tapping Screw - 3x8	3-102
0453 3008B	Bind Tapping Screw - M3x8	3-103
0594 0080Z	Bolt - M4x8	3-104
0623 0140E	Spring Pin - 3x14mm	11-108
0720 0030E	Retaining Ring - M3	5-103
0720 0040E	Retaining Ring - M4	7-105
0720 0040E	Retaining Ring - M4	11-102
0720 0060B	Retaining Ring - M6	11-107
0720 0060B	Retaining Ring - M6	9-101
0720 0060E	Retaining Ring - M6	5-104
0720 0060E	Retaining Ring - M6	13-101
0720 0060E	Retaining Ring - M6	11-101
0720 0060E	Retaining Ring - M6	7-107
0801 0150	Philips Screw - M4x8	11-104
0801 0150	Philips Screw - M4x8	9-103
0802 5276	Tapping Screw With Waser - M3x6	7-101
0805 0083	Retaining Ring - M4	5-105
0805 0092	Retaining Ring - 3M	7-102
0951 3006B	Philips Screw With Flat Washer - M3x6	13-105
1105 0267	Harness Clamp - YMC-10-0	11-105
1105 0267	Harness Clamp - YMC-10-0	7-103
1105 0267	Harness Clamp - YMC-10-0	9-107
1105 0267	Harness Clamp - YMC-10-0	13-103
1105 0283	Clamp	7-109

Part No.	Description	Page and Index No.
1105 0290	Harness Clamp - HORIZONTAL	9-106
1105 0310	Harness Clamp - LWS-1S	9-105
1105 0310	Harness Clamp - LWS-1S	13-102
1105 0328	Harness Clamp - ES-0505	7-108
1105 0462	Harness Clamp	11-106

Part No.	Description	Page and Index No