

**PT200 (A629)**

## PARTS CATALOG


### INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

### INDEX to PARTS CATALOG

|                          |          |
|--------------------------|----------|
| 1.1 Bin Tray (A629)..... | 2        |
| <b>Parts Index.....</b>  | <b>5</b> |

## 1. 1 Bin Tray (A629)



## 1. 1 Bin Tray (A629)

| Index No. | Part No.  | Description                      | Q'ty Per Assembly |
|-----------|-----------|----------------------------------|-------------------|
| 1         | A629 1511 | Left Cover                       | 1                 |
| 2         | AA06 3312 | Exit Roller Spring               | 2                 |
| 3         | AA08 0220 | Bushing - 6mm                    | 4                 |
| 4         | AF02 2090 | Driven Roller                    | 2                 |
| 5         | A629 2211 | Frame - Paper Feed               | 1                 |
| 6         | A629 5200 | Safety Switch Harness            | 1                 |
| 7         | A629 2231 | Grounding Plate                  | 1                 |
| 8         | AB03 0395 | Idle Pulley                      | 1                 |
| 9         | A629 2171 | Belt Tightener                   | 1                 |
| 10        | AA06 0668 | Tension Spring                   | 1                 |
| 11        | A629 2161 | Bracket - Bin Unit               | 1                 |
| 12        | AX04 0093 | Bin Unit Motor DC2.6W            | 1                 |
| 13        | A629 5100 | Tray Board                       | 1                 |
| 14        | A629 5210 | Interface Harness                | 1                 |
| 15        | A629 2131 | Torque Limiter - Paper Exit      | 1                 |
| 16        | AA04 3257 | Timing Belt - 164                | 1                 |
| 17        | A629 2141 | Torque Limiter - Paper Transport | 1                 |
| 18        | A629 1541 | Exhaust Cover                    | 1                 |
| 19        | A629 1521 | Rear Cover                       | 1                 |
| 20        | A629 1531 | Connector Cover                  | 1                 |
| 21        | A629 2115 | Junction Gate Solenoid           | 1                 |
| 22        | A629 2121 | Junction Gate Lever              | 1                 |
| 23        | A629 2111 | Bracket - Junction Gate Solenoid | 1                 |
| 24        | A629 2261 | Harness Cover - Paper Indicator  | 1                 |
| 25        | AA12 0027 | Antistatic Brush                 | 1                 |
| 26        | AW01 0070 | Photoresistor - PS-R11D1-B       | 1                 |
| 27        | AF02 0378 | Exit Roller                      | 1                 |
| 28        | AF02 0379 | Transport Roller                 | 1                 |
| 29        | A629 2251 | Paper Indicator Cover            | 1                 |
| 30        | A629 5110 | Paper Indicator Board            | 1                 |
| 31        | A629 3111 | Receiving Tray                   | 1                 |
| 32        | AA06 3311 | Transport Roller Spring          | 2                 |
| 33        | A629 5220 | Paper Indicator Harness          | 1                 |
| 34        | A629 2221 | Grounding Plate                  | 1                 |
| 35        | A049 3371 | Magnet                           | 2                 |

| Index No. | Part No.   | Description                    | Q'ty Per Assembly |
|-----------|------------|--------------------------------|-------------------|
| 101       | 0805 0089  | Retaining Ring - M4            |                   |
| 102       | 0805 3480  | Bushing - 6mm                  |                   |
| 103       | 0450 3008B | Tapping Screw - M3x8           |                   |
| 104       | 0313 0030B | Philips Pan Head Screw - M3x3  |                   |
| 105       | 1105 0299  | Locking Card Spacer - KglS-18s |                   |
| 106       | 0452 3010Z | Bind Tapping Screw - 3x10      |                   |
| 107       | 0720 0030E | Retaining Ring - M3            |                   |
| 108       | 1105 0328  | Harness Clamp - ES-0505        |                   |
| 109       | 1105 0362  | Spacer - M8                    |                   |
| 110       | 0451 3006B | Tapping Screw - M3x6           |                   |
| 111       | 0720 0040E | Retaining Ring - M4            |                   |
| 112       | 1204 2379  | Micro Switch - CS2A-B2BA       |                   |
| 113       | 0450 3014b | Tapping Screw - M3x14          |                   |
| 114       | 1105 0283  | Clamp                          |                   |

# **PARTS INDEX**

| Part No.  | Description                      | Page and Index No. |
|-----------|----------------------------------|--------------------|
| A629 1511 | Left Cover                       | 3- 1               |
| A629 1521 | Rear Cover                       | 3- 19              |
| A629 1531 | Connector Cover                  | 3- 20              |
| A629 1541 | Exhaust Cover                    | 3- 18              |
| A629 2111 | Bracket - Junction Gate Solenoid | 3- 23              |
| A629 2115 | Junction Gate Solenoid           | 3- 21              |
| A629 2121 | Junction Gate Lever              | 3- 22              |
| A629 2131 | Torque Limiter - Paper Exit      | 3- 15              |
| A629 2141 | Torque Limiter - Paper Transport | 3- 17              |
| A629 2161 | Bracket - Bin Unit               | 3- 11              |
| A629 2171 | Belt Tightener                   | 3- 9               |
| A629 2211 | Frame - Paper Feed               | 3- 5               |
| A629 2221 | Grounding Plate                  | 3- 34              |
| A629 2231 | Grounding Plate                  | 3- 7               |
| A629 2251 | Paper Indicator Cover            | 3- 29              |
| A629 2261 | Harness Cover - Paper Indicator  | 3- 24              |
| A629 3111 | Receiving Tray                   | 3- 31              |
| A629 5100 | Tray Board                       | 3- 13              |
| A629 5110 | Paper Indicator Board            | 3- 30              |
| A629 5200 | Safety Switch Harness            | 3- 6               |
| A629 5210 | Interface Harness                | 3- 14              |
| A629 5220 | Paper Indicator Harness          | 3- 33              |

| Part No.  | Description              | Page and Index No |
|-----------|--------------------------|-------------------|
| AA04 3257 | Timing Belt - 164        | 3- 16             |
| AA06 0668 | Tension Spring           | 3- 10             |
| AA06 3311 | Transport Roller Spring  | 3- 32             |
| AA06 3312 | Exit Roller Spring       | 3- 2              |
| AA08 0220 | Bushing - 6mm            | 3- 3              |
| AA12 0027 | Antistatic Brush         | 3- 25             |
| AB03 0395 | Idle Pulley              | 3- 8              |
| AF02 0378 | Exit Roller              | 3- 27             |
| AF02 0379 | Transport Roller         | 3- 28             |
| AF02 2090 | Driven Roller            | 3- 4              |
| AW01 0070 | Photosebсор - PS-R11D1-B | 3- 26             |
| AX04 0093 | Bin Unit Motor DC2.6W    | 3- 12             |

| Part No.  | Description | Page and Index No. |
|-----------|-------------|--------------------|
| A049 3371 | Magnet      | 3- 35              |

| Part No.   | Description                    | Page and Index No |
|------------|--------------------------------|-------------------|
| 0313 0030B | Philips Pan Head Screw - M3x3  | 3-104             |
| 0450 3008B | Tapping Screw - M3x8           | 3-103             |
| 0450 3014b | Tapping Screw - M3x14          | 3-113             |
| 0451 3006B | Tapping Screw - M3x6           | 3-110             |
| 0452 3010Z | Bind Tapping Screw - 3x10      | 3-106             |
| 0720 0030E | Retaining Ring - M3            | 3-107             |
| 0720 0040E | Retaining Ring - M4            | 3-111             |
| 0805 0089  | Retaining Ring - M4            | 3-101             |
| 0805 3480  | Bushing - 6mm                  | 3-102             |
| 1105 0283  | Clamp                          | 3-114             |
| 1105 0299  | Locking Card Spacer - KglS-18s | 3-105             |
| 1105 0328  | Harness Clamp - ES-0505        | 3-108             |
| 1105 0362  | Spacer - M8                    | 3-109             |
| 1204 2379  | Micro Switch - CS2A-B2BA       | 3-112             |