


# **Punch Unit PU5030**


## **(D3GJ)**

### **Parts Catalog**


# Unit All




U001  
BASE




U002  
GUIDE PLATE



U003  
TONER HOPPER




U004  
ELECTRICAL



U005  
ACCESSORIES


# U001 BASE




# U001 BASE

22.D4492631  
(x3)  
TIMING PULLEY:P  
UNCH UNIT:MOVE


23.D4492641  
(x3)  
BRACKET:HOME P  
OSITION SENSOR:  
PUNCH UNIT



24.D4492651  
(x6)  
STOPPER:PUNCH  
UNIT




# U002 GUIDE PLATE



# U003 TONER HOPPER

1.A6061885  
DECAL - HOPPER



2.A8127214  
FILM - FRONT


6.D4494121  
PIN:TONER HOPP  
ER:PROTECT:FRO  
NT

7.D4494131  
PIN:TONER HOPP  
ER:PROTECT:REA  
R

3.A8127215  
FILM - REAR


4.B5457212  
TONER HOPPER P  
UNCH GUARD

5.D4494111  
HOPPER:PUNCH U  
NIT



U004  
ELECTRICAL



2:D3GJ5220  
PCB:PUNCH:(PCB3  
)



1:D0BX5430  
PCB:CRB:(PCB4)



# U005 ACCESSORIES





## Exclusive Parts

| Number   | Part Name                                      | Group | ID |
|----------|------------------------------------------------|-------|----|
| A6061885 | DECAL - HOPPER                                 | U003  | 1  |
| A8127214 | FILM - FRONT                                   | U003  | 2  |
| A8127215 | FILM - REAR                                    | U003  | 3  |
| A8127331 | LOCK SPRING                                    | U005  | 6  |
| AA062334 | TENSION SPRING:4.9N                            | U001  | 7  |
| AA143702 | SCREW:PIN:POSITIONING                          | U001  | 8  |
|          |                                                | U002  | 6  |
|          |                                                | U005  | 7  |
| AA143790 | SCREW:CONTACT POINT                            | U001  | 9  |
|          |                                                | U005  | 8  |
| AW010143 | PHOTO REFLECTION SENSOR:PS R11TL1R-C:(S77)     | U005  | 9  |
| AW020190 | PHOTO INTERRUPTOR:(S73)                        | U001  | 10 |
| B3021542 | TIMING PULLEY - 20Z                            | U001  | 11 |
| B5457212 | TONER HOPPER PUNCH GUARD                       | U003  | 4  |
| B7061545 | TIGHTENER BRACKET                              | U001  | 12 |
| B8904160 | TIMING BELT:B100S3M207                         | U001  | 13 |
| D0BX2990 | CONTACT IMAGE SENSOR:CING:(S69)                | U002  | 7  |
| D0BX5430 | PCB:CRB:(PCB4)                                 | U004  | 1  |
| D1444484 | SHOULDER SCREW - M3                            | U001  | 14 |
| D3G85320 | DC STEPPER MOTOR:PUNCH UNIT:MOVE:ASS'Y:(STM30) | U001  | 15 |
| D3GJ1217 | (2 & 3 holes type):PUNCH UNIT:2-3 HOLE         | U001  | 16 |
| D3GJ1227 | (2 & 4 holes type):PUNCH UNIT:2-4 HOLE         | U001  | 17 |
| D3GJ1228 | (4 holes type):PUNCH UNIT:4HOLE                | U001  | 18 |
| D3GJ3111 | GUIDE PLATE:PUNCH UNIT:FRONT UPPER             | U002  | 8  |
| D3GJ3173 | BRACKET:SENSOR:REGISTRATION                    | U002  | 9  |
| D3GJ5220 | PCB:PUNCH:(PCB3)                               | U004  | 2  |
| D4492191 | BRACKET:STAY:TIMING BELT                       | U001  | 19 |
| D4492211 | STAY:PUNCH UNIT:SLIDE                          | U001  | 20 |
| D4492615 | BRACKET:MOTOR:PUNCH UNIT:MOVE:ASS'Y            | U001  | 21 |
| D4492631 | TIMING PULLEY:PUNCH UNIT:MO                    | U001  | 22 |

| Number   | Part Name                               | Group | ID |
|----------|-----------------------------------------|-------|----|
|          | VE                                      |       |    |
| D4492641 | BRACKET:HOME POSITION SENSOR:PUNCH UNIT | U001  | 23 |
| D4492651 | STOPPER:PUNCH UNIT                      | U001  | 24 |
| D4493121 | GUIDE PLATE:PUNCH UNIT:FRONT LOWER      | U002  | 10 |
| D4494111 | HOPPER:PUNCH UNIT                       | U003  | 5  |
| D4494121 | PIN:TONER HOPPER:PROTECT:FRONT          | U003  | 6  |
| D4494131 | PIN:TONER HOPPER:PROTECT:REAR           | U003  | 7  |
| D4496111 | BRACKET:LOCK:TONER HOPPER               | U005  | 10 |
| GW010007 | PHOTO REFLECTION SENSOR:EXIT:(S68)      | U002  | 11 |


## Standard Parts



03130120N  
PAN HEAD SCREW:M3X12



04513008N  
TAPPING SCREW - M3X8



04513010N  
TAPPING SCREW:3X10



04514006N  
TAPPING SCREW - 4X6



04514008N  
TAPPING SCREW:4X8



04543006Q  
TAPPING SCREW - M3X6



07200040E  
RETAINING RING - M4




11050723  
CLAMPS:WES-0507



11050724  
CLAMPS:WES-1210



11050758  
CLAMP:LWSM-0306A



11050762  
CLAMP:LWS-0711A

