

EDITOR (A988)


1. EDITOR BOARD 1 (A988)

1. EDITOR BOARD (A988)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A988 5520	Main Control Board	1
2	A988 5560	LED Harness	1
3	A988 5550	Interface Harness	1
4	A982 5054	Grounding Wire	1
5	A982 1064	Pen	1
6	A988 1062	Edit Key Cover	1
7	A988 1252	Upper Cover - A4	1
7	A988 1251	Upper Cover - LT	1
8	A988 1260	Lower Cover	1
9	A988 5530	Edit Key Board	1
10	A982 1252	Original Holder	1
11	A982 1056	Pen Holder	1
12	A982 1055	Harness Holder	1
13	A988 1071	Upper Harness Holder - I/F Cable	1
14	A988 1072	Lower Harness Holder - I/F Cable	1
15	A982 1051	Editing Sheet	1
16	A988 1080	Main Board Cover	1
17	A988 1300	Mounting Bracket	1
18	A049 1576	Original Pressure Pad	1
19	A982 1059	Magnetic	1
20	A982 1052	Base Sheet	1
21	A988 5521	IC - Main Control	1
22	A988 1451	Editor Panel Sheet - English	1
22	A988 1452	Editor Panel Sheet - German	1
22	A988 1453	Editor Panel Sheet - French	1
22	A988 1454	Editor Panel Sheet - Italian	1
22	A988 1455	Editor Panel Sheet - Spanish	1
23	A988 1310	Editor Hinge	1
24	A988 1066	Screw - M3x10	12
25	A988 1061	Edit Key Ass'y	1
26	A988 1055	Spacer	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	08025194	Pan Head Screw - M2x6	
102	0710 0030B	Hexagon Nut - M3	
103	08025146	Tapping Screw - M3x8	
104	08025145	Tapping Screw - M3x6	
105	09513012B	Philip Screw With Flat Washer - M3x12	
106	0414 0104W	Tapping Screw - M4x10	
107	08010124	Screw - M3x12	

2. EDITOR BOARD 2 (A988)



2. EDITOR BOARD 2 (A988)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A988 5516	Interface Harness - 115V	1
1	A988 5510	Large Interface Harness - 230V	1
2	A988 5500	Interface Unit	1
3	A988 5515	Small Interface Harness - 230V	1

Index No.	Part No.	Description	Q'ty Per Assembly
1 0 1	11050229	Clamp	
102	11060241	Bushing - 6.7mm	