

Roll Feeder Type 480 (B758)

Roll Feeder Type 480 (B758)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.EXTERIOR (B758).....	2
2.ROLL PAPER HOLDER (B758)	4
3.ROLL PAPER FEED 1 (B758).....	6
4.ROLL PAPER FEED 2 (B758).....	8
5.ROLL PAPER FEED 3 (B758).....	10
6.FRAME SECTION 1 (B758).....	12
7.FRAME SECTION 2 (B758).....	14
8.DECALS AND DOCUMENTS (B758).....	16
PARTS INDEX.....	19

April ,28 ' 2005

1.EXTERIOR (B758)




1.EXTERIOR (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B188 2979	Bracket:Pin	2
2	B188 2977	Stopper:Right	1
3	B188 2975	Stopper:Left	1
4	AA08 0049	Bushing - 10x18	2
5	5918 3120	Stud - M4	6
6	B188 2936	Slide Rail:Left:Ass'y	1
7	B188 2938	Slide Rail:Right:Ass'y	1
8	AA14 3718	Stepped Screw - M4	8
9	B010 2947	Harness Clamp - FCW-52	3
10	B010 2916	Positioning Pin	2
11	AA06 3612	Compression Spring - Tray Release	2
12	B188 2954	Guide Plate	1
13	B188 2958	Cable:Connector	1
14	AW50 0029	Safety Switch - FA1L-AA20	1
15	B189 5764	Harness:Lower Paper Feed:Option	1
16	B010 2956	Connector Bracket	1
17	AA06 0976	Spring:Connector	2
18	AA14 3253	Pin - Lever - Paper Spool Unit	2
19	AW01 0121	Paper End Sensor	2
20	B189 2632	Bracket:Paper End Sensor	1
21	B189 5842	Harness:Lower Paper Feed:Option2	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0725 0140E	Retaining Ring (C Type) - M14	
103	0951 4006N	Screw:Polished Round:M4x6	
104	0954 5010N	Screw:Polished Round/Spring:M5x10	
105	0802 5291	Tapping Screw:Round Point:M3x6	
106	0701 0050N	Washer:Dia5	
107	0451 4010N	Tapping Screw:4x10	
108	0950 4006N	Screw:Spring Washer:M4x6	
109	1105 0517	Harness Clamp - LWS-2111Z	
110	1105 0518	Edge Saddle - LES-1010	
111	0451 4014N	Tapping Screw:M4x14	

2.ROLL PAPER HOLDER (B758)




2.ROLL PAPER HOLDER (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B189 2846	Decal:Paper Tray:Display:3.4	1
2	B188 2930	Cover:Front	1
3	A353 2243	Lever Knob	1
4	B188 2704	Holder:Roll Paper	1
5	B188 2823	Decal:Roll Paper:Caution Chart:NA	1
6	B010 2717	Exit Guide Roller	2
7	B188 2835	Decal:Operate:Roll Paper:1	1
8	B188 2841	Decal:Operate:Roll Paper:2	1
9	B188 2716	Stay:Guide Plate:Exit	1
10	AA08 0203	Bushing - 6mm	6
11	AF02 2034	Exit Roller	3
12	AA06 3122	Exit Roller Spring	4
13	AA06 0974	Spring:Pressure:Brush Roller	2
14	B189 2711	Guide Plate:Exit:Outer	1
15	B188 2773	Cover:Cutter Unit:Left	1
16	5403 1030	Tension Spring	2
17	B188 2896	Lever:Lock:Left	1
18	5053 0223	Bushing - 8mm	8
19	AA14 3718	Stepped Screw - M4	8
20	AX40 0188	Heater:120V:13W	2
20	AX40 0189	Heater:230V:13W	2
21	B010 2902	Lever Shaft	1
22	B010 2900	Grip Lever	1
23	B188 2898	Lever:Lock:Right	1
24	B010 2978	Keytop	2
25	B188 2824	Decal:Operate:Holder:EXP	1
26	B188 2846	Decal:Dehumidifier:Switch	1
27	B189 2934	Inner Cover:Left:Lower Position	1
28	B010 2842	Decal - Paper Hodler Operate	1
29	B010 2932	Right Inner Cover	1
30	B010 2947	Harness Clamp - FCW-52	3
31	B188 2705	Bracket:Micro Switch	1
32	B010 2827	Right Sheet - Side Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0454 3008Q	Tapping Screw:3x8	
103	0453 4008N	Binding Self Tapping Screw:4x8	
104	0451 4010N	Tapping Screw:4x10	
105	0451 3014N	Tapping Screw:3x14	
106	0452 3010N	Binding Self-Tapping Screw:3x10	
107	1204 2466	Micro Switch - V-16506-1c25	
108	0720 0040E	Retaining Ring - M4	
109	0707 4020N	Bushing:DIA4x2	

3.ROLL PAPER FEED 1 (B758)




3.ROLL PAPER FEED 1 (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B188 2923	Cutter Unit	1
2	A571 7700	Screw:Spring Washer:M2.6X5	2
3	B188 2844	Micro Switch:Dolphin:Ass'y	2
4	B188 2854	DC Motor:Ass'y	1
5	5053 0223	Bushing - 8mm	8
6	AB01 1413	Drive Gear - 27z	1
7	AF02 0525	Exhaust Drive Roller	1
8	B189 5833	Harness:Lower Paper Feed:Option1	1
9	B010 2846	Decal - Paper Size Indication	1
9	B010 2826	Decal - Paper Size	1
10	B189 2725	Guide Plate:Paper Feed Sensor	1
11	AW01 0111	Paper Feed Sensor	1
12	B010 2726	Roller Guide Plate	1
13	B188 2820	Bracket:Rocker Switch	1
14	B188 2950	Bracket:Connector:Tray	1
15	B188 5767	Harness:Upper Paper Feed	1
16	AX40 0188	Heater:120V:13W	2
16	AX40 0189	Heater:230V:13W	2
17	5918 3120	Stud - M4	6
18	B641 2794	Holder:Paper Holder:Middle	2
19	B189 2723	Guide Plate:Exit:Inner	1
20	B189 2858	Bracket:Paper End Sensor Board:Rear	1
21	AW01 0121	Paper End Sensor	2
22	B189 2860	Bracket:Paper End Sensor:Rear:Auxiliary	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0950 4006N	Screw:Spring Washer:M4x6	
103	0451 4010N	Tapping Screw:4x10	
104	0353 0120N	Screw M3x12	
105	1204 2499	Switch:AC250V/10A	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	1105 0522	Edge Saddle - LES0510	
108	0720 0060E	Retaining Ring - M6	
109	1105 0516	Clamp	
110	0802 5291	Tapping Screw:Round Point:M3x6	

4.ROLL PAPER FEED 2 (B758)




4.ROLL PAPER FEED 2 (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AW02 0168	Paper Feed Sensor	2
2	B188 2816	Cover:Motor	1
3	5053 0223	Bushing - 8mm	8
4	AB01 1412	Gear - 36Z	4
5	AB01 7527	Gear Pulley - 37Z/40T	2
6	B010 2856	Timing Belt - 954	1
7	B010 2979	Switch Plate	2
8	AW50 0012	Push Switch	2
9	B188 2878	Stay:Upper	1
10	AX21 0091	Registration Clutch	2
11	B188 2733	Feed Roller:Ass'y	2
12	5215 2621	Snap Ring - M6	2
13	AB03 0677	Pulley - 23MM	1
14	B188 2880	Stay:Inner Back	1
15	AB03 0678	Timing Pulley - 25T	1
16	B188 2868	Tightener:Ass'y	1
17	AA06 0854	Tightener Spring	1
18	B188 2876	Bracket:Motor	1
19	B188 2579	Motor Cushion	1
20	AX06 0295	Stepper Motor:MM56:DC24V	1
21	B188 2968	Bracket:Knob	1
22	B010 2966	Timing Belt - S2M 334	1
23	B010 2964	Timing Belt - S2M 252	1
24	B189 5891	Harness:DC:Motor Control Board	1
25	B189 5840	Harness:DC:Lower Paper Feed:Option	1
26	B188 5787	Harness:Siro-Sikan-Kenti	1
27	B188 5450	PCB:RFDB	1
28	B188 2943	Guide Plate:Base:Tray	1
29	AB03 0679	Timing Pulley - 32T	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0451 4010N	Tapping Screw:4x10	
103	0453 4008N	Binding Self Tapping Screw:4x8	
104	0951 3006N	Screw - M3X6	
105	0720 0060E	Retaining Ring - M6	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	1105 0516	Clamp	
108	1106 0493	Edging	
109	1105 0487	Harness Clamp	

5.ROLL PAPER FEED 3 (B758)




5.ROLL PAPER FEED 3 (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA14 3788	Pin:Guide Plate:Paper Feed	2
2	5918 3120	Stud - M4	6
3	B010 2768	Upper Guide Plate - Connecting	1
4	AA08 0037	Bushing - 6mm	8
5	AA06 0975	Spring:Middle:Pressure	4
6	AF02 0108	Paper Feed Roller - Middle	2
7	B188 2798	Bracket:Paper Feed Sensor	1
8	AW01 0110	Paper Feed Sensor	2
9	B188 5786	Harness:Paper End Sensor	2
10	B010 2756	Front Base	1
11	B188 2865	Guide:Feed Roller:Exit	1
12	AF02 0109	Paper Feed Roller - Side	2
13	AA06 6368	Spring - Exit	8
14	B189 2612	Guide Plate:Lower:Lower Position	1
15	B188 6196	Gasket:Guide Plate:Upper Front	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0453 4010N	Binding Self Tapping Screw:4x10	
103	0353 0140N	Screw:M3x14	
104	0353 0120N	Screw M3x12	
105	0720 0040E	Retaining Ring - M4	
106	1105 0516	Clamp	
107	1105 0511	Harness Clamp - LWS-0306ZC	
108	1105 0329	Clamp - ES-0510	
109	1106 0411	Bushing - 11.5mm	
110	1105 0487	Harness Clamp	

6.FRAME SECTION 1 (B758)




6.FRAME SECTION 1 (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B188 2786	Cover:Mechanical Drive Section:Fron	1
2	B189 2872	Guide Plate:Vertical Transport	1
3	AA00 0646	Decal:Cutter:Caution Chart:EXP	1
4	B188 2740	Guide Plate:Upper:Peen	1
5	B010 2770	Lower Guide Plate - Connecting	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	1105 0522	Edge Saddle - LES0510	
103	1105 0516	Clamp	
104	1105 0511	Harness Clamp - LWS-0306ZC	

7.FRAME SECTION 2 (B758)










7.FRAME SECTION 2 (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B353 2773	Paper Holder Lock Lever	4
2	B353 2778	Decal - Paper Holder Chart	4
3	B353 2772	Paper Holder Stopper	4
4	B353 2774	Arm Stopper Pawl	4
5	B353 2776	Lock Compression Spring	4
6	B353 2777	Upper Arm Stopper Pawl	4
7	B353 2771	Roll Paper Holder	4
8	B353 2775	Paper Holder Pawl	12
9	B353 2765	Roller Shaft	8
10	B353 2766	Paper Holder Brake	4
11	B353 2767	Brake Compression Spring	4
12	B188 2808	Holder:Left	1
13	AG07 0514	Magnet Catch:Ass'y	4
14	B353 2768	Positioning Plate	2
15	B188 2810	Holder:Right	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3010N	Binding Self-tapping Screw:3x10	
102	0740 3008	Ball Bearing - 8x22x7	

8.DECALS AND DOCUMENTS (B758)

1 	2 	3 
4 	5 	
6 		
7 	8 	
9 	10 	

8.DECALS AND DOCUMENTS (B758)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA00 0646	Decal:Cutter:Caution Chart:EXP	1
2	B353 2778	Decal - Paper Holder Chart	1
3	B010 2842	Decal - Paper Hodler Operate	1
4	B188 2823	Decal:Roll Paper:Caution Chart:NA	1
5	B188 2824	Decal:Operate:Holder:EXP	1
6	B188 2835	Decal:Operate:Roll Paper:1	1
7	B188 2841	Decal:Operate:Roll Paper:2	1
8	B188 2846	Decal:Dehumidifier:Switch	2
9	B189 2846	Decal:Paper Tray:Display:3.4	1
10	B010 2826	Decal - Paper Size	2

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
ROLL PAPER FEED 1 (B758)	B188 2923	Cutter Unit	Cutter Unit	1	7 - 1

Parts Index

Part No.	Description	Page and Index No.
A353 2243	Lever Knob	5 - 3
A571 7700	Screw:Spring Washer:M2.6X5	7 - 2
B010 2717	Exit Guide Roller	5 - 6
B010 2726	Roller Guide Plate	7 - 12
B010 2756	Front Base	11 - 10
B010 2768	Upper Guide Plate - Connecting	11 - 3
B010 2770	Lower Guide Plate - Connecting	13 - 5
B010 2826	Decal - Paper Size	17 - 10
B010 2826	Decal - Paper Size	7 - 9
B010 2827	Right Sheet - Side Plate	5 - 32
B010 2842	Decal - Paper Hodler Operate	5 - 28
B010 2842	Decal - Paper Hodler Operate	17 - 3
B010 2846	Decal - Paper Size Indication	7 - 9
B010 2856	Timing Belt - 954	9 - 6
B010 2900	Grip Lever	5 - 22
B010 2902	Lever Shaft	5 - 21
B010 2916	Positioning Pin	3 - 10
B010 2932	Right Inner Cover	5 - 29
B010 2947	Harness Clamp - FCW-52	5 - 30
B010 2947	Harness Clamp - FCW-52	3 - 9
B010 2956	Connector Bracket	3 - 16
B010 2964	Timing Belt - S2M 252	9 - 23
B010 2966	Timing Belt - S2M 334	9 - 22
B010 2978	Keytop	5 - 24
B010 2979	Switch Plate	9 - 7
B188 2579	Motor Cushion	9 - 19
B188 2704	Holder:Roll Paper	5 - 4
B188 2705	Bracket:Micro Switch	5 - 31
B188 2716	Stay:Guide Plate:Exit	5 - 9
B188 2733	Feed Roller:Ass'y	9 - 11
B188 2740	Guide Plate:Upper:Peen	13 - 4
B188 2773	Cover:Cutter Unit:Left	5 - 15
B188 2786	Cover:Mechanical Drive Section:Fron	13 - 1
B188 2798	Bracket:Paper Feed Sensor	11 - 7
B188 2808	Holder:Left	15 - 12

Part No.	Description	Page and Index No.
B188 2810	Holder:Right	15 - 15
B188 2816	Cover:Motor	9 - 2
B188 2820	Bracket:Rocker Switch	7 - 13
B188 2823	Decal:Roll Paper:Caution Chart:NA	17 - 4
B188 2823	Decal:Roll Paper:Caution Chart:NA	5 - 5
B188 2824	Decal:Operate:Holder:EXP	5 - 25
B188 2824	Decal:Operate:Holder:EXP	17 - 5
B188 2835	Decal:Operate:Roll Paper:1	17 - 6
B188 2835	Decal:Operate:Roll Paper:1	5 - 7
B188 2841	Decal:Operate:Roll Paper:2	17 - 7
B188 2841	Decal:Operate:Roll Paper:2	5 - 8
B188 2844	Micro Switch:Dolphin:Ass'y	7 - 3
B188 2846	Decal:Dehumidifier:Switch	17 - 8
B188 2846	Decal:Dehumidifier:Switch	5 - 26
B188 2854	DC Motor:Ass'y	7 - 4
B188 2865	Guide:Feed Roller:Exit	11 - 11
B188 2868	Tightener:Ass'y	9 - 16
B188 2876	Bracket:Motor	9 - 18
B188 2878	Stay:Upper	9 - 9
B188 2880	Stay:Inner Back	9 - 14
B188 2896	Lever:Lock:Left	5 - 17
B188 2898	Lever:Lock:Right	5 - 23
B188 2923	Cutter Unit	7 - 1
B188 2930	Cover:Front	5 - 2
B188 2936	Slide Rail:Left:Ass'y	3 - 6
B188 2938	Slide Rail:Right:Ass'y	3 - 7
B188 2943	Guide Plate:Base:Tray	9 - 28
B188 2950	Bracket:Connector:Tray	7 - 14
B188 2954	Guide Plate	3 - 12
B188 2958	Cable:Connector	3 - 13
B188 2968	Bracket:Knob	9 - 21
B188 2975	Stopper:Left	3 - 3
B188 2977	Stopper:Right	3 - 2
B188 2979	Bracket:Pin	3 - 1
B188 5450	PCB:RFDB	9 - 27

Part No.	Description	Page and Index No.
B188 5767	Harness:Upper Paper Feed	7 - 15
B188 5786	Harness:Paper End Sensor	11 - 9
B188 5787	Harness:Siro-Sikan-Kenti	9 - 26
B188 6196	Gasket:Guide Plate:Upper Front	11 - 15
B189 2612	Guide Plate:Lower:Lower Position	11 - 14
B189 2632	Bracket:Paper End Sensor	3 - 20
B189 2711	Guide Plate:Exit:Outer	5 - 14
B189 2723	Guide Plate:Exit:Inner	7 - 19
B189 2725	Guide Plate:Paper Feed Sensor	7 - 10
B189 2846	Decal:Paper Tray:Display:3.4	17 - 9
B189 2846	Decal:Paper Tray:Display:3.4	5 - 1
B189 2858	Bracket:Paper End Sensor Board:Rear	7 - 20
B189 2860	Bracket:Paper End Sensor:Rear:Auxiliary	7 - 22
B189 2872	Guide Plate:Vertical Transport	13 - 2
B189 2934	Inner Cover:Left:Lower Position	5 - 27
B189 5764	Harness:Lower Paper Feed:Option	3 - 15
B189 5833	Harness:Lower Paper Feed:Option1	7 - 8
B189 5840	Harness:DC:Lower Paper Feed:Option	9 - 25
B189 5842	Harness:Lower Paper Feed:Option2	3 - 21
B189 5891	Harness:DC:Motor Control Board	9 - 24
B353 2765	Roller Shaft	15 - 9
B353 2766	Paper Holder Brake	15 - 10
B353 2767	Brake Compression Spring	15 - 11
B353 2768	Positioning Plate	15 - 14
B353 2771	Roll Paper Holder	15 - 7
B353 2772	Paper Holder Stopper	15 - 3
B353 2773	Paper Holder Lock Lever	15 - 1
B353 2774	Arm Stopper Pawl	15 - 4
B353 2775	Paper Holder Pawl	15 - 8
B353 2776	Lock Compression Spring	15 - 5
B353 2777	Upper Arm Stopper Pawl	15 - 6
B353 2778	Decal - Paper Holder Chart	15 - 2
B353 2778	Decal - Paper Holder Chart	17 - 2
B641 2794	Holder:Paper Holder:Middle	7 - 18

Part No.	Description	Page and Index No.
AA00 0646	Decal:Cutter:Caution Chart:EXP	13 - 3
AA00 0646	Decal:Cutter:Caution Chart:EXP	17 - 1
AA06 0854	Tightener Spring	9 - 17
AA06 0974	Spring:Pressure:Brush Roller	5 - 13
AA06 0975	Spring:Middle:Pressure	11 - 5
AA06 0976	Spring:Connector	3 - 17
AA06 3122	Exit Roller Spring	5 - 12
AA06 3612	Compression Spring - Tray Release	3 - 11
AA06 6368	Spring - Exit	11 - 13
AA08 0037	Bushing - 6mm	11 - 4
AA08 0049	Bushing - 10x18	3 - 4
AA08 0203	Bushing - 6mm	5 - 10
AA14 3253	Pin - Lever - Paper Spool Unit	3 - 18
AA14 3718	Stepped Screw - M4	3 - 8
AA14 3718	Stepped Screw - M4	5 - 19
AA14 3788	Pin:Guide Plate:Paper Feed	11 - 1
AB01 1412	Gear - 36Z	9 - 4
AB01 1413	Drive Gear - 27z	7 - 6
AB01 7527	Gear Pulley - 37Z/40T	9 - 5
AB03 0677	Pulley - 23MM	9 - 13
AB03 0678	Timing Pulley - 25T	9 - 15
AB03 0679	Timing Pulley - 32T	9 - 29
AF02 0108	Paper Feed Roller - Middle	11 - 6
AF02 0109	Paper Feed Roller - Side	11 - 12
AF02 0525	Exhaust Drive Roller	7 - 7
AF02 2034	Exit Roller	5 - 11
AG07 0514	Magnet Catch:Ass'y	15 - 13
AW01 0110	Paper Feed Sensor	11 - 8
AW01 0111	Paper Feed Sensor	7 - 11
AW01 0121	Paper End Sensor	3 - 19
AW01 0121	Paper End Sensor	7 - 21
AW02 0168	Paper Feed Sensor	9 - 1
AW50 0012	Push Switch	9 - 8
AW50 0029	Safety Switch - FA1L-AA20	3 - 14
AX06 0295	Stepper Motor:MM56:DC24V	9 - 20

Part No.	Description	Page and Index No.
AX21 0091	Registration Clutch	9 - 10
AX40 0188	Heater:120V:13W	7 - 16
AX40 0188	Heater:120V:13W	5 - 20
AX40 0189	Heater:230V:13W	5 - 20
AX40 0189	Heater:230V:13W	7 - 16

Part No.	Description	Page and Index No.
0353 0120N	Screw M3x12	7 - 104
0353 0120N	Screw M3x12	11 - 104
0353 0140N	Screw:M3x14	11 - 103
0451 3014N	Tapping Screw:3x14	5 - 105
0451 4008N	Tapping Screw:4x8	11 - 101
0451 4008N	Tapping Screw:4x8	7 - 101
0451 4008N	Tapping Screw:4x8	3 - 101
0451 4008N	Tapping Screw:4x8	5 - 101
0451 4008N	Tapping Screw:4x8	9 - 101
0451 4008N	Tapping Screw:4x8	13 - 101
0451 4010N	Tapping Screw:4x10	3 - 107
0451 4010N	Tapping Screw:4x10	9 - 102
0451 4010N	Tapping Screw:4x10	5 - 104
0451 4010N	Tapping Screw:4x10	7 - 103
0451 4014N	Tapping Screw:M4x14	3 - 111
0452 3010N	Binding Self-tapping Screw:3x10	15 - 101
0452 3010N	Binding Self-Tapping Screw:3x10	5 - 106
0453 4008N	Binding Self Tapping Screw:4x8	5 - 103
0453 4008N	Binding Self Tapping Screw:4x8	9 - 103
0453 4010N	Binding Self Tapping Screw:4x10	11 - 102
0454 3008Q	Tapping Screw:3x8	5 - 102
0701 0050N	Washer:DIA5	3 - 106
0707 4020N	Bushing:DIA4x2	5 - 109
0720 0040E	Retaining Ring - M4	5 - 108
0720 0040E	Retaining Ring - M4	11 - 105
0720 0060E	Retaining Ring - M6	9 - 105
0720 0060E	Retaining Ring - M6	7 - 108
0725 0140E	Retaining Ring (C Type) - M14	3 - 102
0740 3008	Ball Bearing - 8x22x7	15 - 102
0802 5291	Tapping Screw:Round Point:M3x6	7 - 110
0802 5291	Tapping Screw:Round Point:M3x6	3 - 105
0950 4006N	Screw:Spring Washer:M4x6	7 - 102
0950 4006N	Screw:Spring Washer:M4x6	3 - 108
0951 3006N	Screw - M3X6	9 - 104
0951 4006N	Screw:Polished Round:M4x6	3 - 103

Part No.	Description	Page and Index No.
0954 5010N	Screw:Polished Round/Spring:M5x10	3 - 104
1105 0329	Clamp - ES-0510	11 - 108
1105 0487	Harness Clamp	9 - 109
1105 0487	Harness Clamp	11 - 110
1105 0511	Harness Clamp - LWS-0306ZC	9 - 106
1105 0511	Harness Clamp - LWS-0306ZC	13 - 104
1105 0511	Harness Clamp - LWS-0306ZC	7 - 106
1105 0511	Harness Clamp - LWS-0306ZC	11 - 107
1105 0516	Clamp	13 - 103
1105 0516	Clamp	7 - 109
1105 0516	Clamp	11 - 106
1105 0516	Clamp	9 - 107
1105 0517	Harness Clamp - LWS-2111Z	3 - 109
1105 0518	Edge Saddle - LES-1010	3 - 110
1105 0522	Edge Saddle - LES0510	13 - 102
1105 0522	Edge Saddle - LES0510	7 - 107
1106 0411	Bushing - 11.5mm	11 - 109
1106 0493	Edging	9 - 108
1204 2466	Micro Switch - V-16506-1c25	5 - 107
1204 2499	Switch:AC250V/10A	7 - 105

Part No.	Description	Page and Index No.
5053 0223	Bushing - 8mm	5 - 18
5053 0223	Bushing - 8mm	7 - 5
5053 0223	Bushing - 8mm	9 - 3
5215 2621	Snap Ring - M6	9 - 12
5403 1030	Tension Spring	5 - 16
5918 3120	Stud - M4	3 - 5
5918 3120	Stud - M4	7 - 17
5918 3120	Stud - M4	11 - 2