

LCIT RT3010 (D539)

LCIT RT3010 (D539)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior (D539)	2
2.Paper Feed Section (D539)	4
3.Paper Tray (D539)	6
4.Electrical Section (D539)	8
5.Frame (D539)	10
Parts Index	14

October 28, 2010

1.Exterior (D539)




1.Exterior (D539)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D353 1250	Right Cover	1
2	D353 1252	Grip - Right Inner Cover	1
3	AG07 0514	Magnet Catch	1
4	D353 1251	End Fence	1
5	AA10 0014	Retaining Ring C - Separate	2
6	D353 1204	Right Lower Cover	1
7	D353 1255	Cushion	1
8	D353 1088	Cover - Safety Switch	1
9	D353 1208	Push Switch Cover	1
10	D353 1221	Housing - Push Switch	1
11	G020 5626	Push Switch	1
12	B065 3561	Spring	1
13	D353 1222	Keytop - Push Switch	1
14	D353 1201	Front Cover	1
15	D353 1209	Supporting Plate - Front Cover	1
16	D353 3850	Front Coupling Bracket	1
17	D353 1101	Front Support Plate	1
18	D353 1014	Pressure Plate - Vertical Transport	2
19	D353 3857	Positioning Pin:Screw:Coupling	2
20	AA06 3926	Compression Spring - Earth	2
21	G569 6207	Stepped Screw - Long	4
22	D353 3860	Rear Coupling Bracket	1
23	D353 1102	Rear Support Plate	1
24	D353 1203	Upper Left Cover	1
25	D353 1341	Decal - Misfeed Removal	1
26	D353 1207	Inner Cover - Drive	1
27	D353 1202	Rea Cover	1
28	D353 1343	Decal:Paper Set Direction:EXP	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0451 3008N	Tapping Screw - M3x8	
103	0451 4006N	Tapping Screw - 4x6	
104	0454 3006Q	Tapping Screw - M3x6	
105	0454 3008Q	Tapping Screw:3x8	

2.Paper Feed Section (D539)




2.Paper Feed Section (D539)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D353 2510	Guide Plate - Separate	1
2	AA10 0014	Retaining Ring C - Separate	3
3	AF03 2085	Paper Feed Roller - Separate	1
4	B004 2783	Torque Limiter	1
5	D353 2520	Driven Shaft - Separate	1
6	B223 2676	Spring - 11N	2
7	G060 2652	Bushing - M4	2
8	AF02 0646	Vertical Transport Roller	1
9	AA06 0693	Tension Spring	1
10	D353 2512	Pressure Lever - Separate	1
11	AA08 2143	Bushing - 6x10x6	4
12	AB01 0157	Gear:Separate:Driven	1
13	AB01 0156	Gear:Separate:Drive	1
14	D353 2522	Drive Shaft - Separate	1
15	D539 1327	Spacer:Timing Belt	1
16	D539 2819	Gear:Separator:Input	1
17	D353 2511	Guide Plate - Lower	1
18	D353 2525	Shaft - Paper Feed	1
19	D539 2764	Gear:Feed	1
20	AA08 3023	One-Way Bearing - 6x14x10	1
21	D353 2633	Ground Plate	1
22	AA08 2101	Bushing - 6x10x6	3
23	AA06 0691	Tension Spring	1
24	D353 2501	Pick-Up Arm	1
25	AF03 0085	Paper Feed Roller - Pickup	1
26	AF03 1087	Paper Feed Roller - Feed	1
27	D353 2502	One-Way Gear - 18t	1
28	AB01 1252	Gear - 20Z	1
29	B223 2756	Drive Transport Roller	1
30	D353 2651	Paper Feed Sensor Bracket	1
31	AW01 0145	Photo Refiection Sensor:Paper Feed	2
32	GW02 0020	Photointerruptor:Lg248n1	1
33	D539 2640	DC Solenoid:Pickup:Ass'y	1
34	GW01 0007	Photo Reflection Sensor:Exit	1
35	D353 2630	Upper Stay - Paper Feed Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	D353 2634	Ground Plate	1
37	D353 2650	Sensor Bracket	1
38	D539 5311	Harness:Paper Feed Unit	1
101	0450 3008N	Tapping Screw - M3x8	
102	0805 0089	Retaining Ring - M4	
103	0720 0040E	Retaining Ring - M4	
104	0454 3006Q	Tapping Screw - M3x6	
105	0353 0040N	Screw - M3X4	
106	1105 0516	Clamp	
107	1105 0522	Edge Saddle - Les0510	
108	1105 0511	Harness Clamp - LWS-0306ZC	
109	0451 3008N	Tapping Screw - M3x8	

3.Paper Tray (D539)




3.Paper Tray (D539)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D353 1063	Lower Right Stay	1
2	A667 2653	Paper Stopper	1
3	D353 2532	Tray Bottom Plate	1
4	D353 1340	Decal - Paper Set Direction	1
5	A421 2543	Friction Pad	1
6	C408 6691	Shield	1
7	GW02 0020	Photointerruptor:Lg248nl1	5
8	D539 2534	Bracket:Paper Volume Sensor:Ass'y	1
9	AB03 0609	Pulley - 20T	2
10	AA04 3979	Timing Belt - 80S3M501	2
11	B801 2684	Timing Belt Holder	2
12	D353 1034	One-Way Clutch	1
13	D353 1039	Spacer - One-way Clutch	1
14	5353 1818	Wave Washer - M 12.5	1
15	D353 1038	Spacer - Pulley	1
16	AB03 0633	Timing Pulley - Tray Bottom Plate	2
17	D353 1131	Shaft - Tray Lift	1
18	B872 2614	Bushing:R1	2
19	AA00 0713	Decal - Side Fence Rear	1
20	AA14 3963	Knob Screw:Side Fence	2
21	AA06 0693	Tension Spring	2
22	G004 3519	Stepping Screw	4
23	D353 2850	Side Fence:Rear:Ass'y	1
24	B303 2777	Paper Guide Mylar	2
25	D353 2840	Side Fence:Front:Ass'y	1
26	D353 1003	Upper Stay	1
27	B801 1184	Timing Belt Spacer	1
28	D353 1030	Shaft:Rising Tray:Press Fit	1
29	D539 5330	Harness:Paper Volume Sensor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	0720 0030E	Retaining Ring - M3	
104	0720 0060E	Retaining Ring - M6	
105	1105 0522	Edge Saddle - Les0510	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	0623 0140E	Spring Pin - 3x14mm	

4.Electrical Section (D539)




4.Electrical Section (D539)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D353 1009	Safety Switch Ass'y - Right	1
2	D539 5370	Harness:Micro Switch:Rise	1
3	D539 5310	Harness:Paper Feed Unit:Connecting	1
4	D539 5360	Harness:Push Switch	1
5	D539 5100	PCB:Bank:Ass'y	1
6	D353 1075	Bracket	2
7	D539 5300	Harness:Interface	1
9	D353 1031	Lift Motor - DC 24W	1
10	D539 5320	Harness:Motor	1
11	D353 1025	Stepper Motor - DC 3W	1
12	B802 1622	Stepper Motor Damper	1
13	5447 2681	Snap Ring	1
14	AA08 2101	Bushing - 6x10x6	4
15	B223 1187	Magnetic Clutch Bracket	1
16	AX20 0289	Magnetic Clutch - 32Z	1
17	D539 1021	Bracket:Drive Unit:Paper Feed	1
18	D539 1025	Timing Pulley:Paper Feed	1
19	AA04 3982	Timing Belt:40S3M129	1
20	AB01 7699	Gear - 33Z/44Z	1
21	AB01 1258	Gear - 38Z	1
22	D353 1024	Gear - 32Z	1
23	D353 1022	Drive Unit Plate	1
24	B223 1186	Drive Joint	2
25	D353 1183	Grip Shaft	1
26	D353 1023	Feed Shaft	1
27	D539 5350	Harness:Lift Motor	1
28	D539 5340	Harness:Electromagnetic Clutch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	
102	0451 3030N	Tapping Screw:3x30	
103	0434 0100N	Tapping Screw - 4x10	
104	0451 4008N	Tapping Screw:4x8	
105	0451 3006N	Tapping Screw - 3x6	
106	0720 0040E	Retaining Ring - M4	
107	1105 0192	Locking Support	
108	1105 0511	Harness Clamp - LWS-0306ZC	
109	1105 0516	Clamp	
110	0805 0089	Retaining Ring - M4	
111	1204 2521	Micro Switch	
112	1204 2529	Switch - V-5F912DN	
113	1106 0289	Bushing - SR-5N-1	

5.Frame (D539)



5.Frame (D539)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D353 1113	Support Guide Plate	1
2	AW01 0145	Photo Refiection Sensor:Paper Feed	1
3	D539 5331	Harness:On Off Detector:Connecting	1
4	D353 1115	Guide Plate - Paper Feed	1
5	D353 1092	Caster:DIA25H33	3
6	AA07 0083	Slide Rail	2
7	D353 1104	Link - Slide Rail	2
8	D353 1017	Tension Spring	2
9	B872 2614	Bushing:R1	2
10	D353 1066	Lever Stopper - Rear	1
11	D353 1067	Lock Lever	1
12	AW50 0023	Push Switch	2
13	D353 1205	Grip - Lever	1
14	AA14 0923	Lever Shaft	1
15	D353 1091	Bracket - Caster	1
16	D353 1006	Left Stay	1
17	D353 1005	Upper Left Stay	1
18	D353 5309	Front Harness - Open	1
19	D353 1057	Lock Lever	1
20	B390 6910	Binding Self Tapping Screw - M3x6	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	
102	0454 4008Q	Tapping Screw - M4x8	
103	0433 0060N	Pan Self-tapping Screw:3x6	
104	1105 0488	Harness Clamp	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	0454 4006Q	Tapping Screw:4x6	

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
Paper Tray (D539)	A421 2543	Friction Pad	Friction Pad	1	7 - 5
Paper Feed Section (D539)	AF03 0085	Paper Feed Roller - Pickup	Paper Feed Roller - Pickup	1	5 - 25
	AF03 2085	Paper Feed Roller - Separate	Paper Feed Roller - Separate	1	5 - 3
	AF03 1087	Paper Feed Roller - Feed	Paper Feed Roller - Feed	1	5 - 26

Parts Index

Part No.	Description	Page and Index No.
D539 1021	Bracket:Drive Unit:Paper Feed	9 - 17
D539 1025	Timing Pulley:Paper Feed	9 - 18
D539 1327	Spacer:Timing Belt	5 - 15
D539 2534	Bracket:Paper Volume Sensor:Ass'y	7 - 8
D539 2640	DC Solenoid:Pickup:Ass'y	5 - 33
D539 2764	Gear:Feed	5 - 19
D539 2819	Gear:Separator:Input	5 - 16
D539 5100	PCB:Bank:Ass'y	9 - 5
D539 5300	Harness:Interface	9 - 7
D539 5310	Harness:Paper Feed Unit:Connecting	9 - 3
D539 5311	Harness:Paper Feed Unit	5 - 38
D539 5320	Harness:Motor	9 - 10
D539 5330	Harness:Paper Volume Sensor	7 - 29
D539 5331	Harness:On Off Detector:Connecting	11 - 3
D539 5340	Harness:Electromagnetic Clutch	9 - 28
D539 5350	Harness:Lift Motor	9 - 27
D539 5360	Harness:Push Switch	9 - 4
D539 5370	Harness:Micro Switch:Rise	9 - 2

Part No.	Description	Page and Index No.
A421 2543	Friction Pad	7 - 5
A667 2653	Paper Stopper	7 - 2
B004 2783	Torque Limiter	5 - 4
B065 3561	Spring	3 - 12
B223 1186	Drive Joint	9 - 24
B223 1187	Magnetic Clutch Bracket	9 - 15
B223 2676	Spring - 11N	5 - 6
B223 2756	Drive Transport Roller	5 - 29
B303 2777	Paper Guide Mylar	7 - 24
B390 6910	Binding Self Tapping Screw - M3x6	11 - 20
B801 1184	Timing Belt Spacer	7 - 27
B801 2684	Timing Belt Holder	7 - 11
B802 1622	Stepper Motor Damper	9 - 12
B872 2614	Bushing:R1	7 - 18
B872 2614	Bushing:R1	11 - 9
C408 6691	Shield	7 - 6
D353 1003	Upper Stay	7 - 26
D353 1005	Upper Left Stay	11 - 17
D353 1006	Left Stay	11 - 16
D353 1009	Safety Switch Ass'y - Right	9 - 1
D353 1014	Pressure Plate - Vertical Transport	3 - 18
D353 1017	Tension Spring	11 - 8
D353 1022	Drive Unit Plate	9 - 23
D353 1023	Feed Shaft	9 - 26
D353 1024	Gear - 32Z	9 - 22
D353 1025	Stepper Motor - DC 3W	9 - 11
D353 1030	Shaft:Rising Tray:Press Fit	7 - 28
D353 1031	Lift Motor - DC 24W	9 - 9
D353 1034	One-Way Clutch	7 - 12
D353 1038	Spacer - Pulley	7 - 15
D353 1039	Spacer - One-way Clutch	7 - 13
D353 1057	Lock Lever	11 - 19
D353 1063	Lower Right Stay	7 - 1
D353 1066	Lever Stopper - Rear	11 - 10
D353 1067	Lock Lever	11 - 11

Part No.	Description	Page and Index No.
D353 1075	Bracket	9 - 6
D353 1088	Cover - Safety Switch	3 - 8
D353 1091	Bracket - Caster	11 - 15
D353 1092	Caster:DIA25H33	11 - 5
D353 1101	Front Support Plate	3 - 17
D353 1102	Rear Support Plate	3 - 23
D353 1104	Link - Slide Rail	11 - 7
D353 1113	Support Guide Plate	11 - 1
D353 1115	Guide Plate - Paper Feed	11 - 4
D353 1131	Shaft - Tray Lift	7 - 17
D353 1183	Grip Shaft	9 - 25
D353 1201	Front Cover	3 - 14
D353 1202	Rea Cover	3 - 27
D353 1203	Upper Left Cover	3 - 24
D353 1204	Right Lower Cover	3 - 6
D353 1205	Grip - Lever	11 - 13
D353 1207	Inner Cover - Drive	3 - 26
D353 1208	Push Switch Cover	3 - 9
D353 1209	Supporting Plate - Front Cover	3 - 15
D353 1221	Housing - Push Switch	3 - 10
D353 1222	Keytop - Push Switch	3 - 13
D353 1250	Right Cover	3 - 1
D353 1251	End Fence	3 - 4
D353 1252	Grip - Right Inner Cover	3 - 2
D353 1255	Cushion	3 - 7
D353 1340	Decal - Paper Set Direction	7 - 4
D353 1341	Decal - Misfeed Removal	3 - 25
D353 1343	Decal:Paper Set Direction:EXP	3 - 28
D353 2501	Pick-Up Arm	5 - 24
D353 2502	One-Way Gear - 18t	5 - 27
D353 2510	Guide Plate - Separate	5 - 1
D353 2511	Guide Plate - Lower	5 - 17
D353 2512	Pressure Lever - Separate	5 - 10
D353 2520	Driven Shaft - Separate	5 - 5
D353 2522	Drive Shaft - Separate	5 - 14

Part No.	Description	Page and Index No.
D353 2525	Shaft - Paper Feed	5 - 18
D353 2532	Tray Bottom Plate	7 - 3
D353 2630	Upper Stay - Paper Feed Unit	5 - 35
D353 2633	Ground Plate	5 - 21
D353 2634	Ground Plate	5 - 36
D353 2650	Sensor Bracket	5 - 37
D353 2651	Paper Feed Sensor Bracket	5 - 30
D353 2840	Side Fence:Front:Ass'y	7 - 25
D353 2850	Side Fence:Rear:Ass'y	7 - 23
D353 3850	Front Coupling Bracket	3 - 16
D353 3857	Positioning Pin:Screw:Coupling	3 - 19
D353 3860	Rear Coupling Bracket	3 - 22
D353 5309	Front Harness - Open	11 - 18
G004 3519	Stepping Screw	7 - 22
G020 5626	Push Switch	3 - 11
G060 2652	Bushing - M4	5 - 7
G569 6207	Stepped Screw - Long	3 - 21

Part No.	Description	Page and Index No.
AA00 0713	Decal - Side Fence Rear	7 - 19
AA04 3979	Timing Belt - 80S3M501	7 - 10
AA04 3982	Timing Belt:40S3M129	9 - 19
AA06 0691	Tension Spring	5 - 23
AA06 0693	Tension Spring	7 - 21
AA06 0693	Tension Spring	5 - 9
AA06 3926	Compression Spring - Earth	3 - 20
AA07 0083	Slide Rail	11 - 6
AA08 2101	Bushing - 6x10x6	5 - 22
AA08 2101	Bushing - 6x10x6	9 - 14
AA08 2143	Bushing - 6x10x6	5 - 11
AA08 3023	One-Way Bearing - 6x14x10	5 - 20
AA10 0014	Retaining Ring C - Separate	5 - 2
AA10 0014	Retaining Ring C - Separate	3 - 5
AA14 0923	Lever Shaft	11 - 14
AA14 3963	Knob Screw:Side Fence	7 - 20
AB01 0156	Gear:Separate:Drive	5 - 13
AB01 0157	Gear:Separate:Driven	5 - 12
AB01 1252	Gear - 20Z	5 - 28
AB01 1258	Gear - 38Z	9 - 21
AB01 7699	Gear - 33Z/44Z	9 - 20
AB03 0609	Pulley - 20T	7 - 9
AB03 0633	Timing Pulley - Tray Bottom Plate	7 - 16
AF02 0646	Vertical Transport Roller	5 - 8
AF03 0085	Paper Feed Roller - Pickup	5 - 25
AF03 1087	Paper Feed Roller - Feed	5 - 26
AF03 2085	Paper Feed Roller - Separate	5 - 3
AG07 0514	Magnet Catch	3 - 3
AW01 0145	Photo Refiection Sensor:Paper Feed	11 - 2
AW01 0145	Photo Refiection Sensor:Paper Feed	5 - 31
AW50 0023	Push Switch	11 - 12
AX20 0289	Magnetic Clutch - 32Z	9 - 16
GW01 0007	Photo Reflection Sensor:Exit	5 - 34
GW02 0020	Photointerruptor:Lg248n1	7 - 7
GW02 0020	Photointerruptor:Lg248n1	5 - 32

Part No.	Description	Page and Index No.
0353 0040N	Screw - M3X4	5 - 105
0433 0060N	Pan Self-tapping Screw:3x6	11 - 103
0434 0100N	Tapping Screw - 4x10	9 - 103
0450 3008N	Tapping Screw - M3x8	5 - 101
0450 3008N	Tapping Screw - M3x8	7 - 102
0450 3008N	Tapping Screw - M3x8	3 - 101
0451 3006N	Tapping Screw - 3x6	9 - 105
0451 3008N	Tapping Screw - M3x8	3 - 102
0451 3008N	Tapping Screw - M3x8	5 - 109
0451 3030N	Tapping Screw:3x30	9 - 102
0451 4006N	Tapping Screw - 4x6	3 - 103
0451 4008N	Tapping Screw:4x8	9 - 104
0454 3006Q	Tapping Screw - M3x6	7 - 101
0454 3006Q	Tapping Screw - M3x6	9 - 101
0454 3006Q	Tapping Screw - M3x6	5 - 104
0454 3006Q	Tapping Screw - M3x6	11 - 101
0454 3006Q	Tapping Screw - M3x6	3 - 104
0454 3008Q	Tapping Screw:3x8	3 - 105
0454 4006Q	Tapping Screw:4x6	11 - 106
0454 4008Q	Tapping Screw - M4x8	11 - 102
0623 0140E	Spring Pin - 3x14mm	7 - 107
0720 0030E	Retaining Ring - M3	7 - 103
0720 0040E	Retaining Ring - M4	5 - 103
0720 0040E	Retaining Ring - M4	9 - 106
0720 0060E	Retaining Ring - M6	7 - 104
0805 0089	Retaining Ring - M4	9 - 110
0805 0089	Retaining Ring - M4	5 - 102
1105 0192	Locking Support	9 - 107
1105 0488	Harness Clamp	11 - 104
1105 0511	Harness Clamp - LWS-0306ZC	5 - 108
1105 0511	Harness Clamp - LWS-0306ZC	11 - 105
1105 0511	Harness Clamp - LWS-0306ZC	9 - 108
1105 0511	Harness Clamp - LWS-0306ZC	7 - 106
1105 0516	Clamp	9 - 109
1105 0516	Clamp	5 - 106

Part No.	Description	Page and Index No.
1105 0522	Edge Saddle - Les0510	5 - 107
1105 0522	Edge Saddle - Les0510	7 - 105
1106 0289	Bushing - SR-5N-1	9 - 113
1204 2521	Micro Switch	9 - 111
1204 2529	Switch - V-5F912DN	9 - 112

Part No.	Description	Page and Index No.
5353 1818	Wave Washer - M 12.5	7 - 14
5447 2681	Snap Ring	9 - 13