

RT42 (B303)

PARTS CATALOG







INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.







INDEX to PARTS CATALOG

LOCATION OF UNIT	2
1.EXTERIOR (B303)	6
2.PAPER TRAY SECTION 1 (B303)	8
3.PAPER TRAY SECTION 2 (B303)	10
4.PAPER TRAY SECTION 3 (B303)	12
5.PAPER TRAY SECTION 4 (B303)	14
6.PAPER FEED UNIT 1 (B303).....	16
7.PAPER FEED UNIT 2 (B303).....	18
8.TRANSPORT SECTION 1 (B303).....	20
9.TRANSPORT SECTION 2 (B303).....	22
10.TRANSPORT SECTION 3 (B303).....	24
11.DRIVE SECTION (B303).....	26
12.ELECTRICAL SECTION (B303).....	28
13.FRAME SECTION 1 (B303)	30
14.FRAME SECTION 2 (B303)	32
15.DECAL AND DOCUMENT (B303)	34
PARTS INDEX	37



LOCATION OF UNIT

1.EXTERIOR (B303)  See Page 7	2.PAPER TRAY SECTION 1 (B303)  See Page 9	3.PAPER TRAY SECTION 2 (B303)  See Page 11
4.PAPER TRAY SECTION 3 (B303)  See Page 13	5.PAPER TRAY SECTION 4 (B303)  See Page 15	6.PAPER FEED UNIT 1 (B303)  See Page 17


LOCATION OF UNIT

7.PAPER FEED UNIT 2 (B303)  See Page 19	8.TRANSPORT SECTION 1 (B303)  See Page 21	9.TRANSPORT SECTION 2 (B303)  See Page 23
10.TRANSPORT SECTION 3 (B303)  See Page 25	11.DRIVE SECTION (B303)  See Page 27	12.ELECTRICAL SECTION (B303)  See Page 29

LOCATION OF UNIT

13.FRAME SECTION 1 (B303)  See Page 31	14.FRAME SECTION 2 (B303)  See Page 33	

1.EXTERIOR (B303)




1.EXTERIOR (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 1371	Cushion - 10x595	1
2	B303 1374	Cushion - 15x50	1
3	B303 1376	Cushion - 15x30	2
4	B303 1373	Cushion - 15x372	1
5	B303 1372	Cushion - 15x700	1
6	B303 1370	Upper Cover	1
7	B303 1375	Rear Cover	1
8	B303 1385	Right Cover	1
9	B303 2729	Cushion - 30x38	1
10	B303 1386	Key Counter Cover	1
11	B303 1101	Pin - 12x35	2
12	B303 1360	Left Cover	1
13	B303 1309	Decal - Misfeed Removal	1
14	B303 1361	Magnet Catch	1
15	A606 1595	Small Door Cover	2
16	5447 2681	Snap Ring	1
17	B303 1100	Pin - 14x33	2

Index No.	Part No.	Description	Qty Per Assembly
101	0451 4008H	Tapping Screw - 4x8	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0451 4012H	Tapping Screw - 4x12	
104	0450 4008B	Tapping Screw - 4x8	

2.PAPER TRAY SECTION 1 (B303)




2.PAPER TRAY SECTION 1 (B303)

Index No.	Part No.	Description	Qty Per Assembly
*	B303 2801	Upper & Middle Paper Tray - LT	1
*	B303 2800	Upper & Middle Paper Tray - A4	1
1	B303 1304	Decal - Paper Position	1
2	B303 2872	Front Side Fence	1
3	B303 2877	Knob Screw	2
4	B303 2777	Paper Guide Mylar	1
5	B303 2821	Front Guide Plate	1
6	B303 2875	Rear Side Fence	1
7	B303 1305	Decal - Paper Position	1
8	A048 2955	Decal- Manual Feed	1
9	B303 2888	Paper Size Lever	1
10	B303 2887	Paper Size Actuator	1
11	B303 2889	Spring Plate	1
12	B303 2886	Sensor Bracket	1
13	A499 1378	Stepped Screw - M4x6	1
14	AA14 3074	Stepped Screw - M4x5	1
15	B303 2781	Paper Guide Fence	1
16	B303 2782	Knob Screw	1
17	B303 2784	Rubber Tube - 2x4x32	1
18	B303 2783	Guide Fence Bracket	1
19	B303 1302	Decal - Paper Set	1
20	B303 2822	Upper Cover	1
21	B303 2896	5th Guide Fence Stopper	1
21	B303 2895	4th Guide Fence Stopper	1
22	B303 1380	Small Tray Cover	1
23	B303 1313	5th Tray Decal	1
23	B303 1312	4th Tray Decal	1

Index No.	Part No.	Description	Qty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0802 5282	Tapping Screw - M4x8	

3.PAPER TRAY SECTION 2 (B303)




3.PAPER TRAY SECTION 2 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	A667 2656	Friction Pad	1
2	B303 2735	Paper Tray Base Plate	1
3	B303 2732	Paper Tray Shaft Bracket	1
4	B303 2737	Weight Plate	2
5	B303 2742	Bracket	1
6	A667 2660	Belt Stopper	2
7	AA04 3910	Timing Belt - B100S5M435	2
8	AB03 0548	Pilley - 16T	4
9	A335 4351	Guide Roller	4
10	AA08 2096	Bushing - 8x12x7	2
11	B303 1303	Decal - Paper Size	1
12	B303 2723	Grounding Plate	1
13	B303 2745	Spring Plate	1
14	B303 2743	Bracket	1
15	B303 2744	Paper Actuator	1
16	B303 2851	Paper Lift Shaft - 1K	1
17	B303 2729	Cushion - 30x38	1
18	B303 2726	Fixing Plate	1
19	B303 2725	Fixing Plate	1

Index No.	Part No.	Description	Qty Per Assembly
101	0450 4014W	Tapping Screw - M4x14	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0451 3008B	Tapping Screw - M3x8	
104	0720 0060E	Retaining Ring - M6	
105	0633 0140G	Parallel Pin - 3x14	
106	0802 5282	Tapping Screw - M4x8	

4.PAPER TRAY SECTION 3 (B303)




4.PAPER TRAY SECTION 3 (B303)

Index No.	Part No.	Description	Qty Per Assembly
*	B303 2701	Lower Paper Tray - LT	1
*	B303 2700	Lower Paper Tray - A4	1
1	B303 1304	Decal - Paper Position	1
2	B303 2777	Paper Guide Mylar	1
3	B303 2771	Front Side Fence	1
4	B303 2721	Front Guide Plate	1
5	B303 1305	Decal - Paper Position	1
6	B303 2775	Rear Side Fence	1
7	A048 2955	Decal- Manual Feed	1
8	B303 1311	Decal - Paper Set	1
9	B303 2722	Upper Cover	1
10	B303 1381	Large Tray Cover	1
11	B303 1314	Decal - Tray	1
12	B303 2727	Sensor Bracket	1
13	AA14 3074	Stepped Screw - M4x5	2
14	B303 2782	Knob Screw	1
15	B303 2784	Rubber Tube - 2x4x32	1
16	B303 2781	Paper Guide Fence	1
17	B303 2783	Guide Fence Bracket	1
18	B303 2723	Grounding Plate	1
19	B303 2877	Knob Screw	1

Index No.	Part No.	Description	Qty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0802 5282	Tapping Screw - M4x8	

5.PAPER TRAY SECTION 4 (B303)




5.PAPER TRAY SECTION 4 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 2732	Paper Tray Shaft Bracket	2
2	A667 2656	Friction Pad	1
3	B303 2735	Paper Tray Base Plate	1
4	B303 2737	Weight Plate	2
5	B303 2734	Paper Stopper	1
6	B303 2742	Bracket	1
7	A667 2660	Belt Stopper	2
8	B303 2761	Tightener Bracket	2
9	AB03 0548	Pulley - 16T	6
10	AA06 0817	Tighten Spring	2
11	B303 1303	Decal - Paper Size	1
12	A335 4351	Guide Roller	4
13	AA04 3909	Timing Belt - B100S5M780	2
14	AB01 4140	Gear - 24Z	1
15	AA08 2096	Bushing - 8x12x7	2
16	B303 2724	Bracket	2
17	B303 2745	Spring Plate	1
18	B303 2743	Bracket	1
19	B303 2744	Paper Actuator	1
20	B303 2751	Paper Lift Shaft - 2.5K	1
21	B303 2729	Cushion - 30x38	1
22	B303 2725	Fixing Plate	1
23	B303 2726	Fixing Plate	1
24	B303 2791	Oil Dumper	1
25	B303 2792	Oil Dumper Bracket	1

Index No.	Part No.	Description	Qty Per Assembly
101	0450 4014W	Tapping Screw - M4x14	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0451 3008B	Tapping Screw - M3x8	
104	0720 0060E	Retaining Ring - M6	
105	0633 0140G	Parallel Pin - 3x14	
106	0802 5282	Tapping Screw - M4x8	
107	0450 4010B	Tapping Screw - 4x10	
108	0802 5282	Tapping Screw - M4x8	

6.PAPER FEED UNIT 1 (B303)




6.PAPER FEED UNIT 1 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 2583	Feed Guide Plate	1
2	B303 5323	Feed Unit Harness	1
3	AB01 4152	Gear - 32Z	1
4	A232 3566	Ball Bearing - 8x16x5	2
5	B303 2571	Feed Stay	1
6	AW01 0049	Photo Reflection Sensor	2
7	B303 2576	Sensor Bracket	1
8	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
9	B303 2577	Sensor Bracket	1
10	B303 2578	Pick-up DC Solenoid	1
11	AA06 0826	Release Spring	1
12	A134 2868	Solenoid Bracket	1
13	AX21 0073	Electro Magnetic Clutch	1
14	AB01 3000	Idler Gear - 18Z	1
15	AX20 0176	Magnetic Clutch	1
16	AF02 0485	Transport Drive Roller	1
17	AA06 0816	Pressure Spring	1
18	B303 2575	Pick-up Arm	1
19	AA08 3015	Roller Clutch	1
20	AF03 0041	Pick-up Roller - Bypass Feed	1
21	5447 2681	Snap Ring	2
22	5447 2706	Gear - 15T	1
23	AA14 0799	Feed Roller Shaft	1
24	AA08 2070	Bushing - 8x16x7	2
25	AF03 1041	Feed Roller - Bypass Feed	1

Index No.	Part No.	Description	Qty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0720 0060E	Retaining Ring - M6	
103	0353 0040B	Screw - M3X4	
104	0805 0088	Retaining Ring - M6	
105	1105 0267	Harness Clamp - YMC-10-0	
106	1102 6283	Connector - 2P	

7.PAPER FEED UNIT 2 (B303)




7.PAPER FEED UNIT 2 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 2585	Reverse Guide Plate	1
2	A229 2692	Damping Insulation	1
3	AA06 3852	Pressure Spring	2
4	AA08 0034	Bushing - 4x5x7	2
5	AF02 0489	Transport Relay Roller	1
6	AB01 1392	Drive Reverse Gear - 24Z	1
7	A229 6306	Reverse Drive Shaft	1
8	B303 2600	Front Side Plate	1
9	B303 2610	Rear Side Plate	1
10	AA08 2046	Bushing - 6x12x6	3
11	AB01 3776	Gear - 30Z	1
12	B303 2591	Feed Clutch Arm	1
13	AB01 3775	Gear - 33Z	1
14	B303 2552	Feed Stay	1
15	B303 2556	Reverse Pressure Lever	1
16	AA06 0834	Reverse Pressure Spring - 55gf	1
17	AB01 1391	Driven Reverse Gear - 21Z	1
18	A229 5496	Lower Harness	1
19	B303 2558	Reverse DC Solenoid	1
20	B303 2560	Reverse Solenoid Bracket	1
21	AA06 0575	Release Spring	1
22	A229 6307	Reverse Driven Shaft	1
23	A247 2900	Torque Limiter - 53mnm	1
24	AF03 2041	Separation Roller - Bypass Feed	1
25	5447 2681	Snap Ring	1

Index No.	Part No.	Description	Qty Per Assembly
101	0720 0030E	Retaining Ring - M3	
102	0720 0040E	Retaining Ring - M4	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	0720 0060E	Retaining Ring - M6	
105	0573 0030E	Hexagon Headless Set Screw - M3x3	
106	0805 3145	Ball Bearing - 6x12x4mm	
107	1105 0267	Harness Clamp - YMC-10-0	
108	1102 6259	Connector - 2P	
109	1105 0199	Clamp	
110	0353 0040B	Screw - M3X4	
111	1102 6283	Connector - 2P	

8.TRANSPORT SECTION 1 (B303)




8.TRANSPORT SECTION 1 (B303)



Index No.	Part No.	Description	Qty Per Assembly
1	B303 3615	Guide Plate	1
2	AA08 0034	Bushing - 4x5x7	4
3	AA06 3852	Pressure Spring	4
4	AF02 0489	Transport Relay Roller	2
5	B303 3650	Support Stay	1
6	5215 2621	Snap Ring - M6	1
7	B303 3610	Guide Plate	1
8	AF02 0486	Transport Drive Roller	2
9	B303 3830	Upper Support Stay	1
10	A232 3566	Ball Bearing - 8x16x5	4
11	B303 3682	Misfeed Removal Knob	1
12	B303 1306	Decal - Instruction	1
13	AA08 2070	Bushing - 8x16x7	1

Index No.	Part No.	Description	Qty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0720 0030E	Retaining Ring - M3	
103	0451 4008B	Philips Tapping Screw - M4x8	

9.TRANSPORT SECTION 2 (B303)




9.TRANSPORT SECTION 2 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 3640	Guide Plate	1
2	A232 3566	Ball Bearing - 8x16x5	4
3	AF02 0487	Transport Drive Roller	1
4	B303 3676	Exit Sensor Cover	1
5	B303 5315	Sensor Harness	1
6	AW01 0049	Photo Reflection Sensor	1
7	AF02 0488	Transport Drive Roller	1
8	AB01 4152	Gear - 32Z	1
9	B303 3670	Hinge Bracket	2
10	B303 3630	Guide Plate	1
11	B303 3682	Misfeed Removal Knob	1
12	B303 1307	Decal - Instruction	1
13	AA06 0820	Release Spring	3
14	B303 3635	Guide Plate	1
15	A353 2243	Lever Knob	1
16	AF02 0489	Transport Relay Roller	1
17	AA08 0034	Bushing - 4x5x7	2
18	AA06 3852	Pressure Spring	2
19	B303 3901	Air Block Plate	1
20	B303 3903	Seal - 398x38x10	1
21	B303 3660	Support Stay	1
22	5215 2621	Snap Ring - M6	1
23	AA08 2070	Bushing - 8x16x7	1

Index No.	Part No.	Description	Qty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0720 0030E	Retaining Ring - M3	
104	0313 0040B	Philips Pan Head Screw - M3x4	

10.TRANSPORT SECTION 3 (B303)




10.TRANSPORT SECTION 3 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	AA14 3037	Development Cover Screw	4
2	A232 3566	Ball Bearing - 8x16x5	4
3	AA08 0034	Bushing - 4x5x7	6
4	AA06 3852	Pressure Spring	6
5	AF02 0489	Transport Relay Roller	3
6	B303 3645	Guide Plate	1
7	AF02 0487	Transport Drive Roller	2
8	A680 4223	Cushion	1
9	B303 3620	Guide Plate	1
10	B303 3625	Guide Plate	1
11	B303 3810	Front Side Plate	1
12	B303 1320	Decal - U6	1
13	B303 3820	Rear Side Plate	1
14	B303 3830	Upper Support Stay	1

Index No.	Part No.	Description	Qty Per Assembly
101	0720 0030E	Retaining Ring - M3	
102	0720 0060E	Retaining Ring - M6	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	1105 0267	Harness Clamp - YMC-10-0	
105	1105 0358	Edge Saddle - EDS-0607M	
106	1105 0310	Harness Clamp - LWS-1S	

11.DRIVE SECTION (B303)




11.DRIVE SECTION (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	AA04 3908	Timing Belt - S3M1299	1
2	AB03 0653	Pulley - 23T	1
3	AB03 0647	Timing Pulley - 22T	3
4	AB03 0665	Idler Pulley - 18Z	12
5	AB01 4143	Pulley - 30Z/22T	1
6	AB03 0649	Timing Pulley - 24T	5
7	AA04 3907	Timing Belt - S3M810	1
8	AA14 3444	Stepped Screw	1
9	B303 3681	Linkage Bracket	1
10	AA06 0817	Tighten Spring	1
11	B303 3684	Collar - 6.1x10x8	1
12	5447 2681	Snap Ring	1
13	AA06 0830	Tighten Spring	2
14	B303 1571	Tension Bracket	2
15	AB01 3000	Idler Gear - 18z	1
16	AB01 4141	Pulley - 36Z/24T	1
17	AA04 3911	Timing Belt - S3M420	1
18	AB01 4142	Pulley - 30Z/20T	1
19	AB01 3654	Gear - 30Z	1
20	AA14 0798	Drive Shaft	1
21	AB03 0648	Timing Pulley - 27T	1
22	B303 1565	Paper Feed Frive Shaft	3
23	B303 1562	Collar - 8x13x10	4

Index No.	Part No.	Description	Qty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0740 3008	Ball Bearing - 8x22x7	
103	0720 0040E	Retaining Ring - M4	
104	1105 0267	Harness Clamp - YMC-10-0	
105	0741 3808	Ball Bearing - 8x16x5mm	
106	0707 8040B	Bushing - 8x4mm	

12.ELECTRICAL SECTION (B303)




12.ELECTRICAL SECTION (B30)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 1181	Sensor Bracket	1
2	B303 1182	Sensor Bracket	1
3	AW02 0056	Photointerruptor - EE-SX4235A-P1	6
4	B303 1086	Support Stay	2
5	A248 6167	DC Motor - 19.2W	2
6	H515 5054	Paper Size Sensor	2
7	B303 1563	Stopper Plate	1
8	AX21 0072	Electro Magnetic Clutch	1
9	AX04 0118	Lift Motor - DC 14W	1
10	AA06 3605	Pressure Spring	1
11	B303 1185	Metal Joint	1
12	AB03 0673	Pulley - 34Z	1
13	AX06 0190	Transport Motor - DC32W	1
14	B303 1555	Main Motor Bracket	1
15	B303 1571	Tension Bracket	1
16	AA06 0830	Tighten Spring	1
17	B303 5320	Relay Harness	1
18	B303 5322	Relay Harness	1
19	B303 5316	Door Switch Harness	1
20	B303 5311	Sensor Harness	1
21	B303 5312	Sensor Harness	1
22	B303 5313	Sensor Harness	1
23	B303 5319	Sensor Harness	1
24	B303 5302	Relay Harness	1
25	B303 5300	Relay Harness	1
26	B303 5301	Relay Harness	1
27	B303 5100	Interface Board	1
28	B303 5316	Door Switch Harness	1
29	A659 5390	Grounding Harness - Drawer	1
30	B303 5304	Motor Signal Harness	1
31	B303 5307	Clutch Harness	1
32	B303 5306	Lift Motor Harness	1
33	AB03 0665	Idler Pulley - 18Z	1
34	B303 5317	Interlock Harness	1

Index No.	Part No.	Description	Qty Per Assembly
101	1105 0291	Harness Clamp - LWS-3S	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0720 0060E	Retaining Ring - M6	
104	1105 0267	Harness Clamp - YMC-10-0	
105	0720 0080E	Retaining Ring - M8	
106	0451 3008B	Tapping Screw - M3x8	
107	0450 4010B	Tapping Screw - 4x10	
108	0801 0150	Philips Screw - M4x8	
109	1105 0310	Harness Clamp - LWS-1S	
110	0727 0080E	Retaining Ring - M8	
111	0741 3808	Ball Bearing - 8x16x5mm	
112	0707 8040B	Bushing - 8x4mm	

13.FRAME SECTION 1 (B303)




13.FRAME SECTION 1 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 1390	Upper Inner Cover	1
2	B303 1321	Decal - U7	1
3	B303 1316	Decal - U2	1
4	B303 1318	Decal - U4	1
5	AG05 0067	Knob - Transport Roller	2
6	B303 1391	Lower Inner Cover	1
7	B303 1319	Decal - U5	1
8	B303 1322	Tab Paper End Fence Decal	1
9	B303 2785	Tab Paper End Fence	1
10	B303 1125	Right Slide Rail	1
11	B303 1132	Arm Lock Bracket	1
12	AA06 0814	Lock Spring	2
13	B303 1355	Lower Hinge	1
14	B303 1137	Support Stay	2
15	5446 2560	Cushion - Paper Tray	2
16	B303 1136	Rail Bracket	2
17	B303 1134	Arm Lock Bracket	1
18	B303 1155	Right Slide Rail	1
19	B303 1172	Door Switch Actuator	1
20	H510 5001	Push Switch	1
21	AG07 1010	Magnet Catch	1
22	B303 1171	Interlock Switch Bracket	1
23	B303 5316	Door Switch Harness	1
24	B303 5317	Interlock Harness	1
25	B303 2631	Fixing Plate	1
26	B303 1351	Upper Hinge	1

Index No.	Part No.	Description	Qty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0720 0060E	Retaining Ring - M6	
103	0720 0040E	Retaining Ring - M4	
104	0453 4008B	Tapping Bind Screw - M4x8	
105	0805 3270	Ball Bearing - 8x16x5mm	
106	0451 4010B	Tapping Screw - 4x10	
107	0450 4008B	Tapping Screw - 4x8	
108	1102 6254	Connector - 11P	
109	1102 6249	Relay Connector - 6P	

14.FRAME SECTION 2 (B303)




14.FRAME SECTION 2 (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 1147	Support Stay	3
2	B303 1145	Left Slide Rail	2
3	B303 1075	Support Stay	1
4	B303 1113	Grounding Plate	4
5	B303 1112	Support Stay	2
6	B303 1114	Support Stay	1
7	AA14 3403	Stepped Screw - 8x14x2.8	1
8	B303 2895	Guide Fence Stopper	1
9	B303 1085	Support Stay	1
10	B303 1165	Left Slide Rail	1
11	B303 1183	Grounding Plate	1
12	5424 1064	Screw Stand	3
13	AH01 3002	Leveling Shoe	3
14	AH01 2014	Caster - 60kgf	2
15	A507 1096	Philips Screw - M5x6	8
16	AA06 0813	Lock Spring	1
17	B303 1080	Rear Side Plate	1
18	B303 1070	Front Side Plate	1

Index No.	Part No.	Description	Qty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0453 4008B	Tapping Bind Screw - M4x8	
103	1105 0291	Harness Clamp - LWS-3S	


15.DECAL AND DOCUMENT (B303)



15.DECAL AND DOCUMENT (B303)

7 >PS<	8 >PS< 9 10 11
----------------------------	---

15.DECAL AND DOCUMENT (B303)



15.DECAL AND DOCUMENT (B303)

Index No.	Part No.	Description	Qty Per Assembly
1	B303 1302	Decal - Paper Set	1
2	B303 1303	Decal - Paper Size	1
3	B303 1304	Decal - Paper Position	1
4	B303 1306	Decal - Instruction	1
5	B303 1307	Decal - Instruction	1
6	B303 1308	Decal - Paper Size	1
7	B303 1309	Decal - Misfeed Removal	1
8	B303 1311	Decal - Paper Set	1
9	B303 1312	Decal - Tray	1
10	B303 1313	Decal - Tray	1
11	B303 1314	Decal - Tray	1
12	B303 1316	Decal - U2	1
13	B303 1318	Decal - U4	1
14	B303 1319	Decal - U5	1
15	B303 1320	Decal - U6	1
16	B303 1321	Decal - U7	1
17	B303 1322	Tab Paper End Fence Decal	1

Index No.	Part No.	Description	Qty Per Assembly

PARTS INDEX

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No
PAPER FEED UNIT 1 (B303)	AF03 1041	Feed Roller	Feed Roller - Bypass Feed	3	17- 25
	AF03 0041	Pick-up Roller	Pick-up Roller - Bypass Feed	3	17- 20
PAPER FEED UNIT 2 (B303)	AF03 2041	Separation Roller	Separation Roller - Bypass Feed	3	19- 24

Parts Index

Part No.	Description	Page and Index No.
B303 1070	Front Side Plate	33- 18
B303 1075	Support Stay	33- 3
B303 1080	Rear Side Plate	33- 17
B303 1085	Support Stay	33- 9
B303 1086	Support Stay	29- 4
B303 1100	Pin - 14x33	7- 17
B303 1101	Pin - 12x35	7- 11
B303 1112	Support Stay	33- 5
B303 1113	Grounding Plate	33- 4
B303 1114	Support Stay	33- 6
B303 1125	Right Slide Rail	31- 10
B303 1132	Arm Lock Bracket	31- 11
B303 1134	Arm Lock Bracket	31- 17
B303 1136	Rail Bracket	31- 16
B303 1137	Support Stay	31- 14
B303 1145	Left Slide Rail	33- 2
B303 1147	Support Stay	33- 1
B303 1155	Right Slide Rail	31- 18
B303 1165	Left Slide Rail	33- 10
B303 1171	Interlock Switch Bracket	31- 22
B303 1172	Door Switch Actuator	31- 19
B303 1181	Sensor Bracket	29- 1
B303 1182	Sensor Bracket	29- 2
B303 1183	Grounding Plate	33- 11
B303 1185	Metal Joint	29- 11
B303 1302	Decal - Paper Set	9- 19
B303 1302	Decal - Paper Set	35- 1
B303 1303	Decal - Paper Size	11- 11
B303 1303	Decal - Paper Size	15- 11
B303 1303	Decal - Paper Size	35- 2
B303 1304	Decal - Paper Position	35- 3
B303 1304	Decal - Paper Position	9- 1
B303 1304	Decal - Paper Position	13- 1
B303 1305	Decal - Paper Position	13- 5
B303 1305	Decal - Paper Position	9- 7

Part No.	Description	Page and Index No.
B303 1306	Decal - Instruction	35- 4
B303 1306	Decal - Instruction	21- 12
B303 1307	Decal - Instruction	35- 5
B303 1307	Decal - Instruction	23- 12
B303 1308	Decal - Paper Size	35- 6
B303 1309	Decal - Misfeed Removal	35- 7
B303 1309	Decal - Misfeed Removal	7- 13
B303 1311	Decal - Paper Set	13- 8
B303 1311	Decal - Paper Set	35- 8
B303 1312	Decal - Tray	35- 9
B303 1312	4th Tray Decal	9- 23
B303 1313	Decal - Tray	35- 10
B303 1313	5th Tray Decal	9- 23
B303 1314	Decal - Tray	35- 11
B303 1314	Decal - Tray	13- 11
B303 1316	Decal - U2	35- 12
B303 1316	Decal - U2	31- 3
B303 1318	Decal - U4	31- 4
B303 1318	Decal - U4	35- 13
B303 1319	Decal - U5	31- 7
B303 1319	Decal - U5	35- 14
B303 1320	Decal - U6	25- 12
B303 1320	Decal - U6	35- 15
B303 1321	Decal - U7	35- 16
B303 1321	Decal - U7	31- 2
B303 1322	Tab Paper End Fence Decal	35- 17
B303 1322	Tab Paper End Fence Decal	31- 8
B303 1351	Upper Hinge	31- 26
B303 1355	Lower Hinge	31- 13
B303 1360	Left Cover	7- 12
B303 1361	Magnet Catch	7- 14
B303 1370	Upper Cover	7- 6
B303 1371	Cushion - 10x595	7- 1
B303 1372	Cushion - 15x700	7- 5
B303 1373	Cushion - 15x372	7- 4

Part No.	Description	Page and Index No.
B303 1374	Cushion - 15x50	7- 2
B303 1375	Rear Cover	7- 7
B303 1376	Cushion - 15x30	7- 3
B303 1380	Small Tray Cover	9- 22
B303 1381	Large Tray Cover	13- 10
B303 1385	Right Cover	7- 8
B303 1386	Key Counter Cover	7- 10
B303 1390	Upper Inner Cover	31- 1
B303 1391	Lower Inner Cover	31- 6
B303 1555	Main Motor Bracket	29- 14
B303 1562	Collar - 8x13x10	27- 23
B303 1563	Stopper Plate	29- 7
B303 1565	Paper Feed Frive Shaft	27- 22
B303 1571	Tension Bracket	29- 15
B303 1571	Tension Bracket	27- 14
B303 2552	Feed Stay	19- 14
B303 2556	Reverse Pressure Lever	19- 15
B303 2558	Reverse DC Solenoid	19- 19
B303 2560	Reverse Solenoid Bracket	19- 20
B303 2571	Feed Stay	17- 5
B303 2575	Pick-up Arm	17- 18
B303 2576	Sensor Bracket	17- 7
B303 2577	Sensor Bracket	17- 9
B303 2578	Pick-up DC Solenoid	17- 10
B303 2583	Feed Guide Plate	17- 1
B303 2585	Reverse Guide Plate	19- 1
B303 2591	Feed Clutch Arm	19- 12
B303 2600	Front Side Plate	19- 8
B303 2610	Rear Side Plate	19- 9
B303 2631	Fixing Plate	31- 25
B303 2700	Lower Paper Tray - A4	13- *
B303 2701	Lower Paper Tray - LT	13- *
B303 2721	Front Guide Plate	13- 4
B303 2722	Upper Cover	13- 9
B303 2723	Grounding Plate	13- 18

Part No.	Description	Page and Index No
B303 2723	Grounding Plate	11- 12
B303 2724	Bracket	15- 16
B303 2725	Fixing Plate	11- 19
B303 2725	Fixing Plate	15- 22
B303 2726	Fixing Plate	15- 23
B303 2726	Fixing Plate	11- 18
B303 2727	Sensor Bracket	13- 12
B303 2729	Cushion - 30x38	7- 9
B303 2729	Cushion - 30x38	15- 21
B303 2729	Cushion - 30x38	11- 17
B303 2732	Paper Tray Shaft Bracket	15- 1
B303 2732	Paper Tray Shaft Bracket	11- 3
B303 2734	Paper Stopper	15- 5
B303 2735	Paper Tray Base Plate	15- 3
B303 2735	Paper Tray Base Plate	11- 2
B303 2737	Weight Plate	11- 4
B303 2737	Weight Plate	15- 4
B303 2742	Bracket	15- 6
B303 2742	Bracket	11- 5
B303 2743	Bracket	15- 18
B303 2743	Bracket	11- 14
B303 2744	Paper Actuator	15- 19
B303 2744	Paper Actuator	11- 15
B303 2745	Spring Plate	15- 17
B303 2745	Spring Plate	11- 13
B303 2751	Paper Lift Shaft - 2.5K	15- 20
B303 2761	Tightener Bracket	15- 8
B303 2771	Front Side Fence	13- 3
B303 2775	Rear Side Fence	13- 6
B303 2777	Paper Guide Mylar	9- 4
B303 2777	Paper Guide Mylar	13- 2
B303 2781	Paper Guide Fence	13- 16
B303 2781	Paper Guide Fence	9- 15
B303 2782	Knob Screw	13- 14
B303 2782	Knob Screw	9- 16

Part No.	Description	Page and Index No.
B303 2783	Guide Fence Bracket	13- 17
B303 2783	Guide Fence Bracket	9- 18
B303 2784	Rubber Tube - 2x4x32	9- 17
B303 2784	Rubber Tube - 2x4x32	13- 15
B303 2785	Tab Paper End Fence	31- 9
B303 2791	Oil Dumper	15- 24
B303 2792	Oil Dumper Bracket	15- 25
B303 2800	Upper & Middle Paper Tray - A4	9- *
B303 2801	Upper & Middle Paper Tray - LT	9- *
B303 2821	Front Guide Plate	9- 5
B303 2822	Upper Cover	9- 20
B303 2851	Paper Lift Shaft - 1K	11- 16
B303 2872	Front Side Fence	9- 2
B303 2875	Rear Side Fence	9- 6
B303 2877	Knob Screw	9- 3
B303 2877	Knob Screw	13- 19
B303 2886	Sensor Bracket	9- 12
B303 2887	Paper Size Actuator	9- 10
B303 2888	Paper Size Lever	9- 9
B303 2889	Spring Plate	9- 11
B303 2895	4th Guide Fence Stopper	9- 21
B303 2895	Guide Fence Stopper	33- 8
B303 2896	5th Guide Fence Stopper	9- 21
B303 3610	Guide Plate	21- 7
B303 3615	Guide Plate	21- 1
B303 3620	Guide Plate	25- 9
B303 3625	Guide Plate	25- 10
B303 3630	Guide Plate	23- 10
B303 3635	Guide Plate	23- 14
B303 3640	Guide Plate	23- 1
B303 3645	Guide Plate	25- 6
B303 3650	Support Stay	21- 5
B303 3660	Support Stay	23- 21
B303 3670	Hinge Bracket	23- 9
B303 3676	Exit Sensor Cover	23- 4

Part No.	Description	Page and Index No
B303 3681	Linkage Bracket	27- 9
B303 3682	Misfeed Removal Knob	21- 11
B303 3682	Misfeed Removal Knob	23- 11
B303 3684	Collar - 6.1x10x8	27- 11
B303 3810	Front Side Plate	25- 11
B303 3820	Rear Side Plate	25- 13
B303 3830	Upper Support Stay	21- 9
B303 3830	Upper Support Stay	25- 14
B303 3901	Air Block Plate	23- 19
B303 3903	Seal - 398x38x10	23- 20
B303 5100	Interface Board	17- *
B303 5100	Interface Board	29- 27
B303 5300	Relay Harness	29- 25
B303 5301	Relay Harness	29- 26
B303 5302	Relay Harness	29- 24
B303 5304	Motor Signal Harness	29- 30
B303 5306	Lift Motor Harness	29- 32
B303 5307	Clutch Harness	29- 31
B303 5311	Sensor Harness	29- 20
B303 5312	Sensor Harness	29- 21
B303 5313	Sensor Harness	29- 22
B303 5315	Sensor Harness	23- 5
B303 5316	Door Switch Harness	29- 19
B303 5316	Door Switch Harness	31- 23
B303 5316	Door Switch Harness	29- 28
B303 5317	Interlock Harness	31- 24
B303 5317	Interlock Harness	29- 34
B303 5319	Sensor Harness	29- 23
B303 5320	Relay Harness	29- 17
B303 5322	Relay Harness	29- 18
B303 5323	Feed Unit Harness	17- 2

Part No.	Description	Page and Index No.
AA04 3907	Timing Belt - S3M810	27- 7
AA04 3908	Timing Belt - S3M1299	27- 1
AA04 3909	Timing Belt - B100S5M780	15- 13
AA04 3910	Timing Belt - B100S5M435	11- 7
AA04 3911	Timing Belt - S3M420	27- 17
AA06 0575	Release Spring	19- 21
AA06 0813	Lock Spring	33- 16
AA06 0814	Lock Spring	31- 12
AA06 0816	Pressure Spring	17- 17
AA06 0817	Tighten Spring	27- 10
AA06 0817	Tighten Spring	15- 10
AA06 0820	Release Spring	23- 13
AA06 0826	Release Spring	17- 11
AA06 0830	Tighten Spring	29- 16
AA06 0830	Tighten Spring	27- 13
AA06 0834	Reverse Pressure Spring - 55gf	19- 16
AA06 3605	Pressure Spring	29- 10
AA06 3852	Pressure Spring	25- 4
AA06 3852	Pressure Spring	19- 3
AA06 3852	Pressure Spring	21- 3
AA06 3852	Pressure Spring	23- 18
AA08 0034	Bushing - 4x5x7	21- 2
AA08 0034	Bushing - 4x5x7	23- 17
AA08 0034	Bushing - 4x5x7	19- 4
AA08 0034	Bushing - 4x5x7	25- 3
AA08 2046	Bushing - 6x12x6	19- 10
AA08 2070	Bushing - 8x16x7	17- 24
AA08 2070	Bushing - 8x16x7	21- 13
AA08 2070	Bushing - 8x16x7	23- 23
AA08 2096	Bushing - 8x12x7	11- 10
AA08 2096	Bushing - 8x12x7	15- 15
AA08 3015	Roller Clutch	17- 19
AA14 0798	Drive Shaft	27- 20
AA14 0799	Feed Roller Shaft	17- 23
AA14 3037	Development Cover Screw	25- 1

Part No.	Description	Page and Index No.
AA14 3074	Stepped Screw - M4x5	13- 13
AA14 3074	Stepped Screw - M4x5	9- 14
AA14 3403	Stepped Screw - 8x14x2.8	33- 7
AA14 3444	Stepped Screw	27- 8
AB01 1391	Driven Reverse Gear - 21Z	19- 17
AB01 1392	Drive Reverse Gear - 24Z	19- 6
AB01 3000	Idler Gear - 18z	27- 15
AB01 3000	Idler Gear - 18Z	17- 14
AB01 3654	Gear - 30Z	27- 19
AB01 3775	Gear - 33Z	19- 13
AB01 3776	Gear - 30Z	19- 11
AB01 4140	Gear - 24Z	15- 14
AB01 4141	Pulley - 36Z/24T	27- 16
AB01 4142	Pulley - 30Z/20T	27- 18
AB01 4143	Pulley - 30Z/22T	27- 5
AB01 4152	Gear - 32Z	17- 3
AB01 4152	Gear - 32Z	23- 8
AB03 0548	Pilley - 16T	11- 8
AB03 0548	Pulley - 16T	15- 9
AB03 0647	Timing Pulley - 22T	27- 3
AB03 0648	Timing Pulley - 27T	27- 21
AB03 0649	Timing Pulley - 24T	27- 6
AB03 0653	Pulley - 23T	27- 2
AB03 0665	Idler Pulley - 18Z	29- 33
AB03 0665	Idler Pulley - 18Z	27- 4
AB03 0673	Pulley - 34Z	29- 12
AF02 0485	Transport Drive Roller	17- 16
AF02 0486	Transport Drive Roller	21- 8
AF02 0487	Transport Drive Roller	25- 7
AF02 0487	Transport Drive Roller	23- 3
AF02 0488	Transport Drive Roller	23- 7
AF02 0489	Transport Relay Roller	23- 16
AF02 0489	Transport Relay Roller	21- 4
AF02 0489	Transport Relay Roller	25- 5
AF02 0489	Transport Relay Roller	19- 5

Part No.	Description	Page and Index No.
AF03 0041	Pick-up Roller - Bypass Feed	17- 20
AF03 1041	Feed Roller - Bypass Feed	17- 25
AF03 2041	Separation Roller - Bypass Feed	19- 24
AG05 0067	Knob - Transport Roller	31- 5
AG07 1010	Magnet Catch	31- 21
AH01 2014	Caster - 60kgf	33- 14
AH01 3002	Leveling Shoe	33- 13
AW01 0049	Photo Reflection Sensor	23- 6
AW01 0049	Photo Reflection Sensor	17- 6
AW02 0056	Photointerruptor - EE-SX4235A-P1	29- 3
AW02 0056	Photointerruptor - EE-SX4235A-P1	17- 8
AX04 0118	Lift Motor - DC 14W	29- 9
AX06 0190	Transport Motor - DC32W	29- 13
AX20 0176	Magnetic Clutch	17- 15
AX21 0072	Electro Magnetic Clutch	29- 8
AX21 0073	Electro Magnetic Clutch	17- 13
H510 5001	Push Switch	31- 20
H515 5054	Paper Size Sensor	29- 6

Part No.	Description	Page and Index No
A048 2955	Decal- Manual Feed	9- 8
A048 2955	Decal- Manual Feed	13- 7
A134 2868	Solenoid Bracket	17- 12
A229 2692	Damping Insulation	19- 2
A229 5496	Lower Harness	19- 18
A229 6306	Reverse Drive Shaft	19- 7
A229 6307	Reverse Driven Shaft	19- 22
A232 3566	Ball Bearing - 8x16x5	17- 4
A232 3566	Ball Bearing - 8x16x5	21- 10
A232 3566	Ball Bearing - 8x16x5	23- 2
A232 3566	Ball Bearing - 8x16x5	25- 2
A247 2900	Torque Limiter - 53mnm	19- 23
A248 6167	DC Motor - 19.2W	29- 5
A335 4351	Guide Roller	15- 12
A335 4351	Guide Roller	11- 9
A353 2243	Lever Knob	23- 15
A499 1378	Stepped Screw - M4x6	9- 13
A507 1096	Philips Screw - M5x6	33- 15
A606 1595	Small Door Cover	7- 15
A659 5390	Grounding Harness - Drawer	29- 29
A667 2656	Friction Pad	15- 2
A667 2656	Friction Pad	11- 1
A667 2660	Belt Stopper	15- 7
A667 2660	Belt Stopper	11- 6
A680 4223	Cushion	25- 8

Part No.	Description	Page and Index No.
5215 2621	Snap Ring - M6	21- 6
5215 2621	Snap Ring - M6	23- 22
5424 1064	Screw Stand	33- 12
5446 2560	Cushion - Paper Tray	31- 15
5447 2681	Snap Ring	7- 16
5447 2681	Snap Ring	17- 21
5447 2681	Snap Ring	19- 25
5447 2681	Snap Ring	27- 12
5447 2706	Gear - 15T	17- 22

Part No.	Description	Page and Index No.
0313 0040B	Philips Pan Head Screw - M3x4	23-104
0353 0040B	Screw - M3X4	19-110
0353 0040B	Screw - M3X4	17-103
0450 4008B	Tapping Screw - 4x8	7-104
0450 4008B	Tapping Screw - 4x8	31-107
0450 4010B	Tapping Screw - 4x10	29-107
0450 4010B	Tapping Screw - 4x10	15-107
0450 4014W	Tapping Screw - M4x14	15-101
0450 4014W	Tapping Screw - M4x14	11-101
0451 3008B	Tapping Screw - M3x8	29-106
0451 3008B	Tapping Screw - M3x8	15-103
0451 3008B	Tapping Screw - M3x8	11-103
0451 4008B	Philips Tapping Screw - M4x8	17-101
0451 4008B	Philips Tapping Screw - M4x8	33-101
0451 4008B	Philips Tapping Screw - M4x8	25-103
0451 4008B	Philips Tapping Screw - M4x8	31-101
0451 4008B	Philips Tapping Screw - M4x8	23-102
0451 4008B	Philips Tapping Screw - M4x8	21-103
0451 4008B	Philips Tapping Screw - M4x8	15-102
0451 4008B	Philips Tapping Screw - M4x8	13-101
0451 4008B	Philips Tapping Screw - M4x8	7-102
0451 4008B	Philips Tapping Screw - M4x8	9-101
0451 4008B	Philips Tapping Screw - M4x8	29-102
0451 4008B	Philips Tapping Screw - M4x8	19-103
0451 4008B	Philips Tapping Screw - M4x8	11-102
0451 4008H	Tapping Screw - 4x8	7-101
0451 4010B	Tapping Screw - 4x10	31-106
0451 4012H	Tapping Screw - 4x12	7-103
0453 4008B	Tapping Bind Screw - M4x8	33-102
0453 4008B	Tapping Bind Screw - M4x8	31-104
0573 0030E	Hexagon Headless Set Screw - M3x3	19-105
0633 0140G	Parallel Pin - 3x14	11-105
0633 0140G	Parallel Pin - 3x14	15-105
0707 8040B	Bushing - 8x4mm	27-106
0707 8040B	Bushing - 8x4mm	29-112

Part No.	Description	Page and Index No.
0720 0030E	Retaining Ring - M3	23-103
0720 0030E	Retaining Ring - M3	21-102
0720 0030E	Retaining Ring - M3	25-101
0720 0030E	Retaining Ring - M3	19-101
0720 0040E	Retaining Ring - M4	31-103
0720 0040E	Retaining Ring - M4	27-103
0720 0040E	Retaining Ring - M4	19-102
0720 0060E	Retaining Ring - M6	17-102
0720 0060E	Retaining Ring - M6	11-104
0720 0060E	Retaining Ring - M6	29-103
0720 0060E	Retaining Ring - M6	19-104
0720 0060E	Retaining Ring - M6	15-104
0720 0060E	Retaining Ring - M6	21-101
0720 0060E	Retaining Ring - M6	31-102
0720 0060E	Retaining Ring - M6	25-102
0720 0060E	Retaining Ring - M6	23-101
0720 0060E	Retaining Ring - M6	27-101
0720 0080E	Retaining Ring - M8	29-105
0727 0080E	Retaining Ring - M8	29-110
0740 3008	Ball Bearing - 8x22x7	27-102
0741 3808	Ball Bearing - 8x16x5mm	27-105
0741 3808	Ball Bearing - 8x16x5mm	29-111
0801 0150	Philips Screw - M4x8	29-108
0802 5282	Tapping Screw - M4x8	13-102
0802 5282	Tapping Screw - M4x8	9-102
0802 5282	Tapping Screw - M4x8	11-106
0802 5282	Tapping Screw - M4x8	15-108
0802 5282	Tapping Screw - M4x8	15-106
0805 0088	Retaining Ring - M6	17-104
0805 3145	Ball Bearing - 6x12x4mm	19-106
0805 3270	Ball Bearing - 8x16x5mm	31-105
1102 0915	Connector - 10P	17-101
1102 5301	Connector - 2P	17-102
1102 5303	Connector - 4P	17-103
1102 6249	Relay Connector - 6P	31-109

Part No.	Description	Page and Index No.
1102 6254	Connector - 11P	31-108
1102 6259	Connector - 2P	19-108
1102 6283	Connector - 2P	19-111
1102 6283	Connector - 2P	17-106
1102 6295	Connector - 2P	17-104
1102 6296	Connector - 3P	17-105
1102 6299	Connector - 6P	17-106
1102 6300	Connector - 7P	17-107
1102 6301	Connector - 8P	17-108
1102 6304	Connector - 11P	17-109
1102 6305	Connector - 12P	17-110
1102 6306	Connector - 13P	17-111
1102 6309	Connector - 2P	17-112
1102 6313	Connector - 6P	17-113
1102 6315	Connector - 8P	17-114
1102 6318	Connector - 11P	17-115
1102 6319	Connector - 12P	17-116
1102 6320	Connector - 13P	17-117
1105 0199	Clamp	19-109
1105 0267	Harness Clamp - YMC-10-0	17-105
1105 0267	Harness Clamp - YMC-10-0	27-104
1105 0267	Harness Clamp - YMC-10-0	25-104
1105 0267	Harness Clamp - YMC-10-0	19-107
1105 0267	Harness Clamp - YMC-10-0	29-104
1105 0291	Harness Clamp - LWS-3S	29-101
1105 0291	Harness Clamp - LWS-3S	33-103
1105 0310	Harness Clamp - LWS-1S	29-109
1105 0310	Harness Clamp - LWS-1S	25-106
1105 0358	Edge Saddle - EDS-0607M	25-105
1109 0015	Circuit Protector - SMD050	17-118
1109 0016	Circuit Protector - SMD075	17-119
1400 0555	Transistor - DTC143EK	17-120
1402 0688	Diode	17-121
1402 1378	Diode - PTZ12A	17-122
1407 1535	IC - TD62308AP	17-123

Part No.	Description	Page and Index No.
1407 2187	TTLIC - SN74LS07NS	17-124
1407 2231	IC - TD62308AF	17-125
1407 3168	IC - TC74HC251AF	17-126
1407 3173	Driver - 16bit - M66311FP	17-127
1407 3257	CMOSIC - TC74HC14AF	17-128
1407 5002	IC - M66310FP	17-129
1408 0827	IC - TA8429H	17-130
1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/1	17-131
1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16	17-132
1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/1	17-133
1631 0000	Resistor - 0 Ω 1/4W	17-134
1634 0000	Resistor - 0 Ω 1/16W	17-135
1640 5470	Capacitor - 47 μ F $\pm$ 20% 50V	17-136
1660 2150	Capacitor - 15pF $\pm$ 5% 50V	17-137
1660 2471	Capacitor - 470pF - $\pm$ 5% -	17-138
1660 4102	Capacitor - 1000pF $\pm$ 10% 50	17-139
1660 4103	Capacitor - 10000pF - $\pm$ 10%	17-140

Part No.	Description	Page and Index No