

Bridge Unit BU5000 (D379)

Bridge Unit BU5000 (D379)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Bridge Unit 1 (D379)	2
2.Bridge Unit 2 (D379)	4
3.Bridge Unit 3 (D379)	6
4.Bridge Unit 4 (D379)	8
5.Bridge Unit 5 (D379)	10
6.Bridge Unit 6 (D379)	12
7.Bridge Unit 7 (D379)	14
Parts Index.....	18

January 15, 2009

1. Bridge Unit 1 (D379)




1.Bridge Unit 1 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B835 2977	Timing Belt - B40S2M150	1
2	D379 3909	Bracket:Stepper Motor:	
		Vertical Transport:Entrance	1
3	AA16 1122	Motor Cushion	1
4	AX04 0157	Stepper Motor DC1.68V 6.7W	1
5	D379 4575	Decal:Paper Tray:Coupling	1
6	D379 3200	Transport Unit:Vertical Transport:Right:Ass'y	1
7	D379 1316	Inner Cover:Right Upper	1
8	D355 3899	Lever:Misfeed Removal	1
9	D379 3893	Decal:Lever:Operate:Display:U8	1
10	D379 1318	Decal:Knob:Transport:Right	1
11	D355 3846	Knob:Misfeed Removal	1
12	D379 1317	Inner Cover:Right Lower	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 4008Q	Tapping Screw - M4x8	
102	0451 4008N	Tapping Screw:4x8	
103	0314 0080N	Philips Pan Head Screw - M4x8	
104	0954 4010N	Screw:Polished Round/Spring:M4x10	
105	0453 3008N	Binding Self Tapping Screw:3x8	
106	1102 6249	Relay Connector - 6P	

2.Bridge Unit 2 (D379)




2.Bridge Unit 2 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D355 5311	Harness:Sensor:Transport:Ass'y	1
2	D379 3989	Cover:Driven Roller	1
3	AW01 0122	Paper Feed Sensor	1
4	D379 3225	Handle:Vertical Transport:Right Upper:Ass'y	1
5	AA08 2070	Bushing - 8x16x7	2
6	5215 2621	Snap Ring - M6	3
7	D355 3565	Handle:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 4008Q	Tapping Screw - M4x8	
102	1105 0511	Harness Clamp - LWS-0306ZC	

3.Bridge Unit 3 (D379)




3.Bridge Unit 3 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA06 6675	Compression Spring	6
2	AA08 4059	Ball Bearing Holder	6
3	D355 3803	Transport Roller:Driven	3
4	D379 3925	Guide Plate:Vertical Transport:Exit: Right Upper:Peen	1
5	D379 3913	Guide Plate:Vertical Transport:Exit:Right Lower	1
6	D379 3922	Guide Plate:Vertical Transport:Right Upper:Peen	1
7	D379 3912	Bracket:Guide Plate:Roller:Receive	1
8	D379 3920	Guide Plate:Vertical Transport:Right Middle:Peen	1
9	D355 3857	Tension Spring:Guide Plate:12N	1
10	D355 3828	Holder:Stay:Guide Plate	2
11	D355 3897	Screw:M4:3M	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 4008Q	Tapping Screw - M4x8	
102	0451 4008N	Tapping Screw:4x8	

4. Bridge Unit 4 (D379)




4.Bridge Unit 4 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D355 5306	Harness:Sensor:Connecting:Entrance:Ass'y	1
2	D355 3998	Bracket:Sensor:Transport	2
3	AW01 0122	Paper Feed Sensor	2
4	D379 3910	Guide Plate:Vertical Transport: Entrance:Right Lower:Peen	1
5	D355 5311	Harness:Sensor:Transport:Ass'y	2
6	AA06 6675	Compression Spring	2
7	AA08 4059	Ball Bearing Holder	2
8	D355 3803	Transport Roller:Driven	1
9	D379 3915	Guide Plate:Vertical Transport: Entrance:Right Upper:Peen	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 4008Q	Tapping Screw - M4x8	
102	0451 4008N	Tapping Screw:4x8	
103	1105 0511	Harness Clamp - LWS-0306ZC	
104	1105 0534	Clamp	

5.Bridge Unit 5 (D379)




5.Bridge Unit 5 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D379 1196	Timing Belt:60S2M250	1
2	A356 2748	Spacer - 0.5mm	2
3	AB01 7304	Pulley - 25Z	2
4	B234 6507	Timing Pulley - 25T	2
5	D355 3817	Gear:Drive:Grip:Z22	1
6	D379 3924	Transport Roller:Vertical Transport:Right	1
7	D379 3936	Transport Roller:Vertical Transport:Right	2
8	D379 3935	Transport Roller:Vertical Transport:Right Lower	1
9	B234 6506	Timing Pulley - 30T	5
10	D379 1195	Timing Belt:60S2M202	1
11	D355 1197	Timing Belt:60S2M286	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 4008Q	Tapping Screw - M4x8	
102	0720 0060E	Retaining Ring - M6	
103	0741 3708	Ball Bearing - 8x12x3.5mm	
104	0742 3808	Ball Bearing - 8x16x5	

6.Bridge Unit 6 (D379)




6.Bridge Unit 6 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D379 3966	Decal:Grip:Horizontal:Transport	1
2	D379 3965	Cover:Guide Plate:Transport Unit	1
3	D355 3998	Bracket:Sensor:Transport	1
4	AW01 0122	Paper Feed Sensor	1
5	D379 3967	Hinge:Damper:UDH-AHS	1
6	D379 4831	Tension Spring:Pressure:Driven:3.3N	6
7	B234 4858	Driven Roller Holder	6
8	D355 3803	Transport Roller:Driven	3
9	D379 3997	Ground Plate:Transport Unit	1
10	D379 3970	Guide Plate:Transport Unit:Horizontal:Upper:Peen	1
11	B512 1078	Positioning Pin:Guide:Rear	1
12	D379 3955	Bracket:Slide Rail:Transport Unit:Left:Welding	1
13	D379 3940	Bracket:Hinge:Fix:Right:Peen	1
14	D379 3946	Bracket:Cover:Install	1
15	D379 3954	Bracket:Slide Rail:Transport Unit:Right	1
16	B512 1079	Positioning Pin:Guide:Front	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0450 4008N	Tapping Screw - M4x8	
103	0454 4008Q	Tapping Screw - M4x8	
104	0453 4008N	Binding Self Tapping Screw:4x8	
105	1105 0534	Clamp	
106	1105 0522	Edge Saddle - LES0510	

7. Bridge Unit 7 (D379)



7. Bridge Unit 7 (D379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D379 3963	Guide Plate:Transport Unit:Horizontal:Lower	1
2	D379 3975	Transport Roller:Transport Unit:Ass'y	1
3	D379 3976	Transport Roller:Transport Unit	2
4	D379 1198	Timing Belt:60S2M312	2
5	B234 6507	Timing Pulley - 25T	4
6	D379 3951	Bracket:Drawer:Connector	1
7	A659 1272	Door Catch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0453 3008N	Binding Self Tapping Screw:3x8	
103	1102 9432	Connector:Drawer	
104	0720 0060E	Retaining Ring - M6	
105	0742 3808	Ball Bearing - 8x16x5	
106	1105 0522	Edge Saddle - LES0510	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D379 1195	Timing Belt:60S2M202	11 - 10
D379 1196	Timing Belt:60S2M250	11 - 1
D379 1198	Timing Belt:60S2M312	15 - 4
D379 1316	Inner Cover:Right Upper	3 - 7
D379 1317	Inner Cover:Right Lower	3 - 12
D379 1318	Decal:Knob:Transport:Right	3 - 10
D379 3200	Transport Unit:Vertical Transport:Right:Ass'y	3 - 6
D379 3225	Handle:Vertical Transport:Right Upper:Ass'y	5 - 4
D379 3893	Decal:Lever:Operate:Display:U8	3 - 9
D379 3909	Bracket:Stepper Motor:Vertical Transport:Entrance	3 - 2
D379 3910	Guide Plate:Vertical Transport:Entrance: Right Lower:Peen	9 - 4
D379 3912	Bracket:Guide Plate:Roller:Receive	7 - 7
D379 3913	Guide Plate:Vertical Transport:Exit:Right Lower	7 - 5
D379 3915	Guide Plate:Vertical Transport:Entrance: Right Upper:Peen	9 - 9
D379 3920	Guide Plate:Vertical Transport:Right Middle:Peen	7 - 8
D379 3922	Guide Plate:Vertical Transport:Right Upper:Peen	7 - 6
D379 3924	Transport Roller:Vertical Transport:Right	11 - 6
D379 3925	Guide Plate:Vertical Transport:Exit:Right Upper:Peen	7 - 4
D379 3935	Transport Roller:Vertical Transport:Right Lower	11 - 8
D379 3936	Transport Roller:Vertical Transport:Right	11 - 7
D379 3940	Bracket:Hinge:Fix:Right:Peen	13 - 13
D379 3946	Bracket:Cover:Install	13 - 14
D379 3951	Bracket:Drawer:Connector	15 - 6
D379 3954	Bracket:Slide Rail:Transport Unit:Right	13 - 15
D379 3955	Bracket:Slide Rail:Transport Unit:Left:Welding	13 - 12
D379 3963	Guide Plate:Transport Unit:Horizontal:Lower	15 - 1
D379 3965	Cover:Guide Plate:Transport Unit	13 - 2
D379 3966	Decal:Grip:Horizontal:Transport	13 - 1
D379 3967	Hinge:Damper:UDH-AHS	13 - 5
D379 3970	Guide Plate:Transport Unit:Horizontal:Upper:Peen	13 - 10
D379 3975	Transport Roller:Transport Unit:Ass'y	15 - 2
D379 3976	Transport Roller:Transport Unit	15 - 3
D379 3989	Cover:Driven Roller	5 - 2

Part No.	Description	Page and Index No.
D379 3997	Ground Plate:Transport Unit	13 - 9
D379 4575	Decal:Paper Tray:Coupling	3 - 5
D379 4831	Tension Spring:Pressure:Driven:3.3N	13 - 6

Part No.	Description	Page and Index No.
A356 2748	Spacer - 0.5mm	11 - 2
A659 1272	Door Catch	15 - 7
B234 4858	Driven Roller Holder	13 - 7
B234 6506	Timing Pulley - 30T	11 - 9
B234 6507	Timing Pulley - 25T	15 - 5
B234 6507	Timing Pulley - 25T	11 - 4
B512 1078	Positioning Pin:Guide:Rear	13 - 11
B512 1079	Positioning Pin:Guide:Front	13 - 16
B835 2977	Timing Belt - B40S2M150	3 - 1
D355 1197	Timing Belt:60S2M286	11 - 11
D355 3565	Handle:Ass'y	5 - 7
D355 3803	Transport Roller:Driven	7 - 3
D355 3803	Transport Roller:Driven	13 - 8
D355 3803	Transport Roller:Driven	9 - 8
D355 3817	Gear:Drive:Grip:Z22	11 - 5
D355 3828	Holder:Stay:Guide Plate	7 - 10
D355 3846	Knob:Misfeed Removal	3 - 11
D355 3857	Tension Spring:Guide Plate:12N	7 - 9
D355 3897	Screw:M4:3M	7 - 11
D355 3899	Lever:Misfeed Removal	3 - 8
D355 3998	Bracket:Sensor:Transport	9 - 2
D355 3998	Bracket:Sensor:Transport	13 - 3
D355 5306	Harness:Sensor:Connecting:Entrance:Ass'y	9 - 1
D355 5311	Harness:Sensor:Transport:Ass'y	9 - 5
D355 5311	Harness:Sensor:Transport:Ass'y	5 - 1

Part No.	Description	Page and Index No.
AA06 6675	Compression Spring	9 - 6
AA06 6675	Compression Spring	7 - 1
AA08 2070	Bushing - 8x16x7	5 - 5
AA08 4059	Ball Bearing Holder	7 - 2
AA08 4059	Ball Bearing Holder	9 - 7
AA16 1122	Motor Cushion	3 - 3
AB01 7304	Pulley - 25Z	11 - 3
AW01 0122	Paper Feed Sensor	9 - 3
AW01 0122	Paper Feed Sensor	5 - 3
AW01 0122	Paper Feed Sensor	13 - 4
AX04 0157	Stepper Motor DC1.68V 6.7W	3 - 4

Part No.	Description	Page and Index No.
0314 0080N	Philips Pan Head Screw - M4x8	3 - 103
0450 4008N	Tapping Screw - M4x8	13 - 102
0451 4008N	Tapping Screw:4x8	3 - 102
0451 4008N	Tapping Screw:4x8	15 - 101
0451 4008N	Tapping Screw:4x8	7 - 102
0451 4008N	Tapping Screw:4x8	13 - 101
0451 4008N	Tapping Screw:4x8	9 - 102
0453 3008N	Binding Self Tapping Screw:3x8	15 - 102
0453 3008N	Binding Self Tapping Screw:3x8	3 - 105
0453 4008N	Binding Self Tapping Screw:4x8	13 - 104
0454 4008Q	Tapping Screw - M4x8	11 - 101
0454 4008Q	Tapping Screw - M4x8	13 - 103
0454 4008Q	Tapping Screw - M4x8	3 - 101
0454 4008Q	Tapping Screw - M4x8	9 - 101
0454 4008Q	Tapping Screw - M4x8	7 - 101
0454 4008Q	Tapping Screw - M4x8	5 - 101
0720 0060E	Retaining Ring - M6	11 - 102
0720 0060E	Retaining Ring - M6	15 - 104
0741 3708	Ball Bearing - 8x12x3.5mm	11 - 103
0742 3808	Ball Bearing - 8x16x5	11 - 104
0742 3808	Ball Bearing - 8x16x5	15 - 105
0954 4010N	Screw:Polished Round/Spring:M4x10	3 - 104
1102 6249	Relay Connector - 6P	3 - 106
1102 9432	Connector:Drawer	15 - 103
1105 0511	Harness Clamp - LWS-0306ZC	9 - 103
1105 0511	Harness Clamp - LWS-0306ZC	5 - 102
1105 0522	Edge Saddle - LES0510	15 - 106
1105 0522	Edge Saddle - LES0510	13 - 106
1105 0534	Clamp	13 - 105
1105 0534	Clamp	9 - 104

Part No.	Description	Page and Index No.
5215 2621	Snap Ring - M6	5 - 6