

Scanner Accessibility

Option Type C5502 (D647)

Scanner Accesibility Option Type C5502 (D647)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

1.Scanner Accesibility Option Type C5502 (D647).	2
Parts Index	5

January 10, 2012

1.Scanner Accesibility Option Type C5502 (D647)



1.Scanner Accesibility Option Type C5502 (D647)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D144 1342	Cover:Upper:Rear:Option	1
2	D144 1345	Cover:Upper:Right:Option	1
3	D647 1826	Cover:Option:Scanner:Rear:lg	1
4	D647 5235	Harness:Scanner:Separation:NA:Ass'y	1
4	D647 5236	Harness:Scanner:Separation:EU:Ass'y	1
5	D647 1348	Cover:Front Right:Scanner:Separation	1
6	D647 1090	Bracket:Cover:Left:Scanner	1
7	D647 1370	Cap:DIA17:ldg	3
8	G570 1540	Rubber Foot H=10	3
9	G570 1543	Spacer - Adjusting Screw	2
10	AA14 3829	Adjusting Screw:Scanner	2
11	AA14 3842	Screw:DIA6:14.5:M4	1
12	B223 1824	Seal:Scanner:Frame:Base	1
13	B862 1242	Stopper:Hinge:Right	1
14	B838 1822	Bracket:Cover:Left Lower	1
15	D647 8441	Cover:Ferrite Core:Option:Ass'y	1
16	D009 1822	Bracket:Option:Right	1
17	B838 1823	Bracket:Cover:Rear Lower	1
18	B838 1261	Bracket:Key Counter:Rear	2
19	B838 1269	Bracket:Left Rear:Option	1
20	B838 1832	Shielding Plate:Base:1	1
21	B838 1833	Shielding Plate:Base:2	1
22	B862 1241	Stopper:Hinge:Left	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	0451 4008N	Tapping Screw:4x8	
104	0451 4016N	Tapping Screw:4x16	
105	0450 3008N	Tapping Screw - M3x8	
106	0453 3006N	Tapping Screw - M3x6	
107	0454 3006Q	Tapping Screw - M3x6	
108	0954 4008N	Screw - M4X8	
109	1105 0428	Clamp	
110	1105 0488	Harness Clamp	
111	1105 0521	Clamp - LES-1017	
112	1607 0622	Ferrite Core Tfc16816	
112	1607 1460	Ferrite Core:Rfc-9	
112	1607 1461	Ferrite Core	
112	1607 1461	Ferrite Core	
112	1607 1715	Ferrite Core - Rfc-5	
112	1607 1929	Ferrite Core:Tfcm-41-27-16	
113	1005 0503	Clamp Wire	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D647 1090	Bracket:Cover:Left:Scanner	3 - 6
D647 1348	Cover:Front Right:Scanner:Separation	3 - 5
D647 1370	Cap:DIA17:Idg	3 - 7
D647 1826	Cover:Option:Scanner:Rear:Ig	3 - 3
D647 5235	Harness:Scanner:Separation:NA:Ass'y	3 - 4
D647 5236	Harness:Scanner:Separation:EU:Ass'y	3 - 4
D647 8441	Cover:Ferrite Core:Option:Ass'y	3 - 15

Part No.	Description	Page and Index No.
B223 1824	Seal:Scanner:Frame:Base	3 - 12
B838 1261	Bracket:Key Counter:Rear	3 - 18
B838 1269	Bracket:Left Rear:Option	3 - 19
B838 1822	Bracket:Cover:Left Lower	3 - 14
B838 1823	Bracket:Cover:Rear Lower	3 - 17
B838 1832	Shielding Plate:Base:1	3 - 20
B838 1833	Shielding Plate:Base:2	3 - 21
B862 1241	Stopper:Hinge:Left	3 - 22
B862 1242	Stopper:Hinge:Right	3 - 13
D009 1822	Bracket:Option:Right	3 - 16
D144 1342	Cover:Upper:Rear:Option	3 - 1
D144 1345	Cover:Upper:Right:Option	3 - 2
G570 1540	Rubber Foot H=10	3 - 8
G570 1543	Spacer - Adjusting Screw	3 - 9

Part No.	Description	Page and Index No.
AA14 3829	Adjusting Screw:Scanner	3 - 10
AA14 3842	Screw:DIA6:14.5:M4	3 - 11

Part No.	Description	Page and Index No.
0450 3008N	Tapping Screw - M3x8	3 - 105
0451 3006N	Tapping Screw - 3x6	3 - 102
0451 3008N	Tapping Screw - M3x8	3 - 101
0451 4008N	Tapping Screw:4x8	3 - 103
0451 4016N	Tapping Screw:4x16	3 - 104
0453 3006N	Tapping Screw - M3x6	3 - 106
0454 3006Q	Tapping Screw - M3x6	3 - 107
0954 4008N	Screw - M4X8	3 - 108
1005 0503	Clamp Wire	3 - 113
1105 0428	Clamp	3 - 109
1105 0488	Harness Clamp	3 - 110
1105 0521	Clamp - LES-1017	3 - 111
1607 0622	Ferrite Core Tfc16816	3 - 112
1607 1460	Ferrite Core:Rfc-9	3 - 112
1607 1461	Ferrite Core	3 - 112
1607 1461	Ferrite Core	3 - 112
1607 1715	Ferrite Core - Rfc-5	3 - 112
1607 1929	Ferrite Core:Tfcm-41-27-16	3 - 112