

High Capacity Stacker (D364)

High Capacity Stacker (D364)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.










1.Electrical Section (D364).....	2
2.Paper Transport Unit (D364).....	8
3.Shift Unit (D364).....	14
4.Side Jogger (D364)	18
5.Paper Exit (D364).....	22
6.Lead Edge Jogger (D364).....	26
7.Exterior (D364)	30
8.Accessories 1 (D364).....	32
9.Accessories 2 (D364).....	34
Parts Index	38

January 29, 2009










1.Electrical Section (D364)









1.Electrical Section (D364)








1.Electrical Section (D364)










1.Electrical Section (D364)



1.Electrical Section (D364)



1.Electrical Section (D364)







1.Electrical Section (D364)







Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1000	Caster:35kg	4
2	D364 1001	Hinge:Door:Front:Stack:072M-00667	1
3	D364 5100	Set Sensor:Tray:30706430:Ass'y	1
4	D364 5101	Photointerruptor:GP1A73A:31001635	8
5	D364 1002	Tensioner:Drive:40704325:Ass'y	2
6	D364 1003	Wire:Tray:Upper Lower:Gray:072M-00787	2
7	D364 1004	Wire:Tray:Upper Lower:Black:072M-00788	2
8	D364 1005	Shaft:Transmission:Rising Tray:30706442:Ass'y	1
9	D364 1006	Synchronous Belt:1800-5GT-20:31001991	1
10	D364 1007	Timing Pulley:5GT:T36:30706446:Ass'y	2
13	D364 1009	Bracket:Wire:Rear:40704323:Ass'y	4
14	D364 1010	Shaft:Drive:Rising Tray:30706440:Ass'y	1
15	D364 5102	DC Motor:Tray:Upper Lower:072M-00913:Ass'y	1
17	D364 1011	Bracket:DC Motor:Tray Unit:30706432:Ass'y	1
18	D364 5103	Positioning Sensor:Tray:072M-00914:Ass'y	6
20	D364 1012	Holder:Tray:072M-00915:Ass'y	1
21	D364 1013	Roller:Tray:Upper Lower:41515970	6
22	D364 1014	Roller:Tray:Upper Lower:072M-00916:Ass'y	2
24	D364 1020	Radial Ball Bearing:6901ZZNR:31001987	4
25	D364 1021	Inlet:30706429:Ass'y	1
26	D364 5104	Harness:AC Power Supply:072M-00575	1
27	D364 5010	PCB:Main:Ass'y	1
28	D364 5105	Fuse Resistor:3.15A:31001815#6	1
29	D364 5106	Fuse Resistor:2A:31001815#7	1
30	D364 5109	Fuse Resistor:1A:31001815#4	1
31	D364 5107	Fuse Resistor:0.5A:31001815#8	2
32	D364 5108	Fuse Resistor:1A:31001815#5	1
34	D364 5110	Power Supply Unit:31001995	1
35	D364 5111	Safety Switch:072M-00816	1
36	D364 5112	Connector:Connection:072M-00917:Ass'y	1
37	D364 5113	Leak Breaker:072M-00918:Ass'y	1
38	D364 5114	Micro Switch:Tray:072M-00919:Ass'y	1
38-1	D364 5114	Micro Switch:Tray:072M-00919:Ass'y	1
39	D364 5115	Interface Cable:072M-00553	1
40	D364 5116	Harness:Safety Switch:072M-00920:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
41	D364 5117	Harness:Motor:Tray:Upper Lower:072M-00921	1
42	D364 5118	Harness:Power Supply Unit:072M-00555	1
43	D364 5119	Harness:Sensor:1:072M-00556	1
44	D364 5120	Harness:Sensor:2:072M-00557	1
45	D364 5121	Harness:Sensor:2-A:072M-00712	1
46	D364 5122	Harness:Sensor:3:072M-00558	1
47	D364 5123	Harness:Solenoid:072M-00564	1
48	D364 5124	Harness:Motor:1-1:072M-00567	1
49	D364 5125	Harness:Motor:2-1:072M-00570	1
50	D364 5126	Harness:Motor:3-1:072M-00572	1
51	D364 5127	Harness:Power Source:BP:072M-00577	1
52	D364 5128	Harness:DC Power Supply:072M-00578	1
53	D364 5129	Harness:Safety Switch:2-1:072M-00581	1
54	D364 5130	Harness:Operation Sub-unit:1-1:072M-00583	1
55	D364 5131	Harness:AC Power Supply:2-1:072M-00865	1
56	D364 5132	Harness:AC Power Supply:2-2:072M-00866	1
57	D364 5133	Relay:072M-00839:ASS'Y	1
58	D364 5134	Harness:Fan:2:072M-00822	1
59	D364 5135	Fan:Exhaust:DC 1.5W:072M-00980	1
60	D364 1015	Tensioner:Drive:072M-01042:Ass'y	1
61	D364 1016	Guide Roller:Door:072M-01064	1










2.Paper Transport Unit (D364)








2.Paper Transport Unit (D364)












2.Paper Transport Unit (D364)



2.Paper Transport Unit (D364)



2.Paper Transport Unit (D364)




2.Paper Transport Unit (D364)








Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1100	Transport Sub-unit:Entrance:072M-00922:Ass'y	1
2	D364 1101	Guide Plate:Proof Tray:072M-00923:Ass'y	1
3	D364 1102	Driven Roller:Exit:30705679:Ass'y	6
4	D364 5101	Photointerruptor:GP1A73A:31001635	1
5	D364 1103	Discharge Brush:Proof Tray:Exit:31001754	1
6	D364 5136	Photo Reflection Sensor:PS-117L1:31001805	3
7	D364 1104	Driven Roller:072M-00924:Ass'y	8
8	D364 1105	Bushing:Driven Roller:072M-00652	24
9	D364 1106	Compression Spring:Transport Roller:072M-0087	26
10	D364 1107	Grip:Open And Close:L2:072M-00959:Ass'y	1
11	D364 5137	Harness:Sensor:Proof Tray:072M-00768	1
12	D364 1110	Guide Plate:Entrance:072M-00925:Ass'y	1
16	D364 1111	Grip:Open And Close:L2:072M-00960:Ass'y	1
18	D364 5139	Harness:Sensor:PS-117L1:072M-00769	2
19	D364 1120	Exit Roller:Proof Tray:072M-00701	1
20	D364 1122	Radial Ball Bearing:LNR-1360X3ZZR:31001827	2
21	D364 5140	Stepper Motor:DC 8.5W:Entrance:30705685	1
22	D364 1123	Synchronous Belt:S2M172:31001992	1
23	D364 5141	Bracket:Solenoid:Gate Pawl:072M-00926:Ass'y	1
24	D364 1124	Gate Pawl:072M-00927:Ass'y	2
25	D364 1125	Transport Roller:2Koro:072M-00659	2
26	D364 1126	Transport Roller:4Koro:072M-00660	2
27	D364 1127	Transport Roller:Mechanical Roller Clutch:072M-00707	1
28	D364 1128	Knob:L3:072M-00708	1
29	D364 1129	Tensioner:Transport:072M-00928:Ass'y	1
30	D364 1130	Pulley:Idler:Tensioner:072M-00929:Ass'y	1
31	D364 1131	Radial Ball Bearing:LF-1680HH:31001989	10
32	D364 1132	Synchronous Belt:B60S3M882:072M-00684	1
33	D364 1133	Guide Plate:Connecting:072M-00930:Ass'y	1
39	D364 5111	Safety Switch:072M-00816	1
40	D364 5150	Harness:Sensor:4:072M-00559	1
41	D364 5151	Harness:Solenoid:2:072M-00565	1
42	D364 5152	Harness:Motor:2-2:072M-00571	1
43	D364 5153	Harness:Safety Switch:1-2:072M-00580	1

Index No.	Part No.	Description	Q'ty Per Assembly
44	D364 5154	Harness:Operation Sub-unit:1-2:072M-00584	1
45	D364 5155	Fan:Cross Flow:DC 6.3W:072M-00982	1
46	D364 5156	Harness:Fan:3:072M-00984	1
47	D364 5142	Solenoid:Gate Pawl:072M-01084	1
48	D364 6508	Decal:Knob:L3:072M-00898	1
49	D364 6507	Decal:Grip:L2:072M-00897	1
50	D364 6506	Decal:Grip:L1:072M-00896	1





3.Shift Unit (D364)














3.Shift Unit (D364)



3.Shift Unit (D364)



3.Shift Unit (D364)



3.Shift Unit (D364)





Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1200	Shift Tray Unit:072M-00931:Ass'y	1
2	D364 1201	Guide Plate:Exit:Shift Tray:072M-00932:Ass'y	1
3	D364 1203	Driven Roller:Exit:Front:072M-00933:Ass'y	2
4	D364 1204	Driven Roller:Exit:Inner Back: 072M-00934:Ass'y	2
5	D364 1205	Exit Roller:Shift Tray:072M-00617	1
6	D364 5136	Photo Reflection Sensor:PS-117L1:31001805	1
7	D364 1131	Radial Ball Bearing:LF-1680HH:31001989	2
8	D364 1207	Gear:Z28:31505541	1
9	D364 1208	Discharge Brush:Shift Tray:Exit:31001753	1
10	D364 1209	Holder:Exit Roller:Shift Tray:41516167	2
11	D364 1220	End Fence:Shift Tray:072M-00936	1
13	D364 5157	Optics Sensor:Paper Volume:Paper: 072M-00941:Ass'y	2
14	D364 5158	Harness:Optics Sensor:Paper Volume: 072M-00863	2
15	D364 5160	Harness:Optics Sensor:Shift Tray:072M-00861	1
16	D364 1221	Paddle:072M-00620:Ass'y	1
17	D364 1222	Pulley:S2M:T26:31504929	1
18	D364 1122	Radial Ball Bearing:LNR-1360X3ZZR:31001827	2
19	D364 1224	Stepper Motor:DC 9W:Shift:072M-00937	1
20	D364 5161	DC Stepper Motor:SHhft:072M-00938:Ass'y	1
21	D364 1225	Stepper Motor:DC 8.5W:Exit:072M-00939	1
22	D364 1226	Pulley:Slow Down:072M-00988:Ass'y	1
23	D364 5140	Stepper Motor:DC 8.5W:Entrance:30705685	1
24	D364 1227	Holder:Pulley:Slow Down:41516102	1
25	D364 1228	Synchronous Belt:S2M202:072M-00743	1
26	D364 5101	Photointerruptor:GP1A73A:31001635	1
27	D364 5170	Harness:DC Stepper Motor:Shift:072M-00745	1
28	D364 5171	Harness:Sensor:Shift:072M-00744	1
29	D364 1227	Holder:Pulley:Slow Down:41516102	1






Index No.	Part No.	Description	Q'ty Per Assembly










4.Side Jogger (D364)



4.Side Jogger (D364)





4.Side Jogger (D364)








21





5.Paper Exit (D364)



5.Paper Exit (D364)



5.Paper Exit (D364)





5.Paper Exit (D364)









Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1400	Transport Unit:Connecting:072M-00942:Ass'y	1
2	D364 1401	Stepper Motor:DC 13W:Connecting:40704305	1
3	D364 1402	Guide Plate:Connecting:072M-00943:Ass'y	1
4	D364 1104	Driven Roller:072M-00924:Ass'y	6
5	D364 1105	Bushing:Driven Roller:072M-00652	12
6	D364 1106	Compression Spring:Transport Roller: 072M-00873	12
7	D364 1406	Grip:L4:072M-00961:Ass'y	1
8	D364 5139	Harness:Sensor:PS-11711:072M-00769	1
9	D364 1410	Guide Plate:Exit:072M-00944:Ass'y	1
10	D364 5136	Photo Reflection Sensor:PS-117L1:31001805	1
14	D364 1403	Grip:L5:072M-00962:Ass'y	1
15	D364 1103	Discharge Brush:Proof Tray:Exit:31001754	1
16	D364 1125	Transport Roller:2Koro:072M-00659	2
17	D364 1126	Transport Roller:4Koro:072M-00660	2
18	D364 1412	Gear:Coupling:072M-00945:Ass'y	1
19	D364 1413	Pulley:Idler:T30/Z28:072M-00946:Ass'y	1
20	D364 1130	Pulley:Idler:Tensioner:072M-00929:Ass'y	1
21	D364 1135	Tensioner:Transport:072M-01085:Ass'y	1
22	D364 1417	Synchronous Belt:B60S3M1050:072M-00665	1
23	D364 1131	Radial Ball Bearing:LF-1680HH:31001989	8
24	D364 5190	Harness:Sensor:6:072M-00561	1
25	D364 5191	Harness:Motor:1-3:072M-00569	1
26	D364 5192	Harness:Optics Sensor:2:072M-00979	1
27	D364 6510	Decal:Grip:L5:072M-00900	1
28	D364 6509	Decal:Grip:L4:072M-00899	1

Index No.	Part No.	Description	Q'ty Per Assembly













6. Lead Edge Jogger (D364)



6. Lead Edge Jogger (D364)



6. Lead Edge Jogger (D364)




6.Lead Edge Jogger (D364)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1500	Jogger:Lengthwise:Uniform:072M-00947:Ass'y	1
2	D364 5172	Stepper Motor:DC 9W:Jogger:30705698	1
3	D364 1510	Stopper:Leading Edge:072M-00627	2
4	D364 1511	Slider:Stopper:Leading Edge:072M-00628	1
5	D364 5176	Tensioner:Jogger:40704333:Ass'y	1
6	D364 1513	Synchronous Belt:B60S3M894:072M-00645	1
7	D364 5101	Photointerruptor:GP1A73A:31001635	1
8	D364 5181	Optics Sensor:072M-00989:Ass'y	1
9	D364 5182	Harness:Optics Sensor:Photo:072M-00905	1
10	D364 5195	Harness:Optics Sensor:Connecting:072M-00862	1
11	D364 5196	Harness:Sensor:6-A:072M-00817	1
12	D364 5197	Harness:Motor:1-3-A:072M-00818	1
13	D364 1514	Sheet:Plate:Leading Edge:072M-01057:Ass'y	1
14	D364 1515	Sheet:Plate:072M-01052	2

Index No.	Part No.	Description	Q'ty Per Assembly

7.Exterior (D364)




7.Exterior (D364)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1600	Cover:Rear:072M-00671	1
2	D364 1601	Door:Shift Tray:072M-00948:Ass'y	1
3	D364 1602	Grip:Door:Shift Tray:072M-00949	2
4	D364 1610	Cover:Upper:072M-00675:Ass'y	1
5	D364 1612	Operation Panel:072M-00950:Ass'y	1
6	D364 5198	Printed Circuit Board:Operation Panel: 072M-00855	1
7	D364 1611	Proof Tray:072M-00676	1
8	D364 1613	Cover:Left:072M-00677	1
9	D364 1614	Cover:Left Front:072M-00678	1
10	D364 1615	Door:Transport Sub-unit:072M-00951:Ass'y	1
12	D364 1620	Cover:Paper Exit Sub-unit:072M-00681	1
13	D364 1621	Cover:Rear:Small:072M-00682	1
14	D364 1622	Cooling Fan:DC 6.3W:072M-00953	1
15	D364 5155	Fan:Cross Flow:DC 6.3W:072M-00982	1
16	D364 5199	Harness:Cross Flow:072M-00821	1
17	D364 1603	Magnet Catch:31001983	2
18	D364 6504	Decal:Misfeed Removal:Transport Sub-unit: 072M-00895	1
19	D364 6505	Decal:Misfeed Removal:Shift Tray:072M-00894	1
20	D364 6560	Decal:Caution:Stack:Tray	1
21	D364 6515	Decal:Leak Breaker:On/Off:072M-01011	1

Index No.	Part No.	Description	Q'ty Per Assembly

8.Accessories 1 (D364)




8.Accessories 1 (D364)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D364 1700	Stack:Tray:072M-00954:Ass'y	1
2	D364 1701	Stand:Move:Paper:072M-00955:Ass'y	1
3	D364 1702	Caster:GR-50N:072M-00685	2
4	D364 1703	Caster:G-50N:072M-00686	2
5	D364 1710	Grip:Stand:072M-00952:Ass'y	1
6	D364 1711	Plate:Paper:072M-00956:Ass'y	1
7	D364 5294	Power Supply Cord:EU:072M-00993	1
8	D364 5293	Power Supply Cord:NA:072M-00994	1
9	D364 1750	Ground Plate:072M-01024:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly

9.Accessories 2 (D364)



9.Accessories 2 (D364)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B132 1226	Holder:Stand	4
2	B706 7531	Cushion:Spacer	1
3	AA14 3396	Screw - M4x4	1
4	B830 7536	Coupling Bracket - Correct	1
5	B830 7530	Coupling Bracket	1
6	B835 1188	Guide Plate - Upper	1
7	B830 7511	Connecting Guide Plate - Lower	1
8	D364 8517	Operating Instructions:NA:CD-ROM	1
8	D364 8527	Operating Instructions:EU:CD-ROM	1
9	D364 8520	Operating Instructions:NA	1
9	D364 8530	Operating Instructions:User Cautions:English:EU	1
9	D364 8546	Operating Instructions:User Cautions:German	1
9	D364 8547	Operating Instructions:User Cautions:French	1
9	D364 8548	Operating Instructions:User Cautions:Italian	1
9	D364 8549	Operating Instructions:User Cautions:Spanish	1
9	D364 8550	Operating Instructions:User Cautions:Dutch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0451 4008N	Tapping Screw:4x8	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D364 1000	Caster:35kg	7 - 1
D364 1001	Hinge:Door:Front:Stack:072M-00667	7 - 2
D364 1002	Tensioner:Drive:40704325:Ass'y	7 - 5
D364 1003	Wire:Tray:Upper Lower:Gray:072M-00787	7 - 6
D364 1004	Wire:Tray:Upper Lower:Black:072M-00788	7 - 7
D364 1005	Shaft:Transmission:Rising Tray:30706442:Ass'y	7 - 8
D364 1006	Synchronous Belt:1800-5GT-20:31001991	7 - 9
D364 1007	Timing Pulley:5GT:T36:30706446:Ass'y	7 - 10
D364 1009	Bracket:Wire:Rear:40704323:Ass'y	7 - 13
D364 1010	Shaft:Drive:Rising Tray:30706440:Ass'y	7 - 14
D364 1011	Bracket:DC Motor:Tray Unit:30706432:Ass'y	7 - 17
D364 1012	Holder:Tray:072M-00915:Ass'y	7 - 20
D364 1013	Roller:Tray:Upper Lower:41515970	7 - 21
D364 1014	Roller:Tray:Upper Lower:072M-00916:Ass'y	7 - 22
D364 1015	Tensioner:Drive:072M-01042:Ass'y	7 - 60
D364 1016	Guide Roller:Door:072M-01064	7 - 61
D364 1020	Radial Ball Bearing:6901ZZNR:31001987	7 - 24
D364 1021	Inlet:30706429:Ass'y	7 - 25
D364 1100	Transport Sub-unit:Entrance:072M-00922:Ass'y	13 - 1
D364 1101	Guide Plate:Proof Tray:072M-00923:Ass'y	13 - 2
D364 1102	Driven Roller:Exit:30705679:Ass'y	13 - 3
D364 1103	Discharge Brush:Proof Tray:Exit:31001754	25 - 15
D364 1103	Discharge Brush:Proof Tray:Exit:31001754	13 - 5
D364 1104	Driven Roller:072M-00924:Ass'y	13 - 7
D364 1104	Driven Roller:072M-00924:Ass'y	25 - 4
D364 1105	Bushing:Driven Roller:072M-00652	13 - 8
D364 1105	Bushing:Driven Roller:072M-00652	25 - 5
D364 1106	Compression Spring:Transport Roller:072M-0087	13 - 9
D364 1106	Compression Spring:Transport Roller:072M-00873	25 - 6
D364 1107	Grip:Open And Close:L2:072M-00959:Ass'y	13 - 10
D364 1110	Guide Plate:Entrance:072M-00925:Ass'y	13 - 12
D364 1111	Grip:Open And Close:L2:072M-00960:Ass'y	13 - 16
D364 1120	Exit Roller:Proof Tray:072M-00701	13 - 19
D364 1122	Radial Ball Bearing:LNR-1360X3ZZR:31001827	17 - 18
D364 1122	Radial Ball Bearing:LNR-1360X3ZZR:31001827	13 - 20

Part No.	Description	Page and Index No.
D364 1123	Synchronous Belt:S2M172:31001992	13 - 22
D364 1124	Gate Pawl:072M-00927:Ass'y	13 - 24
D364 1125	Transport Roller:2Koro:072M-00659	25 - 16
D364 1125	Transport Roller:2Koro:072M-00659	13 - 25
D364 1126	Transport Roller:4Koro:072M-00660	25 - 17
D364 1126	Transport Roller:4Koro:072M-00660	13 - 26
D364 1127	Transport Roller:Mechanical Roller Clutch:072M-00707	13 - 27
D364 1128	Knob:L3:072M-00708	13 - 28
D364 1129	Tensioner:Transport:072M-00928:Ass'y	13 - 29
D364 1130	Pulley:Idler:Tensioner:072M-00929:Ass'y	25 - 20
D364 1130	Pulley:Idler:Tensioner:072M-00929:Ass'y	13 - 30
D364 1131	Radial Ball Bearing:LF-1680HH:31001989	13 - 31
D364 1131	Radial Ball Bearing:LF-1680HH:31001989	25 - 23
D364 1131	Radial Ball Bearing:LF-1680HH:31001989	17 - 7
D364 1132	Synchronous Belt:B60S3M882:072M-00684	13 - 32
D364 1133	Guide Plate:Connecting:072M-00930:Ass'y	13 - 33
D364 1135	Tensioner:Transport:072M-01085:Ass'y	25 - 21
D364 1200	Shift Tray Unit:072M-00931:Ass'y	17 - 1
D364 1201	Guide Plate:Exit:Shift Tray:072M-00932:Ass'y	17 - 2
D364 1203	Driven Roller:Exit:Front:072M-00933:Ass'y	17 - 3
D364 1204	Driven Roller:Exit:Inner Back:072M-00934:Ass'y	17 - 4
D364 1205	Exit Roller:Shift Tray:072M-00617	17 - 5
D364 1207	Gear:Z28:31505541	17 - 8
D364 1208	Discharge Brush:Shift Tray:Exit:31001753	17 - 9
D364 1209	Holder:Exit Roller:Shift Tray:41516167	17 - 10
D364 1220	End Fence:Shift Tray:072M-00936	17 - 11
D364 1221	Paddle:072M-00620:Ass'y	17 - 16
D364 1222	Pulley:S2M:T26:31504929	17 - 17
D364 1224	Stepper Motor:DC 9W:Shift:072M-00937	17 - 19
D364 1225	Stepper Motor:DC 8.5W:Exit:072M-00939	17 - 21
D364 1226	Pulley:Slow Down:072M-00988:Ass'y	17 - 22
D364 1227	Holder:Pulley:Slow Down:41516102	17 - 24
D364 1227	Holder:Pulley:Slow Down:41516102	17 - 29
D364 1228	Synchronous Belt:S2M202:072M-00743	17 - 25
D364 1300	Jogger:Side:072M-00940:Ass'y	21 - 1

Part No.	Description	Page and Index No.
D364 1301	Stepper Motor:DC 9W:Jogger:Front:072M-00957	21 - 2
D364 1340	Stepper Motor:DC 9W:Jogger:Rear:072M-00958	21 - 4
D364 1341	Synchronous Belt:B60S3M519:072M-00636	21 - 6
D364 1342	Slider:Jogger:072M-00637	21 - 7
D364 1343	Feeler:Overflow:Shift Tray:31505537	21 - 11
D364 1344	Jogger:Front:072M-00638	21 - 12
D364 1346	Side Fence:Front:072M-00639	21 - 13
D364 1347	Jogger:Inner Back:072M-00640	21 - 14
D364 1348	Side Fence:Inner Back:072M-00763	21 - 15
D364 1400	Transport Unit:Connecting:072M-00942:Ass'y	25 - 1
D364 1401	Stepper Motor:DC 13W:Connecting:40704305	25 - 2
D364 1402	Guide Plate:Connecting:072M-00943:Ass'y	25 - 3
D364 1403	Grip:L5:072M-00962:Ass'y	25 - 14
D364 1406	Grip:L4:072M-00961:Ass'y	25 - 7
D364 1410	Guide Plate:Exit:072M-00944:Ass'y	25 - 9
D364 1412	Gear:Coupling:072M-00945:Ass'y	25 - 18
D364 1413	Pulley:Idler:T30/Z28:072M-00946:Ass'y	25 - 19
D364 1417	Synchronous Belt:B60S3M1050:072M-00665	25 - 22
D364 1500	Jogger:Lengthwise:Uniform:072M-00947:Ass'y	29 - 1
D364 1510	Stopper:Leading Edge:072M-00627	29 - 3
D364 1511	Slider:Stopper:Leading Edge:072M-00628	29 - 4
D364 1513	Synchronous Belt:B60S3M894:072M-00645	29 - 6
D364 1514	Sheet:Plate:Leading Edge:072M-01057:Ass'y	29 - 13
D364 1515	Sheet:Plate:072M-01052	29 - 14
D364 1600	Cover:Rear:072M-00671	31 - 1
D364 1601	Door:Shift Tray:072M-00948:Ass'y	31 - 2
D364 1602	Grip:Door:Shift Tray:072M-00949	31 - 3
D364 1603	Magnet Catch:31001983	31 - 17
D364 1610	Cover:Upper:072M-00675:Ass'y	31 - 4
D364 1611	Proof Tray:072M-00676	31 - 7
D364 1612	Operation Panel:072M-00950:Ass'y	31 - 5
D364 1613	Cover:Left:072M-00677	31 - 8
D364 1614	Cover:Left Front:072M-00678	31 - 9
D364 1615	Door:Transport Sub-unit:072M-00951:Ass'y	31 - 10
D364 1620	Cover:Paper Exit Sub-unit:072M-00681	31 - 12

Part No.	Description	Page and Index No.
D364 1621	Cover:Rear:Small:072M-00682	31 - 13
D364 1622	Cooling Fan:DC 6.3W:072M-00953	31 - 14
D364 1700	Stack:Tray:072M-00954:Ass'y	33 - 1
D364 1701	Stand:Move:Paper:072M-00955:Ass'y	33 - 2
D364 1702	Caster:GR-50N:072M-00685	33 - 3
D364 1703	Caster:G-50N:072M-00686	33 - 4
D364 1710	Grip:Stand:072M-00952:Ass'y	33 - 5
D364 1711	Plate:Paper:072M-00956:Ass'y	33 - 6
D364 1750	Ground Plate:072M-01024:Ass'y	33 - 9
D364 5010	PCB:Main:Ass'y	7 - 27
D364 5100	Set Sensor:Tray:30706430:Ass'y	7 - 3
D364 5101	Photointerruptor:GP1A73A:31001635	29 - 7
D364 5101	Photointerruptor:GP1A73A:31001635	7 - 4
D364 5101	Photointerruptor:GP1A73A:31001635	13 - 4
D364 5101	Photointerruptor:GP1A73A:31001635	17 - 26
D364 5101	Photointerruptor:GP1A73A:31001635	21 - 8
D364 5102	DC Motor:Tray:Upper Lower:072M-00913:Ass'y	7 - 15
D364 5103	Positioning Sensor:Tray:072M-00914:Ass'y	7 - 18
D364 5104	Harness:AC Power Supply:072M-00575	7 - 26
D364 5105	Fuse Resistor:3.15A:31001815#6	7 - 28
D364 5106	Fuse Resistor:2A:31001815#7	7 - 29
D364 5107	Fuse Resistor:0.5A:31001815#8	7 - 31
D364 5108	Fuse Resistor:1A:31001815#5	7 - 32
D364 5109	Fuse Resistor:1A:31001815#4	7 - 30
D364 5110	Power Supply Unit:31001995	7 - 34
D364 5111	Safety Switch:072M-00816	7 - 35
D364 5111	Safety Switch:072M-00816	13 - 39
D364 5112	Connector:Connection:072M-00917:Ass'y	7 - 36
D364 5113	Leak Breaker:072M-00918:Ass'y	7 - 37
D364 5114	Micro Switch:Tray:072M-00919:Ass'y	7 - 38
D364 5114	Micro Switch:Tray:072M-00919:Ass'y	7 - 38-1
D364 5115	Interface Cable:072M-00553	7 - 39
D364 5116	Harness:Safety Switch:072M-00920:Ass'y	7 - 40
D364 5117	Harness:Motor:Tray:Upper Lower:072M-00921	7 - 41
D364 5118	Harness:Power Supply Unit:072M-00555	7 - 42

Part No.	Description	Page and Index No.
D364 5119	Harness:Sensor:1:072M-00556	7 - 43
D364 5120	Harness:Sensor:2:072M-00557	7 - 44
D364 5121	Harness:Sensor:2-A:072M-00712	7 - 45
D364 5122	Harness:Sensor:3:072M-00558	7 - 46
D364 5123	Harness:Solenoid:072M-00564	7 - 47
D364 5124	Harness:Motor:1-1:072M-00567	7 - 48
D364 5125	Harness:Motor:2-1:072M-00570	7 - 49
D364 5126	Harness:Motor:3-1:072M-00572	7 - 50
D364 5127	Harness:Power Source:BP:072M-00577	7 - 51
D364 5128	Harness:DC Power Supply:072M-00578	7 - 52
D364 5129	Harness:Safety Switch:2-1:072M-00581	7 - 53
D364 5130	Harness:Operation Sub-unit:1-1:072M-00583	7 - 54
D364 5131	Harness:AC Power Supply:2-1:072M-00865	7 - 55
D364 5132	Harness:AC Power Supply:2-2:072M-00866	7 - 56
D364 5133	Relay:072M-00839:ASS'Y	7 - 57
D364 5134	Harness:Fan:2:072M-00822	7 - 58
D364 5135	Fan:Exhaust:DC 1.5W:072M-00980	7 - 59
D364 5136	Photo Reflection Sensor:PS-117L1:31001805	25 - 10
D364 5136	Photo Reflection Sensor:PS-117L1:31001805	17 - 6
D364 5136	Photo Reflection Sensor:PS-117L1:31001805	13 - 6
D364 5137	Harness:Sensor:Proof Tray:072M-00768	13 - 11
D364 5139	Harness:Sensor:PS-117I1:072M-00769	25 - 8
D364 5139	Harness:Sensor:PS-117I1:072M-00769	13 - 18
D364 5140	Stepper Motor:DC 8.5W:Entrance:30705685	13 - 21
D364 5140	Stepper Motor:DC 8.5W:Entrance:30705685	17 - 23
D364 5141	Bracket:Solenoid:Gate Pawl:072M-00926:Ass'y	13 - 23
D364 5142	Solenoid:Gate Pawl:072M-01084	13 - 47
D364 5150	Harness:Sensor:4:072M-00559	13 - 40
D364 5151	Harness:Solenoid:2:072M-00565	13 - 41
D364 5152	Harness:Motor:2-2:072M-00571	13 - 42
D364 5153	Harness:Safety Switch:1-2:072M-00580	13 - 43
D364 5154	Harness:Operation Sub-unit:1-2:072M-00584	13 - 44
D364 5155	Fan:Cross Flow:DC 6.3W:072M-00982	31 - 15
D364 5155	Fan:Cross Flow:DC 6.3W:072M-00982	13 - 45
D364 5156	Harness:Fan:3:072M-00984	13 - 46

Part No.	Description	Page and Index No.
D364 5157	Optics Sensor:Paper Volume:Paper:072M-00941:Ass'y	17 - 13
D364 5158	Harness:Optics Sensor:Paper Volume:072M-00863	17 - 14
D364 5160	Harness:Optics Sensor:Shift Tray:072M-00861	17 - 15
D364 5161	DC Stepper Motor:SHift:072M-00938:Ass'y	17 - 20
D364 5170	Harness:DC Stepper Motor:Shift:072M-00745	17 - 27
D364 5171	Harness:Sensor:Shift:072M-00744	17 - 28
D364 5172	Stepper Motor:DC 9W:Jogger:30705698	21 - 3
D364 5172	Stepper Motor:DC 9W:Jogger:30705698	29 - 2
D364 5175	Micro Switch:V-165-1A510E:31001833	21 - 9
D364 5176	Tensioner:Jogger:40704333:Ass'y	29 - 5
D364 5176	Tensioner:Jogger:40704333:Ass'y	21 - 10
D364 5177	Harness:Sensor:Jogger Section:072M-00746	21 - 16
D364 5178	Harness:Optics Sensor:Jogger Section:072M-00860	21 - 17
D364 5179	Harness:Motor:Jogger Section:072M-00749	21 - 18
D364 5180	Harness:Safety Switch:Jogger Section:072M-00750	21 - 19
D364 5181	Optics Sensor:072M-00989:Ass'y	29 - 8
D364 5181	Optics Sensor:072M-00989:Ass'y	21 - 20
D364 5182	Harness:Optics Sensor:Photo:072M-00905	29 - 9
D364 5182	Harness:Optics Sensor:Photo:072M-00905	21 - 21
D364 5190	Harness:Sensor:6:072M-00561	25 - 24
D364 5191	Harness:Motor:1-3:072M-00569	25 - 25
D364 5192	Harness:Optics Sensor:2:072M-00979	25 - 26
D364 5195	Harness:Optics Sensor:Connecting:072M-00862	29 - 10
D364 5196	Harness:Sensor:6-A:072M-00817	29 - 11
D364 5197	Harness:Motor:1-3-A:072M-00818	29 - 12
D364 5198	Printed Circuit Board:Operation Panel:072M-00855	31 - 6
D364 5199	Harness:Cross Flow:072M-00821	31 - 16
D364 5293	Power Supply Cord:NA:072M-00994	33 - 8
D364 5294	Power Supply Cord:EU:072M-00993	33 - 7
D364 6504	Decal:Misfeed Removal:Transport Sub-unit: 072M-00895	31 - 18
D364 6505	Decal:Misfeed Removal:Shift Tray:072M-00894	31 - 19
D364 6506	Decal:Grip:L1:072M-00896	13 - 50
D364 6507	Decal:Grip:L2:072M-00897	13 - 49
D364 6508	Decal:Knob:L3:072M-00898	13 - 48

Part No.	Description	Page and Index No.
D364 6509	Decal:Grip:L4:072M-00899	25 - 28
D364 6510	Decal:Grip:L5:072M-00900	25 - 27
D364 6515	Decal:Leak Breaker:On/Off:072M-01011	31 - 21
D364 6560	Decal:Caution:Stack:Tray	31 - 20
D364 8517	Operating Instructions:NA:CD-ROM	35 - 8
D364 8520	Operating Instructions:NA	35 - 9
D364 8527	Operating Instructions:EU:CD-ROM	35 - 8
D364 8530	Operating Instructions:User Cautions:English:EU	35 - 9
D364 8546	Operating Instructions:User Cautions:German	35 - 9
D364 8547	Operating Instructions:User Cautions:French	35 - 9
D364 8548	Operating Instructions:User Cautions:Italian	35 - 9
D364 8549	Operating Instructions:User Cautions:Spanish	35 - 9
D364 8550	Operating Instructions:User Cautions:Dutch	35 - 9

Part No.	Description	Page and Index No.
B132 1226	Holder:Stand	35 - 1
B706 7531	Cushion:Spacer	35 - 2
B830 7511	Connecting Guide Plate - Lower	35 - 7
B830 7530	Coupling Bracket	35 - 5
B830 7536	Coupling Bracket - Correct	35 - 4
B835 1188	Guide Plate - Upper	35 - 6

Part No.	Description	Page and Index No.
AA14 3396	Screw - M4x4	35 - 3

Part No.	Description	Page and Index No.
0451 3006N	Tapping Screw - 3x6	35 - 101
0451 4008N	Tapping Screw:4x8	35 - 102