

SR210 (A666)

This Parts catalog is includes MB No 1

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.EXTERIOR (A666)	2
2.ENTRANCE SECTION (A666)	4
3.INVERTER AND EXIT SECTION (A666)	6
4.STAPLE UNIT (A666).....	8
5.JOGGER UNIT (A666)	10
6.SHIFT TRAY DRIVE SECTION (A666).....	12
7.DRIVE AND ELECTRICAL SECTION (A666)	14
8.DECAL AND DOCUMENT	16
PARTS INDEX	19

1.EXTERIOR (A666)




1.EXTERIOR (A666)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A666 2421	Sub - Shift Tray	1
2	A666 2411	Shift Tray	1
3	A666 4671	Rear Cover - Shift Tray	1
4	A666 4661	Front Cover - Shift Tray	1
5	A666 4631	Left Lower Cover	1
6	A666 4930	Staple Exchange Decal	1
7	A666 4641	Upper Cover	1
8	A666 4910	Jam Removal Decal - W1	1
9	A666 4651	Rear Upper Cover	1
10	5446 2824	Screw - Duplex Guide Plate	2
11	A666 4621	Rear Cover	1
12	A666 4920	Jam Removal Decal - W2	1
13	A666 4150	Upper Entrance Cover	1
14	A666 4260	Entrance Roller	1
15	A666 4145	Upper Entrance Guide	1
16	G020 2630	Magnetic Catch	2
17	A666 4290	Support Entrance Guide	1
18	A666 6621	Rear Joint Bracket	1
19	A666 6611	Front Joint Bracket	1
20	A666 6666	Screw - M4X14	1
21	A666 4611	Front Cover	1
22	A666 4711	Stapler Cover	1
23	A666 4721	Inner Cover - Stapler Unit	1
24	5215 2621	Snap Ring - M6	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5254	Tapping Screw-m3x6	
102	0450 3008B	Tapping Screw - M3x8	

2.ENTRANCE SECTION (A666)




2.ENTRANCE SECTION (A666)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A353 3173	Pressure Spring	1
2	A666 1355	Upper Sensor Lever	1
3	AW02 0075	Photointerrupter	1
4	A353 3172	Actuator Bracket	1
5	A666 1351	Upper Stay - Paper Exit	1
6	AA12 0027	Antistatic Brush	1
7	A556 2151	Antistatic Brush	1
8	A666 4220	Bracket - Guide Plate	1
9	AW01 0070	Photosebsor - Ps-r11d1-b	1
10	A666 5224	Relay Harness - Shift Tray	1
11	A666 4135	Upper Guide Plate - Paper Exit	1
12	A666 4215	Fixed Plate - Exit Roller	1
13	A666 4205	Driven Roller - Paper Exit	2
14	A666 4210	Shaft - Exit Roller	1
15	A666 4125	Lower Entrance Guide Plate	1
16	A666 1411	Link Stay	1
17	5446 2824	Screw - Duplex Guide Plate	3
18	5413 1882	Stepped Screw	1
19	A666 1271	Bracket - Grounding Plate	2
20	A666 5222	Relay Harness - Paper Entrance	1
21	A666 4250	Sensor Bracket	1
22	A666 4300	Sensor Bracket	1
23	AW02 0095	Photointerruptor	1
24	A666 1412	Link Stay	1
25	A666 4170	Stepped Screw - M3x6	1
26	A666 1412	Link Stay	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006B	Tapping Screw - 4x6	
102	1105 0199	Clamp	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0450 3008B	Tapping Screw - M3x8	
105	1105 0328	Harnes Clamp - ES-050	
106	0313 0100B	Philips Pan Head Screw - M3x10	
107	0720 0040B	Retaining Ring - M4	
108	0451 3006B	Tapping Screw - M3x6	
109	1106 0193	Bushing - 7.9mm	

3.INVERTER AND EXIT SECTION (A666)




3.INVERTER AND EXIT SECTION (A666)



Index No.	Part No.	Description	Q'ty Per Assembly
1	A666 4145	Upper Entrance Guide	1
2	A666 4180	Exit Roller	1
3	A666 4165	Support Guide	1
4	A666 4105	Upper Guide Plate - Paper Out	1
5	A666 4155	Transport Roller	1
6	AW01 0070	Photosebsor - Ps-r11d1-b	1
7	A666 5223	Relay - Harness - Inverter	1
8	A666 4175	Sensor Bracket	1
9	A666 4110	Middle Guide Plate - Inverter	1
10	AA08 0071	Bushing -6x10x6	4
11	A666 1811	Torque Limiter - Exit	2
12	A666 1821	Torque Limiter - Inverter	1
13	A666 1831	Torque Limiter - Transport	1
14	A566 1510	Gate Pawl Lever	1
15	5446 2824	Screw - Duplex Guide Plate	2
16	5053 0447	Bushing - 6mm	3
17	5447 2681	Snap Ring	1
18	A666 4130	Turn Gate	1
19	A458 2251	Cushion - Bin Solenoid Lever	1
20	A666 4120	Inverter Guide Plate	1
21	5215 2621	Snap Ring - M6	1
22	A666 4190	Inverter Roller	1
23	A666 4155	Transport Roller	1
24	A666 4160	Torsion Spring	1
25	A666 4161	Torsion Spring	1
26	A666 4100	Inveryer Guide Plate	1
27	AA08 0034	Bushing - 4x5x7	2
28	AA06 3529	Pressure Spring - 14.5mm	2
29	AF02 2075	Driven Roller	1
30	A566 4505	Seal - 15 X 20	1
31	A376 3242	Antistatic Brush	1
32	A548 2343	Clutch Stopper	1
33	A666 4170	Stepped Screw - M3x6	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0451 3006B	Tapping Screw - M3x6	
103	0313 0100B	Philips Pan Head Screw - M3x10	
104	1105 0199	Clamp	

4.STAPLE UNIT (A666)




4.STAPLE UNIT (A666)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A666 3150	Guide Plate - Stapler Tray	1
2	AX04 0096	Stepping Motor - DC 9w	1
3	A666 3140	Rear Plate - Stapler Tray	1
4	A666 3280	Timing Belt - B40S2M328	1
5	A666 3155	Cover - Stapler	1
6	AJ01 1011	Stapler - Eh155r	1
7	A666 5228	Relay Harness - Stapler	1
8	5446 2824	Screw - Duplex Guide Plate	2
9	A666 3310	Feeler - Interlock Switch	1
10	A666 5227	Harness - Staple Sensor	1
11	A666 5229	Harness - Staple Motor	1
12	A666 3300	Guide - Stapler	1
13	A666 3125	Lower Stay - Slide Rail	1
14	A666 3127	Guide Mylar	4
15	A666 3126	Guide Mylar	1
16	A666 1314	Stapler Unit Stand	1
17	A666 1310	Lower Stay Guide	1
18	A666 3130	Front Plate - Stapler Tray	1
19	A666 3320	Antistatic Brush	1
20	A666 3330	Antistatic Brush	2
21	A666 3340	Guide Mylar	1
22	A666 3350	Guide Mylar	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1106 0200	Bushing - 19.44mm	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 4006B	Tapping Screw - 4x6	
104	0453 3006B	Tapping Screw - M3x6	
105	1105 0310	Wire Clamp	
106	0720 0040B	Retaining Ring - M4	
107	1607 0638	Ferrite Core - Tfc25-15-12	
108	1105 0376	Nylon Clamp	

5.JOGGER UNIT (A666)




5.JOGGER UNIT (A666)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A666 3290	Sensor Bracket	1
2	AW02 0049	Photointerruptor - Os - 580213-703	1
3	A666 3240	Sensor Bracket	1
4	AW01 0070	Photosebsor - Ps-r11d1-b	1
5	A666 3220	Tightener - Timing Belt	1
6	A134 5291	Jogger Drive Motor DC 6.48w	1
7	A666 3110	Base - Stapler	1
8	A666 3120	Rack - Side Fence	1
9	AA14 3314	Stepped Screw - M4x4	1
10	A666 3250	Gear - Z40	1
11	AB01 3881	Gear - 31Z	1
12	AB01 7400	Gear- 18z/68z	1
13	A666 3260	Shaft Paper Out	1
14	A666 3180	Timing Pulley - Z32	2
15	A666 3260	Shaft Paper Out	1
16	A666 3270	Pulley - Z40	1
17	A666 3190	Shaft - Middle Idler	1
18	A666 3180	Timing Pulley - Z32	2
19	A666 3210	Shaft - Lower Idler	1
20	A666 3100	Stapler Tray	1
21	AW02 0075	Photointerrupter	1
22	A666 3105	Jogger Fence	1
23	A666 3170	Timing Belt - 680P2M14	1
24	A666 3160	Pawl - Paper Out	1
25	A353 2763	Washer - M5	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0450 3010B	Tapping Screw - M3x10	
103	0313 0100B	Philips Pan Head Screw - M3x10	
104	0720 0040B	Retaining Ring - M4	
105	0242 0040Z	Pan Head Screw - M2x4	
106	0710 0020W	Hexagonal Nut - M2	
107	0805 3480	Bushing - 6mm	
108	0632 0100G	Pin - 2x10mm	
109	1105 0310	Wire Clamp	
110	1105 0199	Clamp	

6.SHIFT TRAY DRIVE SECTION (A666)




6.SHIFT TRAY DRIVE SECTION (A666)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A666 2251	Slider - Shift Tray	1
2	A666 2211	Frame - Shift Tray	1
3	A666 2159	Cover - Shift Tray	2
4	A666 2221	Front Side Plate	1
5	A666 2231	Rear Side Plate	1
6	A666 2351	Rear Rack Bracket	1
7	A666 2355	Front Rack Bracket	1
8	A666 2331	Rack	1
9	A666 2121	Stay - Shift Tray	2
10	A666 1311	Stay - Slide Rail	1
11	A666 2111	Copy Tray Guide	2
12	A666 2157	Guide:end Fence:front	1
13	A666 2156	Guide:end Fence:inner Back	1
14	A666 2151	End Fence	1
15	A379 3316	Shift Guide Roller	4
16	A353 3272	Guide Roller	4
17	A666 1311	Stay - Slide Rail	1
18	A666 1315	Slide Rail	1
19	A666 2374	Arm - Shift Plate	1
20	A666 2345	Gear - Z20	1
21	5053 0223	Bushing - 8mm	2
22	A666 2346	Shaft - Tray Drive	1
23	A666 2347	Gear - Z45	1
24	AH01 2019	Caster	4
25	AX04 0098	Motor - DC 12w	1
26	A666 1127	Grounding Plate	1
27	A666 1126	Bracket - Grounding Plate	1
28	5215 2621	Snap Ring - M6	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 3010B	Tapping Screw - M3x10	
103	0720 0040B	Retaining Ring - M4	
104	0720 0060B	Retaining Ring - M6	
105	0453 3006B	Tapping Screw - M3x6	
106	0450 4020B	Tapping Screw - 4x20	
107	0451 4006B	Tapping Screw - 4x6	
108	0633 0140G	Parallel Pin - 3x14	
109	1105 0199	Clamp	
110	1105 0310	Wire Clamp	

7.DRIVE AND ELECTRICAL SECTION (A666)













7.DRIVE AND ELECTRICAL SECTION (A666)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX04 0056	Stepping Motor - Dc9.5v 9.0w	1
2	A666 1621	Motor Bracket	1
3	A666 1741	Timing Belt - B40S2M152	1
4	A666 4230	Paper Entrance Solenoid	1
5	A666 4240	Solenoid Bracket	1
6	AA06 0092	Release Spring	1
7	A300 3151	Support Bracket	1
8	A666 5220	Harness - Interlock Switch	1
9	AG07 0004	Magnetic Catch	1
10	A666 1261	Bracket - Magnet Catch	1
11	A566 2101	Stepping Motor - DC 6.3w	1
12	A666 1611	Bracket - Main Motor	1
13	5920 2144	Spring - Lock	1
14	A666 1651	Gear Pulley - Z25/Z18	2
15	A666 1652	Flange - Timing Pulley	2
16	A666 1711	Timing Belt - B40S3M192	1
17	A666 1731	Timing Belt - B40S3M366	1
18	A666 1721	Timing Belt - B40S3M246	1
19	A666 5452	Bracket - Harness Clamp	1
20	A666 5453	Interface Harness Bracket	1
21	A666 5211	Harness - Interface	1
22	AW02 0075	Photointerrupter	2
23	A666 5451	Bracket - Main Board	1
24	A666 5510	Main Control Board	1
	A666 5500	X/O MB 1	
25	A666 5221	Harness - Sensor	1
26	A666 5225	Harness - Motor	1
27	A666 2375	Cam - Shift Tray	1
28	5447 2681	Snap Ring	1
29	A666 2371	Motor Bracket	1
30	AX04 0097	DC Motor - DC 5w	1
31	A666 2372	Sensor Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0313 0040B	Philips Pan Head Screw - M3x4	
104	0720 0040B	Retaining Ring - M4	
105	1106 0459	Bushing - 20.2mm	
106	1105 0310	Wire Clamp	
107	1204 2382	Interlock Switch - FAIL-CA22	

8.DECAL AND DOCUMENT

1   1 2 3 4 1 2 3 4 5 >PS<	2  1 2 >PS< 3   2 1
--	---

>PS<

8.DECAL AND DOCUMENT

Index No.	Part No.	Description	Q'ty Per Assembly
1	A666 4930	Staple Exchange Decal	1
2	A666 4910	Jam Removal Decal - W1	1
3	A666 4920	Jam Removal Decal - W2	1
			

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

Parts Index

Part No.	Description	Page and Index No.
A666 1126	Bracket - Grounding Plate	13- 27
A666 1127	Grounding Plate	13- 26
A666 1261	Bracket - Magnet Catch	15- 10
A666 1271	Bracket - Grounding Plate	5- 19
A666 1310	Lower Stay Guide	9- 17
A666 1311	Stay - Slide Rail	13- 17
A666 1311	Stay - Slide Rail	13- 10
A666 1314	Stapler Unit Stand	9- 16
A666 1315	Slide Rail	13- 18
A666 1351	Upper Stay - Paper Exit	5- 5
A666 1355	Upper Sensor Lever	5- 2
A666 1411	Link Stay	5- 16
A666 1412	Link Stay	5- 24
A666 1412	Link Stay	5- 26
A666 1611	Bracket - Main Motor	15- 12
A666 1621	Motor Bracket	15- 2
A666 1651	Gear Pulley - Z25/Z18	15- 14
A666 1652	Flange - Timing Pulley	15- 15
A666 1711	Timing Belt - B40S3M192	15- 16
A666 1721	Timing Belt - B40S3M246	15- 18
A666 1731	Timing Belt - B40S3M366	15- 17
A666 1741	Timing Belt - B40S2M152	15- 3
A666 1811	Torque Limiter - Exit	7- 11
A666 1821	Torque Limiter - Inverter	7- 12
A666 1831	Torque Limiter - Transport	7- 13
A666 2111	Copy Tray Guide	13- 11
A666 2121	Stay - Shift Tray	13- 9
A666 2151	End Fence	13- 14
A666 2156	Guide:end Fence:inner Back	13- 13
A666 2157	Guide:end Fence:front	13- 12
A666 2159	Cover - Shift Tray	13- 3
A666 2211	Frame - Shift Tray	13- 2
A666 2221	Front Side Plate	13- 4
A666 2231	Rear Side Plate	13- 5
A666 2251	Slider - Shift Tray	13- 1

Part No.	Description	Page and Index No.
A666 2331	Rack	13- 8
A666 2345	Gear - Z20	13- 20
A666 2346	Shaft - Tray Drive	13- 22
A666 2347	Gear - Z45	13- 23
A666 2351	Rear Rack Bracket	13- 6
A666 2355	Front Rack Bracket	13- 7
A666 2371	Motor Bracket	15- 29
A666 2372	Sensor Bracket	15- 31
A666 2374	Arm - Shift Plate	13- 19
A666 2375	Cam - Shift Tray	15- 27
A666 2411	Shift Tray	3- 2
A666 2421	Sub - Shift Tray	3- 1
A666 3100	Stapler Tray	11- 20
A666 3105	Jogger Fence	11- 22
A666 3110	Base - Stapler	11- 7
A666 3120	Rack - Side Fence	11- 8
A666 3125	Lower Stay - Slide Rail	9- 13
A666 3126	Guide Mylar	9- 15
A666 3127	Guide Mylar	9- 14
A666 3130	Front Plate - Stapler Tray	9- 18
A666 3140	Rear Plate - Stapler Tray	9- 3
A666 3150	Guide Plate - Stapler Tray	9- 1
A666 3155	Cover - Stapler	9- 5
A666 3160	Pawl - Paper Out	11- 24
A666 3170	Timing Belt - 680P2M14	11- 23
A666 3180	Timing Pulley - Z32	11- 18
A666 3180	Timing Pulley - Z32	11- 14
A666 3190	Shaft - Middle Idler	11- 17
A666 3210	Shaft - Lower Idler	11- 19
A666 3220	Tightener - Timing Belt	11- 5
A666 3240	Sensor Bracket	11- 3
A666 3250	Gear - Z40	11- 10
A666 3260	Shaft Paper Out	11- 13
A666 3260	Shaft Paper Out	11- 15
A666 3270	Pulley - Z40	11- 16

Part No.	Description	Page and Index No.
A666 3280	Timing Belt - B40S2M328	9- 4
A666 3290	Sensor Bracket	11- 1
A666 3300	Guide - Stapler	9- 12
A666 3310	Feeler - Interlock Switch	9- 9
A666 3320	Antistatic Brush	9- 19
A666 3330	Antistatic Brush	9- 20
A666 3340	Guide Mylar	9- 21
A666 3350	Guide Mylar	9- 22
A666 4100	Inveryer Guide Plate	7- 26
A666 4105	Upper Guide Plate - Paper Out	7- 4
A666 4110	Middle Guide Plate - Inverter	7- 9
A666 4120	Inverter Guide Plate	7- 20
A666 4125	Lower Entrance Guide Plate	5- 15
A666 4130	Turn Gate	7- 18
A666 4135	Upper Guide Plate - Paper Exit	5- 11
A666 4145	Upper Entrance Guide	3- 15
A666 4145	Upper Entrance Guide	7- 1
A666 4150	Upper Entrance Cover	3- 13
A666 4155	Transport Roller	7- 23
A666 4155	Transport Roller	7- 5
A666 4160	Torsion Spring	7- 24
A666 4161	Torsion Spring	7- 25
A666 4165	Support Guide	7- 3
A666 4170	Stepped Screw - M3x6	7- 33
A666 4170	Stepped Screw - M3x6	5- 25
A666 4175	Sensor Bracket	7- 8
A666 4180	Exit Roller	7- 2
A666 4190	Inverter Roller	7- 22
A666 4205	Driven Roller - Paper Exit	5- 13
A666 4210	Shaft - Exit Roller	5- 14
A666 4215	Fixed Plate - Exit Roller	5- 12
A666 4220	Bracket - Guide Plate	5- 8
A666 4230	Paper Entrance Solenoid	15- 4
A666 4240	Solenoid Bracket	15- 5
A666 4250	Sensor Bracket	5- 21

Part No.	Description	Page and Index No.
A666 4260	Entrance Roller	3- 14
A666 4290	Support Entrance Guide	3- 17
A666 4300	Sensor Bracket	5- 22
A666 4611	Front Cover	3- 21
A666 4621	Rear Cover	3- 11
A666 4631	Left Lower Cover	3- 5
A666 4641	Upper Cover	3- 7
A666 4651	Rear Upper Cover	3- 9
A666 4661	Front Cover - Shift Tray	3- 4
A666 4671	Rear Cover - Shift Tray	3- 3
A666 4711	Stapler Cover	3- 22
A666 4721	Inner Cover - Stapler Unit	3- 23
A666 4910	Jam Removal Decal - W1	17- 2
A666 4910	Jam Removal Decal - W1	3- 8
A666 4920	Jam Removal Decal - W2	3- 12
A666 4920	Jam Removal Decal - W2	17- 3
A666 4930	Staple Exchange Decal	3- 6
A666 4930	Staple Exchange Decal	17- 1
A666 5211	Harness - Interface	15- 21
A666 5220	Harness - Interlock Switch	15- 8
A666 5221	Harness - Sensor	15- 25
A666 5222	Relay Harness - Paper Entrance	5- 20
A666 5223	Relay - Harness - Inverter	7- 7
A666 5224	Relay Harness - Shift Tray	5- 10
A666 5225	Harness - Motor	15- 26
A666 5227	Harness - Staple Sensor	9- 10
A666 5228	Relay Harness - Stapler	9- 7
A666 5229	Harness - Staple Motor	9- 11
A666 5451	Bracket - Main Board	15- 23
A666 5452	Bracket - Harness Clamp	15- 19
A666 5453	Interface Harness Bracket	15- 20
A666 5500	X/O MB 1	15- 24
A666 5510	Main Control Board	15- 24
A666 6611	Front Joint Bracket	3- 19
A666 6621	Rear Joint Bracket	3- 18

Part No.	Description	Page and Index No.
A666 6666	Screw - M4X14	3- 20

Part No.	Description	Page and Index No
AA06 0092	Release Spring	15- 6
AA06 3529	Pressure Spring - 14.5mm	7- 28
AA08 0034	Bushing - 4x5x7	7- 27
AA08 0071	Bushing -6x10x6	7- 10
AA12 0027	Antistatic Brush	5- 6
AA14 3314	Steped Screw - M4x4	11- 9
AB01 3881	Gear - 31Z	11- 11
AB01 7400	Gear- 18z/68z	11- 12
AF02 2075	Driven Roller	7- 29
AG07 0004	Magnetic Catch	15- 9
AH01 2019	Caster	13- 24
AJ01 1011	Stapler - Eh155r	9- 6
AW01 0070	Photosebsor - Ps-r11d1-b	7- 6
AW01 0070	Photosebsor - Ps-r11d1-b	11- 4
AW01 0070	Photosebsor - Ps-r11d1-b	5- 9
AW02 0049	Photointerruptor - Os - 580213-703	11- 2
AW02 0075	Photointerrupter	5- 3
AW02 0075	Photointerrupter	11- 21
AW02 0075	Photointerrupter	15- 22
AW02 0095	Photointerruptor	5- 23
AX04 0056	Stepping Motor - Dc9.5v 9.0w	15- 1
AX04 0096	Stepping Motor - DC 9w	9- 2
AX04 0097	DC Motor - DC 5w	15- 30
AX04 0098	Motor - DC 12w	13- 25
G020 2630	Magnetic Catch	3- 16

Part No.	Description	Page and Index No.
A134 5291	Jogger Drive Motor DC 6.48w	11- 6
A300 3151	Support Bracket	15- 7
A353 2763	Washer - M5	11- 25
A353 3172	Actuator Bracket	5- 4
A353 3173	Pressure Spring	5- 1
A353 3272	Guide Roller	13- 16
A376 3242	Antistatic Brush	7- 31
A379 3316	Shift Guide Roller	13- 15
A458 2251	Cushion - Bin Solenoid Lever	7- 19
A548 2343	Clutch Stopper	7- 32
A556 2151	Antistatic Brush	5- 7
A566 1510	Gate Pawl Lever	7- 14
A566 2101	Stepping Motor - DC 6.3w	15- 11
A566 4505	Seal - 15 X 20	7- 30

Part No.	Description	Page and Index No
5053 0223	Bushing - 8mm	13- 21
5053 0447	Bushing - 6mm	7- 16
5215 2621	Snap Ring - M6	3- 24
5215 2621	Snap Ring - M6	7- 21
5215 2621	Snap Ring - M6	13- 28
5413 1882	Stepped Screw	5- 18
5446 2824	Screw - Duplex Guide Plate	5- 17
5446 2824	Screw - Duplex Guide Plate	7- 15
5446 2824	Screw - Duplex Guide Plate	3- 10
5446 2824	Screw - Duplex Guide Plate	9- 8
5447 2681	Snap Ring	15- 28
5447 2681	Snap Ring	7- 17
5920 2144	Spring - Lock	15- 13

Part No.	Description	Page and Index No.
0242 0040Z	Pan Head Screw - M2x4	11-105
0313 0040B	Philips Pan Head Screw - M3x4	15-103
0313 0100B	Philips Pan Head Screw - M3x10	11-103
0313 0100B	Philips Pan Head Screw - M3x10	5-106
0313 0100B	Philips Pan Head Screw - M3x10	7-103
0314 0060B	Philips Pan Head Screw - M4x6	5-103
0353 0060B	Philips Pan Head Screw - M3x6	15-102
0450 3008B	Tapping Screw - M3x8	3-102
0450 3008B	Tapping Screw - M3x8	5-104
0450 3010B	Tapping Screw - M3x10	11-102
0450 4020B	Tapping Screw - 4x20	13-106
0451 3006B	Tapping Screw - M3x6	15-101
0451 3006B	Tapping Screw - M3x6	11-101
0451 3006B	Tapping Screw - M3x6	9-102
0451 3006B	Tapping Screw - M3x6	13-101
0451 3006B	Tapping Screw - M3x6	5-108
0451 3006B	Tapping Screw - M3x6	7-102
0451 3010B	Tapping Screw - M3x10	13-102
0451 4006B	Tapping Screw - 4x6	13-107
0451 4006B	Tapping Screw - 4x6	9-103
0451 4006B	Tapping Screw - 4x6	5-101
0453 3006B	Tapping Screw - M3x6	9-104
0453 3006B	Tapping Screw - M3x6	13-105
0632 0100G	Pin - 2x10mm	11-108
0633 0140G	Parallel Pin - 3x14	13-108
0710 0020W	Hexagonal Nut - M2	11-106
0720 0040B	Retaining Ring - M4	9-106
0720 0040B	Retaining Ring - M4	7-101
0720 0040B	Retaining Ring - M4	5-107
0720 0040B	Retaining Ring - M4	15-104
0720 0040B	Retaining Ring - M4	11-104
0720 0040B	Retaining Ring - M4	13-103
0720 0060B	Retaining Ring - M6	13-104
0802 5254	Tapping Screw-m3x6	3-101
0805 3480	Bushing - 6mm	11-107

Part No.	Description	Page and Index No.
1105 0199	Clamp	11-110
1105 0199	Clamp	13-109
1105 0199	Clamp	7-104
1105 0199	Clamp	5-102
1105 0310	Wire Clamp	11-109
1105 0310	Wire Clamp	9-105
1105 0310	Wire Clamp	13-110
1105 0310	Wire Clamp	15-106
1105 0328	Harnes Clamp - ES-050	5-105
1105 0376	Nylon Clamp	9-108
1106 0193	Bushing - 7.9mm	5-109
1106 0200	Bushing - 19.44mm	9-101
1106 0459	Bushing - 20.2mm	15-105
1204 2382	Interlock Switch - FAIL-CA22	15-107
1607 0638	Ferrite Core - Tfc25-15-12	9-107