

Finisher SR3070 (D585)

Finisher SR3070 (D585)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior (D585)	2
2.Paper Transfer 1 (D585).....	4
3.Paper Transfer 2 (D585).....	6
4.Jogger Unit 1 (D585)	8
5.Jogger Unit 2 (D585)	10
6.Stapler Unit (D585).....	12
7.Paper Exit (D585)	14
8.Drive Section (D585)	16
9.Decals and Documents (D585)	16
Parts Index	19

August 30, 2011

1.Exterior (D585)




1.Exterior (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D585 1512	Cover:Rear	1
2	D585 3411	Tray:Exit	1
3	D585 3413	Tray:Exit:Slide:Auxiliary	1
4	D585 3412	Tray:Exit:Slide:Middle	1
5	D585 1571	Cover:Front:EXP:Ass'y	1
6	D585 1525	Hinge:Door:Staple Exchange	1
7	D585 1524	Hinge:Door:Fix:Staple Exchange	1
8	D585 6812	Decal:Staple Exchange	1
9	D585 6814	Decal:Caution:Paper:Pick-up	1
10	D585 1523	Door:Front:Staple Exchange	1
11	D585 6215	Cover:Stand	2
12	D372 6211	Left Stand	2
13	D372 6117	Upper Guide Plate - Connecting	1
14	D372 6116	Lower Guide Plate - Connecting	1
15	D372 6130	Bracket:Coupling:Main:Ass'y	1
16	D372 6118	Stay - Connecting Bracket	1
17	D372 6122	Cover Bracket - Lower Right	1
18	D372 6121	Bracket - Lock Lever Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0450 3008N	Tapping Screw - M3x8	
103	0454 3006Q	Tapping Screw - M3x6	
104	0451 4014N	Tapping Screw:M4x14	
105	0451 4020N	Tapping Screw - M4x20	
106	0451 4025N	Tapping Screw:M4x25	

2.Paper Transfer 1 (D585)




2.Paper Transfer 1 (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D585 1531	Cover:Exit	1
2	D585 6813	Decal:Misfeed Removal	1
3	D585 6811	Decal:Staple:Pick-up Paper Jam	1
4	D372 2222	Discharge Brush:Exit	1
5	D372 2221	Upper Guide Plate - Exit	1
6	AA06 3529	Pressure Spring - 14.5MM	4
7	AA08 0237	Bushing - 4x5x7	6
8	AF02 2097	Driven Roller	3
9	D372 2216	Guide Plate:Transport:Ass'y	1
10	B352 1607	Timing Pulley - T20-S3M	1
11	B872 2614	Bushing:R1	2
12	D372 2141	Entrance Roller	1
13	D372 2212	Entrance Sensor Bracket	1
14	AW02 0154	Photointerruptor:Entrance	1
15	D372 2312	Compression Spring	2
16	AG07 0514	Magnet Catch	2
17	D585 2311	Cover:Transport	1
18	G020 5626	Push Switch	1
19	AA14 3790	Screw:Contact Point	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0454 3006Q	Tapping Screw - M3x6	
103	1105 0511	Harness Clamp - LWS-0306ZC	
104	0451 3006N	Tapping Screw - 3x6	
105	0805 0088	Retaining Ring - M6	

3.Paper Transfer 2 (D585)




3.Paper Transfer 2 (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D372 1112	Lever:Un Lock	1
2	D372 1113	Tension Spring - Lever	1
3	AA14 3702	Screw:Pin:Positioning	2
4	D372 2231	Exit Lever	1
5	D372 2232	Tension Spring - Exit Lever	1
6	D372 2131	Roller Arm	1
7	B872 2515	Cushion:Bracket:Feed	1
8	D372 2133	Shaft - Roller Fix	1
9	D372 2135	Gathering Roller	1
10	AA08 2101	Bushing - 6x10x6	4
11	D372 2241	Switch Holder	1
12	D372 1542	Bracket - Door Switch	1
13	D372 1543	Spring Plate - Door Switch	1
14	D372 2136	Ground Plate	1
15	D372 2113	Timing Pulley - 22T	2
16	AA14 3788	Pin:Guide Plate:Paper Feed	1
17	B352 1607	Timing Pulley - T20-S3M	1
18	D372 2132	Drive Shaft - Roller	1
19	AA04 3632	Timing Belt - 40S2M126	2
20	D372 2134	Timing Pulley - 18T	1
21	D372 2114	Guide - Trailing Edge	4
22	D372 2112	Exit Roller	1
23	D372 2122	Shaft - Reverse Roller	2
24	D372 2121	Holder - Reverse Roller	2
25	D372 2123	Gear - 20Z	2
26	D372 2124	Reverse Roller	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0353 0140N	Screw:M3x14	
103	0720 0040E	Retaining Ring - M4	
104	0805 0089	Retaining Ring - M4	
105	0805 3385	Bushing - 6mm	
106	1204 2515	Micro Switch - DE2L-FJ10	
107	1204 2612	Micro Switch:D3V-16506-3C25	

4. Jogger Unit 1 (D585)




4.Jogger Unit 1 (D585)


Index No.	Part No.	Description	Q'ty Per Assembly
1	D372 5802	Stepper Motor - DC 4W	1
2	D372 4243	Heat Sink - Exit Motor	1
3	D372 5892	Cushion - Stepper Motor	1
4	D372 4242	Bracket - Exit Motor	1
5	D372 4212	Stay:Exit	1
6	D372 4268	Exit Arm	1
7	AW02 0203	Photointerruptor:GP1A173LCS2F	1
8	D372 4281	Shaft - Standard Fence	1
9	D372 4292	Tension Spring - ARM	1
10	D372 4282	Pulley - 32T	1
11	AA04 3637	Timing Belt - 40S2M124	1
12	D372 4285	Pulley - 16T	1
13	AA04 3328	Timing Belt:40S2M130	1
14	D372 4284	Pulley - 32T/16T	1
15	AA04 3604	Timing Belt:B40S2M110	1
16	D372 4269	Pulley/Arm - Standard Fence	1
17	AA04 3636	Timing Belt - 40S2M96	1
18	D372 4283	Pulley - 16T	1
19	D372 4261	Bracket - Exit	1
20	D372 4266	Arm Shaft - Exit	1
21	D372 4265	Cam Shaft - Slide	1
22	D372 4267	Slider Shaft - Standard Fence	1
23	AB01 1252	Gear - 20Z	1
24	D372 4277	Standard Fence - Middle	1
25	D372 4272	Slider - Standard Fence	1
26	D372 4198	Guide:Exit	1
27	D372 4216	Bracket:Guide:Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 3008P	Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	0720 0040E	Retaining Ring - M4	
104	0452 3008N	Tapping Screw - M3x8	
105	1105 0619	Clamp:LBWS-0605S-V0	
106	1105 0328	Harness Clamp - ES-0505	
107	1105 0522	Edge Saddle - LES0510	
108	0805 3385	Bushing - 6mm	

5.Jogger Unit 2 (D585)



6. Stapler Unit (D585)




6.Stapler Unit (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D372 5803	Stepper Motor - 20.4W	1
2	D372 5892	Cushion - Stepper Motor	1
3	D372 4518	Cover Bracket - Rear Lower	1
4	D372 4513	Front/Rear Rail - Stapler	2
5	D372 4562	Timing Belt - B60S3M900	1
6	D372 4524	Gear/Pulley - 40Z/20T	1
7	D372 4535	Pulley - 20T	1
8	AW02 0203	Photointerruptor:GP1A173LCS2F	1
9	D372 4531	Tightener Bracket	1
10	D372 4514	Middle Rail - Stapler	1
11	D372 4534	Tension Spring - Stapler	1
12	D372 4512	Shaft - Stapler	1
13	D372 4548	Stay - Stapler Timing Belt	1
14	D372 4547	Spacer - Stapler	2
15	D372 4546	Bracket - End Fence	1
16	D372 4541	Base - Stapler	1
17	D372 4552	Gear - Stapler	1
18	D372 4567	Bracket:Gear:Stapler	1
19	D372 4553	Turn Gear - Stapler	1
20	B352 4318	Bushing - Lower Slider	2
21	D372 4545	Bracket - Staple	1
22	AA14 3790	Screw:Contact Point	1
23	D372 4559	Tension Spring - Gear	1
24	D372 4555	Holder:Bracket:Gear:Pressure	1
25	D372 4556	Bracket:Stapler:Positioning:Peen	1
26	D372 4561	Spacer:DIA4	1
27	D372 4568	Bracket:Stapler	1
28	D585 4592	Guide:Standard Fence:Stapler:Ass'y	1
29	D372 4564	Stapler Guide	1
30	D372 4570	Gear Bracket - Pressure	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0451 3008N	Tapping Screw - M3x8	
103	0360 3006P	Screw - M3x6	
104	0720 0040E	Retaining Ring - M4	
105	0720 0060E	Retaining Ring - M6	
106	0450 3008N	Tapping Screw - M3x8	
107	0805 0089	Retaining Ring - M4	
108	1105 0619	Clamp:LBWS-0605S-V0	
109	1105 0326	Locking Support	

7.Paper Exit (D585)




7.Paper Exit (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D372 3211	Tray Base Plate	1
2	D585 3100	End Fence:Ass'y	1
3	D585 3111	End Fence	1
4	D372 3145	Cushion - Guide Plate	4
5	D372 3152	Bracket - Solenoid	1
6	D372 3141	Torsion Spring - Front	1
7	D372 3121	Guide - Paper Sensor	2
8	D372 3122	Stopper - Paper Sensor	2
9	D372 5220	Interface Harness - End Fence	1
10	AW02 0203	Photointerruptor:GP1A173LCS2F	1
11	D372 3132	Release Lever	1
12	D372 3142	Torsion Spring - Inner Back	1
13	D372 3221	Front Side Plate - Tray Lift	1
14	D372 3223	Timing Belt Stopper	2
15	D372 3511	Pulley - 20T	2
16	D372 3521	Pulley - 20T	2
17	D372 3516	Timing Belt - 60S3M492	2
18	D372 3512	Cover - Timing Belt	2
19	B872 2614	Bushing:R1	2
20	AX04 0248	DC Motor:Tray:Upper Lower:Drive:4.8W	1
21	D372 3513	Drive Shaft - Tray Lift	1
22	D372 3514	Gear - 30Z	1
23	5215 2621	Snap Ring - M6	1
24	D372 3231	Rear Side Plate - Tray Lift	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	0450 3008N	Tapping Screw - M3x8	
104	0353 0040N	Screw - M3x4	
105	0805 0089	Retaining Ring - M4	
106	0805 3385	Bushing - 6mm	
107	1105 0623	Clamp - LBWS-0206S-V0	
108	0720 0060E	Retaining Ring - M6	
109	0720 0040E	Retaining Ring - M4	
110	0450 4020N	Tapping Screw - M4x20	
111	0623 0140G	Spring Pin - 3x14	

8. Drive Section (D585)




8. Drive Section (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D372 2432	Tension Spring - Tightener	1
2	D372 2421	Bracket - Tightener	1
3	A548 2139	Pulley	2
4	AA14 3790	Screw:Contact Point	1
5	AA04 3633	Timing Belt - 40S3M312	1
6	D372 2414	Timing Pulley - 14T/37T	1
7	AA04 3620	Timing Belt - 40S2M102	1
8	D372 2455	Bracket:Motor:Transport:Ass'y	1
9	D372 5892	Cushion - Stepper Motor	1
10	D372 2418	Heat Sink:Motor:Transport	1
11	D372 5802	Stepper Motor - DC 4W	1
12	D372 5221	Upper Bracket - PCB	1
13	D585 5100	PCB:Main Control:Ass'y	1
14	D372 5210	Harness - Jogger	1
15	D372 5250	Harness - Entrance Sensor	1
16	D372 5430	Harness:Stapler:Sensor	1
17	D372 5241	Harness:Stapler Unit	1
18	D372 5201	Interface Harness	1
19	D372 5222	Lower Upper Bracket - PCB	1
20	AX04 0236	Stepper Motor - DC 20.4W	1
21	D372 2511	Bracket:Gathering Roller:Drive:Ass'y	1
22	D372 2521	Cam - Lever	1
23	AW02 0203	Photointerruptor:GP1A173LCS2F	2
24	D372 3518	Down Sensor Bracket	1
25	D372 2522	Lever	1
26	D372 2523	Tension Spring - Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0360 3008P	Screw - M3x8	
104	0451 3008N	Tapping Screw - M3x8	
105	0451 3006N	Tapping Screw - 3x6	
106	1105 0623	Clamp - LBWS-0206S-V0	
107	0453 3006N	Tapping Screw - M3x6	
108	1105 0487	Harness Clamp	
109	1105 0522	Edge Saddle - LES0510	
110	0805 0089	Retaining Ring - M4	
111	1105 0723	Clamps:WES-0507	

9. Decals and Documents (D585)


1




2



3



4



9. Decals and Documents (D585)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D585 6811	Decal:Staple:Pick-up Paper Jam	1
2	D585 6812	Decal:Staple Exchange	1
3	D585 6813	Decal:Misfeed Removal	1
4	D585 6814	Decal:Caution:Paper:Pick-up	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D585 1512	Cover:Rear	3 - 1
D585 1523	Door:Front:Staple Exchange	3 - 10
D585 1524	Hinge:Door:Fix:Staple Exchange	3 - 7
D585 1525	Hinge:Door:Staple Exchange	3 - 6
D585 1531	Cover:Exit	5 - 1
D585 1571	Cover:Front:EXP:Ass'y	3 - 5
D585 2311	Cover:Transport	5 - 17
D585 3100	End Fence:Ass'y	15 - 2
D585 3111	End Fence	15 - 3
D585 3411	Tray:Exit	3 - 2
D585 3412	Tray:Exit:Slide:Middle	3 - 4
D585 3413	Tray:Exit:Slide:Auxiliary	3 - 3
D585 4143	Tray:Staple:Rear	11 - 5
D585 4147	Tray:Staple:Front	11 - 6
D585 4164	Jogger Fence:Rear	11 - 2
D585 4168	Jogger Fence:Front	11 - 4
D585 4195	Tray:Staple:Middle	11 - 7
D585 4197	Tray:Staple:Middle:Auxiliary	11 - 8
D585 4592	Guide:Standard Fence:Stapler:Ass'y	13 - 28
D585 5100	PCB:Main Control:Ass'y	17 - 13
D585 6215	Cover:Stand	3 - 11
D585 6811	Decal:Staple:Pick-up Paper Jam	5 - 3
D585 6811	Decal:Staple:Pick-up Paper Jam	19 - 1
D585 6812	Decal:Staple Exchange	19 - 2
D585 6812	Decal:Staple Exchange	3 - 8
D585 6813	Decal:Misfeed Removal	5 - 2
D585 6813	Decal:Misfeed Removal	19 - 3
D585 6814	Decal:Caution:Paper:Pick-up	3 - 9
D585 6814	Decal:Caution:Paper:Pick-up	19 - 4

Part No.	Description	Page and Index No.
A353 2763	Washer - M5	11 - 36
A548 2139	Pulley	17 - 3
A666 3180	Timing Pulley - Z32	11 - 32
A681 4515	Bushing - 6mm	11 - 1
B352 1607	Timing Pulley - T20-S3M	7 - 17
B352 1607	Timing Pulley - T20-S3M	5 - 10
B352 4318	Bushing - Lower Slider	13 - 20
B872 2515	Cushion:Bracket:Feed	7 - 7
B872 2614	Bushing:R1	15 - 19
B872 2614	Bushing:R1	5 - 11
D372 1112	Lever:Un Lock	7 - 1
D372 1113	Tension Spring - Lever	7 - 2
D372 1542	Bracket - Door Switch	7 - 12
D372 1543	Spring Plate - Door Switch	7 - 13
D372 2112	Exit Roller	7 - 22
D372 2113	Timing Pulley - 22T	7 - 15
D372 2114	Guide - Trailing Edge	7 - 21
D372 2121	Holder - Reverse Roller	7 - 24
D372 2122	Shaft - Reverse Roller	7 - 23
D372 2123	Gear - 20Z	7 - 25
D372 2124	Reverse Roller	7 - 26
D372 2131	Roller Arm	7 - 6
D372 2132	Drive Shaft - Roller	7 - 18
D372 2133	Shaft - Roller Fix	7 - 8
D372 2134	Timing Pulley - 18T	7 - 20
D372 2135	Gathering Roller	7 - 9
D372 2136	Ground Plate	7 - 14
D372 2141	Entrance Roller	5 - 12
D372 2212	Entrance Sensor Bracket	5 - 13
D372 2216	Guide Plate:Transport:Ass'y	5 - 9
D372 2221	Upper Guide Plate - Exit	5 - 5
D372 2222	Discharge Brush:Exit	5 - 4
D372 2231	Exit Lever	7 - 4
D372 2232	Tension Spring - Exit Lever	7 - 5
D372 2241	Switch Holder	7 - 11

Part No.	Description	Page and Index No.
D372 2312	Compression Spring	5 - 15
D372 2414	Timing Pulley - 14T/37T	17 - 6
D372 2418	Heat Sink:Motor:Transport	17 - 10
D372 2421	Bracket - Tightener	17 - 2
D372 2432	Tension Spring - Tightener	17 - 1
D372 2455	Bracket:Motor:Transport:Ass'y	17 - 8
D372 2511	Bracket:Gathering Roller:Drive:Ass'y	17 - 21
D372 2521	Cam - Lever	17 - 22
D372 2522	Lever	17 - 25
D372 2523	Tension Spring - Lever	17 - 26
D372 3121	Guide - Paper Sensor	15 - 7
D372 3122	Stopper - Paper Sensor	15 - 8
D372 3132	Release Lever	15 - 11
D372 3141	Torsion Spring - Front	15 - 6
D372 3142	Torsion Spring - Inner Back	15 - 12
D372 3145	Cushion - Guide Plate	15 - 4
D372 3152	Bracket - Solenoid	15 - 5
D372 3211	Tray Base Plate	15 - 1
D372 3221	Front Side Plate - Tray Lift	15 - 13
D372 3223	Timing Belt Stopper	15 - 14
D372 3231	Rear Side Plate - Tray Lift	15 - 24
D372 3511	Pulley - 20T	15 - 15
D372 3512	Cover - Timing Belt	15 - 18
D372 3513	Drive Shaft - Tray Lift	15 - 21
D372 3514	Gear - 30Z	15 - 22
D372 3516	Timing Belt - 60S3M492	15 - 17
D372 3518	Down Sensor Bracket	17 - 24
D372 3521	Pulley - 20T	15 - 16
D372 4111	Stay:Jogger:Ass'y	11 - 39
D372 4115	Front Cover - Jogger Sensor	11 - 24
D372 4116	Rear Cover - Jogger Sensor	11 - 26
D372 4122	Bracket - Exit Belt	11 - 23
D372 4126	Exit Belt - 140S2M200	11 - 35
D372 4127	Pawl - Exit Belt	11 - 34
D372 4128	Pawl Cover - Exit Belt	11 - 33

Part No.	Description	Page and Index No.
D372 4131	Exit Shaft	11 - 31
D372 4132	Idler Shaft - Exit	11 - 21
D372 4133	Pulley - 16T	11 - 30
D372 4134	Pulley - 24T	11 - 22
D372 4159	Guide Shaft - Jogger Fence	11 - 3
D372 4162	Motor Bracket	11 - 37
D372 4163	Timing Pulley - 18T	11 - 28
D372 4172	Rear Slider - Standard Fence	11 - 18
D372 4173	Rear Standard Fence	11 - 16
D372 4174	Rack - Standard	11 - 19
D372 4176	Front Slider - Standard Fence	11 - 13
D372 4178	Rear Guide - Standard Fence	11 - 15
D372 4179	Front Guide - Standard Fence	11 - 10
D372 4181	Rear Slide Shaft - Standard Fence	11 - 17
D372 4182	Front Slide Shaft - Standard Fence	11 - 12
D372 4183	Standard Fence:Staple:Trailing Edge:Front	11 - 11
D372 4186	Pinion Holder - Standard Fence	11 - 20
D372 4187	Guide:Stapler:Rear	11 - 40
D372 4188	Guide:Stapler:Front	11 - 41
D372 4198	Guide:Exit	9 - 26
D372 4212	Stay:Exit	9 - 5
D372 4216	Bracket:Guide:Harness	9 - 27
D372 4242	Bracket - Exit Motor	9 - 4
D372 4243	Heat Sink - Exit Motor	9 - 2
D372 4261	Bracket - Exit	9 - 19
D372 4265	Cam Shaft - Slide	9 - 21
D372 4266	Arm Shaft - Exit	9 - 20
D372 4267	Slider Shaft - Standard Fence	9 - 22
D372 4268	Exit Arm	9 - 6
D372 4269	Pulley/Arm - Standard Fence	9 - 16
D372 4272	Slider - Standard Fence	9 - 25
D372 4277	Standard Fence - Middle	9 - 24
D372 4281	Shaft - Standard Fence	9 - 8
D372 4282	Pulley - 32T	9 - 10
D372 4283	Pulley - 16T	9 - 18

Part No.	Description	Page and Index No.
D372 4284	Pulley - 32T/16T	9 - 14
D372 4285	Pulley - 16T	9 - 12
D372 4291	Tension Spring:Return:Standard Fence	11 - 14
D372 4292	Tension Spring - ARM	9 - 9
D372 4512	Shaft - Stapler	13 - 12
D372 4513	Front/Rear Rail - Stapler	13 - 4
D372 4514	Middle Rail - Stapler	13 - 10
D372 4518	Cover Bracket - Rear Lower	13 - 3
D372 4524	Gear/Pulley - 40Z/20T	13 - 6
D372 4531	Tightener Bracket	13 - 9
D372 4534	Tension Spring - Stapler	13 - 11
D372 4535	Pulley - 20T	13 - 7
D372 4541	Base - Stapler	13 - 16
D372 4545	Bracket - Staple	13 - 21
D372 4546	Bracket - End Fence	13 - 15
D372 4547	Spacer - Stapler	13 - 14
D372 4548	Stay - Stapler Timing Belt	13 - 13
D372 4552	Gear - Stapler	13 - 17
D372 4553	Turn Gear - Stapler	13 - 19
D372 4555	Holder:Bracket:Gear:Pressure	13 - 24
D372 4556	Bracket:Stapler:Positioning:Peen	13 - 25
D372 4559	Tension Spring - Gear	13 - 23
D372 4561	Spacer:DIA4	13 - 26
D372 4562	Timing Belt - B60S3M900	13 - 5
D372 4564	Stapler Guide	13 - 29
D372 4567	Bracket:Gear:Stapler	13 - 18
D372 4568	Bracket:Stapler	13 - 27
D372 4570	Gear Bracket - Pressure	13 - 30
D372 5201	Interface Harness	17 - 18
D372 5210	Harness - Jogger	17 - 14
D372 5220	Interface Harness - End Fence	15 - 9
D372 5221	Upper Bracket - PCB	17 - 12
D372 5222	Lower Upper Bracket - PCB	17 - 19
D372 5241	Harness:Stapler Unit	17 - 17
D372 5250	Harness - Entrance Sensor	17 - 15

Part No.	Description	Page and Index No.
D372 5430	Harness:Stapler:Sensor	17 - 16
D372 5802	Stepper Motor - DC 4W	17 - 11
D372 5802	Stepper Motor - DC 4W	9 - 1
D372 5803	Stepper Motor - 20.4W	13 - 1
D372 5892	Cushion - Stepper Motor	9 - 3
D372 5892	Cushion - Stepper Motor	17 - 9
D372 5892	Cushion - Stepper Motor	13 - 2
D372 6116	Lower Guide Plate - Connecting	3 - 14
D372 6117	Upper Guide Plate - Connecting	3 - 13
D372 6118	Stay - Connecting Bracket	3 - 16
D372 6121	Bracket - Lock Lever Cover	3 - 18
D372 6122	Cover Bracket - Lower Right	3 - 17
D372 6130	Bracket:Coupling:Main:Ass'y	3 - 15
D372 6211	Left Stand	3 - 12
G020 5626	Push Switch	5 - 18

Part No.	Description	Page and Index No.
AA04 3328	Timing Belt:40S2M130	9 - 13
AA04 3604	Timing Belt:B40S2M110	9 - 15
AA04 3620	Timing Belt - 40S2M102	17 - 7
AA04 3632	Timing Belt - 40S2M126	7 - 19
AA04 3633	Timing Belt - 40S3M312	17 - 5
AA04 3634	Timing Belt - 40S2M296	11 - 29
AA04 3635	Timing Belt - 40S2M276	11 - 27
AA04 3636	Timing Belt - 40S2M96	9 - 17
AA04 3637	Timing Belt - 40S2M124	9 - 11
AA06 3529	Pressure Spring - 14.5MM	5 - 6
AA08 0237	Bushing - 4x5x7	5 - 7
AA08 2101	Bushing - 6x10x6	7 - 10
AA14 3702	Screw:Pin:Positioning	7 - 3
AA14 3788	Pin:Guide Plate:Paper Feed	7 - 16
AA14 3790	Screw:Contact Point	5 - 19
AA14 3790	Screw:Contact Point	17 - 4
AA14 3790	Screw:Contact Point	13 - 22
AB01 1252	Gear - 20Z	9 - 23
AF02 2097	Driven Roller	5 - 8
AG07 0514	Magnet Catch	5 - 16
AW02 0154	Photointerruptor:Entrance	5 - 14
AW02 0203	Photointerruptor:GP1A173LCS2F	15 - 10
AW02 0203	Photointerruptor:GP1A173LCS2F	17 - 23
AW02 0203	Photointerruptor:GP1A173LCS2F	9 - 7
AW02 0203	Photointerruptor:GP1A173LCS2F	13 - 8
AW02 0203	Photointerruptor:GP1A173LCS2F	11 - 25
AX04 0235	Stepper Motor - 20.4W	11 - 38
AX04 0236	Stepper Motor - DC 20.4W	17 - 20
AX04 0248	DC Motor:Tray:Upper Lower:Drive:4.8W	15 - 20
GW01 0007	Photo Reflection Sensor:Exit	11 - 9

Part No.	Description	Page and Index No.
0242 0035N	Pan Head Screw:M2x3.5	11 - 107
0353 0040N	Screw - M3x4	15 - 104
0353 0140N	Screw:M3x14	7 - 102
0360 3006P	Screw - M3x6	13 - 103
0360 3008P	Screw - M3x8	17 - 103
0360 3008P	Screw - M3x8	9 - 101
0450 3008N	Tapping Screw - M3x8	3 - 102
0450 3008N	Tapping Screw - M3x8	11 - 103
0450 3008N	Tapping Screw - M3x8	13 - 106
0450 3008N	Tapping Screw - M3x8	15 - 103
0450 4020N	Tapping Screw - M4x20	15 - 110
0451 3006N	Tapping Screw - 3x6	11 - 101
0451 3006N	Tapping Screw - 3x6	15 - 102
0451 3006N	Tapping Screw - 3x6	9 - 102
0451 3006N	Tapping Screw - 3x6	13 - 101
0451 3006N	Tapping Screw - 3x6	7 - 101
0451 3006N	Tapping Screw - 3x6	17 - 105
0451 3006N	Tapping Screw - 3x6	5 - 104
0451 3008N	Tapping Screw - M3x8	5 - 101
0451 3008N	Tapping Screw - M3x8	13 - 102
0451 3008N	Tapping Screw - M3x8	15 - 101
0451 3008N	Tapping Screw - M3x8	17 - 104
0451 3008N	Tapping Screw - M3x8	3 - 101
0451 4014N	Tapping Screw:M4x14	3 - 104
0451 4020N	Tapping Screw - M4x20	3 - 105
0451 4025N	Tapping Screw:M4x25	3 - 106
0452 3008N	Tapping Screw - M3x8	9 - 104
0453 3006N	Tapping Screw - M3x6	17 - 107
0453 3006N	Tapping Screw - M3x6	11 - 105
0454 3006Q	Tapping Screw - M3x6	5 - 102
0454 3006Q	Tapping Screw - M3x6	3 - 103
0454 3006Q	Tapping Screw - M3x6	17 - 101
0623 0140G	Spring Pin - 3x14	15 - 111
0632 0100G	Pin - 2x10mm	11 - 110
0710 0020P	Hexagonal Nut:M2	11 - 108

Part No.	Description	Page and Index No.
0720 0040E	Retaining Ring - M4	11 - 104
0720 0040E	Retaining Ring - M4	13 - 104
0720 0040E	Retaining Ring - M4	7 - 103
0720 0040E	Retaining Ring - M4	17 - 102
0720 0040E	Retaining Ring - M4	15 - 109
0720 0040E	Retaining Ring - M4	9 - 103
0720 0060E	Retaining Ring - M6	15 - 108
0720 0060E	Retaining Ring - M6	13 - 105
0805 0088	Retaining Ring - M6	5 - 105
0805 0089	Retaining Ring - M4	17 - 110
0805 0089	Retaining Ring - M4	11 - 102
0805 0089	Retaining Ring - M4	13 - 107
0805 0089	Retaining Ring - M4	7 - 104
0805 0089	Retaining Ring - M4	15 - 105
0805 3385	Bushing - 6mm	7 - 105
0805 3385	Bushing - 6mm	11 - 109
0805 3385	Bushing - 6mm	15 - 106
0805 3385	Bushing - 6mm	9 - 108
1105 0326	Locking Support	13 - 109
1105 0328	Harness Clamp - ES-0505	9 - 106
1105 0487	Harness Clamp	17 - 108
1105 0511	Harness Clamp - LWS-0306ZC	5 - 103
1105 0522	Edge Saddle - LES0510	9 - 107
1105 0522	Edge Saddle - LES0510	17 - 109
1105 0619	Clamp:LBWS-0605S-V0	9 - 105
1105 0619	Clamp:LBWS-0605S-V0	13 - 108
1105 0623	Clamp - LBWS-0206S-V0	15 - 107
1105 0623	Clamp - LBWS-0206S-V0	17 - 106
1105 0623	Clamp - LBWS-0206S-V0	11 - 106
1105 0723	Clamps:WES-0507	17 - 111
1204 2515	Micro Switch - DE2L-FJ10	7 - 106
1204 2612	Micro Switch:D3V-16506-3C25	7 - 107

Part No.	Description	Page and Index No.
5215 2621	Snap Ring - M6	15 - 23