

Punch Unit PU5000 (B831)

Second Edition. March 2009

Punch Unit PU5000 (B831)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Punch Unit (B831)	2
Parts Index	6

March 2, 2009

1.Punch Unit (B831)



1.Punch Unit (B831)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B831 3000	Punch Unit (2-3Hole NA)	1
*	B831 4000	Punch Unit (2-4Hole EU)	1
*	B831 5000	Punch Unit (Punch-4 NE)	1
1	B531 5241	Harness:Sensor:Punch	1
2	B531 5221	Harness:Sensor:Punch:Home Position Sensor	1
3	AW02 0156	Photointerruptor:EE-SX4235A-P2	2
4	B831 1211	Sensor:Punch Bracket	1
5	AA04 3226	Timing Belt - 180S2M	1
6	B831 1110	Stepper Motor DC1.76V 7.3W	1
7	B531 5230	Harness:Motor:Punch	1
8	B831 5510	PCB Punch	1
9	5875 2088	Shoulder Screw - M4	4
10	B831 3212	Guide Plate:Punch:2-3Hole:NA (-01)	2
10	B831 4212	Guide Plate:Punch:2-4Hole:EU (-02)	2
10	B831 5212	Guide Plate:Punch:4:NE (-03)	2
11	B531 3215	Film:Guide:Punch:2-3Hole:NA (-01)	1
11	A812 7145	Film:Guide:Punch (-02)	1
11	A812 7141	Guide Mylar (-03)	1
12	A377 7161	Punch Knob	1
13	A812 7200	Dust Hopper (-02)	1
13	A812 7240	Dust Hopper (-01/-03)	1
14	A606 1885	Decal - Hopper	1
15	A812 7214	Film - Front (-02)	1
15	A812 7245	Film - Front (-01/-03)	1
16	A812 7215	Film - Rear (-02)	1
16	A812 7246	Film - Rear (-01/-03)	1
17	A812 7212	Pin - Front	1
18	A812 7213	Pin - Rear	1
19	AW01 0123	Photo Refiection Sensor:PSR11D1-B	1
20	A812 7323	Dust Hopper Stopper	1
21	A812 7331	Lock Spring	1
22	AA14 3790	Screw:Contact Point	1
23	B531 5200	Harness:PCB:Punch	1
24	B545 7411	Spacer:2mm	1
25	B545 7412	Spacer:1mm	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0951 4006P	Screw:Polished Round:M4x6	
103	0451 3010N	Tapping Screw:3x10	
104	0451 4008N	Tapping Screw:4x8	
105	0313 0100N	Pan Head Screw:M3x10	
106	1105 0522	Edge Saddle - LES0510	
107	1105 0192	Locking Support	
108	1607 0623	Ferrite Core - TFC-16-8-13	



Parts Index

Parts Index

Part No.	Description	Page and Index No.
B831 1110	Stepper Motor DC1.76V 7.3W	3 - 6
B831 1211	Sensor:Punch Bracket	3 - 4
B831 3000	Punch Unit (2-3Hole NA)	3 - *
B831 3212	Guide Plate:Punch:2-3Hole:NA (-01)	3 - 10
B831 4000	Punch Unit (2-4Hole EU)	3 - *
B831 4212	Guide Plate:Punch:2-4Hole:EU (-02)	3 - 10
B831 5000	Punch Unit (Punch-4 NE)	3 - *
B831 5212	Guide Plate:Punch:4:NE (-03)	3 - 10
B831 5510	PCB Punch	3 - 8

Part No.	Description	Page and Index No.
A377 7161	Punch Knob	3 - 12
A606 1885	Decal - Hopper	3 - 14
A812 7141	Guide Mylar (-03)	3 - 11
A812 7145	Film:Guide:Punch (-02)	3 - 11
A812 7200	Dust Hopper (-02)	3 - 13
A812 7212	Pin - Front	3 - 17
A812 7213	Pin - Rear	3 - 18
A812 7214	Film - Front (-02)	3 - 15
A812 7215	Film - Rear (-02)	3 - 16
A812 7240	Dust Hopper (-01/-03)	3 - 13
A812 7245	Film - Front (-01/-03)	3 - 15
A812 7246	Film - Rear (-01/-03)	3 - 16
A812 7323	Dust Hopper Stopper	3 - 20
A812 7331	Lock Spring	3 - 21
B531 3215	Film:Guide:Punch:2-3Hole:NA (-01)	3 - 11
B531 5200	Harness:PCB:Punch	3 - 23
B531 5221	Harness:Sensor:Punch:Home Position Sensor	3 - 2
B531 5230	Harness:Motor:Punch	3 - 7
B531 5241	Harness:Sensor:Punch	3 - 1
B545 7411	Spacer:2mm	3 - 24
B545 7412	Spacer:1mm	3 - 25

Part No.	Description	Page and Index No.
AA04 3226	Timing Belt - 180S2M	3 - 5
AA14 3790	Screw:Contact Point	3 - 22
AW01 0123	Photo Refiection Sensor:PSR11D1-B	3 - 19
AW02 0156	Photointerruptor:EE-SX4235A-P2	3 - 3

Part No.	Description	Page and Index No.
0313 0100N	Pan Head Screw:M3x10	3 - 105
0451 3006N	Tapping Screw - 3x6	3 - 101
0451 3010N	Tapping Screw:3x10	3 - 103
0451 4008N	Tapping Screw:4x8	3 - 104
0951 4006P	Screw:Polished Round:M4x6	3 - 102
1105 0192	Locking Support	3 - 107
1105 0522	Edge Saddle - LES0510	3 - 106
1607 0623	Ferrite Core - TFC-16-8-13	3 - 108

