

SR750 (A763)

This parts catalog is includes MB No. 1 to 2

SR750 (A763)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.


LOCATION OF UNIT	2
1.EXTERIOR 1 (A763)	8
2.EXTERIOR 2 (A763)	10
3.EXTERIOR 3 (A763)	12
4.EXTERIOR 4 (A763)	14
5.ENTRANCE GUIDE SECTION 1 (A763)	16
6.ENTRANCE GUIDE SECTION 2 (A763)	18
7.STAPLE TRAY GUIDE UNIT (A763)	20
8.UPPER EXIT UNIT (A763)	22
9.JOGGER SECTION (A763)	24
10.LOWER EXIT UNIT (A763)	26
11.TRANSPORT SECTION 1 (A763)	28
12.TRANSPORT SECTION 2 (A763)	30
13.TRANSPORT SECTION 3 (A763)	32
14.FINISHER STAPL UNIT (A763)	34
15. TRAY DRIVE SECTION (A763)	36
16.FINISHER DRIVE SECTION (A763)	38

17.BOOKLET TRANSPORT SECTION 1 (A763) ..	40
18.BOOKLET TRANSPORT SECTION 2 (A763) ..	42
19.BOOKLET PAPER GUIDE 1 (A763)	44
20.BOOKLET PAPER GUIDE 2 (A763)	46
21.BOOKLET STAPLE UNIT (A763)	48
22.PAPER FOLDER UNIT 1 (A763)	50
23.PAPER FOLDER UNIT 2 (A763)	52
24.BOOKLET DRIVE SECTION (A763)	54
25.BOOKLET EXIT SECTION (A763)	56
PARTS INDEX.....	59

July ,30 ' 2002


LOCATIONS OF UNITS

1. EXTERIOR 1 (A763)




See Page 9

2. EXTERIOR 2 (A763)




See Page 11

3. EXTERIOR 3 (A763)




See Page 13

4. EXTERIOR 4 (A763)




See Page 15

5. ENTRANCE GUIDE SECTION 1 (A763)



See Page 17


6. ENTRANCE GUIDE SECTION 2 (A763)



See Page 19


LOCATIONS OF UNITS

7. STAPLE TRAY GUIDE UNIT (A763)




See Page 21

8. UPPER EXIT UNIT (A763)




See Page 23

9. JOGGER SECTION (A763)




See Page 25

10. LOWER EXIT UNIT (A763)




See Page 27

11. TRANSPORT SECTION 1 (A763)



See Page 29


12. TRANSPORT SECTION 2 (A763)



See Page 31


LOCATIONS OF UNITS

13. TRANSPORT SECTION 3 (A763)




See Page 33

14. FINISHER STAPL UNIT (A763)




See Page 35

15. TRAY DRIVE SECTION (A763)




See Page 37

16. FINISHER DRIVE SECTION (A763)




See Page 39

17. BOOKLET TRANSPORT SECTION 1



See Page 41


18. BOOKLET TRANSPORT SECTION 2



See Page 43


LOCATIONS OF UNITS

19. BOOKLET PAPER GUIDE 1 (A763)




See Page 45

20. BOOKLET PAPER GUIDE 2 (A763)




See Page 47

21. BOOKLET STAPLE UNIT (A763)




See Page 49

22. PAPER FOLDER UNIT 1 (A763)




See Page 51

23. PAPER FOLDER UNIT 2 (A763)




See Page 53

24. BOOKLET DRIVE SECTION (A763)




See Page 55

LOCATIONS OF UNITS

25. BOOKLET EXIT SECTION (A763)  See Page 57		

1.EXTERIOR 1 (A763)




1.EXTERIOR 1 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFC1 6314	Slide Shoe	1
2	VFA6 0777	Grounding Plate	1
3	V4A1 4478	Tray Cover	1
4	V4A1 5555	Joint Rail	1
5	VFA6 0914	Guide Roller	1
6	V4F1 1298	Caster Support Bracket	1
7	VFS6 2556	Spring	1
8	VFB3 7307	Sensor Actuator	1
9	VWG8 5309	Photointerrupter	1
10	V4A1 4515	Shift Tray Sensor Cover	1
11	VFF5 5689	Relay Harness - Tray Sensor	1
12	V4A1 4514	Shift Tray	1
13	V4A1 4545	Proof Tray	1
14	V4A1 5553	Joint Bracket	1
15	V4F1 1297	Rail Mounting Plate	1
16	V4A1 5538	Limit Sensor Feeler	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 4010W	Binding Self-Tapping Screw - M4X10	
102	0951 4006W	Philips Screw With Flat Washer - M4X6	
103	0452 3006W	Tapping Screw - 3X6	
104	0354 0060W	Philips Truss Head Screw - M4X6	
105	0314 0200Z	Philips Screw - 4x20	

2.EXTERIOR 2 (A763)




2.EXTERIOR 2 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4A1 4489	Lower Rear Cover	1
2	V4A1 4494	Upper Rear Cover	1
3	VRS5 2596	Spring	1
4	VFB3 7310	Sensor Actuator	1
5	V4A1 5552	Right Cover	1
6	VFB3 7436	Door Hinge	1
7	V4A1 4490	Right Front Cover	1
8	VXA9 0732	Screw	32
9	VFB3 7958	Right Cover	1
10	V4F1 1014	Upper Inner Cover	1
11	V4A1 4520	Upper Door Actuator	1
12	V4F1 1024	Upper Door	1
13	VFB3 7962	Front Door Hinge	1
14	V4A1 4492	Lower Door	1
15	V4A1 4488	Lower Inner Cover	1
16	V4A1 4487	Folder Roller Knob	1
17	VRB2 1624	Caster	1
18	VFB4 0655	Caster	1
19	V4A1 5525	Rail Bracket	1
20	V4A1 4481	Front Stand Cover	1
21	V4A1 4482	Rear Stand Cover	1
22	VFS5 9579	Stepped Screw	1
23	V4A1 6206	Decal - Misfeed Removal	1
24	V4A1 4543	Decal - Upper Door	1
25	V4A1 4537	Decal - Lower Door	1
26	V4A1 4538	Decal - Caution	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082W	Tapping Screw With Flat Washer - M4X8	

3.EXTERIOR 3 (A763)




3.EXTERIOR 3 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4G1 3233	Slide Guide Ass'y	1
2	V4A1 4511	Slider	1
3	V4A1 4512	Front Slide Cover	1
4	V4A1 4513	Rear Slide Cover	1
5	V4A1 4484	Front Slider Stopper	1
6	V4A1 4485	Rear Slider Stopper	1
7	V4A1 4479	Guide Plate	1
8	V4G1 3235	Upper Tray Guide Ass'y	1
9	V4A1 4516	Shift Guide Shutter	1
10	VFB3 9408	Leaf Spring	2
11	VFB3 9401	Guide Plate Stay	1
12	V4A1 2460	Cushion	2
13	VFF3 4080	Shutter Sensor Harness	1
14	VFF6 0639	Shutter Holder Ass'y	1
15	VWG8 5364	Photointerrupter	1
16	VFB3 7253	Damper	1
17	VFB3 7285	Shutter Damper	1
18	V4A1 5551	Lower Shift Guide	1
19	V4A1 4519	Shift Guide Plate - 4	2
20	VFB5 6240	Shift Guide Plate - 3	2
21	VFB4 9168	Mylar	1
22	VFB5 5908	Grounding Plate	2
23	V4A1 2461	Cushion	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 4008B	Binding Self Tapping Screw - M4x8	
102	0452 4012B	Philips Tapping Screw - M4x12	
103	0452 3008B	Tapping Screw - M3X8	
104	0252 0080W	Screw - M2X8	
105	0353 0040B	Screw - M3X4	

4.EXTERIOR 4 (A763)




4.EXTERIOR 4 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFS5 6546	Roller	2
2	VXA9 0732	Screw	4
3	VFB3 7903	Plate Spring	2
4	V4F1 1028	Exit Upper Guide	1
5	VFB3 7855	Discharge Brush	1
6	V4A1 4526	Exit Guide	1
7	VFS5 6545	Roller	1
8	VFB3 7971	Spring	1
9	V4A1 4554	Sensor Cover	1
10	V4F1 1317	Paper Sensor Harness	1
11	V4H1 6280	Sensor	1
12	V4A1 4480	Slide Table	1
13	VFS6 2567	Spring	1
14	V4G1 3225	Top Cover	1
15	VFS6 2545	Spring	1
16	V4A1 4502	Grip	1
17	VFS6 2544	Spring	2
18	VFB3 7357	Pressure Ring	2
19	VFS5 6516	Washer	2
20	V4A1 4524	Booklet Tray	1
21	VFF3 4081	Trailing Sensor Harness	1
22	VWG8 5362	Photointerrupter	1
23	VFB3 7905	Sensor Actuator	1
24	VFB3 7964	Torsion Spring	1
25	V4A1 4525	Booklet Tray Sensor Cover	1
26	VFB4 9175	Cushion	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060W	Philips Pan Head Screw - M3X6	
102	0413 0252W	Tapping Screw - M3x25	
103	0452 4010B	Tapping Bind Screw - M4x10	
104	0452 3008B	Tapping Screw - M3X8	
105	0452 4008W	Tapping Bind Screw - M4X8	

5.ENTRANCE GUIDE SECTION 1 (A763)




5.ENTRANCE GUIDE SECTION 1 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VWG8 5364	Photointerrupter	3
2	V4A1 5535	Sensor Holder	1
3	VFB4 0654	Paper Pressure Arm	1
4	VFS6 2649	Spring	1
5	VFB3 7395	Sensor Actuator	1
6	VFS6 2552	Spring	1
7	V4A1 5544	I Guide Pressure Spring	2
8	V4A1 5531	Lower Entrance Guide	1
9	VWT2 0308	Clamp	1
10	V4A1 5542	Harness Guide	1
11	V4A1 5532	Roller Holder	4
12	VFS6 2555	Spring Plate	4
13	V4A1 5536	Transport Roller	4
14	V4A1 5534	Leaf Spring	2
15	V4A1 5543	Grounding Plate	1
16	VFS2 9407	Stepped Screw	1
17	V4A1 5540	Exit Sensor Actuator	1
18	V4A1 5541	Exit Sensor Actuator Spring	1
19	V4A1 5539	Guide Sensor Holder	1
20	V4A1 5533	Antistatic Brush	1
21	V4F1 1287	Relay Harness	1
22	V4G1 3546	Guide Unit - R70	1
23	V4A1 4506	Joint Shaft	1
24	VFB4 9690	Grounding Spring	1
25	VFB4 9689	Grounding Spring - F	1
26	VFS6 2547	Spring	1
27	VFB3 7322	Pin	2
28	VXA9 0732	Screw	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0413 0062F	bind Tapping Screw - M3x6	
102	0414 0082F	Philips Truss Head Screw - M4x8	
103	0414 0102F	Tapping Screw - M4x10	
104	0353 0060W	Philips Pan Head Screw - M3X6	
105	0720 0050E	Retaining Ring - M5	

6.ENTRANCE GUIDE SECTION 2 (A763)




6.ENTRANCE GUIDE SECTION 2 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4A1 5516	Lower Entrance Guide	1
2	V4F1 1286	Entrance/Transport Harness	1
3	V4K1 1046	Stepping Motor	1
4	VXF2 16070	Timing Belt - B40S2M140	1
5	V4A1 5520	Pulley - 19T	1
6	VXG9 0407	Bearing - 6x10x3	2
7	VFB5 6222	Entrance Sensor Holder	1
8	VFE9 0018	Stepped Screw - M3	1
9	VWG8 5364	Photointerrupter	1
10	VFB5 6223	Entrance Sensor Feeler	1
11	VFS7 2476	Spring	1
12	V4A1 5519	Entrance Transport Roller	1
13	V4A1 5517	Front Side Plate	1
14	V4A1 5518	Rear Side Plate	1
15	V4A1 5522	Lower Entrance Guide	1
16	V4A1 5521	Upper Guide Spring	2
17	V4A1 5523	Upper Entrance Guide	1
18	V4A1 5524	Entrance Support Guide	1
19	V4A1 5557	Entrance Roller Spring	4
20	VFS5 6518	Roller	4
21	V4A1 5559	Grounding Plate	1
22	VWT2 5026	Clamp	1
23	VWT2 5598	Clamp	2
24	VXA9 0732	Screw	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0060W	Tapping Screw - M4X6	
102	0414 0082F	Philips Truss Head Screw - M4x8	
103	0720 0030E	Retaining Ring - M3	
104	0313 0060W	Philips Pan Head Screw - M3X6	
105	0413 0062F	Bind Tapping Screw - M3x6	

7.STAPLE TRAY GUIDE UNIT (A763)




7.STAPLE TRAY GUIDE UNIT (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFB3 7272	Rear Sheet	2
2	VFS1 1187	Bushing	2
3	VXD1 1106	Spacer	1
4	VFS5 3547	Gear - 18Z	1
5	VFB3 7298	Shutter Cam	1
6	VFF3 4021	Detector Harness	1
7	VFF3 4020	Detector Harness	1
8	VWG8 5364	Photointerrupter	1
9	VWT2 5035	Edge Sadle	1
10	VFB5 5842	Switch Plate - Exit Sensor	1
11	VFF3 4079	Grounding Wire	1
12	VFB5 5834	Stapler Support Guide - Rear	1
13	VFH7 7419	Photointerrupter	1
14	VFB4 6656	Transport Belt	2
15	VFB5 6250	Paper Guide Mylar - F	1
16	VFB5 5909	Exit Roller - 1D	1
17	VFS7 0830	Gear	1
18	VFS7 0829	Gear	1
19	VFS6 2543	Spring	1
20	VFB4 9051	Exit Sensor Actuator	1
21	VFB5 5833	Stapler Support Guide - Front	1
22	VFB5 6251	Paper Guide Mylar - RR	1
23	VFF6 0434	Stp Guide Ass'y	1
24	VFB5 5854	Pressure Roller	2
25	VFB3 7292	Sensor Bracket	1
26	VFB5 5903	Release Roller - B	2
27	VFB5 5902	Release Roller - A	2
28	VFB5 5901	Roller Holder	2
29	VXA9 0732	Screw	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0050E	Retaining Ring - M5	
102	0632 0080G	Parallel Key - 2x8mm	
103	0252 0140W	Philips Pan Head Screw - M2x14	
104	0353 0040W	Philips Pan Head Bind Screw -M3X4	
105	0452 4010W	Binding Self-Tapping Screw - M4X10	
106	0452 4008W	Tapping Bind Screw - M4X8	
107	1105 0199	Clamp	

8.UPPER EXIT UNIT (A763)




8.UPPER EXIT UNIT (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFS5 6514	Roller	2
2	VFB3 7289	Roller Shaft	1
3	VFB3 7283	Lever	1
4	VFS6 2562	Spring	1
5	V4G1 3554	Upper Exit Guide Arm Unit	1
6	VFB5 6242	Antistatic Brush FD	2
7	VFB4 6651	Antistatic Brush	1
8	VFB4 9054	Antistatic Brush	1
9	VFB4 9053	Antistatic Brush FD	2
10	VFB5 5852	Grounding Plate - Exit Guide	1
11	V4A1 2449	Front Grounding Plate	1
12	VFB4 6649	Grounding Plate	1
13	V4A1 2250	Rear Grounding Plate	1
14	VFS5 6531	Roller	2
15	VFB4 8153	Roller Holder	2
16	VFS6 2541	Spring	1
17	VFS6 2648	Spring	1
18	VFF6 0420	Trailing Edge Guide Plate 2R	1
19	VFB3 7284	Plate Spring	1
20	VFF6 0419	Trailing Edge Guide Plate 2R	1
21	VFB3 7288	Paddle Shaft	1
22	VFS5 1805	Bushing	2
23	VFB5 5858	Paper Guide Plate - 1	2
24	VFB4 8147	Cushion	2
25	VFH7 5979	Solenoid	1
26	VFS5 3542	Gear - 21Z	1
27	VRB1 2190	Spring Hook	1
28	VFS6 2542	Spring	1
29	VFS5 3541	Gear - 21Z	1
30	VFF5 5654	Paddle Drive Plate	1
31	V4G1 3542	Upper Exit Guide Unit	1
32	VFB4 6826	Paddle Holder	2
33	VFB4 6825	Paddle	4
34	VFB5 5851	Support Plate - Exit Guide	1
35	VFB5 5850	Swing Guide Arm	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 4006B	Philips Screw With Washer - M4x6	
102	0452 4008W	Tapping Bind Screw - M4X8	
103	0353 0040W	Philips Pan Head Bind Screw -M3X4	
104	0720 0050E	Retaining Ring - M5	
105	0632 0080G	Parallel Key - 2x8mm	

9.JOGGER SECTION (A763)




9.JOGGER SECTION (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFB5 5847	Shutter Link - A	1
2	VFS6 2647	Spring	1
3	VFB3 7249	Shutter Link	1
4	VFF6 0428	Jogger Motor Holder	1
5	VFB5 5846	Stopper Holder Plate - R	1
6	VFB5 5845	Stopper Holder Plate - R	1
7	VFB5 5835	Stopper Link - R	1
8	VFB3 7409	Link	2
9	VFB5 5836	Stopper - R	1
10	VFS6 2646	Spring	2
11	VFB5 5848	Stopper Shaft Collar	1
12	VFB3 7400	Front Stopper Lever	1
13	VFS6 2565	Spring	2
14	VFB3 9409	Front Stopper	1
15	VFH6 1342	Stepping Motor - DC 14.4W	1
16	VWT2 5035	Edge Sadle	1
17	VWG8 5364	Photointerrupter	2
18	VFB3 9403	Spacer	1
19	VFS5 3548	Coupled Gear - 12Z/36Z	1
20	VFB3 7252	Shutter Lever	1
21	V4F1 1299	Jogger Shutter Ass'y	1
22	VFS6 2650	Spring	1
23	VFH7 5940	Solenoid	1
24	VFB5 5859	Stopper Shaft Collar	1
25	VFS6 2778	Spring	2
26	VWT2 5357	Clamp	4
27	VFS5 1004	Bushing - 5mm	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0050E	Retaining Ring - M5	
102	0452 4008W	Tapping Bind Screw - M4X8	
103	0720 0030E	Retaining Ring - M3	
104	0353 0040W	Philips Pan Head Bind Screw -M3X4	
105	0951 3008W	Philips Screw With Flat Washer - M3x8	
106	0623 0080E	Spring Pin - 3x8mm	

10.LOWER EXIT UNIT (A763)




10.LOWER EXIT UNIT (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFB5 5853	Exit Support Guide	1
2	VFS7 0833	Gear	1
3	VFB5 5860	Collar	1
4	VRB1 2190	Spring Hook	1
5	VFB5 5857	Shutter Cam Spring	1
6	VFF6 0425	Rear Bracket	1
7	VFB4 9056	Shift Guide Mylar - M	1
8	VXF2 16078	Timing Belt - B40S2M156	1
9	VXF9 0719	Timing Belt - B40S2M196	1
10	VFH6 1781	Motor	1
11	VFH6 1460	Motor - DC 4.8W	1
12	VFH7 7394	Photointerruptor	2
13	VFB5 5843	Sensor Bracket - Exit Motor	1
14	VFS5 3849	Pulley	1
15	VFS5 3850	Gear - 30/14Z	1
16	VFS7 0834	Gear - 15Z	1
17	VFS5 3563	Gear - 23/15Z	1
18	VFS7 0831	Gear - 15/34Z	1
19	VFS7 0832	Gear - 20Z	2
20	VFB5 5913	Exit Gear Flange	1
21	VFS5 3540	Gear - 25Z	1
22	VFS7 2480	Spring	1
23	VFF3 4018	Main Harness - Swing Guide	1
24	V4A1 5564	Jogger Fence	1
25	VXG3 60103	Ball Bearing	1
26	V4F1 1290	Staple Tray Ass'y	1
27	VFB5 5849	Exit Roller - 2	1
28	VRB1 8589	Seal	1
29	VFB4 6655	Mylar	1
30	VFS5 6526	Washer	1
31	VFB3 9407	Leaf Spring	1
32	VFB3 9404	Silencer Sheet	1
33	VFS1 1213	Bushing - 6mm	1
34	VFB5 5840	Actuator - Stapler Tray Sensor	1
35	VFS7 2481	Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0030E	Retaining Ring - M3	
102	0720 0050E	Retaining Ring - M5	
103	0720 0040E	Retaining Ring - M4	
104	0353 0040W	Philips Pan Head Bind Screw -M3X4	

11.TRANSPORT SECTION 1 (A763)




11.TRANSPORT SECTION 1 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4G1 3229	Middle Transport Unit	1
2	VFB3 7417	Junction Gate	1
3	VFS6 2546	Spring	1
4	V4F1 1019	Upper Guide	1
5	VFB3 7423	Junction Gate Holder	1
6	VFS5 6530	Roller	2
7	VFB4 8148	Guide	1
8	VFF5 7557	Middle Guide Plate	1
9	VWG8 5309	Photointerrupter	1
10	V4F1 1316	Relay Harness	1
11	VFS5 3550	Gear - 35Z	1
12	VFB3 7419	Guide Plate	1
13	VFS6 2548	Spring	8
14	VFS5 6517	Roller	8
15	VFS6 2550	Spring	1
16	VFB3 7420	Sensor Actuator	1
17	VFS1 1508	Bushing	1
18	VFB4 5387	Roller Shaft	1
19	VFB4 5388	Roller - 1	4
20	VFB4 5389	Roller - 2	2
21	VFS1 1187	Bushing	1
22	V4F1 1292	Solenoid	1
23	VFB3 7422	Guide Roller Holder	4
24	VFS5 6518	Roller	6
25	VFB3 7415	Plate Spring	2
26	V4F1 1020	Guide Grip	1
27	V4G1 3228	Upper Transport Unit	1
28	V4A1 4542	Decal - R2	1
29	V4A1 4541	Decal - R1	1
30	V4A1 6205	Decal - Misfeed Removal	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0040W	Philips Pan Head Bind Screw -M3X4	
102	0632 0080G	Parallel Key - 2x8mm	
103	0720 0050E	Retaining Ring - M5	
104	1105 0199	Clamp	
105	0314 0060W	Philips Pan Head Screw - M4X6	
106	0413 0062W	Tapping Screw - M3x6	
107	0452 4010W	Binding Self-Tapping Screw - M4X10	

12.TRANSPORT SECTION 2 (A763)




12.TRANSPORT SECTION 2 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4A1 5528	Rear Inner Guide	1
2	VXA9 0732	Screw	6
3	VFB4 0657	Grounding Plate	1
4	VFS1 1187	Bushing	1
5	V4A1 5529	Exit Support Roller	1
6	VFS1 1213	Bushing - 6mm	1
7	VFS5 3561	Pulley - 26Z	1
8	V4A1 5550	Buffer Entrance	1
9	VFB3 7403	Rear Stopper Lever	1
10	VFB3 7404	Junction Gate	1
11	VFB3 7366	Solenoid Bracket	1
12	VFF5 5668	Solenoid	1
13	VFS6 2549	Spring	2
14	VFB3 7405	Junction Gate Lever	1
15	VFB3 7406	Junction Gate Lever	1
16	VFF5 5667	Solenoid	1
17	VFB3 7407	Junction Gate Lever	1
18	VFB3 7431	Link	1
19	VFF5 5666	Solenoid	1
20	VFF5 5669	Solenoid Bracket	1
21	V4A1 5562	Buffer Entrance Spring	1
22	V4A1 5560	Cushion	1
23	V4A1 5561	Proof Exit Guide	1
24	V4A1 4879	Support Guide Mylar	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0050E	Retaining Ring - M5	
102	0632 0100G	Pin - 2x10mm	
103	0353 0040W	Philips Pan Head Bind Screw -M3X4	

13.TRANSPORT SECTION 3 (A763)




13.TRANSPORT SECTION 3 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VXA9 0732	Screw	12
2	VFB3 7975	Stay	2
3	VXG9 0407	Bearing - 6x10x3	2
4	VFF5 5809	Guide Holder	1
5	VFS5 3549	Gear - 21Z	1
6	VFB3 7399	Switch Bracket	1
7	VFF3 4074	Detector Harness	1
8	VFB4 0656	Leaf Spring	1
9	VFB3 7434	Sensor Bracket	1
10	VWG8 5364	Photointerrupter	2
11	VWT2 0136	Clamp	4
12	VFB4 8148	Guide	1
13	VFB4 9157	Torsion Spring	1
14	VFB3 7963	Guide Plate	1
15	VFB3 7438	Transport Roller	1
16	V4A1 4883	Tension Spring	1
17	VFB5 5830	Middle Frame	1
18	VFB3 7398	Harness Guide	1
19	VFF5 5662	Tightener	1
20	VFB5 5868	Holder Plate	1
21	VFB5 5870	Release Link - A	1
22	VFB5 5898	Release Link - B	1
23	VFB5 5899	Release Link - C	1
24	VFB5 5900	Release Link Shaft	1
25	VFF6 0426	RB Release Holder 1	1
26	VFF6 0640	Release Solenoid Ass'y	1
27	VFF6 0427	RB Release Holder 3	2
28	VFS7 2482	Spring	1
29	VFB5 6243	Cushion	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0229	Clamp	
102	0720 0050E	Retaining Ring - M5	
103	0314 0060W	Philips Pan Head Screw - M4X6	
104	1105 0310	Harness Clamp - LWS-1S	

14.FINISHER STAPL UNIT (A763)




14.FINISHER STAPL UNIT (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4G1 3559	Staple Unit - R70	1
2	VFF3 4069	Stapler Relay Harness	1
3	VFB3 7373	Guide Plate	1
4	VFB3 7375	Bracket	1
5	VFB3 7371	Stapler Guide	1
6	VFS5 6524	Roller	1
7	VFB3 7382	Stopper Cam	1
8	VFS5 6525	Washer	1
9	VFS5 3551	Gear/Pulley - 44Z/16Z	1
10	VFS5 3552	Gear/Pulley - 16Z/40Z	1
11	VFB3 7380	Timing Belt - B40S2M264	1
12	VFS5 6528	Washer	2
13	VFS1 9102	Stepped Screw - M3	4
14	VFS5 6523	Roller	2
15	VFB3 7367	Grounding Plate	1
16	VFH6 1343	Stepping Motor - DC 14.4W	1
17	VFF3 4077	Stapler Harness	1
18	VFG5 8191	Stapler Relay Harness	1
19	VFB3 7318	Board Cover	1
20	VFB3 7372	Rack	1
21	VFB4 6652	Upper Entrance Guide	1
22	V4A1 4504	Stapler	1
23	V4A1 4505	Stapler Cover	1
24	VFF3 4078	Stapler Harness 2	1
25	VFB3 7374	Sensor Cover	1
26	VWG8 5364	Photointerrupter	1
27	VWT2 5472	Clamp	1
28	VFB4 6653	Lower Entrance Guide	1
29	VFB5 6261	Securing Plate	1
30	VFF5 5699	Staple Unit Holder MB2 ADDED	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006W	Tapping Screw - M3x6	
102	0720 0050E	Retaining Ring - M5	
103	0353 0040W	Philips Pan Head Bind Screw - M3X4	
104	0452 3008W	Binding Self Tapping Screw - M3x8	
105	0354 0060W	Philips Truss Head Screw - M4X6	
106	0720 0070E	Retaining Ring - M7	
107	0451 4006Z	Tapping Screw 4x6	
108	1105 0229	Clamp	

15. TRAY DRIVE SECTION (A763)




15. TRAY DRIVE SECTION (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFB4 0659	Harness Guide	1
2	VXA9 0732	Screw	7
3	VFG6 6242	Tray Drive Unit	1
4	VFS1 1273	Bushing	1
5	VFB4 0658	Cam	1
6	VFB5 5865	Gear - 22Z	1
7	VFS5 6527	Washer	1
8	VFS6 2561	Spring	1
9	VFG5 8190	Sensor PCB	1
10	VFS7 0835	Gear - 48Z	2
11	VFB5 5862	Drive Bracket Base	1
12	VFS1 1189	Bushing	2
13	VFH7 1763	Motor - DC 21.6W	1
14	VFB3 7306	Guide Plate	1
15	VFB5 5864	Tray Drive Shaft	1
16	VFF5 5660	Front Tray Frame	1
17	V4F1 1319	Tray Unit Relay Harness	1
18	V4G1 3232	Shift Tray Ass'y	1
19	VFB3 7302	Slide Guide A	1
20	VFB3 7344	Roller	4
21	VFF5 7554	Rear Tray Frame	1
22	VFB3 7303	Slide Guide B	1
23	V4A1 4552	Shift Tray Stay	2
24	VFB3 7365	Roller	2
25	VWT2 5123	Clamp	1
26	VFB3 7304	Bracket	1
27	VFB5 5863	Lower Drive Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0632 0160G	Parallel Pin-m2x16	
102	0353 0040W	Philips Pan Head Bind Screw -M3X4	
103	0633 0160E	Pin - 3x16mm	
104	0452 3008W	Binding Self Tapping Screw - M3x8	
105	0720 0070E	Retaining Ring - M7	
106	0354 0060W	Philips Truss Head Screw - M4x6	
107	0704 0040E	Toothed Washer - M4	
108	0720 0050E	Retaining Ring - M5	
109	0354 0060W	Philips Truss Head Screw - M4X6	
110	1105 0229	Clamp	

16.FINISHER DRIVE SECTION (A763)




16.FINISHER DRIVE SECTION (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4G1 1203	Interface Harness	1
2	VXA9 0732	Screw	10
3	V4A1 5558	Gear - 18Z	1
4	VFS7 0827	Gear - 20/21/21Z	1
5	V4A1 4553	Harness Guide	1
6	VFF3 4074	Detector Harness	1
7	VFB3 7345	Sensor Cover	1
8	VFS6 2563	Spring Plate	1
9	VWT2 0204	Clamp	1
10	V4A1 5546	Pulley Gear - 32Z	1
11	V4A1 4550	Finisher Board Bracket	1
12	VXF2 16050	Timing Belt - B40S2M100	2
13	VFF3 4071	Booklet Interface Harness	1
14	VXF2 16098	Timing Belt - B40S2M196	1
15	V4G1 3536	Finisher Board	1
16	V4F1 1301	IC - M27C4002-80XF1	1
17	V4G1 3548	Transfer Drive Unit - R70	1
18	VFS5 6520	Roller	1
19	V4K1 1046	Stepping Motor - DC 18W	2
20	VXF2 16172	Timing Belt - B40S2M344	1
21	V4A1 5545	Transport Gear - 25/45/85Z	1
22	V4F1 1296	Drive Bracket	1
23	V4G1 3537	Main Harness	1
24	VVT2 5027	Cap	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060B	Philips Pan Head Screw - M3x6	
102	1105 0310	Harness Clamp - LWS-1S	
103	0720 0050E	Retaining Ring - M5	
104	0353 0040W	Philips Pan Head Bind Screw -M3X4	

17.BOOKLET TRANSPORT SECTION 1 (A763)




17.BOOKLET TRANSPORT SECTION 1 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFF3 4086	Relay Harness - Paper Size	1
2	VFG5 8408	Paper Size Sensor PCB	1
3	VFS1 9166	Stepped Screw - M4	1
4	VFB3 7846	Sensor Actuator	1
5	VFB3 7848	Torsion Spring	1
6	VFB3 7847	Sensor Board	1
7	VXA9 0732	Screw	11
8	VFS1 1187	Bushing	1
9	VFB3 7849	Guide Plate	1
10	VFF5 8683	Antistatic Brush	1
11	VFB3 7928	Junction Gate	2
12	VFB3 7949	Upper Slide Rail	1
13	VFB3 7915	Entrance Roller	1
14	VFB4 9171	Switch Holder	1
15	VFS5 9212	Stepped Screw	1
16	VFB3 7979	Sensor Actuator	1
17	VFB3 7980	Torsion Spring	1
18	VWG8 5362	Photointerrupter	2
19	VWC4 5128	Microswitch	1
20	VFS6 2576	Spring	2
21	VFB3 7930	Junction Gate Lever	2
22	VFS1 1213	Bushing - 6mm	1
23	V4A1 4549	Guide Mylar	1
24	V4A1 4809	Guide Mylar Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060W	Philips Pan Head Screw - M3X6	
102	0720 0050E	Retaining Ring - M5	
103	0252 0080W	Screw - M2X8	

18.BOOKLET TRANSPORT SECTION 2 (A763)




18.BOOKLET TRANSPORT SECTION 2 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFB3 7950	Lower Rail	1
2	VXA9 0732	Screw	11
3	VFB3 7883	Right Cover Bracket	2
4	VFB3 7953	Upper Plate	1
5	VFS6 4200	Shaft	1
6	VFB3 7984	Sensor Actuator	1
7	VFF3 3111	Paper Pass Sensor Harness	1
8	VFB3 7985	Torsion Spring	1
9	VWG8 5362	Photointerrupter	2
10	VFB3 7885	Sensor Bracket	1
11	VWT2 5056	Clamp	2
12	VFB4 9171	Switch Holder	1
13	VWC4 5128	Microswitch	1
14	VFB3 7976	Switch Bracket	1
15	VFF5 5809	Guide Holder	1
16	V4A1 4535	Entrance Guide Grip	1
17	VFS6 2581	Spring	2
18	VFB3 7854	Discharge Brush	1
19	VWS6 5091	Connector	1
20	VWT2 0369	Clamp	1
21	VFF5 8684	Antistatic Brush	1
22	VFB3 7853	Guide Plate	1
23	VFS5 6544	Roller	2
24	VFB3 7851	Plate Spring	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0183	Spacer	
102	0720 0030E	Retaining Ring - M3	
103	1105 0310	Harness Clamp - LWS-1S	
104	0353 0040W	Philips Pan Head Bind Screw -M3X4	
105	0354 0080W	Philips Pan Head Screw - M4x8	
106	0353 0080W	Tapping Screw - M3x8	
107	1105 0229	Clamp	

19.BOOKLET PAPER GUIDE 1 (A763)




19.BOOKLET PAPER GUIDE 1 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VXA9 0732	Screw	4
2	VFB3 7891	Shaft	1
3	VFB3 7892	Shaft	1
4	VFB3 7894	Guide	1
5	VFB3 7955	Stay	1
6	VXF9 0669	Timing Belt - B40S2M438	2
7	VFS5 3574	Gear - 30Z	2
8	VFS6 2571	Spring	2
9	VFB3 7977	Guide	1
10	VWT2 5031	Clamp	2
11	VFH6 1527	Motor - DC 12.72W	1
12	VFB3 7897	Belt Holder	2
13	VFS6 0820	Coupled Gear - 15Z/30Z	1
14	VFS5 3575	Gear - 30Z	1
15	VFS6 0821	Gear - 30Z	2
16	VWT2 5056	Clamp	1
17	VFB3 7896	Torsion Spring	1
18	VFB3 7895	Sensor Actuator	1
19	VFS5 9212	Stepped Screw	1
20	VFF3 4132	Paper Position Sensor Harness	1
21	VWG8 5382	Photointerrupter	1
22	V4G1 3539	Booklet Unit Board	1
23	V4F1 1302	IC - CY27H010-70WC	1
24	VFB3 7893	Stopper	1
25	VFG3 1373	Main Saddle Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060W	Philips Pan Head Screw - M3X6	
102	0353 0120W	Philips Pan Head Screw - M3x12	
103	0720 0050E	Retaining Ring - M5	
104	1105 0229	Clamp	
105	1105 0310	Harness Clamp - LWS-1S	

20.BOOKLET PAPER GUIDE 2 (A763)




20.BOOKLET PAPER GUIDE 2 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFG5 8390	Lower Bus Guide Ass'y	1
2	VXF9 0646	Timing Belt - B40S2M286	1
3	VFF3 4087	Relay Harness	1
4	VWG8 5362	Photointerrupter	2
5	VFF5 5804	Motor Bracket	1
6	VFB3 7878	Guide Gear Holder	2
7	VFF5 5798	Guide Plate	1
8	VFS6 0814	Pulley/gear - 32Z/32Z	1
9	VWT2 5056	Clamp	1
10	VFH6 1457	Motor - DC 12.72W	1
11	VXA9 0732	Screw	4
12	VFS6 0815	Pulley/gear - 16Z/32Z	1
13	VWT2 5031	Clamp	1
14	VFB3 7946	Sensor Bracket	1
15	VFB3 7947	Rear Slide Guide	1
16	VFB3 7945	Guide Roller	1
17	VFS6 2570	Spring	1
18	VFB3 7877	Rear Guide Gear	1
19	VFB3 7926	Roller Bracket	1
20	VFB3 7927	Idle Roller	3
21	VFS6 4200	Shaft	1
22	VFB3 7876	Front Guide Gear	1
23	VFB3 7875	Roller Guide	1
24	VFS1 1187	Bushing	2
25	VFB3 7923	Cam Shaft	1
26	VFB3 7920	Middle Roller	1
27	VFB3 7943	Front Side Guide	1
28	VFB3 7944	Rear Side Guide	1
29	VFB3 7973	Link	1
30	VFS1 1213	Bushing - 6mm	2
31	VFS5 3580	Gear - 24Z	1
32	VFS6 2574	Spring	1
33	VFS6 2583	Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0050E	Retaining Ring - M5	
102	0353 0040W	Philips Pan Head Bind Screw -M3X4	
103	0720 0040E	Retaining Ring - M4	
104	0313 0060W	Philips Pan Head Screw - M3X6	
105	1105 0201	Harness Clamp	
106	1105 0310	Harness Clamp - LWS-1S	
107	1105 0229	Clamp	
108	0413 0082W	Tapping Screw - M3x8	

21.BOOKLET STAPLE UNIT (A763)




21.BOOKLET STAPLE UNIT (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4G1 3243	Stapler Ass'y	1
2	V4A1 4531	Booklet Stapler	2
3	VFB4 9159	Stapler Sheet	2
4	VFS1 9076	Stepped Screw - M1.9	2
5	VFS5 1753	Bushing	2
6	VFS6 2569	Spring	1
7	VFB2 6416	Plastic Washer	2
8	VFB3 7863	Stopper	1
9	VXA9 0732	Screw	16
10	V4A1 4532	Booklet Stapler Cover	1
11	VFB3 7866	Stapler Positioning Pin	1
12	VFB3 7859	Stapler Guide	3
13	VFB3 7871	Cover	1
14	VFB4 9158	Leaf Spring	1
15	VWT2 0136	Clamp	1
16	VFS6 2572	Spring	2
17	VFF3 4084	Stapler Relay Harness	1
18	VFS2 9407	Stepped Screw	2
19	VFB3 7865	Upper Slider	2
20	VFB3 7862	Slide Shaft	1
21	VFB3 7867	Lower Slider	1
22	VFB3 7981	Plate Spring	1
23	V4A1 4533	Rail Cover	1
24	VFS6 4199	Shaft	1
25	VFS5 6549	Roller	1
26	VFA9 3739	Stapler Unit Grip	1
27	VFB3 7864	Plate	1
28	VFB3 7861	Guide	1
29	VFB3 7857	Stay	1
30	VFB3 7858	Stapler Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006Z	Tapping Screw 4x6	
102	0720 0070E	Retaining Ring - M7	
103	1105 0229	Clamp	
104	0354 0100W	Philips Pan Head Screw - M4x10	
105	0720 0050E	Retaining Ring - M5	

22.PAPER FOLDER UNIT 1 (A763)




22.PAPER FOLDER UNIT 1 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VWT2 5056	Clamp	4
2	VFB3 7974	Sensor Bracket	1
3	VFH7 7394	Photointerruptor	2
4	VXA9 0732	Screw	5
5	V4A1 4527	Folder Table Knob	1
6	VFB3 7882	Guide Gear Holder	1
7	VFS6 0816	Gear - 42Z	1
8	VFS1 1510	Bushing	1
9	VFS6 0819	Pulley/gear - 44Z/24Z	2
10	VXF9 0698	Timing Belt - B60S3M192	2
11	VFS6 0828	Coupled Gear - 16Z/60Z	1
12	VFS6 0831	Gear - 16Z	1
13	VFS1 1206	Bushing	1
14	VFS6 2578	Spring	1
15	VFB3 7884	Sensor Bracket	1
16	VFB3 7918	Shaft	1
17	VRS1 1042	Bushing	1
18	VFS6 0833	Gear - 16Z	1
19	VFH6 1455	Motor - DC 55.5W	1
20	VFS6 0817	Gear - 16Z	1
21	VFH6 1456	Motor - DC 28.8W	1
22	VFS1 9073	Stepped Screw - 8.2	1
23	VFB3 7941	Stopper	1
24	VWG8 5362	Photointerrupter	2
25	VFB3 7869	Guide Pulley	1
26	VFS5 1754	Bushing	5
27	VFB3 7937	Link	2
28	VFS1 1189	Bushing	4
29	VFS6 2582	Spring	1
30	VFB3 7888	Folder Bracket	1
31	VFB5 5939	Folder Plate	1
32	VFB3 7889	Folder Holder	1
33	VFB3 7870	Shaft	1
34	VFS6 0824	Gear - 44Z	1
35	VFS6 2579	Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	VFB4 9172	Back Up Plate	1
37	VFF5 5799	Motor Bracket	1
101	0720 0070E	Retaining Ring - M7	
102	0951 4006W	Philips Screw With Flat Washer - M4X6	
103	0354 0060W	Philips Truss Head Screw - M4X6	
104	0633 0200G	Pin - M3x20	
105	0622 0100E	Spring Pin - 2x10MM	

23.PAPER FOLDER UNIT 2 (A763)




23.PAPER FOLDER UNIT 2 (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VFS1 1187	Bushing	3
2	VFS6 0823	Gear - 16Z	1
3	VFS6 0829	Coupled Gear - 16Z/56Z	1
4	VXG9 0131	Ball Bearing - 12x28x7	4
5	VFB3 7934	Rear Rack Gear	1
6	VFS6 0830	Gear - 16Z	1
7	VFB3 7940	Rear Pressure Lever	1
8	VFS1 9076	Stepped Screw - M1.9	2
9	VFS6 2580	Spring	2
10	VFB3 7939	Front Pressure Lever	1
11	VWT2 5031	Clamp	1
12	VFF3 4085	Relay Harness - Cover Sensor	1
13	VFB3 7873	Switch Bracket	1
14	VXA9 0732	Screw	4
15	VWT2 5056	Clamp	2
16	VWC4 5128	Microswitch	1
17	VFB4 9171	Switch Holder	1
18	VWG8 5362	Photointerrupter	3
19	VFB3 7967	Front Rack Gear	1
20	VFB3 7856	Front Roller Holder	1
21	VFB5 5936	Folding Roller	2
22	VFB3 7969	Rear Roller Holder	1
23	VFB3 7935	Drive Shaft	1
24	VFB3 7911	Shaft	1
25	VFB3 7912	Roller	2
26	VFB3 7954	Guide Sheet	1
27	VFF5 5810	Roller Guide	1
28	VFS1 1213	Bushing - 6mm	1
29	VFB3 7925	Sensor Actuator	1
30	VFS6 0822	Coupled Gear - 16Z/33Z	1
31	VFB3 7948	Sensor Bracket	1
32	VFB3 7884	Sensor Bracket	1
33	VFB5 5937	Positioning Roller Sensor Actuator	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0050E	Retaining Ring - M5	
102	0725 0150E	Retaining Ring C - M15	
103	0353 0080W	Tapping Screw - M3x8	
104	0353 0060W	Philips Pan Head Screw - M3X6	
105	1105 0310	Harness Clamp - LWS-1S	
106	0252 0080W	Screw - M2X8	

24.BOOKLET DRIVE SECTION (A763)




24.BOOKLET DRIVE SECTION (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	VWG8 5309	Photointerrupter	1
2	VFB3 7351	Sensor Bracket	1
3	VXA9 0732	Screw	11
4	VWC4 5130	Microswitch	1
5	VFB3 7350	Holder	1
6	VFB3 7353	Bracket	1
7	VFS6 2564	Spring	1
8	VFH7 5766	Solenoid	2
9	VFB3 7931	Solenoid Bracket	2
10	VXF9 0647	Timing Belt - B40S3M1119	1
11	VFS5 3577	Gear - 39Z	1
12	VFS5 3409	Idle Pulley	2
13	VFF5 5807	Motor Bracket	1
14	VFS6 2573	Spring	1
15	VFH7 5767	Solenoid	1
16	VFF5 5806	Solenoid Bracket	1
17	VFS5 3576	Gear - 30Z	1
18	VFS5 6550	Washer	1
19	VFH6 1458	Motor - DC 7.68W	1
20	VFS1 9054	Stepped Screw	1
21	VFB3 7972	Link	1
22	VFS6 0832	Coupled Gear - 22Z/48Z	1
23	VFH6 1457	Motor - DC 12.72W	1
24	VFS5 6547	Washer	1
25	V4A1 4740	Transport Idle Roller	1
26	VXF2 13038	Timing Belt - B40S2M114	1
27	VFF5 5805	Tightener	1
28	V4F1 1095	Transport Motor Bracket	1
29	VFS6 2574	Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0623 0080E	Spring Pin - 3x8mm	
102	0353 0040W	Philips Pan Head Bind Screw -M3X4	
103	0623 0100E	Spring Pin - 3x10mm	
104	0720 0050E	Retaining Ring - M5	
105	1105 0310	Harness Clamp - LWS-1S	

25.BOOKLET EXIT SECTION (A763)



25.BOOKLET EXIT SECTION (A763)

Index No.	Part No.	Description	Q'ty Per Assembly
1	V4G1 3242	Exit Frame Ass'y	1
2	VFB3 7929	Lock Lever	2
3	VFC1 7432	Torsion Spring	1
4	VFA2 8244	Bushing	2
5	VFS1 1187	Bushing	1
6	V4A1 4530	Grip	1
7	V4A1 4544	Exit Roller	1
8	VFB4 9165	Paddle Holder	1
9	VFB4 9166	Paddle	1
10	VFB3 7978	Discharge Brush	1
11	VFB3 7909	Exit Sensor Cover	1
12	VFB3 7904	Release Shaft	1
13	VFB3 7907	Torsion Spring	1
14	VFB3 7910	Photosensor	1
15	VWG8 5362	Photointerrupter	1
16	VFF3 4073	Relay Harness - Exit Sensor	1
17	VFB3 7966	Grounding Plate	1
18	VFS6 0825	Gear - 71Z	1
19	VFB3 7906	Idle Roller	1
20	VFS6 0826	Gear - 17Z	1
21	VFS1 1213	Bushing - 6mm	1
22	V4A1 2349	Door Shaft	1
23	VFF5 5802	Idler Gear Bracket	1
24	VFB4 9168	Mylar	1
25	VFB3 7932	Grounding Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060W	Philips Pan Head Screw - M3X6	
102	0720 0050E	Retaining Ring - M5	
103	0452 4008W	Tapping Bind Screw - M4X8	
104	0314 0060W	Philips Pan Head Screw - M4X6	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
V4A1 2250	Rear Grounding Plate	23 - 13
V4A1 2349	Door Shaft	57 - 22
V4A1 2449	Front Grounding Plate	23 - 11
V4A1 2460	Cushion	13 - 12
V4A1 2461	Cushion	13 - 23
V4A1 4478	Tray Cover	9 - 3
V4A1 4479	Guide Plate	13 - 7
V4A1 4480	Slide Table	15 - 12
V4A1 4481	Front Stand Cover	11 - 20
V4A1 4482	Rear Stand Cover	11 - 21
V4A1 4484	Front Slider Stopper	13 - 5
V4A1 4485	Rear Slider Stopper	13 - 6
V4A1 4487	Folder Roller Knob	11 - 16
V4A1 4488	Lower Inner Cover	11 - 15
V4A1 4489	Lower Rear Cover	11 - 1
V4A1 4490	Right Front Cover	11 - 7
V4A1 4492	Lower Door	11 - 14
V4A1 4494	Upper Rear Cover	11 - 2
V4A1 4502	Grip	15 - 16
V4A1 4504	Stapler	35 - 22
V4A1 4505	Stapler Cover	35 - 23
V4A1 4506	Joint Shaft	17 - 23
V4A1 4511	Slider	13 - 2
V4A1 4512	Front Slide Cover	13 - 3
V4A1 4513	Rear Slide Cover	13 - 4
V4A1 4514	Shift Tray	9 - 12
V4A1 4515	Shift Tray Sensor Cover	9 - 10
V4A1 4516	Shift Guide Shutter	13 - 9
V4A1 4519	Shift Guide Plate - 4	13 - 19
V4A1 4520	Upper Door Actuator	11 - 11
V4A1 4524	Booklet Tray	15 - 20
V4A1 4525	Booklet Tray Sensor Cover	15 - 25
V4A1 4526	Exit Guide	15 - 6
V4A1 4527	Folder Table Knob	51 - 5
V4A1 4530	Grip	57 - 6

Part No.	Description	Page and Index No.
V4A1 4531	Booklet Stapler	49 - 2
V4A1 4532	Booklet Stapler Cover	49 - 10
V4A1 4533	Rail Cover	49 - 23
V4A1 4535	Entrance Guide Grip	43 - 16
V4A1 4537	Decal - Lower Door	11 - 25
V4A1 4538	Decal - Caution	11 - 26
V4A1 4541	Decal - R1	29 - 29
V4A1 4542	Decal - R2	29 - 28
V4A1 4543	Decal - Upper Door	11 - 24
V4A1 4544	Exit Roller	57 - 7
V4A1 4545	Proof Tray	9 - 13
V4A1 4549	Guide Mylar	41 - 23
V4A1 4550	Finisher Board Bracket	39 - 11
V4A1 4552	Shift Tray Stay	37 - 23
V4A1 4553	Harness Guide	39 - 5
V4A1 4554	Sensor Cover	15 - 9
V4A1 4740	Transport Idle Roller	55 - 25
V4A1 4809	Guide Mylar Plate	41 - 24
V4A1 4879	Support Guide Mylar	31 - 24
V4A1 4883	Tension Spring	33 - 16
V4A1 5516	Lower Entrance Guide	19 - 1
V4A1 5517	Front Side Plate	19 - 13
V4A1 5518	Rear Side Plate	19 - 14
V4A1 5519	Entrance Transport Roller	19 - 12
V4A1 5520	Pulley - 19T	19 - 5
V4A1 5521	Upper Guide Spring	19 - 16
V4A1 5522	Lower Entrance Guide	19 - 15
V4A1 5523	Upper Entrance Guide	19 - 17
V4A1 5524	Entrance Support Guide	19 - 18
V4A1 5525	Rail Bracket	11 - 19
V4A1 5528	Rear Inner Guide	31 - 1
V4A1 5529	Exit Support Roller	31 - 5
V4A1 5531	Lower Entrance Guide	17 - 8
V4A1 5532	Roller Holder	17 - 11
V4A1 5533	Antistatic Brush	17 - 20

Part No.	Description	Page and Index No.
V4A1 5534	Leaf Spring	17 - 14
V4A1 5535	Sensor Holder	17 - 2
V4A1 5536	Transport Roller	17 - 13
V4A1 5538	Limit Sensor Feeler	9 - 16
V4A1 5539	Guide Sensor Holder	17 - 19
V4A1 5540	Exit Sensor Actuator	17 - 17
V4A1 5541	Exit Sensor Actuator Spring	17 - 18
V4A1 5542	Harness Guide	17 - 10
V4A1 5543	Grounding Plate	17 - 15
V4A1 5544	I Guide Pressure Spring	17 - 7
V4A1 5545	Transport Gear - 25/45/85Z	39 - 21
V4A1 5546	Pulley Gear - 32Z	39 - 10
V4A1 5550	BuFfer Entrance	31 - 8
V4A1 5551	Lower Shift Guide	13 - 18
V4A1 5552	Right Cover	11 - 5
V4A1 5553	Joint Bracket	9 - 14
V4A1 5555	Joint Rail	9 - 4
V4A1 5557	Entrance Roller Spring	19 - 19
V4A1 5558	Gear - 18Z	39 - 3
V4A1 5559	Grounding Plate	19 - 21
V4A1 5560	Cushion	31 - 22
V4A1 5561	Proof Exit Guide	31 - 23
V4A1 5562	BuFfer Entrance Spring	31 - 21
V4A1 5564	Jogger Fence	27 - 24
V4A1 6205	Decal - Misfeed Removal	29 - 30
V4A1 6206	Decal - Misfeed Removal	11 - 23
V4F1 1014	Upper Inner Cover	11 - 10
V4F1 1019	Upper Guide	29 - 4
V4F1 1020	Guide Grip	29 - 26
V4F1 1024	Upper Door	11 - 12
V4F1 1028	Exit Upper Guide	15 - 4
V4F1 1095	Transport Motor Bracket	55 - 28
V4F1 1286	Entrance/Transport Harness	19 - 2
V4F1 1287	Relay Harness	17 - 21
V4F1 1290	Staple Tray Ass'y	27 - 26

Part No.	Description	Page and Index No.
V4F1 1292	Solenoid	29 - 22
V4F1 1296	Drive Bracket	39 - 22
V4F1 1297	Rail Mounting Plate	9 - 15
V4F1 1298	Caster Support Bracket	9 - 6
V4F1 1299	Jogger Shutter Ass'y	25 - 21
V4F1 1301	IC - M27C4002-80XF1	39 - 16
V4F1 1302	IC - CY27H010-70WC	45 - 23
V4F1 1316	Relay Harness	29 - 10
V4F1 1317	Paper Sensor Harness	15 - 10
V4F1 1319	Tray Unit Relay Harness	37 - 17
V4G1 1203	Interface Harness	39 - 1
V4G1 3225	Top Cover	15 - 14
V4G1 3228	Upper Transport Unit	29 - 27
V4G1 3229	Middle Transport Unit	29 - 1
V4G1 3232	Shift Tray Ass'y	37 - 18
V4G1 3233	Slide Guide Ass'y	13 - 1
V4G1 3235	Upper Tray Guide Ass'y	13 - 8
V4G1 3242	Exit Frame Ass'y	57 - 1
V4G1 3243	Stapler Ass'y	49 - 1
V4G1 3536	Finisher Board	39 - 15
V4G1 3537	Main Harness	39 - 23
V4G1 3539	Booklet Unit Board	45 - 22
V4G1 3542	Upper Exit Guide Unit	23 - 31
V4G1 3546	Guide Unit - R70	17 - 22
V4G1 3548	Transfer Drive Unit - R70	39 - 17
V4G1 3554	Upper Exit Guide Arm Unit	23 - 5
V4G1 3559	Staple Unit - R70	35 - 1
V4H1 6280	Sensor	15 - 11
V4K1 1046	Stepping Motor	19 - 3
V4K1 1046	Stepping Motor - DC 18W	39 - 19

Part No.	Description	Page and Index No.
VFA2 8244	Bushing	57 - 4
VFA6 0777	Grounding Plate	9 - 2
VFA6 0914	Guide Roller	9 - 5
VFA9 3739	Stapler Unit Grip	49 - 26
VFB2 6416	Plastic Washer	49 - 7
VFB3 7249	Shutter Link	25 - 3
VFB3 7252	Shutter Lever	25 - 20
VFB3 7253	Damper	13 - 16
VFB3 7272	Rear Sheet	21 - 1
VFB3 7283	Lever	23 - 3
VFB3 7284	Plate Spring	23 - 19
VFB3 7285	Shutter Damper	13 - 17
VFB3 7288	Paddle Shaft	23 - 21
VFB3 7289	Roller Shaft	23 - 2
VFB3 7292	Sensor Bracket	21 - 25
VFB3 7298	Shutter Cam	21 - 5
VFB3 7302	Slide Guide A	37 - 19
VFB3 7303	Slide Guide B	37 - 22
VFB3 7304	Bracket	37 - 26
VFB3 7306	Guide Plate	37 - 14
VFB3 7307	Sensor Actuator	9 - 8
VFB3 7310	Sensor Actuator	11 - 4
VFB3 7318	Board Cover	35 - 19
VFB3 7322	Pin	17 - 27
VFB3 7344	Roller	37 - 20
VFB3 7345	Sensor Cover	39 - 7
VFB3 7350	Holder	55 - 5
VFB3 7351	Sensor Bracket	55 - 2
VFB3 7353	Bracket	55 - 6
VFB3 7357	Pressure Ring	15 - 18
VFB3 7365	Roller	37 - 24
VFB3 7366	Solenoid Bracket	31 - 11
VFB3 7367	Grounding Plate	35 - 15
VFB3 7371	Stapler Guide	35 - 5
VFB3 7372	Rack	35 - 20

Part No.	Description	Page and Index No.
VFB3 7373	Guide Plate	35 - 3
VFB3 7374	Sensor Cover	35 - 25
VFB3 7375	Bracket	35 - 4
VFB3 7380	Timing Belt - B40S2M264	35 - 11
VFB3 7382	Stopper Cam	35 - 7
VFB3 7395	Sensor Actuator	17 - 5
VFB3 7398	Harness Guide	33 - 18
VFB3 7399	Switch Bracket	33 - 6
VFB3 7400	Front Stopper Lever	25 - 12
VFB3 7403	Rear Stopper Lever	31 - 9
VFB3 7404	Junction Gate	31 - 10
VFB3 7405	Junction Gate Lever	31 - 14
VFB3 7406	Junction Gate Lever	31 - 15
VFB3 7407	Junction Gate Lever	31 - 17
VFB3 7409	Link	25 - 8
VFB3 7415	Plate Spring	29 - 25
VFB3 7417	Junction Gate	29 - 2
VFB3 7419	Guide Plate	29 - 12
VFB3 7420	Sensor Actuator	29 - 16
VFB3 7422	Guide Roller Holder	29 - 23
VFB3 7423	Junction Gate Holder	29 - 5
VFB3 7431	Link	31 - 18
VFB3 7434	Sensor Bracket	33 - 9
VFB3 7436	Door Hinge	11 - 6
VFB3 7438	Transport Roller	33 - 15
VFB3 7846	Sensor Actuator	41 - 4
VFB3 7847	Sensor Board	41 - 6
VFB3 7848	Torsion Spring	41 - 5
VFB3 7849	Guide Plate	41 - 9
VFB3 7851	Plate Spring	43 - 24
VFB3 7853	Guide Plate	43 - 22
VFB3 7854	Discharge Brush	43 - 18
VFB3 7855	Discharge Brush	15 - 5
VFB3 7856	Front Roller Holder	53 - 20
VFB3 7857	Stay	49 - 29

Part No.	Description	Page and Index No.
VFB3 7858	Stapler Bracket	49 - 30
VFB3 7859	Stapler Guide	49 - 12
VFB3 7861	Guide	49 - 28
VFB3 7862	Slide Shaft	49 - 20
VFB3 7863	Stopper	49 - 8
VFB3 7864	Plate	49 - 27
VFB3 7865	Upper Slider	49 - 19
VFB3 7866	Stapler Positioning Pin	49 - 11
VFB3 7867	Lower Slider	49 - 21
VFB3 7869	Guide Pulley	51 - 25
VFB3 7870	Shaft	51 - 33
VFB3 7871	Cover	49 - 13
VFB3 7873	Switch Bracket	53 - 13
VFB3 7875	Roller Guide	47 - 23
VFB3 7876	Front Guide Gear	47 - 22
VFB3 7877	Rear Guide Gear	47 - 18
VFB3 7878	Guide Gear Holder	47 - 6
VFB3 7882	Guide Gear Holder	51 - 6
VFB3 7883	Right Cover Bracket	43 - 3
VFB3 7884	Sensor Bracket	51 - 15
VFB3 7884	Sensor Bracket	53 - 32
VFB3 7885	Sensor Bracket	43 - 10
VFB3 7888	Folder Bracket	51 - 30
VFB3 7889	Folder Holder	51 - 32
VFB3 7891	Shaft	45 - 2
VFB3 7892	Shaft	45 - 3
VFB3 7893	Stopper	45 - 24
VFB3 7894	Guide	45 - 4
VFB3 7895	Sensor Actuator	45 - 18
VFB3 7896	Torsion Spring	45 - 17
VFB3 7897	Belt Holder	45 - 12
VFB3 7903	Plate Spring	15 - 3
VFB3 7904	Release Shaft	57 - 12
VFB3 7905	Sensor Actuator	15 - 23
VFB3 7906	Idle Roller	57 - 19

Part No.	Description	Page and Index No.
VFB3 7907	Torsion Spring	57 - 13
VFB3 7909	Exit Sensor Cover	57 - 11
VFB3 7910	Photosensor	57 - 14
VFB3 7911	Shaft	53 - 24
VFB3 7912	Roller	53 - 25
VFB3 7915	Entrance Roller	41 - 13
VFB3 7918	Shaft	51 - 16
VFB3 7920	Middle Roller	47 - 26
VFB3 7923	Cam Shaft	47 - 25
VFB3 7925	Sensor Actuator	53 - 29
VFB3 7926	Roller Bracket	47 - 19
VFB3 7927	Idle Roller	47 - 20
VFB3 7928	Junction Gate	41 - 11
VFB3 7929	Lock Lever	57 - 2
VFB3 7930	Junction Gate Lever	41 - 21
VFB3 7931	Solenoid Bracket	55 - 9
VFB3 7932	Grounding Plate	57 - 25
VFB3 7934	Rear Rack Gear	53 - 5
VFB3 7935	Drive Shaft	53 - 23
VFB3 7937	Link	51 - 27
VFB3 7939	Front Pressure Lever	53 - 10
VFB3 7940	Rear Pressure Lever	53 - 7
VFB3 7941	Stopper	51 - 23
VFB3 7943	Front Side Guide	47 - 27
VFB3 7944	Rear Side Guide	47 - 28
VFB3 7945	Guide Roller	47 - 16
VFB3 7946	Sensor Bracket	47 - 14
VFB3 7947	Rear Slide Guide	47 - 15
VFB3 7948	Sensor Bracket	53 - 31
VFB3 7949	Upper Slide Rail	41 - 12
VFB3 7950	Lower Rail	43 - 1
VFB3 7953	Upper Plate	43 - 4
VFB3 7954	Guide Sheet	53 - 26
VFB3 7955	Stay	45 - 5
VFB3 7958	Right Cover	11 - 9

Part No.	Description	Page and Index No.
VFB3 7962	Front Door Hinge	11 - 13
VFB3 7963	Guide Plate	33 - 14
VFB3 7964	Torsion Spring	15 - 24
VFB3 7966	Grounding Plate	57 - 17
VFB3 7967	Front Rack Gear	53 - 19
VFB3 7969	Rear Roller Holder	53 - 22
VFB3 7971	Spring	15 - 8
VFB3 7972	Link	55 - 21
VFB3 7973	Link	47 - 29
VFB3 7974	Sensor Bracket	51 - 2
VFB3 7975	Stay	33 - 2
VFB3 7976	Switch Bracket	43 - 14
VFB3 7977	Guide	45 - 9
VFB3 7978	Discharge Brush	57 - 10
VFB3 7979	Sensor Actuator	41 - 16
VFB3 7980	Torsion Spring	41 - 17
VFB3 7981	Plate Spring	49 - 22
VFB3 7984	Sensor Actuator	43 - 6
VFB3 7985	Torsion Spring	43 - 8
VFB3 9401	Guide Plate Stay	13 - 11
VFB3 9403	Spacer	25 - 18
VFB3 9404	Silencer Sheet	27 - 32
VFB3 9407	Leaf Spring	27 - 31
VFB3 9408	Leaf Spring	13 - 10
VFB3 9409	Front Stopper	25 - 14
VFB4 0654	Paper Pressure Arm	17 - 3
VFB4 0655	Caster	11 - 18
VFB4 0656	Leaf Spring	33 - 8
VFB4 0657	Grounding Plate	31 - 3
VFB4 0658	Cam	37 - 5
VFB4 0659	Harness Guide	37 - 1
VFB4 5387	Roller Shaft	29 - 18
VFB4 5388	Roller - 1	29 - 19
VFB4 5389	Roller - 2	29 - 20
VFB4 6649	Grounding Plate	23 - 12

Part No.	Description	Page and Index No.
VFB4 6651	Antistatic Brush	23 - 7
VFB4 6652	Upper Entrance Guide	35 - 21
VFB4 6653	Lower Entrance Guide	35 - 28
VFB4 6655	Mylar	27 - 29
VFB4 6656	Transport Belt	21 - 14
VFB4 6825	Paddle	23 - 33
VFB4 6826	Paddle Holder	23 - 32
VFB4 8147	Cushion	23 - 24
VFB4 8148	Guide	33 - 12
VFB4 8148	Guide	29 - 7
VFB4 8153	Roller Holder	23 - 15
VFB4 9051	Exit Sensor Actuator	21 - 20
VFB4 9053	Antistatic Brush FD	23 - 9
VFB4 9054	Antistatic Brush	23 - 8
VFB4 9056	Shift Guide Mylar - M	27 - 7
VFB4 9157	Torsion Spring	33 - 13
VFB4 9158	Leaf Spring	49 - 14
VFB4 9159	Stapler Sheet	49 - 3
VFB4 9165	Paddle Holder	57 - 8
VFB4 9166	Paddle	57 - 9
VFB4 9168	Mylar	57 - 24
VFB4 9168	Mylar	13 - 21
VFB4 9171	Switch Holder	43 - 12
VFB4 9171	Switch Holder	53 - 17
VFB4 9171	Switch Holder	41 - 14
VFB4 9172	Back Up Plate	51 - 36
VFB4 9175	Cushion	15 - 26
VFB4 9689	Grounding Spring - F	17 - 25
VFB4 9690	Grounding Spring	17 - 24
VFB5 5830	Middle Frame	33 - 17
VFB5 5833	Stapler Support Guide - Front	21 - 21
VFB5 5834	Stapler Support Guide - Rear	21 - 12
VFB5 5835	Stopper Link - R	25 - 7
VFB5 5836	Stopper - R	25 - 9
VFB5 5840	Actuator - Stapler Tray Sensor	27 - 34

Part No.	Description	Page and Index No.
VFB5 5842	Switch Plate - Exit Sensor	21 - 10
VFB5 5843	Sensor Bracket - Exit Motor	27 - 13
VFB5 5845	Stopper Holder Plate - R	25 - 6
VFB5 5846	Stopper Holder Plate - R	25 - 5
VFB5 5847	Shutter Link - A	25 - 1
VFB5 5848	Stopper Shaft Collar	25 - 11
VFB5 5849	Exit Roller - 2	27 - 27
VFB5 5850	Swing Guide Arm	23 - 35
VFB5 5851	Support Plate - Exit Guide	23 - 34
VFB5 5852	Grounding Plate - Exit Guide	23 - 10
VFB5 5853	Exit Support Guide	27 - 1
VFB5 5854	Pressure Roller	21 - 24
VFB5 5857	Shutter Cam Spring	27 - 5
VFB5 5858	Paper Guide Plate - 1	23 - 23
VFB5 5859	Stopper Shaft Collar	25 - 24
VFB5 5860	Collar	27 - 3
VFB5 5862	Drive Bracket Base	37 - 11
VFB5 5863	Lower Drive Bracket	37 - 27
VFB5 5864	Tray Drive Shaft	37 - 15
VFB5 5865	Gear - 22Z	37 - 6
VFB5 5868	Holder Plate	33 - 20
VFB5 5870	Release Link - A	33 - 21
VFB5 5898	Release Link - B	33 - 22
VFB5 5899	Release Link - C	33 - 23
VFB5 5900	Release Link Shaft	33 - 24
VFB5 5901	Roller Holder	21 - 28
VFB5 5902	Release Roller - A	21 - 27
VFB5 5903	Release Roller - B	21 - 26
VFB5 5908	Grounding Plate	13 - 22
VFB5 5909	Exit Roller - 1D	21 - 16
VFB5 5913	Exit Gear Flange	27 - 20
VFB5 5936	Folding Roller	53 - 21
VFB5 5937	Positioning Roller Sensor Actuator	53 - 33
VFB5 5939	Folder Plate	51 - 31
VFB5 6222	Entrance Sensor Holder	19 - 7

Part No.	Description	Page and Index No.
VFB5 6223	Entrance Sensor Feeler	19 - 10
VFB5 6240	Shift Guide Plate - 3	13 - 20
VFB5 6242	Antistatic Brush FD	23 - 6
VFB5 6243	Cushion	33 - 29
VFB5 6250	Paper Guide Mylar - F	21 - 15
VFB5 6251	Paper Guide Mylar - RR	21 - 22
VFB5 6261	Securing Plate	35 - 29
VFC1 6314	Slide Shoe	9 - 1
VFC1 7432	Torsion Spring	57 - 3
VFE9 0018	Stepped Screw - M3	19 - 8
VFF3 3111	Paper Pass Sensor Harness	43 - 7
VFF3 4018	Main Harness - Swing Guide	27 - 23
VFF3 4020	Detector Harness	21 - 7
VFF3 4021	Detector Harness	21 - 6
VFF3 4069	Stapler Relay Harness	35 - 2
VFF3 4071	Booklet Interface Harness	39 - 13
VFF3 4073	Relay Harness - Exit Sensor	57 - 16
VFF3 4074	Detector Harness	33 - 7
VFF3 4074	Detector Harness	39 - 6
VFF3 4077	Stapler Harness	35 - 17
VFF3 4078	Stapler Harness 2	35 - 24
VFF3 4079	Grounding Wire	21 - 11
VFF3 4080	Shutter Sensor Harness	13 - 13
VFF3 4081	Trailing Sensor Harness	15 - 21
VFF3 4084	Stapler Relay Harness	49 - 17
VFF3 4085	Relay Harness - Cover Sensor	53 - 12
VFF3 4086	Relay Harness - Paper Size	41 - 1
VFF3 4087	Relay Harness	47 - 3
VFF3 4132	Paper Position Sensor Harness	45 - 20
VFF5 5654	Paddle Drive Plate	23 - 30
VFF5 5660	Front Tray Frame	37 - 16
VFF5 5662	Tightener	33 - 19
VFF5 5666	Solenoid	31 - 19
VFF5 5667	Solenoid	31 - 16
VFF5 5668	Solenoid	31 - 12

Part No.	Description	Page and Index No.
VFF5 5669	Solenoid Bracket	31 - 20
VFF5 5689	Relay Harness - Tray Sensor	9 - 11
VFF5 5699	Staple Unit Holder MB2 ADDED	35 - 30
VFF5 5798	Guide Plate	47 - 7
VFF5 5799	Motor Bracket	51 - 37
VFF5 5802	Idler Gear Bracket	57 - 23
VFF5 5804	Motor Bracket	47 - 5
VFF5 5805	Tightener	55 - 27
VFF5 5806	Solenoid Bracket	55 - 16
VFF5 5807	Motor Bracket	55 - 13
VFF5 5809	Guide Holder	33 - 4
VFF5 5809	Guide Holder	43 - 15
VFF5 5810	Roller Guide	53 - 27
VFF5 7554	Rear Tray Frame	37 - 21
VFF5 7557	Middle Guide Plate	29 - 8
VFF5 8683	Antistatic Brush	41 - 10
VFF5 8684	Antistatic Brush	43 - 21
VFF6 0419	Trailing Edge Guide Plate 2R	23 - 20
VFF6 0420	Trailing Edge Guide Plate 2R	23 - 18
VFF6 0425	Rear Bracket	27 - 6
VFF6 0426	RB Release Holder 1	33 - 25
VFF6 0427	RB Release Holder 3	33 - 27
VFF6 0428	Jogger Motor Holder	25 - 4
VFF6 0434	Stp Guide Ass'y	21 - 23
VFF6 0639	Shutter Holder Ass'y	13 - 14
VFF6 0640	Release Solenoid Ass'y	33 - 26
VFG3 1373	Main Saddle Harness	45 - 25
VFG5 8190	Sensor PCB	37 - 9
VFG5 8191	Stapler Relay Harness	35 - 18
VFG5 8390	Lower Bus Guide Ass'y	47 - 1
VFG5 8408	Paper Size Sensor PCB	41 - 2
VFG6 6242	Tray Drive Unit	37 - 3
VFH6 1342	Stepping Motor - DC 14.4W	25 - 15
VFH6 1343	Stepping Motor - DC 14.4W	35 - 16
VFH6 1455	Motor - DC 55.5W	51 - 19

Part No.	Description	Page and Index No.
VFH6 1456	Motor - DC 28.8W	51 - 21
VFH6 1457	Motor - DC 12.72W	47 - 10
VFH6 1457	Motor - DC 12.72W	55 - 23
VFH6 1458	Motor - DC 7.68W	55 - 19
VFH6 1460	Motor - DC 4.8W	27 - 11
VFH6 1527	Motor - DC 12.72W	45 - 11
VFH6 1781	Motor	27 - 10
VFH7 1763	Motor - DC 21.6W	37 - 13
VFH7 5766	Solenoid	55 - 8
VFH7 5767	Solenoid	55 - 15
VFH7 5940	Solenoid	25 - 23
VFH7 5979	Solenoid	23 - 25
VFH7 7394	Photointerruptor	27 - 12
VFH7 7394	Photointerruptor	51 - 3
VFH7 7419	Photointerruptor	21 - 13
VFS1 1187	Bushing	47 - 24
VFS1 1187	Bushing	31 - 4
VFS1 1187	Bushing	29 - 21
VFS1 1187	Bushing	41 - 8
VFS1 1187	Bushing	21 - 2
VFS1 1187	Bushing	53 - 1
VFS1 1187	Bushing	57 - 5
VFS1 1189	Bushing	51 - 28
VFS1 1189	Bushing	37 - 12
VFS1 1206	Bushing	51 - 13
VFS1 1213	Bushing - 6mm	27 - 33
VFS1 1213	Bushing - 6mm	53 - 28
VFS1 1213	Bushing - 6mm	31 - 6
VFS1 1213	Bushing - 6mm	57 - 21
VFS1 1213	Bushing - 6mm	41 - 22
VFS1 1213	Bushing - 6mm	47 - 30
VFS1 1273	Bushing	37 - 4
VFS1 1508	Bushing	29 - 17
VFS1 1510	Bushing	51 - 8
VFS1 9054	Stepped Screw	55 - 20

Part No.	Description	Page and Index No.
VFS1 9073	Stepped Screw - 8.2	51 - 22
VFS1 9076	Stepped Screw - M1.9	49 - 4
VFS1 9076	Stepped Screw - M1.9	53 - 8
VFS1 9102	Stepped Screw - M3	35 - 13
VFS1 9166	Stepped Screw - M4	41 - 3
VFS2 9407	Stepped Screw	49 - 18
VFS2 9407	Stepped Screw	17 - 16
VFS5 1004	Bushing - 5mm	25 - 27
VFS5 1753	Bushing	49 - 5
VFS5 1754	Bushing	51 - 26
VFS5 1805	Bushing	23 - 22
VFS5 3409	Idle Pulley	55 - 12
VFS5 3540	Gear - 25Z	27 - 21
VFS5 3541	Gear - 21Z	23 - 29
VFS5 3542	Gear - 21Z	23 - 26
VFS5 3547	Gear - 18Z	21 - 4
VFS5 3548	Coupled Gear - 12Z/36Z	25 - 19
VFS5 3549	Gear - 21Z	33 - 5
VFS5 3550	Gear - 35Z	29 - 11
VFS5 3551	Gear/Pulley - 44Z/16Z	35 - 9
VFS5 3552	Gear/Pulley - 16Z/40Z	35 - 10
VFS5 3561	Pulley - 26Z	31 - 7
VFS5 3563	Gear - 23/15Z	27 - 17
VFS5 3574	Gear - 30Z	45 - 7
VFS5 3575	Gear - 30Z	45 - 14
VFS5 3576	Gear - 30Z	55 - 17
VFS5 3577	Gear - 39Z	55 - 11
VFS5 3580	Gear - 24Z	47 - 31
VFS5 3849	Pulley	27 - 14
VFS5 3850	Gear - 30/14Z	27 - 15
VFS5 6514	Roller	23 - 1
VFS5 6516	Washer	15 - 19
VFS5 6517	Roller	29 - 14
VFS5 6518	Roller	19 - 20
VFS5 6518	Roller	29 - 24

Part No.	Description	Page and Index No.
VFS5 6520	Roller	39 - 18
VFS5 6523	Roller	35 - 14
VFS5 6524	Roller	35 - 6
VFS5 6525	Washer	35 - 8
VFS5 6526	Washer	27 - 30
VFS5 6527	Washer	37 - 7
VFS5 6528	Washer	35 - 12
VFS5 6530	Roller	29 - 6
VFS5 6531	Roller	23 - 14
VFS5 6544	Roller	43 - 23
VFS5 6545	Roller	15 - 7
VFS5 6546	Roller	15 - 1
VFS5 6547	Washer	55 - 24
VFS5 6549	Roller	49 - 25
VFS5 6550	Washer	55 - 18
VFS5 9212	Stepped Screw	45 - 19
VFS5 9212	Stepped Screw	41 - 15
VFS5 9579	Stepped Screw	11 - 22
VFS6 0814	Pulley/gear - 32Z/32Z	47 - 8
VFS6 0815	Pulley/gear - 16Z/32Z	47 - 12
VFS6 0816	Gear - 42Z	51 - 7
VFS6 0817	Gear - 16Z	51 - 20
VFS6 0819	Pulley/gear - 44Z/24Z	51 - 9
VFS6 0820	Coupled Gear - 15Z/30Z	45 - 13
VFS6 0821	Gear - 30Z	45 - 15
VFS6 0822	Coupled Gear - 16Z/33Z	53 - 30
VFS6 0823	Gear - 16Z	53 - 2
VFS6 0824	Gear - 44Z	51 - 34
VFS6 0825	Gear - 71Z	57 - 18
VFS6 0826	Gear - 17Z	57 - 20
VFS6 0828	Coupled Gear - 16Z/60Z	51 - 11
VFS6 0829	Coupled Gear - 16Z/56Z	53 - 3
VFS6 0830	Gear - 16Z	53 - 6
VFS6 0831	Gear - 16Z	51 - 12
VFS6 0832	Coupled Gear - 22Z/48Z	55 - 22

Part No.	Description	Page and Index No.
VFS6 0833	Gear - 16Z	51 - 18
VFS6 2541	Spring	23 - 16
VFS6 2542	Spring	23 - 28
VFS6 2543	Spring	21 - 19
VFS6 2544	Spring	15 - 17
VFS6 2545	Spring	15 - 15
VFS6 2546	Spring	29 - 3
VFS6 2547	Spring	17 - 26
VFS6 2548	Spring	29 - 13
VFS6 2549	Spring	31 - 13
VFS6 2550	Spring	29 - 15
VFS6 2552	Spring	17 - 6
VFS6 2555	Spring Plate	17 - 12
VFS6 2556	Spring	9 - 7
VFS6 2561	Spring	37 - 8
VFS6 2562	Spring	23 - 4
VFS6 2563	Spring Plate	39 - 8
VFS6 2564	Spring	55 - 7
VFS6 2565	Spring	25 - 13
VFS6 2567	Spring	15 - 13
VFS6 2569	Spring	49 - 6
VFS6 2570	Spring	47 - 17
VFS6 2571	Spring	45 - 8
VFS6 2572	Spring	49 - 16
VFS6 2573	Spring	55 - 14
VFS6 2574	Spring	55 - 29
VFS6 2574	Spring	47 - 32
VFS6 2576	Spring	41 - 20
VFS6 2578	Spring	51 - 14
VFS6 2579	Spring	51 - 35
VFS6 2580	Spring	53 - 9
VFS6 2581	Spring	43 - 17
VFS6 2582	Spring	51 - 29
VFS6 2583	Spring	47 - 33
VFS6 2646	Spring	25 - 10

Part No.	Description	Page and Index No.
VFS6 2647	Spring	25 - 2
VFS6 2648	Spring	23 - 17
VFS6 2649	Spring	17 - 4
VFS6 2650	Spring	25 - 22
VFS6 2778	Spring	25 - 25
VFS6 4199	Shaft	49 - 24
VFS6 4200	Shaft	47 - 21
VFS6 4200	Shaft	43 - 5
VFS7 0827	Gear - 20/21/21Z	39 - 4
VFS7 0829	Gear	21 - 18
VFS7 0830	Gear	21 - 17
VFS7 0831	Gear - 15/34Z	27 - 18
VFS7 0832	Gear - 20Z	27 - 19
VFS7 0833	Gear	27 - 2
VFS7 0834	Gear - 15Z	27 - 16
VFS7 0835	Gear - 48Z	37 - 10
VFS7 2476	Spring	19 - 11
VFS7 2480	Spring	27 - 22
VFS7 2481	Spring	27 - 35
VFS7 2482	Spring	33 - 28
VRB1 2190	Spring Hook	23 - 27
VRB1 2190	Spring Hook	27 - 4
VRB1 8589	Seal	27 - 28
VRB2 1624	Caster	11 - 17
VRS1 1042	Bushing	51 - 17
VRS5 2596	Spring	11 - 3
VVT2 5027	Cap	39 - 24
VWC4 5128	Microswitch	43 - 13
VWC4 5128	Microswitch	41 - 19
VWC4 5128	Microswitch	53 - 16
VWC4 5130	Microswitch	55 - 4
VWG8 5309	Photointerrupter	55 - 1
VWG8 5309	Photointerrupter	9 - 9
VWG8 5309	Photointerrupter	29 - 9
VWG8 5362	Photointerrupter	53 - 18

Part No.	Description	Page and Index No.
VWG8 5362	Photointerrupter	47 - 4
VWG8 5362	Photointerrupter	57 - 15
VWG8 5362	Photointerrupter	43 - 9
VWG8 5362	Photointerrupter	41 - 18
VWG8 5362	Photointerrupter	51 - 24
VWG8 5362	Photointerrupter	15 - 22
VWG8 5364	Photointerrupter	21 - 8
VWG8 5364	Photointerrupter	25 - 17
VWG8 5364	Photointerrupter	17 - 1
VWG8 5364	Photointerrupter	19 - 9
VWG8 5364	Photointerrupter	33 - 10
VWG8 5364	Photointerrupter	13 - 15
VWG8 5364	Photointerrupter	35 - 26
VWG8 5382	Photointerrupter	45 - 21
VWS6 5091	Connector	43 - 19
VWT2 0136	Clamp	33 - 11
VWT2 0136	Clamp	49 - 15
VWT2 0204	Clamp	39 - 9
VWT2 0308	Clamp	17 - 9
VWT2 0369	Clamp	43 - 20
VWT2 5026	Clamp	19 - 22
VWT2 5031	Clamp	47 - 13
VWT2 5031	Clamp	53 - 11
VWT2 5031	Clamp	45 - 10
VWT2 5035	Edge Sadle	21 - 9
VWT2 5035	Edge Sadle	25 - 16
VWT2 5056	Clamp	51 - 1
VWT2 5056	Clamp	47 - 9
VWT2 5056	Clamp	43 - 11
VWT2 5056	Clamp	45 - 16
VWT2 5056	Clamp	53 - 15
VWT2 5123	Clamp	37 - 25
VWT2 5357	Clamp	25 - 26
VWT2 5472	Clamp	35 - 27
VWT2 5598	Clamp	19 - 23

Part No.	Description	Page and Index No.
VXA9 0732	Screw	31 - 2
VXA9 0732	Screw	51 - 4
VXA9 0732	Screw	49 - 9
VXA9 0732	Screw	47 - 11
VXA9 0732	Screw	45 - 1
VXA9 0732	Screw	55 - 3
VXA9 0732	Screw	43 - 2
VXA9 0732	Screw	41 - 7
VXA9 0732	Screw	39 - 2
VXA9 0732	Screw	37 - 2
VXA9 0732	Screw	33 - 1
VXA9 0732	Screw	11 - 8
VXA9 0732	Screw	17 - 28
VXA9 0732	Screw	15 - 2
VXA9 0732	Screw	53 - 14
VXA9 0732	Screw	19 - 24
VXA9 0732	Screw	21 - 29
VXD1 1106	Spacer	21 - 3
VXF2 13038	Timing Belt - B40S2M114	55 - 26
VXF2 16050	Timing Belt - B40S2M100	39 - 12
VXF2 16070	Timing Belt - B40S2M140	19 - 4
VXF2 16078	Timing Belt - B40S2M156	27 - 8
VXF2 16098	Timing Belt - B40S2M196	39 - 14
VXF2 16172	Timing Belt - B40S2M344	39 - 20
VXF9 0646	Timing Belt - B40S2M286	47 - 2
VXF9 0647	Timing Belt - B40S3M1119	55 - 10
VXF9 0669	Timing Belt - B40S2M438	45 - 6
VXF9 0698	Timing Belt - B60S3M192	51 - 10
VXF9 0719	Timing Belt - B40S2M196	27 - 9
VXG3 60103	Ball Bearing	27 - 25
VXG9 0131	Ball Bearing - 12x28x7	53 - 4
VXG9 0407	Bearing - 6x10x3	19 - 6
VXG9 0407	Bearing - 6x10x3	33 - 3

Part No.	Description	Page and Index No.
0252 0080W	Screw - M2X8	13 -104
0252 0080W	Screw - M2X8	41 -103
0252 0080W	Screw - M2X8	53 -106
0252 0140W	Philips Pan Head Screw - M2x14	21 -103
0313 0060W	Philips Pan Head Screw - M3X6	47 -104
0313 0060W	Philips Pan Head Screw - M3X6	19 -104
0314 0060W	Philips Pan Head Screw - M4X6	29 -105
0314 0060W	Philips Pan Head Screw - M4X6	57 -104
0314 0060W	Philips Pan Head Screw - M4X6	33 -103
0314 0200Z	Philips Screw - 4x20	9 -105
0353 0040B	Screw - M3X4	13 -105
0353 0040W	Philips Pan Head Bind Screw -M3X4	31 -103
0353 0040W	Philips Pan Head Bind Screw -M3X4	21 -104
0353 0040W	Philips Pan Head Bind Screw -M3X4	23 -103
0353 0040W	Philips Pan Head Bind Screw -M3X4	43 -104
0353 0040W	Philips Pan Head Bind Screw -M3X4	55 -102
0353 0040W	Philips Pan Head Bind Screw -M3X4	39 -104
0353 0040W	Philips Pan Head Bind Screw -M3X4	25 -104
0353 0040W	Philips Pan Head Bind Screw -M3X4	47 -102
0353 0040W	Philips Pan Head Bind Screw -M3X4	37 -102
0353 0040W	Philips Pan Head Bind Screw -M3X4	27 -104
0353 0040W	Philips Pan Head Bind Screw -M3X4	29 -101
0353 0040W	Philips Pan Head Bind Screw -M3X4	35 -103
0353 0060B	Philips Pan Head Screw - M3x6	39 -101
0353 0060W	Philips Pan Head Screw - M3X6	17 -104
0353 0060W	Philips Pan Head Screw - M3X6	41 -101
0353 0060W	Philips Pan Head Screw - M3X6	57 -101
0353 0060W	Philips Pan Head Screw - M3X6	53 -104
0353 0060W	Philips Pan Head Screw - M3X6	45 -101
0353 0060W	Philips Pan Head Screw - M3X6	15 -101
0353 0080W	Tapping Screw - M3x8	53 -103
0353 0080W	Tapping Screw - M3x8	43 -106
0353 0120W	Philips Pan Head Screw - M3x12	45 -102
0354 0060W	Philips Truss Head Screw - M4X6	9 -104
0354 0060W	Philips Truss Head Screw - M4X6	51 -103

Part No.	Description	Page and Index No.
0354 0060W	Philips Truss Head Screw - M4X6	37 -109
0354 0060W	Philips Truss Head Screw - M4x6	37 -106
0354 0060W	Philips Truss Head Screw - M4X6	35 -105
0354 0080W	Philips Pan Head Screw - M4x8	43 -105
0354 0100W	Philips Pan Head Screw - M4x10	49 -104
0413 0062F	bind Tapping Screw - M3x6	17 -101
0413 0062F	Bind Tapping Screw - M3x6	19 -105
0413 0062W	Tapping Screw - M3x6	29 -106
0413 0082W	Tapping Screw - M3x8	47 -108
0413 0252W	Tapping Screw - M3x25	15 -102
0414 0060W	Tapping Screw - M4X6	19 -101
0414 0082F	Philips Truss Head Screw - M4x8	19 -102
0414 0082F	Philips Truss Head Screw - M4x8	17 -102
0414 0082W	Tapping Screw With Flat Washer - M4X8	11 -101
0414 0102F	Tapping Screw - M4x10	17 -103
0451 3006W	Tapping Screw - M3x6	35 -101
0451 4006Z	Tapping Screw 4x6	35 -107
0451 4006Z	Tapping Screw 4x6	49 -101
0452 3006W	Tapping Screw - 3X6	9 -103
0452 3008B	Tapping Screw - M3X8	15 -104
0452 3008B	Tapping Screw - M3X8	13 -103
0452 3008W	Binding Self Tapping Screw - M3x8	37 -104
0452 3008W	Binding Self Tapping Screw - M3x8	35 -104
0452 4008B	Binding Self Tapping Screw - M4x8	13 -101
0452 4008W	Tapping Bind Screw - M4X8	23 -102
0452 4008W	Tapping Bind Screw - M4X8	57 -103
0452 4008W	Tapping Bind Screw - M4X8	21 -106
0452 4008W	Tapping Bind Screw - M4X8	15 -105
0452 4008W	Tapping Bind Screw - M4X8	25 -102
0452 4010B	Tapping Bind Screw - M4x10	15 -103
0452 4010W	Binding Self-Tapping Screw - M4X10	29 -107
0452 4010W	Binding Self-Tapping Screw - M4X10	21 -105
0452 4010W	Binding Self-Tapping Screw - M4X10	9 -101
0452 4012B	Philips Tapping Screw - M4x12	13 -102
0622 0100E	Spring Pin - 2x10MM	51 -105

Part No.	Description	Page and Index No.
0623 0080E	Spring Pin - 3x8mm	55 -101
0623 0080E	Spring Pin - 3x8mm	25 -106
0623 0100E	Spring Pin - 3x10mm	55 -103
0632 0080G	Parallel Key - 2x8mm	29 -102
0632 0080G	Parallel Key - 2x8mm	23 -105
0632 0080G	Parallel Key - 2x8mm	21 -102
0632 0100G	Pin - 2x10mm	31 -102
0632 0160G	Parallel Pin-m2x16	37 -101
0633 0160E	Pin - 3x16mm	37 -103
0633 0200G	Pin - M3x20	51 -104
0704 0040E	Toothed Washer - M4	37 -107
0720 0030E	Retaining Ring - M3	43 -102
0720 0030E	Retaining Ring - M3	25 -103
0720 0030E	Retaining Ring - M3	19 -103
0720 0030E	Retaining Ring - M3	27 -101
0720 0040E	Retaining Ring - M4	47 -103
0720 0040E	Retaining Ring - M4	27 -103
0720 0050E	Retaining Ring - M5	39 -103
0720 0050E	Retaining Ring - M5	21 -101
0720 0050E	Retaining Ring - M5	33 -102
0720 0050E	Retaining Ring - M5	17 -105
0720 0050E	Retaining Ring - M5	31 -101
0720 0050E	Retaining Ring - M5	35 -102
0720 0050E	Retaining Ring - M5	57 -102
0720 0050E	Retaining Ring - M5	29 -103
0720 0050E	Retaining Ring - M5	47 -101
0720 0050E	Retaining Ring - M5	53 -101
0720 0050E	Retaining Ring - M5	49 -105
0720 0050E	Retaining Ring - M5	45 -103
0720 0050E	Retaining Ring - M5	55 -104
0720 0050E	Retaining Ring - M5	27 -102
0720 0050E	Retaining Ring - M5	23 -104
0720 0050E	Retaining Ring - M5	37 -108
0720 0050E	Retaining Ring - M5	25 -101
0720 0050E	Retaining Ring - M5	41 -102

Part No.	Description	Page and Index No.
0720 0070E	Retaining Ring - M7	35 -106
0720 0070E	Retaining Ring - M7	37 -105
0720 0070E	Retaining Ring - M7	49 -102
0720 0070E	Retaining Ring - M7	51 -101
0725 0150E	Retaining Ring C - M15	53 -102
0951 3008W	Philips Screw With Flat Washer - M3x8	25 -105
0951 4006B	Philips Screw With Washer - M4x6	23 -101
0951 4006W	Philips Screw With Flat Washer - M4X6	51 -102
0951 4006W	Philips Screw With Flat Washer - M4X6	9 -102
1105 0183	Spacer	43 -101
1105 0199	Clamp	29 -104
1105 0199	Clamp	21 -107
1105 0201	Harness Clamp	47 -105
1105 0229	Clamp	49 -103
1105 0229	Clamp	35 -108
1105 0229	Clamp	37 -110
1105 0229	Clamp	33 -101
1105 0229	Clamp	43 -107
1105 0229	Clamp	45 -104
1105 0229	Clamp	47 -107
1105 0310	Harness Clamp - LWS-1S	43 -103
1105 0310	Harness Clamp - LWS-1S	39 -102
1105 0310	Harness Clamp - LWS-1S	45 -105
1105 0310	Harness Clamp - LWS-1S	55 -105
1105 0310	Harness Clamp - LWS-1S	47 -106
1105 0310	Harness Clamp - LWS-1S	33 -104
1105 0310	Harness Clamp - LWS-1S	53 -105